


TERMINALS OF ECU



1. INSPECT INTEGRATION RELAY

(a) Disconnect the connector and check the continuity of each terminal of the disconnected connector.

Standard :

Symbols (Terminal No.)	Wiring color	Condition	Specified Condition
L1 (I11-9) ⇔ Body ground	L-W ⇔ Body ground	[w/ power window] Master switch (Manual door lock operation) OFF → LOCK	No continuity → Continuity
		[w/o power window] Driver's door control switch (Manual operation) OFF → LOCK	
		Passenger's door control switch (Manual operation) OFF → LOCK	
L2 (I11-7) ⇔ Body ground	G ⇔ Body ground	Key in driver's door lock cylinder LOCK → Other position	Continuity → No continuity
		Key in passenger's door lock cylinder LOCK → Other position	
UL1 (I11-8) ⇔ Body ground	L ⇔ Body ground	[w/ power window] Master switch (Manual door lock operation) OFF → UNLOCK	No continuity → Continuity
		[w/o power window] Door control switch (Manual operation) OFF → UNLOCK	
		Passenger's door control switch (Manual operation) OFF → UNLOCK	
UL2 (I11-5) ⇔ Body ground	L-B ⇔ Body ground	Key in passenger's door lock cylinder UNLOCK → Other position	Continuity → No continuity
UL3 (I11-6) ⇔ Body ground	L-Y ⇔ Body ground	Key in driver's door lock cylinder UNLOCK → Other position	
LSWD (I11-19) ⇔ Body ground	W ⇔ Body ground	Driver's door lock control knob LOCK → UNLOCK	No continuity → Continuity
LSWP (I11-18) ⇔ Body ground	W-R ⇔ Body ground	Passenger's door lock control knob LOCK → UNLOCK	
PCTY (I11-13) ⇔ Body ground	R-W ⇔ Body ground	Passenger's door fully closed → Opened	No continuity → Continuity

If the result is not as specified, the vehicle's side may malfunction.


(b) Reconnect the connector and check each terminal.

Standard:

Symbols (Terminal No.)	Wiring color	Condition	Specified Condition
ACTD (I11-1) ↔ Body ground	R ↔ Body ground	Key in driver's door lock cylinder OFF → LOCK	0 V → 10 - 14 V → 1 V or less

If the result is not as specified, the integration relay may malfunction.

2. INSPECT INSTRUMENT PANEL J/B (INTEGRATION RELAY)



- (a) Inspect the DOOR fuse.
 (b) Disconnect connectors ID, IF, IH and IJ of the instrument panel J/B.
 (c) Check each terminal of the disconnected connectors.

Standard:

Symbols (Terminal No.)	Wiring color	Condition	Specified Condition
KSW (IJ-8) ⇔ Body ground	L-B ⇔ Body ground	No key in ignition switch lock cylinder → Inserted	No continuity → Continuity
GND (IF-4) ⇔ Body ground	W-B ⇔ Body ground	Constant	Continuity
GND (IH-10) ⇔ Body ground	W-B ⇔ Body ground		
DCTY (ID-1) ⇔ Body ground	R-W ⇔ Body ground	Driver's door fully closed → Opened	No continuity → Continuity
PRCTY (ID-14) ⇔ Body ground	R-B ⇔ Body ground	Rear LH door fully closed → Opened	
PRCTY (ID-15) ⇔ Body ground	R-Y ⇔ Body ground	Rear RH door fully closed → Opened	

If the result is not as specified, the vehicle's side may malfunction.

- (d) Reconnect the connectors and check each terminal.

Standard:

Symbols (Terminal No.)	Wiring color	Condition	Specified Condition
IG (IA-1) ⇔ Body ground	W ⇔ Body ground	Constant	10 - 14 V
+B (IB-1) ⇔ Body ground	W ⇔ Body ground		
KSW (IJ-8) ⇔ Body ground	L-B ⇔ Body ground	No key in ignition switch lock cylinder → Inserted	10 - 14 V → 0 V
ACT+ (IK-2) ⇔ Body ground	L ⇔ Body ground	Key in driver's door lock cylinder OFF → LOCK	0 V → 10 - 14 V → 1 V or less
ACT+ (ID-9) ⇔ Body ground	L ⇔ Body ground	Key in driver's door lock cylinder OFF → UNLOCK	
ACT- (IK-5) ⇔ Body ground	R ⇔ Body ground	Key in driver's door lock cylinder OFF → LOCK	
ACT- (ID-20) ⇔ Body ground	R ⇔ Body ground	Key in driver's door lock cylinder OFF → UNLOCK	

If the result is not as specified, the instrument panel J/B (integration relay) assembly may malfunction.