

# SFI SYSTEM (April, 2003)

05288-10

## HOW TO PROCEED WITH TROUBLESHOOTING

The hand-held tester can be used at step 3, 4, 5, 7, 10.

**1** | **VEHICLE BROUGHT TO WORKSHOP**



**2** | **CUSTOMER PROBLEM ANALYSIS (See page 05-4)**



**3** | **CONNECT HAND-HELD TESTER TO DLC3**

HINT:

If the display indicates a communication fault in the tool, inspect DLC3.



**4** | **CHECK DTC AND FREEZE FRAME DATA (See page 05-9)**

HINT:

Record or print DTC and freeze frame data, if needed.



**5** | **CLEAR DTC AND FREEZE FRAME DATA (See page 05-9)**



**6** | **VISUAL INSPECTION**



**7** | **SETTING CHECK (TEST) MODE DIAGNOSIS (See page 05-11)**



**8** | **PROBLEM SYMPTOM CONFIRMATION**

HINT:

If the engine does not start, perform steps 10 and 12 first.

|   |                            |
|---|----------------------------|
| A | Malfunction does not occur |
| B | Malfunction occurs         |

**B** | **GO TO STEP 10**



|          |                           |
|----------|---------------------------|
| <b>9</b> | <b>SYMPTOM SIMULATION</b> |
|----------|---------------------------|



|           |                                  |
|-----------|----------------------------------|
| <b>10</b> | <b>DTC CHECK (See page 05-9)</b> |
|-----------|----------------------------------|

|   |                  |
|---|------------------|
| A | Malfunction code |
| B | No code          |

|          |                      |
|----------|----------------------|
| <b>B</b> | <b>GO TO STEP 12</b> |
|----------|----------------------|

|          |
|----------|
| <b>A</b> |
|----------|

|           |                                  |
|-----------|----------------------------------|
| <b>11</b> | <b>DTC CHART (See page 05-9)</b> |
|-----------|----------------------------------|



|                      |
|----------------------|
| <b>GO TO STEP 14</b> |
|----------------------|

|           |  |
|-----------|--|
| <b>12</b> | <b>BASIC INSPECTION (See page 05-13)</b> |
|-----------|--|

|   |                           |
|---|---------------------------|
| A | Wrong parts not confirmed |
| B | Wrong parts confirmed     |

|          |                      |
|----------|----------------------|
| <b>B</b> | <b>GO TO STEP 17</b> |
|----------|----------------------|

|          |
|----------|
| <b>A</b> |
|----------|

|           |  |
|-----------|--|
| <b>13</b> | <b>PROBLEM SYMPTOMS TABLE (See page 05-42)</b> |
|-----------|--|

|   |                         |
|---|-------------------------|
| A | Wrong circuit confirmed |
| B | Wrong parts confirmed   |

|          |                      |
|----------|----------------------|
| <b>B</b> | <b>GO TO STEP 17</b> |
|----------|----------------------|

|          |
|----------|
| <b>A</b> |
|----------|

|           |   |
|-----------|---|
| <b>14</b> | <b>CHECK ECM POWER SOURCE CIRCUIT (See page 05-273)</b> |
|-----------|---|



|           |                           |
|-----------|---------------------------|
| <b>15</b> | <b>CIRCUIT INSPECTION</b> |
|-----------|---------------------------|

|   |                           |
|---|---------------------------|
| A | Malfunction not confirmed |
| B | Malfunction confirmed     |

|          |                      |
|----------|----------------------|
| <b>B</b> | <b>GO TO STEP 18</b> |
|----------|----------------------|

|          |
|----------|
| <b>A</b> |
|----------|

|           |   |
|-----------|---|
| <b>16</b> | <b>CHECK FOR INTERMITTENT PROBLEMS (See page 05-41)</b> |
|-----------|---|



|                      |
|----------------------|
| <b>GO TO STEP 18</b> |
|----------------------|

|           |                         |
|-----------|-------------------------|
| <b>17</b> | <b>PARTS INSPECTION</b> |
|-----------|-------------------------|



|           |                                  |
|-----------|----------------------------------|
| <b>18</b> | <b>IDENTIFICATION OF PROBLEM</b> |
|-----------|----------------------------------|



|           |                           |
|-----------|---------------------------|
| <b>19</b> | <b>ADJUSTMENT, REPAIR</b> |
|-----------|---------------------------|



|           |                          |
|-----------|--------------------------|
| <b>20</b> | <b>CONFIRMATION TEST</b> |
|-----------|--------------------------|



|            |
|------------|
| <b>END</b> |
|------------|