


## TERMINALS OF ECU



### 1. INSPECT INTEGRATION RELAY

- (a) Disconnect the connector from the integration relay.
- (b) Check the continuity between each terminal of the disconnected connector and the body ground, as shown in the illustration and table.

#### Standard:

Symbols (Terminal No.)	Wiring color	Condition	Specified condition
LSWD (I11-19) ⇔ Body ground	W ⇔ Body ground	Driver's door lock control knob LOCK → UNLOCK	No continuity → Continuity
LSWP (I11-18) ⇔ Body ground	W-R ⇔ Body ground	Front passenger's door lock control knob LOCK → UNLOCK	
L1 (I11-9) ⇔ Body ground	L-W ⇔ Body ground	Door lock control switch (Manual operation) OFF → LOCK	
UL1 (I11-8) ⇔ Body ground	L ⇔ Body ground	Door lock control switch (Manual operation) OFF → UNLOCK	
L2 (I11-7) ⇔ Body ground	G ⇔ Body ground	Using key, front door lock cylinder LOCK → Other position	Continuity → No continuity
UL3 (I11-6) ⇔ Body ground	L-Y ⇔ Body ground	Using key, driver's door lock cylinder UNLOCK → Other position	Continuity → No continuity
UL2 (I11-5) ⇔ Body ground	L-B ⇔ Body ground	Using key, front passenger's door lock cylinder UNLOCK → Other position	
PCTY (I11-13) ⇔ Body ground	R-W ⇔ Body ground	Front passenger's door fully closed → Opened	No continuity → Continuity

If the result is not as specified, the vehicle's side may malfunction.


- (c) Reconnect the connector and check the voltage between each terminal and the body ground, as shown in the illustration and table.

#### Standard:

Symbols (Terminal No.)	Wiring color	Condition	Specified condition
ACTD (I11-1) ⇔ Body ground	R ⇔ Body ground	Driver's door lock OFF → ON	0 V → 10 – 14 V → 1 V or less
HAZ (I11-25) ⇔ Body ground	Y-B ⇔ Body ground	Transmitter LOCK or UNLOCK switch is pushed Hazard warning switch ON	0 V (Hazard not flashing) → 10 – 14 V (Hazard flashing)

If the result is not as specified, the integration relay may malfunction.

2. INSPECT INSTRUMENTAL PANEL J/B (INTEGRATION RELAY)



- (a) Disconnect the connectors IA, IB, ID, IF, IH and IJ of the instrument panel J/B.  
 (b) Check the continuity between each terminal of the disconnected connectors and the body ground, as shown in the illustration and table.

**Standard:**

Symbols (Terminal No.)	Wiring color	Condition	Specified condition
DCTY (ID-1) ⇔ Body ground	R-W ⇔ Body ground	Driver's door fully closed → Opened	No continuity → Continuity
PRCTY (ID-14) ⇔ Body ground	R-B ⇔ Body ground	Rear LH door fully closed → Opened	
PRCTY (ID-15) ⇔ Body ground	R-Y ⇔ Body ground	Rear RH door fully closed → Opened	
KSW (IJ-8) ⇔ Body ground	L-B ⇔ Body ground	No key in ignition switch cylinder → Key inserted	No continuity → Continuity
+B (IB-1) ⇔ Body ground	W ⇔ Body ground	Constant	10 – 14 V
IG (IA-1) ⇔ Body ground	W ⇔ Body ground		
GND (IF-4) ⇔ Body ground	W-B ⇔ Body ground	Constant	Continuity
GND (IH-10) ⇔ Body ground	W-B ⇔ Body ground		

If the result is not as specified, the vehicle's side may malfunction.

- (c) Reconnect the connectors and check the voltage between each terminal and the body ground, as shown in the illustration and table.

**Standard:**

Symbols (Terminal No.)	Wiring color	Condition	Specified condition
ACT+ (IK-2) ⇔ Body ground	L ⇔ Body ground	• Front door lock OFF → ON • Rear RH door lock OFF → ON	0 V → 10 – 14 V → 1 V or less
ACT- (IK-5) ⇔ Body ground	R ⇔ Body ground	• Front passenger's door lock OFF → ON • Rear RH door lock OFF → ON	
ACT+ (ID-9) ⇔ Body ground	L ⇔ Body ground	Rear LH door lock OFF → ON	
ACT- (ID-20) ⇔ Body ground	R ⇔ Body ground		
RDA (ID-8) ⇔ Body ground	L-R ⇔ Body ground	No key in ignition key cylinder, all doors closed and transmitter switch OFF → ON	1 V or less → Approx. 6 – 7 V → 1 V or less

If the result is not as specified, the integration relay or instrument panel J/B assembly may malfunction.