



Winchester Model 1300 Pump Shotgun Owner's Manual

Important instructions for

## Winchester Model 1300 Pump Shotgun

U.S. Repeating Arms Company, Inc.

275 Winchester Ave.

New Haven, CT, U. S. A. 06511-1970

*Winchester trademarks licensed from Olin Corporation.*

Use the space below to record information about your  
new Model 1300 shotgun.

Model \_\_\_\_\_

Serial Number \_\_\_\_\_

Purchased From \_\_\_\_\_

Date of Purchase \_\_\_\_\_

We sincerely hope that you are pleased with your new Winchester Model 1300. We at U.S. Repeating Arms Company thank you for the privilege of crafting this shotgun for you. We are especially proud of the many years of enjoyment it is certain to provide for you and your family. The Model 1300 is another shotgun in an over 130 year-old tradition of producing quality firearms for the World's sportsmen. Quality of manufacture, design, craftsmanship and function are of utmost concern to us. We believe you'll find that your new 1300 meets the Winchester tradition of quality in every way. If you have any questions or comments regarding your new firearm, please feel free write to us.

|  |             |
|--|-------------|
| <b>Contents</b> .....                      | <b>Page</b> |
| Gun safety warnings .....                  | 2 - 3       |
| General description .....                  | 3 - 4       |
| Terminology and descriptions .....         | 4           |
| Serial number .....                        | 4           |
| Ammunition .....                           | 5           |
| Magazine capacity .....                    | 5           |
| General operation/special reminders .....  | 5 - 8       |
| Initial cleaning/Oiling the action .....   | 8           |
| Operation of the safety .....              | 9           |
| Installing/removing the bolt .....         | 9           |
| Initial Assembly .....                     | 10          |
| Loading/unloading procedures .....         | 11 - 12     |
| Firing procedures .....                    | 13          |
| In the case of a misfire .....             | 13          |
| Removing the 3-shot plug .....             | 14          |
| Full Disassembly .....                     | 16 - 21     |
| Sight adjustments .....                    | 21 - 22     |
| Winchoke® System .....                     | 22 - 25     |
| Cleaning and maintenance suggestions ..... | 25 - 27     |
| Ordering parts .....                       | 27          |
| Service or Repair .....                    | 28          |

No pump is faster than today's Winchester Model 1300. And there's no pump shotgun with more modern advantages. The 1300 has an overall design that is uniquely durable, drawing on nearly a century of Winchester firearms pump shotgun experience.

The Model 1300 is a gun for these times. It stands comparison with every other slide action on the market past and present. The reasons are many, but avid slide gunners know that the big advantage of a 1300 is speed. A 1300 is so fast, we like to think of it as the "Speed Pump."

In more ways than one it's "the pump that thinks it's a semi-auto." Here's why: a fraction of a second after you pull the trigger and fire a 1300, the lugs of the ultra-strong rotary bolt begin disengaging from the barrel extension. Recoil forces still present in the gun then assist the slide rearward. You can feel the slight rearward force on the forearm as you shoot, which makes it much easier to begin your pumping action. And you'll find that you will complete the pumping action forward quickly and without conscious effort. In a brief instant you've cycled a shell and are ready for a second shot. Speed like this makes a big difference allowing you to set up for a second shot more quickly and concentrate on your target — not just on pumping.

With the 1300's rotary bolt design, the lugs engage directly in the lug recesses in the barrel extension. This is an unusually strong, consistent and reliable lockup design used on many military firearms.

Every design feature works together to make what many consider the most reliable pump shotgun on the market today.

## GUN SAFETY WARNINGS

***IT IS ESSENTIAL THAT THESE OPERATING INSTRUCTIONS BE THOROUGHLY STUDIED BEFORE USING THIS FIREARM TO ASSURE PROPER AND SAFE GUN HANDLING. FAILURE TO FOLLOW THESE INSTRUCTIONS OR FAILURE TO OBEY ANY SAFETY WARNING MAY RESULT IN INJURY TO YOURSELF OR OTHERS, OR CAUSE DAMAGE TO YOUR GUN.***

As a gun owner, you accept a set of demanding responsibilities. How seriously you take these responsibilities can be the difference between life and death. There is no excuse for careless or abusive handling of any firearm. At all times handle your rifle and any other firearm with intense respect for its power and potential danger.

***PLEASE READ AND UNDERSTAND ALL OF THE CAUTIONS, PROPER HANDLING PROCEDURES AND INSTRUCTIONS OUTLINED IN THIS BOOKLET BEFORE USING YOUR NEW FIREARM.***

1. Do not carry a loaded gun with a live round in the chamber while walking, running, climbing a tree, crossing a fence or anywhere you might slip or fall, drop the gun or otherwise bump or jar the gun. A gun that is dropped,

bumped, or jarred with a chambered round might accidentally discharge even with the safety on, causing serious injury to you or someone else. When a round is chambered keep the safety on until you are ready to shoot.

2. Do not rely on the safety to prevent accidental discharge. Many safeties merely block the trigger and prevent firing by pulling the trigger. The safety may not prevent an accidental discharge due to dropping, jarring, or bumping a gun.

3. Use only ammunition for which the gun is chambered as indicated on the barrel, to prevent excessive pressure and possible serious personal injury.

4. Incorrectly reloaded ammunition can cause serious personal injury and damage to the firearm due to excessive pressure. Reload only after proper instruction and in strict compliance with instruction and data contained in current reloading manuals.

5. Never point a gun at anything you do not intend to shoot. Always keep it pointed in a safe direction in case of accidental discharge.

6. Always check to ensure that the barrel is free of obstructions before loading and using the gun. If you experience light recoil or off sound, check the barrel for an obstruction.

7. Before firing, clean any grease or oil out of barrel with cleaning rod and patch. Grease or heavy accumulation of oil can cause excessive pressure and result in serious personal injury.

8. Keep barrel, chamber and action free of rust. Rust in the barrel and chamber can cause excessive pressures resulting in serious injury. A rusted, pitted or eroded barrel should be replaced.

9. Use hearing protection to prevent ear damage from repeated exposure to gunfire.

10. Always use proper shooting glasses to prevent eye injury from flying particles.

11. Never carry a loaded gun in a motor vehicle or carry one into a dwelling. Always carefully unload the gun before entering a motor vehicle, a dwelling or an area such as a camp. Always point a gun in a safe direction while loading or unloading to prevent serious injury in case of an accidental discharge. Never load in the house or in your vehicle.

12. Never shoot at a hard, flat surface or at the surface of water to avoid a ricochet and possible serious personal injury to yourself or a bystander.

13. Store gun in a clean dry place out of reach of children and separated from stored ammunition.

14. Never alter any parts of your gun. Any alterations or adjustments that may become necessary to the operating mechanism should be performed by a qualified gunsmith.


15. Hunting from elevated surfaces such as tree stands is dangerous. Doing so may increase the risk of handling any firearm. Always make certain that the stand being used is safe, sturdy and stable. Always make certain your firearm is unloaded when it is being taken up and down from the stand. Always make certain that your firearm is not dropped from the stand or dropped while it is being taken up or down from the stand.

## Be Careful!

### GENERAL DESCRIPTION

Your new Model 1300 is one of a number of different versions and configurations offered. The basic operating procedures are the same for nearly all of them. Where there are differences they are pointed out in this booklet for your convenience.

The Model 1300 is a pump action design that allows the shooter to load a round by cycling the action and moving a shell from a loaded magazine tube to the chamber.



**FIGURE 1**

This can be repeated until the magazine is empty. A single round can also be inserted into the chamber manually.

### **TERMINOLOGY AND DESCRIPTIONS**

Descriptions in this booklet generally refer to the gun in the horizontal position. That is, in the normal firing position. For example, the muzzle is forward or front; the buttstock is rearward or rear; the trigger is downward or underneath; the sight is upward or on top. For general parts terminology, refer to Figure 1.

The Winchester Model 1300 is also shown disassembled to the extent necessary in order to follow instructions

contained in this book (see Figure 9). Figure 2 covers the general features and benefits of the Model 1300 design. Throughout this manual the "action" refers to the mechanism of this shotgun which loads and secures the shells in the chamber.

### **SERIAL NUMBER**

The serial number is located on the left side of the receiver, just above the trigger guard. Record the serial number at the front of this book for future reference.

### AMMUNITION

All current 12 and 20 gauge Model 1300s have a 3-inch chamber and are designed to shoot with all factory loads such as 3" Magnum, 2 3/4" Magnum, 2 3/4" High Velocity, 2 3/4" Field and Target loads. This Winchester proof steel barrel can safely shoot both lead and steel shot. Special rifled choke tubes and rifled barrels are designed for shooting sabot-type slugs. U.S. Repeating Arms Co. can assume no responsibility for incidents which occur through use of cartridges of nonstandard dimension or those developing pressures in excess of SAAMI (Sporting Arms and Ammunition Manufacturer's Institute) established standards.

***MAKE SURE YOU USE ONLY THE EXACT AMMUNITION/GAUGE AS LISTED ON THE LEFT SIDE OF THE BARREL.***

Incorrectly reloaded ammunition can cause serious personal injury and damage to the firearm due to excessive pressure. Reload only after proper instruction and in strict compliance with instructions and data contained in current reloading manuals.

***DISCHARGING FIREARMS IN POORLY VENTILATED AREAS, CLEANING FIREARMS, OR HANDLING AMMUNITION MAY RESULT IN***

***EXPOSURE TO LEAD AND OTHER SUBSTANCES KNOWN TO CAUSE BIRTH DEFECTS, REPRODUCTIVE HARM AND OTHER SERIOUS PHYSICAL INJURY. HAVE ADEQUATE VENTILATION AT ALL TIMES. WASH HANDS THOROUGHLY AFTER EXPOSURE.***

### MAGAZINE CAPACITY


It is extremely important that you know the magazine capacity of your Model 1300. It is listed on the hang tag supplied with your Model 1300. Under appropriate circumstances — at a range or other suitable shooting location — load your magazine to full capacity and make note of the number of cartridges. Remember, "total" capacity includes an additional round which can be loaded manually in the chamber in addition to a full magazine.

### GENERAL OPERATION/ SPECIAL REMINDERS

***IMPORTANT: ALWAYS KEEP THE MUZZLE POINTED IN A SAFE DIRECTION.***


Prior to using live ammunition, familiarize yourself thoroughly with these operating instructions. Get accustomed to the feel of your new gun — know the forces required to operate the action. Learn how to pull the trigger and,

## MODEL 1300 FEATURES






Choice of barrels. Choose standard ventilated rib models with WinChokes; rifled barrels with rifle sights for shooting slugs; smoothbore barrels with rifle sights; and shorter, smoothbore barrels for protection uses.



WinChoke® threaded choke system.



Faster, power-assisted pumping. The rotary bolt disengages from the barrel fractions of a second after the shell fires. The bolt is forced rearward by inertia, actually assisting you as you pump the forearm rearward for the next shot.

Model 1300 field guns feature our fully floating, ventilated rib. On all barrels, as the barrel heats with shooting, dimensions can vary slightly. The 1300's floating rib design allows the rib to move without distorting your sight plane.

Many Model 1300 hunting models are fitted with the WinChoke system. It allows you to change choke constriction to the demands of the game being hunted. You can easily change the pattern size and density by simply switching the tubes. Also available is an accessory rifled choke tube for shooting sabot-type slugs.

FIGURE 2

above all, know the location and operation of the safety. Procedures for disassembly and operation of various components are outlined in the sections below. Please read and study them thoroughly. In addition, always remember:

**USE THE CORRECT AMMUNITION REFERENCED BY THE INSCRIPTION ON THE BARREL.**

**BEFORE LOADING YOUR GUN BE SURE ALL GREASE AND OIL HAVE BEEN REMOVED FROM THE BARREL AND CHAMBER, AND THERE ARE NO OBSTRUCTIONS.**

#### INITIAL CLEANING


Some metal parts of your new Model 1300 have been coated at the factory with a rust preventative compound. Before using your Model 1300, clean the anti-rust compound from the inside of the barrel, receiver, breech bolt mechanism and the action/chamber areas. A high quality, light weight gun oil should be used to remove this compound and to give your new gun its first lubrication. Clean the barrel using a cleaning rod and patch as explained under "Cleaning and Maintenance Suggestions" found later in this booklet. First lubrication suggestions are outlined below.

If your new Model 1300 is to be stored for an extended period of time, it is permissible to leave the rust preventative compound in place and keep your Model 1300 in its box for maximum protection during long-term storage.

#### OILING THE ACTION

Before beginning assembly of your Model 1300 you should first wipe the mechanism clean and apply a few drops of quality oil on the following surfaces (see Figure 3):


Avoid applying too much oil. Only a light film is necessary. Excessive oil should be wiped off.



**FIGURE 3**

### OPERATION OF THE SAFETY

Your new Model 1300 Winchester shotgun is designed with a cross bolt type safety. It is located just forward of the trigger on the trigger guard: convenient for gloved or ungloved fingers (see Figure 4). It is essential that you become very familiar with the feel, look and operation of the safety on this shotgun before attempting to load and shoot.



With the safety in the "ON SAFE" position the trigger and hammer are blocked and the shotgun cannot be fired. In the "OFF SAFE" position — if your gun is loaded with a round in the chamber — the chambered round can be fired by simply pulling the trigger.

- "ON SAFE". The safety button is pushed fully to the right. The red band on the left side is not showing.
- "OFF SAFE". The safety button is pushed fully to the left. A large red band is exposed on the button as it protrudes on the left side. The red band is an added aid to safe gun handling. However, with time and exposure to the elements it can wear off.

Never rely totally on your gun's safety button. It is merely an aid to safe gun handling. Like any mechanical device the safety can possibly fail: it can be jarred or inadvertently manipulated into an unsafe condition. Always keep your shotgun pointed in a safe direction.

At all times in the field keep the safety in the "ON SAFE" position and the barrel pointed in a safe direction. It is a good idea never to load your shotgun until you are in the field and shooting is imminent or until you are at your station and it is your turn to shoot when you are shooting at a range. For extra safety, and as a courtesy to others, fully unload and place the action in the open position at all times other than when shooting is immediately imminent.

### **INITIAL ASSEMBLY**

---


Remove the barrel assembly and receiver/stock section from the carton. Be sure you have wiped them clean and oiled them. Unscrew the magazine cap from the magazine tube. Because the magazine spring is held in place by a friction-type magazine spring retainer always be careful with which direction the end of the magazine is pointed.

#### **ALWAYS KEEP THE MAGAZINE POINTING AWAY FROM YOU AND OTHERS WHEN REMOVING THE MAGAZINE CAP.**

Your shotgun will usually come out of the box with the bolt assembly in the closed position (forward) with the trigger assembly already in place in the receiver. The barrel can be assembled with the action closed, but it is usually much easier if the action has been opened slightly.

To unlock the action and then open the action — without pulling the trigger — push up on the disconnecter release button at rear of the trigger guard (see Figure 5) on the left side and pull back on the forearm. Do this then:

1. Grasp the barrel ahead of the magazine tube bracket.
2. Position the barrel over and in line with the magazine tube.
3. Slide the barrel rearward.



4. Guide the magazine tube bracket over the end of the magazine tube and guide the barrel extension into the receiver. Be sure that the slot in the barrel aligns with the ejector. As a guide in assembly, align the rib on the barrel assembly with the grooves on the top of the receiver
5. Slide the barrel rearward until it seats in the receiver.
6. Immediately replace the magazine cap and tighten it hand tight at least 3 threads.

### **TAKING DOWN THE BARREL**

---

1. Depress the disconnecter release button, found behind the trigger guard on the left side, to unlock the action without releasing the hammer.

2. Open the action and place the safety in the "ON SAFE" position. (The red warning band must not be visible.)
3. With the magazine pointed in a safe direction, unscrew and remove the magazine cap. Be careful, the magazine spring and magazine plug are retained by a friction-type retainer.

***ALWAYS KEEP THE MAGAZINE POINTING AWAY FROM YOU AND OTHERS WHEN REMOVING THE MAGAZINE CAP.***

4. Carefully disengage the barrel from the receiver while sliding the magazine from the barrel ring. ***DO NOT USE EXCESSIVE FORCE.*** Immediately replace the magazine cap and hand tighten at least three threads.

Reassembly of the barrel to the action was explained earlier under "Initial Assembly."

#### **LOADING PROCEDURES**

Use the correct ammunition referenced by the inscription on the barrel. Before loading your gun, be sure all grease and oil has been removed from the barrel and chamber and there is no obstruction.

1. Depress the disconnecter release button found behind

the trigger guard on the left side. This unlocks the action without releasing the hammer.

2. Open the action and push the safety in the "ON SAFE" position. The chamber is now ready to be loaded.

3. To operate your Model 1300 in a single-shot mode a shell can now be placed directly into the chamber.


**IMPORTANT:** When the slide is moved forward with a shell placed directly into the chamber the gun is now ready to fire.

#### **LOADING THE MAGAZINE**

Before loading, make sure your shotgun is pointed in a safe direction and you are in an appropriate location for loading and that shooting will be imminent.

1. Place the safety in the "ON SAFE" position and close the action.
2. Depress the carrier with the forward end of the nose of the shell.
3. With your thumb on the base of the brass push the shell into the magazine until the carrier returns to the original position (see Figure 6).
4. Repeat the procedure until the magazine is fully loaded.

**DO NOT CARRY A GUN WITH A SHELL IN THE CHAMBER TO AVOID ACCIDENTAL DISCHARGE.**



#### **UNLOADING PROCEDURES**

Perform the following steps to remove shells from the chamber and magazine on all Model 1300s.

1. Point the muzzle in a safe direction.
2. The safety should be in the "ON SAFE" position (the red warning band will not be visible).
3. Hold the disconnecter release button inward to release the slide.
4. Slide the forearm through a complete cycle of the action and repeat the process until all the shells in the magazine have been transferred to the chamber and then ejected.

5. When the last shell in the magazine has been cycled through the chamber and out the ejection port, leave the action open.
6. Using your index finger, feel the entry of the magazine to make sure there are no longer any shells unejected.

#### **ALTERNATE WAY TO UNLOAD —**

The shells can also be removed from the magazine by following these steps:

1. Place the safety in the "ON SAFE" position, make sure the action is closed and keep the muzzle pointing in a safe direction.
2. Turn the gun over so the trigger guard is facing up, then push the carrier down as far as it will go.
3. Push inward on the right of the cartridge cutoff releasing the shell from the magazine. Press the cutoff again to release the second shell. The cartridge cutoff is located on the inside-right of the ejection port. When a shell is in the magazine the cutoff rests on the brass of the shell.
4. With the safety still in the "ON SAFE" position, press the disconnecter release button and move the forearm all the way rearward to remove the shell from the chamber.

**IMPORTANT— ALWAYS VISUALLY CHECK AND KNOW FOR SURE THAT YOUR SHOTGUN IS NOT LOADED.**

#### **FIRING PROCEDURES**

---

1. When ready to shoot, and with a loaded shell in the chamber, the safety "ON SAFE", and your finger off the trigger, push the safety to the "OFF SAFE" position (with the red warning band fully visible). Your shotgun is now ready to fire with a pull of the trigger.

**REMEMBER, THE RECOIL FROM A SHOTGUN, ESPECIALLY MAGNUM LOADS, WILL BE SOMEWHAT HEAVIER THAN MOST OTHER GUNS, SO FIRMLY SHOULDER YOUR MODEL 1300, TAKE AIM, AND — WHEN ON TARGET — SQUEEZE THE TRIGGER.**

2. Pull the forearm fully rearward until the fired shell is ejected out the ejection port.

3. Push the forearm fully forward, transferring a new shell from the magazine into the chamber. Your Model 1300 is again cocked and ready to fire. Immediately put the safety in the "ON SAFE" position (with the red warning ring hidden) until you are ready to fire again.

#### **IN THE CASE OF A MISFIRE**

---

Only rarely will modern factory ammunition experience a misfire. If this ever happens to you when shooting your Model 1300, please follow these instructions carefully.

**CAUTION: IN CASE OF MISFIRE, KEEP THE BARREL POINTED IN A SAFE DIRECTION, CAREFULLY OPEN THE ACTION WHILE AVOIDING DIRECT EXPOSURE TO THE BREECH BY YOURSELF AND OTHERS. REMOVE THE SHELL FROM THE CHAMBER. FULLY UNLOAD YOUR SHOTGUN, REMOVING ALL SHELLS FROM THE MAGAZINE.**

Carefully inspect the ejected shell. If the primer is indented, the shell should be disposed of in a manner that would prevent accidental injury to you, others, or the environment. If there is no indentation, your gun has malfunctioned and should be serviced by a qualified gunsmith, or by the U. S. Repeating Arms Company Service Center in New Haven, Connecticut, or by an Authorized U.S. Repeating Arms Company Repair Station.

### **REMOVING THE MAGAZINE PLUG**

When hunting migratory birds, Federal Law mandates the use of a magazine restriction device that allows only a total of three shells to be held in your shotgun at one time.

**WHEN REMOVING THE PLUG BE CERTAIN THERE ARE NO SHELLS IN THE MAGAZINE OR CHAMBER AND KEEP THE BARREL AND MAGAZINE POINTED IN A SAFE DIRECTION AT ALL TIMES.**

**REMEMBER, THE PLUG IS UNDER SPRING PRESSURE SO CARE MUST BE TAKEN FOR SAFE REMOVAL. ALWAYS POINT THE END OF THE MAGAZINE AWAY FROM YOUR FACE AND IN A SAFE DIRECTION.**

**ALWAYS WEAR EYE PROTECTION WHEN REMOVING AND REINSTALLING THE MAGAZINE'S 3-SHOT PLUG.**


The magazine plug is spring loaded and can thrust out of the magazine when the friction-type magazine retainer is removed too quickly. Never look directly down into the cap end of the open magazine.

1. Remove the magazine cap.

2. Place one hand over the retainer and pry it up slowly with a screw driver using your other hand (see Figure 7). When the retainer releases you will feel the pressure of the friction ring and plug on the palm of your hand.

3. Slowly raise your hand and let the magazine spring relax. Capture the parts in your hand as they spring out.

4. With the spring relaxed, the friction ring, plug, spring and follower can be removed. To reinstall, reverse this procedure.





### RANGER LADIES/YOUTH MODELS ONLY

The Ranger Ladies/Youth 1300s are specially equipped with a segmented plug that can be cut to adjust the number of shells that can be loaded into the magazine. A full length plug with no segments removed turns this Model 1300 into a single shot when installed into the magazine. As a new shooter becomes more experienced with his or

her Model 1300, the first section of the plug can be cut off at the segment notch allowing one shell to be held in the magazine (see Figure 8).

Eventually, with more experience other notches can be removed to facilitate more shells in the chamber. When the entire plug is removed, four shells can be loaded into the magazine with one also in the chamber.





FIGURE 9



#### FULL DISASSEMBLY

One of the advantages of a Model 1300 is the ability to disassemble the action for cleaning. Under very harsh weather conditions and in dirty environments just knowing that parts are clean and lightly oiled can add an extra measure of confidence to your hunt.

Make sure you have a clean place to work and a good place to put the components as they are disassembled.

Wear eye protection at all times. Never disassemble beyond what is explained and shown in this manual (see Figure 9).

Disassembling the action can be done in the field, but remember, there are small parts involved, some of which are under spring tension.

**FIRST, BE CERTAIN THERE ARE NO SHELLS IN THE MAGAZINE OR CHAMBER.**

#### **HOW TO TAKE DOWN THE BARREL**


1. Open the action and make sure the gun is not loaded.
2. Close the action and place the safety in the "ON SAFE" position.
3. Unscrew and remove the magazine cap. Remember, always keep the end of the magazine pointed in a safe direction.
4. Slide the barrel forward withdrawing the barrel from the receiver and disengaging the magazine bracket from the front end of the magazine.
5. Immediately screw the magazine cap back onto the magazine.

#### **HOW TO REMOVE THE TRIGGER GUARD GROUP FROM THE RECEIVER**

Removing the trigger guard group is another necessary procedure in performing thorough maintenance of your shotgun. It is easy to do, and removing it allows you to perform cleaning and maintenance whenever and wherever required. Make sure the gun is unloaded. With both the trigger guard group and bolt assembly removed, it is easy to wipe out any debris or moisture that sometimes accumulates in the receiver. The trigger guard group should be removed before you attempt to remove the bolt assembly. The action should be cycled by sliding the fore-

arm forward and then rearward. This puts the hammer in the cocked position. Place the safety in the "ON SAFE" position.

1. If the barrel assembly has been removed, always be sure to replace the magazine cap on the end of the magazine tube to prevent accidental disengagement of the magazine spring retainer.
2. Place your gun with the trigger guard facing up, on a suitable surface that will protect the receiver finish and stock.
3. Remove the trigger guard pin by pushing it out from the LEFT side of the receiver, side opposite the ejection port. Any sturdy pushing tool that is smaller in diameter than the pin, and that will not mar the finish, is acceptable. Make sure you can maintain a good grip on the pushing tool and on your shotgun while you push.
4. Push the pin through sufficiently until it can be grasped with your fingers. Pull it the rest of the way out. If it cannot be removed with fingers, make sure your pushing tool or punch has a diameter small enough so that it will push the pin completely through without the tool damaging the hole.
5. With the pin removed, lift the trigger guard group out of the receiver by lifting upward and pulling rearward. (see Figure 10)



**HOW TO DISASSEMBLE THE SLIDE AND BREECH BOLT  
(12 GAUGE ONLY).**

1. Remove the barrel and trigger guard group as explained earlier, but do not replace the magazine cap.
2. With the action slide arms still attached to the slide arm bridge, simultaneously slide both assemblies forward and out of the front of the receiver. Note, that as the breech bolt assembly passes by the ejection port, there may be some resistance from the ejector spring. Carefully work it past.

**HOW TO DISASSEMBLE THE SLIDE AND BREECH BOLT  
(20 GAUGE ONLY).**

1. Refer to step one of disassembling a 12 gauge above.

2. You must disengage the slide arms from the slide arm bridge. Remove the slide arms through the front of the receiver. Remove the bolt slide assembly through the trigger guard group opening. (This procedure is necessary because the bolt will not extract out through the front of the receiver as it does on the 12 gauge model.)

**HOW TO REMOVE THE FIRING PIN.**

Begin with the breech bolt assembly removed from the gun.

1. Grasp the breech bolt assembly, bottom side up (flat side), and push the rear of the firing pin forward with your forefinger. While holding the firing pin in this position, take your other hand, tilt the front end of the slide arm bridge and move it slightly forward. Lift up on the slide arm bridge and disengage the curved tongue on the slide arm bridge from the groove in the firing pin. This will detach the slide arm bridge from the breech bolt slide.

2. The firing pin is under spring tension and will snap out the rear of the breech bolt when your forefinger releases it. Control the pin as you remove the firing pin and spring.


For cleaning purposes no further dismantling is necessary or recommended. Do not disassemble your Model 1300 further than shown in Figure 9. Doing so may void your warranty. For repairs that require further disassembly con-

tact your local Service Representative or U.S. Repeating Arms Co.


**HOW TO REASSEMBLE THE FIRING PIN, BREECH BOLT AND SLIDE. (12 GAUGE ONLY)**

1. Reinstall the firing pin spring over the firing pin. Either end can go on first.
2. Insert the firing pin (with spring) into the rear opening of the bolt slide, pin end first.
3. To reinstall the bolt assembly on the slide arm bridge push or compress the "knob end" of the firing pin sufficiently into the hole in the bolt slide so that the large space between the grooved "knob" and the flange on the firing pin is centered in the round hole in the bolt slide.
4. Place the curved tongue, located on the slide arm bridge, into the space between the knob and flange and slowly release pressure on the end of the firing pin. Let the flange on the pin pull the tongue toward the rear of the bolt assembly. This should hold the breech bolt assembly and the slide arm bridge together during further assembly.
5. With the firing pin and breech bolt now assembled, engage the slide arm bridge into the matching cuts on the slide arms (see Figure 11).

6. Hold the slide arms and bolt/slide arm bridge assemblies together. Start the forearm assembly onto the magazine tube.



7. Remove the magazine cap and carefully guide the slide arms and bolt/slide arm bridge assemblies into the front of the receiver. As the assemblies enter the receiver, slide them fully rearward (see Figure 12).



**HOW TO REASSEMBLE THE FIRING PIN, BREECH BOLT AND SLIDE. (20 GAUGE ONLY)**

1. Reinstall the firing pin spring over the firing pin. Either end can go on first.
2. Insert the firing pin (with spring) into the rear opening of the bolt slide, pin end first.
3. To reinstall the bolt assembly on the slide arm bridge push or compress the "knob end" of the firing pin sufficiently into the hole in the bolt slide so that the large space between the grooved "knob" and the flange on the firing pin is centered in the round hole in the bolt slide.
4. Place the curved tongue, located on the slide arm bridge, into the space between the knob and flange and slowly release pressure on the end of the firing pin. Let the flange on the pin pull the tongue toward the rear of the bolt assembly. This should hold the breech bolt assembly and the slide arm bridge together during further assembly.
5. With the trigger guard group removed, insert the bolt assembly through the trigger guard opening up into the receiver. The front face and extractor of the bolt assembly should be facing the barrel or front of the shotgun. The slide arm bridge should be facing down toward the trigger guard group opening.

6. While holding the bolt assembly in place, insert the slide arm bars into the breech and connect them to the slide arm bridge.

**HOW TO REINSTALL THE TRIGGER GUARD GROUP.**

Be careful when reinstalling the trigger group. Never force parts into position. Normally the bolt assembly, slide arms and barrel should be attached before installing the trigger guard group. The hammer should be in the cocked position and the safety in the "ON SAFE" position. Carefully insert the trigger guard group into place. It may be necessary to slide the forearm into different positions until the trigger guard group fits flush into the receiver. When it is properly installed it will fit easily and the pin will slide in without excessive force.

Installing the bolt assembly after the trigger guard group is installed should not be attempted. Consequently, make sure you have already installed the bolt assembly before installing the trigger guard group. It is not necessary that the barrel already be attached to install the trigger group. Install the trigger group by as follows:

1. Turn your shotgun over with the open bottom of the receiver facing upward. Hold the trigger guard group at an angle to the receiver (about 45 degrees) and then engage the front tabs on the trigger guard group with the corre-

sponding slots in the magazine throat at the forward end of receiver opening as shown earlier in Figure 10.

2. Rotate the trigger guard group towards and into the receiver opening, until it is parallel with the receiver.

3. Align the trigger guard group with the hole in the receiver and install the trigger guard pin from the RIGHT side of the receiver (ejection port side) until it is flush with both sides of the receiver. The pin should pass through easily with little force. If significant resistance is felt, remove the trigger group and repeat step one above.

Your Model 1300 shotgun is now fully assembled.

Immediately confirm that the safety is in the "ON SAFE" position. Take time to wipe down and clean all external surfaces as explained under Cleaning and Maintenance Suggestions later in this manual.

### **SIGHT ADJUSTMENTS**

Some Model 1300 shotguns are fitted with rifle-type open sights. The style and adjustment system may vary between models and grades. The proper procedure is to shoot a group with the sights set as they come from the factory (intermediate position on both elevation and windage), and then make incremental adjustments to move the sight blade and blade holder to position the group on your target. The procedures below are for the

most common type of open sights found on Model 1300 shotguns.

***BEFORE MAKING ANY SIGHT ADJUSTMENTS, MAKE SURE YOUR SHOTGUN IS FULLY UNLOADED AND THE MUZZLE IS POINTED IN A SAFE DIRECTION. PLACE THE SAFETY IN THE "ON SAFE" POSITION.***

#### **UP OR DOWN ELEVATION ADJUSTMENTS.**


Adjusting elevation on your Model 1300 requires you to lift up the rear notch blade on your shotgun's rear sight with your fingers and move the notched elevator either forward or backward. To raise point of impact, use your fingers to lift up on the blade and slide the elevator rearward. Adjusting the sight to make your gun shoot lower is just the opposite — move the elevator forward.

Remember:

- Move the blade up to shoot higher.
- Move the blade down to shoot lower.

#### **RIGHT OR LEFT WINDAGE ADJUSTMENTS.**

On most Model 1300 sights, the entire rear sight blade holder is dove-tailed in the rear sight base. To adjust for windage, gently move the rear sight blade to the right by tapping at the dove-tail using a wood dowel or similar



material that will not mar the sight (see Figure 13). Your gun will now shoot more to the right. Moving the blade holder to the left is just as easily done. Note how much you adjust the sight as you sight in your Model 1300. Remember:

- Move the rear sight to the right to shoot farther to the right on the target.
- Move the rear sight to the left to shoot farther to the left on the target.

Care should be taken not to mar the finish or bend sights when adjustments are made.

#### **WINCHOKE® THREADED CHOKE TUBE SYSTEM**

Some Model 1300s are fitted with the interchangeable WinChoke choke tube system. If your shotgun has the

words "WinChoke" inscribed on the side of the barrel then you have the system.

The WinChoke system allows you to configure your Model 1300 for the pattern and/or choke constriction your hunt demands. It also offers versatility when using slugs or sabots. And allows the use of an accessory 5" rifled choke tube for use with sabot-type slugs.

Your Model 1300 is provided with the WinChoke screw-in choke tube system. This gives you the finest possible patterns for target and field situations. Plus, it is extremely easy to switch choke constrictions to match your shooting conditions. WinChoke tubes are fully steel and lead shot compatible. A special choke tube spanner wrench is provided to remove and tighten these tubes.

**CAUTION: DO NOT USE WINCHOKE TUBES IN ANY SHOTGUN BARRELS NOT SUPPLIED BY U. S. REPEATING ARMS COMPANY (THE MAKERS OF WINCHESTER BRAND FIREARMS). ALSO, DO NOT USE ANY OTHER CHOKING DEVICE IN ANY SHOTGUN BARRELS SUPPLIED BY U. S. REPEATING ARMS. USE ONLY THE APPROPRIATE GAUGE AND TYPE OF CHOKE TUBES MARKED WINCHOKE IN YOUR MODEL 1300 SHOTGUN.**



**CAUTION: WHENEVER HANDLING ANY SHOTGUN FOR THE PURPOSE OF REMOVING OR INSTALLING A CHOKING DEVICE, MAKE ABSOLUTELY CERTAIN THE GUN IS FULLY UNLOADED, AND THE ACTION IS LOCKED OPEN! NEVER ATTEMPT TO REMOVE OR INSTALL A SHOTGUN CHOKING DEVICE ON A LOADED FIREARM!**

**DO NOT FIRE THIS SHOTGUN WITHOUT HAVING THE WINCHOKE CHOKE TUBE INSTALLED. PERMANENT DAMAGE MAY RESULT TO THE THREADS.**

| <b>SHOT CONVERSION CHART</b> |                   |
|------------------------------|-------------------|
| <b>Lead</b>                  | <b>Steel</b>      |
| Full                         | *                 |
| Improved Modified            | Full              |
| Modified                     | Full              |
| Improved Cylinder            | Modified          |
| Skeet                        | Improved Cylinder |
| Cylinder                     | Cylinder          |
| *not for use with steel shot |                   |

**FAILURE TO FOLLOW THESE WARNINGS MAY CAUSE DAMAGE TO YOUR GUN AND CAUSE INJURY TO YOURSELF AND OTHERS.**


#### TUBE REMOVAL

1. Fully unload your Model 1300. Place the safety in the "ON SAFE" position.

**ALWAYS UNLOAD YOUR MODEL 1300 COMPLETELY. INSPECT THE CHAMBER, MAGAZINE AND FEED MECHANISM TO MAKE SURE THEY DO NOT CONTAIN ANY SHELLS.**

2. Open the action.

3. Use the WinChoke spanner wrench to loosen the tube, turning it counterclockwise (see Figure 14). Finger twist the tube the rest of the way out of the barrel.



#### TUBE INSTALLATION

1. Fully unload your Model 1300. Place the safety in the "ON SAFE" position.

**ALWAYS UNLOAD YOUR MODEL 1300 COMPLETELY. INSPECT THE CHAMBER, MAGAZINE AND FEED MECHANISM TO MAKE SURE THEY DO NOT CONTAIN ANY SHELLS.**

2. Open the action and lock it open as explained previously.

3. Before installing a tube, check the internal choke tube threads in the muzzle, as well as the threads on the WinChoke choke tube to be sure they are clean. Lightly oil the threads with quality light gun oil.

4. Using your fingers, screw the appropriate tube into the muzzle end of the barrel, tapered end first, notched end outward. When it becomes finger-tight, use the WinChoke choke tube spanner-type wrench to firmly seat the tube. DO NOT OVER TIGHTEN or forcefully tighten with wrench.

**CHOKE TUBES SHOULD BE PERIODICALLY CHECKED TO ASSURE THAT THEY ARE TIGHT AND FIRMLY SEATED. BEFORE CHECKING, FOLLOW THE SAFETY GUIDELINES OUTLINED ABOVE.**

Replacement and additional tubes and wrenches are available from your Winchester firearms dealer.

#### WINCHOKE CHOKE IDENTIFICATION

To identify individual WinChoke choke tubes, refer to the abbreviated indications on the outside rim of each tube.

#### SELECTING THE CORRECT WINCHOKE TUBE

The WinChoke choke system is fully compatible with factory lead or steel shot loads. The chart includes both lead and steel shot information. Lead and steel shot perform differently in tubes with the same choke constriction. For this reason, both lead and steel designations have proven necessary. In fact, even larger steel shot diameters result in different patterns than smaller steel shot sizes. Each designation is inscribed on each choke tube.

#### SPECIAL NOTE ON SHOTGUN SLUGS

Cylinder or Improved Cylinder WinChokes are suitable for shooting rifled slugs or sabot-type slugs. A special 5-inch rifled choke tube (#1820143) is available from your dealer that is specially made for shooting sabot slugs in WinChoke barrels. Never shoot slugs or sabots in any WinChoke barrel with the choke tube removed.

#### **SPECIAL CARE OF CHOKE TUBES AND CHOKE TUBE THREADS**

1. If your gun is equipped with WinChoke choke tubes, do not use a brass brush to clean your gun unless a choke tube is installed in the barrel. Bristles could break off and lodge in the threads, making installation and removal difficult.
2. Regularly remove your gun's tube in order to clean and oil the threads inside the barrel, as well as on the choke tube itself. This will protect the threads from being damaged and also prevent a dirt build up that would cause the choke tube to become difficult to remove from the barrel. Clean the threads with solvent and a small, soft brush like a toothbrush. Wipe completely clean and leave a thin film of clean oil on the threads: both on the tube and in the barrel. The threads of the choke tube and the internal threads of the barrel should be cleaned after each use and before the installation of a tube.
3. Be careful when removing/installing a tube. Use the specially designed WinChoke spanner wrench. Damage can result to both choke tube and barrel when attempting to remove sticky choke tubes.
4. Never fire your shotgun or run cleaning tools

through the barrel of any choke-tubed gun without having the choke tube installed.

#### **CLEANING AND MAINTENANCE SUGGESTIONS**

Your Model 1300 will function better and more reliably over a longer period of time if it is properly maintained and kept clean.

***BEFORE PERFORMING ANY CLEANING PROCEDURES, ALWAYS MAKE CERTAIN THERE ARE NO SHELLS IN THE CHAMBER, MAGAZINE OR ACTION/FEED AREAS.***

You should clean your Model 1300 after every day of shooting and more often if it becomes excessively dirty.

A minimum cleaning includes wiping down the action and oiling key parts. Most regular maintenance will also include cleaning the barrel. If you encounter a function problem (tight action when working the forearm) be sure to give your gun a thorough cleaning to see if it solves the problem before seeking the services of our service facility or a competent gunsmith. To clean your firearm; adhere to the following general guidelines.

#### CLEANING PROCEDURES

**BE CERTAIN YOUR GUN'S CHAMBER AND MAGAZINE ARE UNLOADED. ALWAYS WEAR PROTECTIVE SAFETY GLASSES DURING ALL CLEANING PROCEDURES. KEEP AMMUNITION AWAY FROM THE CLEANING AREA. DO NOT TEST THE FUNCTION OF YOUR FIREARM WITH LIVE AMMUNITION.**

Always place the safety in "ON SAFE" position before beginning any cleaning procedure.

1. Use a cleaning rod with a tip and patch suitable for the size of your Model 1300's bore. Make sure the patch is large enough for a snug fit in the bore. Insert the rod and patch into the barrel at the receiver end and run it back and forth several times.
2. Inspect the chamber and bore for lead and powder fouling. A normal amount of powder residue can be expected and is not serious. It can usually be removed by repeating step one, using a patch saturated with solvent. If or when fouling should become heavy, it can be removed with a brass bore brush. Dip or spray the brush with solvent and scrub the chamber and bore until the fouling is removed. To prevent brass bristles from breaking off, the brush should be pushed completely through the bore before being withdrawn.

3. After fouling has been removed the bore should be wiped dry. Then pass a slightly oiled patch through the bore, for preservation. A fine, light gun oil is recommended.

4. Wipe all exposed metal surfaces of the receiver, forearm and barrel with a clean rag. Finger marks should be removed because they provide a place where moisture can accumulate. Any dried oil in the receiver area should also be removed.

5. Lightly oil your gun at the points described under "Oiling the Action" explained earlier in this manual.

Ordinary good judgment will, of course, indicate that the metal of the gun should receive a light film of oil any time the rifle has been exposed to weather or handling. This is very important and must be done with every gun — even stainless steel models. Remember, the polished, finely fitted surfaces of the receiver and action mechanisms must always have a thin film of oil. Make sure that the surfaces of the breech bolt are especially clean and lightly oiled with a high quality gun oil.

6. Inspect the barrel and chamber. Make certain that no patches have been inadvertently left in them. Remove any that remain.

7. Wipe all wood surfaces with a soft cloth.

8. When transporting only, store your Model 1300 in a quality protective case to prevent scratches and dents. Store in a dry place to prevent corrosion. Store away from children.

**MAKE SURE YOUR SHOTGUN IS UNLOADED AND ALWAYS STORE AMMUNITION SEPARATELY.**

**OTHER CLEANING SUGGESTIONS**

- Never pour large quantities of oil into the receiver or other parts. It can drain down to the wood and soften it — and cause permanent damage and loosening of the stock.
- After extended periods of heavy use, your shotgun should be taken to a qualified gunsmith to have the action disassembled for professional cleaning and lubrication.
- Camouflage models require the same care and cleaning as non-camouflage. Use the same oils and solvents as described previous in this manual.

**NEVER ATTEMPT TO TAKE YOUR MODEL 1300 APART FURTHER THAN EXPLAINED IN THIS MANUAL.**

This is a specialized, finely fitted mechanism. You may permanently mar it by attempting to disassemble the inner mechanism assemblies. If further disassembly for

service or cleaning is required, take your gun to a U. S. Repeating Arms Company recommended Service Center or a competent gunsmith as explained under "Service or Repair."

**ORDERING PARTS**

---

To order parts, please write our parts department and furnish the following: your name, address, and telephone number. Also specify the model and serial number of your Winchester Model 1300. When we receive your request, we will send an order form and a parts breakdown with prices.

Write to:

**Parts Department**  
**U.S. Repeating Arms Company, Inc.**  
275 Winchester Avenue  
New Haven, Connecticut 06511-1970

**CAUTION: PARTS ARE MADE FOR WINCHESTER BRAND FIREARMS MANUFACTURED BY U.S. REPEATING ARMS COMPANY, INC., AND SHOULD NOT BE USED IN OTHER GUNS EVEN THOUGH MODELS MAY BE SIMILAR. IMPROPERLY FITTED PARTS MAY BE DANGEROUS.**


### **SERVICE OR REPAIR**

If your Winchester Model 1300 shotgun should ever need repair or service, please utilize one of the world-wide network of U.S. Repeating Arms Company Authorized Repair Centers for Winchester firearms. If you have any questions about how to obtain service for your Winchester Model 1300 shotgun, call or write the Authorized Repair Center (ARC) nearest you. A list of ARCs is packaged with your new 1300. If you need to obtain a new list of ARCs call us at:

**1-800-945-1392**

If you have other questions about Winchester rifles and shotguns, call or write our Customer Service Department:

**Customer Service  
U. S. Repeating Arms Company, Inc.  
275 Winchester Avenue  
Morgan, Utah 84050-9333  
Phone: 1-800-945-5237**



## ***WINCHESTER***

U.S. Repeating Arms Company, Inc.

275 Winchester Avenue

New Haven, Connecticut, U.S.A. 06511-1970

Administrative Offices:

275 Winchester Avenue, Morgan, Utah 84050-9333

Winchester trademarks licensed from Olin Corporation.

This Manual Was Provided To You By:



**CENTURY  
INTERNATIONAL  
ARMS INC.**

**[www.centuryarms.com](http://www.centuryarms.com)**