

Acoustics

[Wikibooks.org](https://en.wikibooks.org/wiki/Acoustics)

March 13, 2013

On the 28th of April 2012 the contents of the English as well as German Wikibooks and Wikipedia projects were licensed under Creative Commons Attribution-ShareAlike 3.0 Unported license. An URI to this license is given in the list of figures on page 157. If this document is a derived work from the contents of one of these projects and the content was still licensed by the project under this license at the time of derivation this document has to be licensed under the same, a similar or a compatible license, as stated in section 4b of the license. The list of contributors is included in chapter Contributors on page 155. The licenses GPL, LGPL and GFDL are included in chapter Licenses on page 163, since this book and/or parts of it may or may not be licensed under one or more of these licenses, and thus require inclusion of these licenses. The licenses of the figures are given in the list of figures on page 157. This PDF was generated by the L^AT_EX typesetting software. The L^AT_EX source code is included as an attachment (`source.7z.txt`) in this PDF file. To extract the source from the PDF file, we recommend the use of <http://www.pdfplabs.com/tools/pdftk-the-pdf-toolkit/> utility or clicking the paper clip attachment symbol on the lower left of your PDF Viewer, selecting **Save Attachment**. After extracting it from the PDF file you have to rename it to `source.7z`. To uncompress the resulting archive we recommend the use of <http://www.7-zip.org/>. The L^AT_EX source itself was generated by a program written by Dirk Hünninger, which is freely available under an open source license from http://de.wikibooks.org/wiki/Benutzer:Dirk_Huenniger/wb2pdf. This distribution also contains a configured version of the `pdflatex` compiler with all necessary packages and fonts needed to compile the L^AT_EX source included in this PDF file.

Contents

1	Fundamentals of Acoustics	3
1.1	Introduction	3
1.2	Equation of waves	3
1.3	Helmholtz equation	4
1.4	Acoustic intensity and decibel	5
1.5	Solving the wave equation	5
1.6	Boundary conditions	6
2	Fundamentals of Room Acoustics	7
2.1	Introduction	7
2.2	The modal theory	7
2.3	The geometry theory	8
2.4	The theory of Sabine	8
3	Fundamentals of Psychoacoustics	11
3.1	Perception of sound	11
3.2	Phons and sones	12
3.3	Metrics	14
4	Sound Speed	17
4.1	Details	17
4.2	Speed of sound in air	22
4.3	Sound in solids	22
4.4	Experimental methods	22
4.5	External links	23
5	Filter Design and Implementation	25
5.1	Introduction	25
5.2	Basic wave theory	26
5.3	Basic filter design	27
5.4	Actual filter design	34
5.5	Links	39
5.6	References	39
6	Flow-induced oscillations of a Helmholtz resonator	41
6.1	Introduction	41
6.2	Fundamentals of active control of noise	42
6.3	Active control systems	45
6.4	Applications	46
6.5	Further reading	48

7	Anechoic and reverberation rooms	49
8	Basic Room Acoustic Treatments	51
8.1	Introduction	51
8.2	Room sound combinations	51
8.3	Good and bad reflected sound	52
8.4	How to find overall trouble spots in a room	57
8.5	References	57
9	Human Vocal Fold	59
9.1	Physiology of vocal fold	59
9.2	Voice production	59
9.3	Model	61
9.4	Simulation of the model	62
9.5	The acoustic output	63
9.6	Related links	64
9.7	References	64
10	Threshold of Hearing/Pain	65
11	Musical Acoustics Applications	67
12	Microphone Technique	69
12.1	General technique	69
12.2	Types of microphones	69
12.3	Working distance	71
12.4	Stereo and surround technique	73
12.5	Placement for varying instruments	75
12.6	Sound Propagation	76
12.7	Sources	77
13	Microphone Design and Operation	79
13.1	Introduction	79
13.2	Dynamic microphones	79
13.3	Condenser microphones	81
13.4	Conclusion	84
13.5	References	84
13.6	Microphone manufacturer links	84
14	Acoustic Loudspeaker	85
14.1	The Magnet Motor Drive System	86
14.2	The loudspeaker cone system	88
14.3	The loudspeaker suspension	91
14.4	Modeling the loudspeaker as a lumped system	93
14.5	The acoustical enclosure	95
14.6	References	97
15	Sealed Box Subwoofer Design	99
15.1	Introduction	99

15.2	Closed baffle circuit	99
15.3	Driver parameters	100
15.4	Acoustic compliance	101
15.5	Sealed box design	102
16	Miscellaneous Applications	105
17	Bass-Reflex Enclosure Design	107
17.1	Effects of the Port on the Enclosure Response	108
17.2	Quantitative Analysis of Port on Enclosure	110
17.3	Development of Low-Frequency Pressure Response	111
17.4	Alignments	112
17.5	Butterworth Alignment	113
17.6	Quasi-Butterworth Alignment	114
17.7	Chebyshev Alignment	115
17.8	Choosing the Correct Alignment	117
17.9	References	117
17.10	Appendix A: Equivalent Circuit Parameters	118
17.11	Appendix B: Enclosure Parameter Formulas	119
18	Polymer-Film Acoustic Filters	121
18.1	Introduction	121
18.2	Changes in Media Properties Due to Sound Wave Characteristics	122
18.3	Why Coupled Acoustic Media in Acoustic Filters?	122
18.4	Effects of High-Intensity, Ultrasonic Waves in Acoustic Media in Audio Frequency Spectrum	124
18.5	An Application of Coupled Media in Acoustic Filters	124
18.6	References	125
19	Noise in Hydraulic Systems	127
19.1	Noise in Hydraulic Systems	127
19.2	Sound in fluids	127
19.3	Source of Noise	128
19.4	Fluidborne Noise (FBN)	128
19.5	Structureborne Noise (SBN)	129
19.6	Transmission	130
19.7	Airborne noise (ABN)	131
19.8	Noise reduction	131
19.9	Hydraulic System noise	132
19.10	References	132
20	Noise from Cooling Fans	133
20.1	Proposal	133
20.2	Introduction	133
20.3	Noise Generation Mechanisms	134
20.4	Installation Effects	138
20.5	Closing Comment	138
20.6	Links to Interesting Sites about Fan Noise	139

20.7	References	140
21	Piezoelectric Transducers	141
22	Introduction	143
23	Vibrations & Displacements	145
24	Dynamic Performance	147
24.1	Equivalent Electric Circuit	147
24.2	Frequency Response	147
25	Resonant Devices	149
26	Applications	151
26.1	Mechanical Measurement	151
26.2	Ultrasonic	151
27	More Information and Source of Information	153
28	Contributors	155
	List of Figures	157
29	Licenses	163
29.1	GNU GENERAL PUBLIC LICENSE	163
29.2	GNU Free Documentation License	164
29.3	GNU Lesser General Public License	165

1 Fundamentals of Acoustics



Figure 1

1.1 Introduction

Sound is an oscillation of pressure transmitted through a gas, liquid, or solid in the form of a traveling wave¹, and can be generated by any localized pressure variation in a medium. An easy way to understand how sound propagates is to consider that space can be divided into thin layers. The vibration (the successive compression and relaxation) of these layers, at a certain velocity, enables the sound to propagate, hence producing a wave. The speed of sound depends on the compressibility and density of the medium.

In this chapter, we will only consider the propagation of sound waves in an area without any acoustic source, in a homogeneous² fluid.

1.2 Equation of waves

Sound waves consist in the propagation of a scalar quantity, acoustic over-pressure. The propagation of sound waves in a stationary medium (e.g. still air or water) is governed by the following equation (see wave equation³):

1 <http://en.wikipedia.org/wiki/wave>
2 <http://en.wikipedia.org/wiki/homogeneous>
3 <http://en.wikipedia.org/wiki/wave%20equation>

$$\nabla^2 p - \frac{1}{c_0^2} \frac{\partial^2 p}{\partial t^2} = 0$$

This equation is obtained using the conservation equations (mass, momentum and energy) and the thermodynamic equations of state of an ideal gas (or of an ideally compressible solid or liquid), supposing that the pressure variations are small, and neglecting viscosity and thermal conduction, which would give other terms, accounting for sound attenuation.

In the propagation equation of sound waves, c_0 is the propagation velocity of the sound wave (which has nothing to do with the vibration velocity of the air layers). This propagation velocity has the following expression:

$$c_0 = \frac{1}{\sqrt{\rho_0 \chi_s}}$$

where ρ_0 is the density and χ_s is the compressibility coefficient of the propagation medium.

1.3 Helmholtz equation

Since the velocity field \underline{v} for acoustic waves is irrotational we can define an acoustic potential Φ by:

$$\underline{v} = \text{grad } \Phi$$

Using the propagation equation of the previous paragraph, it is easy to obtain the new equation:

$$\nabla^2 \Phi - \frac{1}{c_0^2} \frac{\partial^2 \Phi}{\partial t^2} = 0$$

Applying the Fourier Transform, we get the widely used Helmholtz equation:

$$\nabla^2 \hat{\Phi} + k^2 \hat{\Phi} = 0$$

where k is the wave number associated with Φ . Using this equation is often the easiest way to solve acoustical problems.

1.4 Acoustic intensity and decibel

The acoustic intensity represents the acoustic energy flux associated with the wave propagation:

$$\underline{i}(t) = p\underline{v}$$

We can then define the average intensity:

$$\underline{I} = \langle \underline{i} \rangle$$

However, acoustic intensity does not give a good idea of the sound level, since the sensitivity of our ears is logarithmic. Therefore we define decibels, either using acoustic over-pressure or acoustic average intensity:

$$p^{dB} = 20 \log \left(\frac{p}{p_{\text{ref}}} \right)$$

$$;$$

$$L_I = 10 \log \left(\frac{I}{I_{\text{ref}}} \right)$$

where $p_{\text{ref}} = 2 \cdot 10^{-5} Pa$ for air, or $p_{\text{ref}} = 10^{-6} Pa$ for any other media, and $I_{\text{ref}} = 10^{-12} W/m^2$.

1.5 Solving the wave equation

1.5.1 Plane waves

If we study the propagation of a sound wave, far from the acoustic source, it can be considered as a plane 1D wave. If the direction of propagation is along the x axis, the solution is:

$$\Phi(x, t) = f \left(t - \frac{x}{c_0} \right) + g \left(t + \frac{x}{c_0} \right)$$

where f and g can be any function. f describes the wave motion toward increasing x, whereas g describes the motion toward decreasing x.

The momentum equation provides a relation between p and \underline{v} which leads to the expression of the specific impedance, defined as follows:

$$\frac{p}{v} = Z = \pm \rho_0 c_0$$

And still in the case of a plane wave, we get the following expression for the acoustic intensity:

$$\dot{i} = \pm \frac{p^2}{\rho_0 c_0} e_x$$

1.5.2 Spherical waves

More generally, the waves propagate in any direction and are spherical waves. In these cases, the solution for the acoustic potential Φ is:

$$\Phi(r, t) = \frac{1}{r} f\left(t - \frac{r}{c_0}\right) + \frac{1}{r} g\left(t + \frac{r}{c_0}\right)$$

The fact that the potential decreases linearly while the distance to the source rises is just a consequence of the conservation of energy. For spherical waves, we can also easily calculate the specific impedance as well as the acoustic intensity.

1.6 Boundary conditions

Concerning the boundary conditions which are used for solving the wave equation, we can distinguish two situations. If the medium is not absorptive, the boundary conditions are established using the usual equations for mechanics. But in the situation of an absorptive material, it is simpler to use the concept of acoustic impedance.

1.6.1 Non-absorptive material

In that case, we get explicit boundary conditions either on stresses and on velocities at the interface. These conditions depend on whether the media are solids, inviscid or viscous fluids.

1.6.2 Absorptive material

Here, we use the acoustic impedance as the boundary condition. This impedance, which is often given by experimental measurements depends on the material, the fluid and the frequency of the sound wave.

2 Fundamentals of Room Acoustics



Figure 2

2.1 Introduction

Three theories are used to understand room acoustics :

1. The modal theory
2. The geometric theory
3. The theory of Sabine

2.2 The modal theory

This theory comes from the homogeneous Helmholtz equation $\nabla^2 \hat{\Phi} + k^2 \hat{\Phi} = 0$. Considering a simple geometry of a parallelepiped (L1,L2,L3), the solution of this problem is with separated variables :

$$P(x, y, z) = X(x)Y(y)Z(z)$$

Hence each function X, Y and Z has this form :

$$X(x) = Ae^{-ikx} + Be^{ikx}$$

With the boundary condition $\frac{\partial P}{\partial x} = 0$, for $x = 0$ and $x = L1$ (idem in the other directions), the expression of pressure is :

$$P(x, y, z) = C \cos\left(\frac{m\pi x}{L1}\right) \cos\left(\frac{n\pi y}{L2}\right) \cos\left(\frac{p\pi z}{L3}\right)$$

$$k^2 = \left(\frac{m\pi}{L1}\right)^2 + \left(\frac{n\pi}{L2}\right)^2 + \left(\frac{p\pi}{L3}\right)^2$$

where m, n, p are whole numbers

It is a three-dimensional stationary wave. Acoustic modes appear with their modal frequencies and their modal forms. With a non-homogeneous problem, a problem with an acoustic source Q in r_0 , the final pressure in r is the sum of the contribution of all the modes described above.

The modal density $\frac{dN}{df}$ is the number of modal frequencies contained in a range of 1Hz. It depends on the frequency f , the volume of the room V and the speed of sound c_0 :

$$\frac{dN}{df} \simeq \frac{4\pi V}{c_0^2} f^2$$

The modal density depends on the square frequency, so it increase rapidly with the frequency. At a certain level of frequency, the modes are not distinguished and the modal theory is no longer relevant.

2.3 The geometry theory

For rooms of high volume or with a complex geometry, the theory of acoustical geometry is critical and can be applied. The waves are modelised with rays carrying acoustical energy. This energy decrease with the reflection of the rays on the walls of the room. The reason of this phenomenon is the absorption of the walls.

The problem is this theory needs a very high power of calculation and that is why the theory of Sabine is often chosen because it is easier.

2.4 The theory of Sabine

2.4.1 Description of the theory

This theory uses the hypothesis of the diffuse field, the acoustical field is homogeneous and isotropic. In order to obtain this field, the room has to be sufficiently reverberant and the frequencies have to be high enough to avoid the effects of predominating modes.

The variation of the acoustical energy E in the room can be written as :

$$\frac{dE}{dt} = W_s - W_{abs}$$

Where W_s and W_{abs} are respectively the power generated by the acoustical source and the power absorbed by the walls.

The power absorbed is related to the voluminal energy in the room e :

$$W_{abs} = \frac{ec_0}{4}a$$

Where a is the equivalent absorption area defined by the sum of the product of the absorption coefficient and the area of each material in the room :

$$a = \sum_i \alpha_i S_i$$

The final equation is : $V \frac{de}{dt} = W_s - \frac{ec_0}{4}a$

The level of stationary energy is : $e_{sat} = 4 \frac{W_{abs}}{ac_0}$

2.4.2 Reverberation time

With this theory described, the reverberation time can be defined. It is the time for the level of energy to decrease of 60 dB. It depends on the volume of the room V and the equivalent absorption area a :

$$T_{60} = \frac{0.16V}{a}$$

Sabine formula

This reverberation time is the fundamental parameter in room acoustics and depends through the equivalent absorption area and the absorption coefficients on the frequency. It is used for several measurement :

- Measurement of an absorption coefficient of a material
- Measurement of the power of a source
- Measurement of the transmission of a wall

3 Fundamentals of Psychoacoustics




Figure 3

Due to the famous principle enounced by Gustav Theodor Fechner, the sensation of perception doesn't follow a linear law, but a logarithmic one. The perception of the intensity of light, or the sensation of weight, follow this law, as well. This observation legitimates the use of logarithmic scales in the field of acoustics. A 80dB (10^{-4} W/m²) sound seems to be twice as loud as a 70 dB (10^{-5} W/m²) sound, although there is a factor 10 between the two acoustic powers. This is quite a naïve law, but it led to a new way of thinking acoustics, by trying to describe the auditive sensations. That's the aim of psychoacoustics. By now, as the neurophysiologic mechanisms of human hearing haven't been successfully modelled, the only way of dealing with psychoacoustics is by finding metrics that best describe the different aspects of sound.

3.1 Perception of sound

The study of sound perception is limited by the complexity of the human ear mechanisms. The figure below represents the domain of perception and the thresholds of pain and listening. The pain threshold is not frequency-dependent (around 120 dB in the audible bandwidth). At the opposite side, the listening threshold, as all the equal loudness curves, is frequency-dependent.




Figure 4

3.2 Phons and sones

3.2.1 Phons

Two sounds of equal intensity do not have the same loudness, because of the frequency sensibility of the human ear. A 80 dB sound at 100 Hz is not as loud as a 80 dB sound at 3 kHz. A new unit, the phon, is used to describe the loudness of a harmonic sound. X phons means “as loud as X dB at 1000 Hz”. Another tool is used : the equal loudness curves, a.k.a. Fletcher curves.




Figure 5

3.2.2 Sones

Another scale currently used is the sone, based upon the rule of thumb for loudness. This rule states that the sound must be increased in intensity by a factor 10 to be perceived as twice as loud. In decibel (or phon) scale, it corresponds to a 10 dB (or phons) increase. The sone scale's purpose is to translate those scales into a linear one.

$$\log(S) = 0,03(L_{ph} - 40)$$

Where S is the sone level, and L_{ph} the phon level. The conversion table is as follows:

Phons	Sones
100	64
90	32
80	16
70	8
60	4
50	2
40	1

3.3 Metrics

We will now present five psychoacoustics parameters to provide a way to predict the subjective human sensation.

3.3.1 dB A

The measurement of noise perception with the sone or phon scale is not easy. A widely used measurement method is a weighting of the sound pressure level, according to frequency repartition. For each frequency of the density spectrum, a level correction is made. Different kinds of weightings (dB A, dB B, dB C) exist in order to approximate the human ear at different sound intensities, but the most commonly used is the dB A filter. Its curve is made to match the ear equal loudness curve for 40 phons, and as a consequence it's a good approximation of the phon scale.




Figure 6

Example : for a harmonic 40 dB sound, at 200 Hz, the correction is -10 dB, so this sound is 30 dB A.

3.3.2 Loudness

It measures the sound strength. Loudness can be measured in sone, and is a dominant metric in psychoacoustics.

3.3.3 Tonality

As the human ear is very sensible to the pure harmonic sounds, this metric is a very important one. It measures the number of pure tones in the noise spectrum. A broadband sound has a very low tonality, for example.

3.3.4 Roughness

It describes the human perception of temporal variations of sounds. This metric is measured in asper.

3.3.5 Sharpness

Sharpness is linked to the spectral characteristics of the sound. A high-frequency signal has a high value of sharpness. This metric is measured in acum.

3.3.6 Blocking effect

A sinusoidal sound can be masked by a white noise in a narrowing bandwidth. A white noise is a random signal with a flat power spectral density. In other words, the signal's power spectral density has equal power in any band, at any centre frequency, having a given bandwidth. If the intensity of the white noise is high enough, the sinusoidal sound will not be heard. For example, in a noisy environment (in the street, in a workshop), a great effort has to be made in order to distinguish someone's talking.

4 Sound Speed



Figure 7

The **speed of sound** c (from Latin *celeritas*, "velocity") varies depending on the medium through which the sound waves pass. It is usually quoted in describing properties of substances (e.g. see the article on sodium). In conventional use and in scientific literature sound velocity v is the same as sound speed c . Sound velocity c or velocity of sound should not be confused with sound particle velocity v , which is the velocity of the individual particles.

More commonly the term refers to the speed of sound in air. The speed varies depending on atmospheric conditions; the most important factor is the temperature. The humidity has very little effect on the speed of sound, while the static sound pressure (air pressure) has none. Sound travels slower with an increased altitude (elevation if you are on solid earth), primarily as a result of temperature and humidity changes. An approximate speed (in metres per second) can be calculated from:

$$c_{\text{air}} = (331.5 + (0.6 \cdot \theta)) \text{ m/s}$$

where θ (theta) is the temperature in degrees Celsius.

4.1 Details

A more accurate expression for the speed of sound is

$$c = \sqrt{\kappa \cdot R \cdot T}$$

where

- R (287.05 J/(kg · K) for air) is the gas constant for air: the universal gas constant R , which units of J/(mol · K), is divided by the molar mass of air, as is common practice in aerodynamics)
- κ (kappa) is the adiabatic index (1.402 for air), sometimes noted γ
- T is the absolute temperature in kelvins.

In the standard atmosphere :

T_0 is 273.15 K (= 0 °C = 32 °F), giving a value of 331.5 m/s (= 1087.6 ft/s = 1193 km/h = 741.5 mph = 643.9 knots).

T_{20} is 293.15 K (= 20 °C = 68 °F), giving a value of 343.4 m/s (= 1126.6 ft/s = 1236 km/h = 768.2 mph = 667.1 knots).

T_{25} is 298.15 K (= 25 °C = 77 °F), giving a value of 346.3 m/s (= 1136.2 ft/s = 1246 km/h = 774.7 mph = 672.7 knots).

In fact, assuming an ideal gas, the speed of sound c depends on temperature only, **not on the pressure**. Air is almost an ideal gas. The temperature of the air varies with altitude, giving the following variations in the speed of sound using the standard atmosphere - *actual conditions may vary*. Any qualification of the speed of sound being "at sea level" is also irrelevant. Speed of sound varies with altitude (height) only because of the changing temperature!

Altitude	Temperature	m/s	km/h	mph	knots
Sea level (?)	15 °C (59 °F)	340	1225	761	661
11,000 m–20,000 m (Cruising altitude of commercial jets, and first supersonic flight)	-57 °C (-70 °F)	295	1062	660	573
29,000 m (Flight of X-43A)	-48 °C (-53 °F)	301	1083	673	585

In a **Non-Dispersive Medium** – Sound speed is independent of frequency, therefore the speed of energy transport and sound propagation are the same. For audio sound range air is a non-dispersive medium. We should also note that air contains CO₂ which is a dispersive medium and it introduces dispersion to air at ultrasound frequencies (28kHz).

In a **Dispersive Medium** – Sound speed is a function of frequency. The spatial and temporal distribution of a propagating disturbance will continually change. Each frequency component propagates at each its own phase speed, while the energy of the disturbance propagates at the group velocity. Water is an example of a dispersive medium.

In general, the speed of sound c is given by

$$c = \sqrt{\frac{C}{\rho}}$$

where

C is a coefficient of stiffness

ρ is the density

Thus the speed of sound increases with the stiffness of the material, and decreases with the density.

In a fluid the only non-zero stiffness is to volumetric deformation (a fluid does not sustain shear forces).

Hence the speed of sound in a fluid is given by

$$c = \sqrt{\frac{K}{\rho}}$$

where

K is the adiabatic bulk modulus

For a gas, K is approximately given by

$$K = \kappa \cdot p$$

where

κ is the adiabatic index, sometimes called γ .

p is the pressure.

Thus, for a gas the speed of sound can be calculated using:

$$c = \sqrt{\frac{\kappa \cdot p}{\rho}}$$

which using the ideal gas law is identical to:

$$c = \sqrt{\kappa \cdot R \cdot T}$$

(Newton famously considered the speed of sound before most of the development of thermodynamics and so incorrectly used isothermal calculations instead of adiabatic. His result was missing the factor of κ but was otherwise correct.)

In a solid, there is a non-zero stiffness both for volumetric and shear deformations. Hence, in a solid it is possible to generate sound waves with different velocities dependent on the deformation mode.

In a solid rod (with thickness much smaller than the wavelength) the speed of sound is given by:

$$c = \sqrt{\frac{E}{\rho}}$$

where

E is Young's modulus

ρ (rho) is density

Thus in steel the speed of sound is approximately 5100 m/s.

In a solid with lateral dimensions much larger than the wavelength, the sound velocity is higher. It is found by replacing Young's modulus with the plane wave modulus, which can be expressed in terms of the Young's modulus and Poisson's ratio as:

$$M = E \frac{1 - \nu}{1 - \nu - 2\nu^2}$$

For air, see density of air.

The speed of sound in water is of interest to those mapping the ocean floor. In saltwater, sound travels at about 1500 m/s and in freshwater 1435 m/s. These speeds vary due to pressure, depth, temperature, salinity and other factors.

For general equations of state, if classical mechanics is used, the speed of sound c is given by

$$c^2 = \frac{\partial p}{\partial \rho}$$

where differentiation is taken with respect to adiabatic change.

If relativistic effects are important, the speed of sound S is given by:

$$S^2 = c^2 \left. \frac{\partial p}{\partial e} \right|_{\text{adiabatic}}$$

(Note that $e = \rho(c^2 + e^C)$ is the relativistic internal energy density).

This formula differs from the classical case in that ρ has been replaced by e/c^2 .

4.2 Speed of sound in air

Impact of temperature			
θ in °C	c in m/s	ρ in kg/m ³	Z in N·s/m ³
-10	325.4	1.341	436.5
-5	328.5	1.316	432.4
0	331.5	1.293	428.3
+5	334.5	1.269	424.5
+10	337.5	1.247	420.7
+15	340.5	1.225	417.0
+20	343.4	1.204	413.5
+25	346.3	1.184	410.0
+30	349.2	1.164	406.6

Mach number is the ratio of the object's speed to the speed of sound in air (medium).

4.3 Sound in solids

In solids, the velocity of sound depends on *density* of the material, not its temperature. Solid materials, such as steel, conduct sound much faster than air.

4.4 Experimental methods

In air a range of different methods exist for the measurement of sound.

4.4.1 Single-shot timing methods

The simplest concept is the measurement made using two microphones and a fast recording device such as a digital storage scope. This method uses the following idea.

If a sound source and two microphones are arranged in a straight line, with the sound source at one end, then the following can be measured:

1. The distance between the microphones (x)
2. The time delay between the signal reaching the different microphones (t)

Then $v = x/t$

An older method is to create a sound at one end of a field with an object that can be seen to move when it creates the sound. When the observer sees the sound-creating device act

they start a stopwatch and when the observer hears the sound they stop their stopwatch. Again using $v = x/t$ you can calculate the speed of sound. A separation of at least 200 m between the two experimental parties is required for good results with this method.

4.4.2 Other methods

In these methods the time measurement has been replaced by a measurement of the inverse of time (frequency).

Kundt's tube is an example of an experiment which can be used to measure the speed of sound in a small volume, it has the advantage of being able to measure the speed of sound in any gas. This method uses a powder to make the nodes and antinodes visible to the human eye. This is an example of a compact experimental setup.

A tuning fork can be held near the mouth of a long pipe which is dipping into a barrel of water, in this system it is the case that the pipe can be brought to resonance if the length of the air column in the pipe is equal to $(\{1+2n\}/\lambda)$ where n is an integer. As the antinodal point for the pipe at the open end is slightly outside the mouth of the pipe it is best to find two or more points of resonance and then measure half a wavelength between these.

Here it is the case that $v = f\lambda$

4.5 External links

- Calculation: Speed of sound in air and the temperature¹
- The speed of sound, the temperature, and ... **not** the air pressure²
- Properties Of The U.S. Standard Atmosphere 1976³

1 <http://www.sengpielaudio.com/calculator-speedsound.htm>

2 <http://www.sengpielaudio.com/SpeedOfSoundPressure.pdf>

3 <http://www.pdas.com/atmos.htm>

5 Filter Design and Implementation



Figure 8

5.1 Introduction

Acoustic filters, or mufflers, are used in a number of applications requiring the suppression or attenuation of sound. Although the idea might not be familiar to many people, acoustic mufflers make everyday life much more pleasant. Many common appliances, such as refrigerators and air conditioners, use acoustic mufflers to produce a minimal working noise. The application of acoustic mufflers is mostly directed to machine components or areas where there is a large amount of radiated sound such as high pressure exhaust pipes, gas turbines, and rotary pumps.

Although there are a number of applications for acoustic mufflers, there are really only two main types which are used. These are absorptive and reactive mufflers. Absorptive mufflers incorporate sound absorbing materials to attenuate the radiated energy in gas flow. Reactive mufflers use a series of complex passages to maximize sound attenuation while meeting set specifications, such as pressure drop, volume flow, etc. Many of the more complex mufflers today incorporate both methods to optimize sound attenuation and provide realistic specifications.

In order to fully understand how acoustic filters attenuate radiated sound, it is first necessary to briefly cover some basic background topics. For more information on wave theory and other material necessary to study acoustic filters please refer to the references below.

5.2 Basic wave theory

Although not fundamentally difficult to understand, there are a number of alternate techniques used to analyze wave motion which could seem overwhelming to a novice at first. Therefore, only 1-D wave motion will be analyzed to keep most of the mathematics as simple as possible. This analysis is valid, with not much error, for the majority of pipes and enclosures encountered in practice.

5.2.1 Plane-wave pressure distribution in pipes

The most important equation used is the wave equation in 1-D form (See [1],[2], 1-D Wave Equation¹, for information).

Therefore, it is reasonable to suggest, if plane waves are propagating, that the pressure distribution in a pipe is given by:

$$\mathbf{p} = \mathbf{P}_i e^{j[\omega t - kx]} + \mathbf{P}_r e^{j[\omega t + kx]}$$

where P_i and P_r are incident and reflected wave amplitudes respectively. Also note that bold notation is used to indicate the possibility of complex terms. The first term represents a wave travelling in the +x direction and the second term, -x direction.

Since acoustic filters or mufflers typically attenuate the radiated sound power as much as possible, it is logical to assume that if we can find a way to maximize the ratio between reflected and incident wave amplitude then we will effectively attenuated the radiated noise at certain frequencies. This ratio is called the reflection coefficient and is given by:

$$\mathbf{R} = \left(\frac{\mathbf{P}_r}{\mathbf{P}_i} \right)$$

It is important to point out that wave reflection only occurs when the impedance of a pipe changes. It is possible to match the end impedance of a pipe with the characteristic impedance of a pipe to get no wave reflection. For more information see [1] or [2].

Although the reflection coefficient isn't very useful in its current form since we want a relation describing sound power, a more useful form can be derived by recognizing that the power intensity coefficient is simply the magnitude of reflection coefficient square [1]:

$$R_\pi = |\mathbf{R}|^2$$

As one would expect, the power reflection coefficient must be less than or equal to one. Therefore, it is useful to define the transmission coefficient as:

$$T_\pi = (1 - R_\pi)$$

which is the amount of power transmitted. This relation comes directly from conservation of energy. When talking about the performance of mufflers, typically the power transmission coefficient is specified.

¹ <http://mathworld.wolfram.com/WaveEquation1-Dimensional.html>

5.3 Basic filter design

For simple filters, a long wavelength approximation can be made to make the analysis of the system easier. When this assumption is valid (e.g. low frequencies) the components of the system behave as lumped acoustical elements. Equations relating the various properties are easily derived under these circumstances.

The following derivations assume long wavelength. Practical applications for most conditions are given later.

5.3.1 Low-pass filter




Figure 9 T_{pi} for Low-Pass Filter

Low-Pass Filter Schematic




Figure 10

These are devices that attenuate the radiated sound power at higher frequencies. This means the power transmission coefficient is approximately 1 across the band pass at low frequencies (see figure to right).

This is equivalent to an expansion in a pipe, with the volume of gas located in the expansion having an acoustic compliance (see figure to right). Continuity of acoustic impedance (see Java Applet at: [Acoustic Impedance Visualization](#)²) at the junction, see [1], gives a power transmission coefficient of:

$$T_{\pi} \approx \frac{1}{1 + \left(\frac{S_1 - S}{2S} kL\right)^2}$$

where k is the wavenumber (see [Wave Properties](#)³), L & S_1 are length and area of expansion respectively, and S is the area of the pipe.

The cut-off frequency is given by:

$$f_c = \left(\frac{cS}{\pi L(S_1 - S)}\right)$$

2 <http://www.ndt-ed.org/EducationResources/CommunityCollege/Ultrasonics/Physics/acousticimpedance.htm>

3 http://en.wikibooks.org/wiki/Engineering_Acoustics%2FBoundary_Conditions_and_Forced_Vibrations%23Wave_Properties

5.3.2 High-pass filter




Figure 11 T_{pi} for High-Pass Filter

High-Pass Filter Schematic




Figure 12

These are devices that attenuate the radiated sound power at lower frequencies. Like before, this means the power transmission coefficient is approximately 1 across the band pass at high frequencies (see figure to right).

This is equivalent to a short side branch (see figure to right) with a radius and length much smaller than the wavelength (lumped element assumption). This side branch acts like an acoustic mass and applies a different acoustic impedance to the system than the low-pass filter. Again using continuity of acoustic impedance at the junction yields a power transmission coefficient of the form [1]:

$$T_{\pi} = \left(\frac{1}{1 + \left(\frac{\pi a^2}{2SLk} \right)^2} \right)$$

where a and L are the area and effective length of the small tube, and S is the area of the pipe.

The cut-off frequency is given by:

$$f_c = \left(\frac{ca^2}{2SL} \right)$$

5.3.3 Band-stop filter




Figure 13 T_{pi} for Band-Stop Filter

Band-Stop Filter Schematic




Figure 14

These are devices that attenuate the radiated sound power over a certain frequency range (see figure to right). Like before, the power transmission coefficient is approximately 1 in the band pass region.

Since the band-stop filter is essentially a cross between a low and high pass filter, one might expect to create one by using a combination of both techniques. This is true in that the combination of a lumped acoustic mass and compliance gives a band-stop filter. This can be realized as a helmholtz resonator (see figure to right). Again, since the impedance of the helmholtz resonator can be easily determined, continuity of acoustic impedance at the junction can give the power transmission coefficient as [1]:

$$T_{\pi} = \left(\frac{1}{1 + \left(\frac{c/2S}{\omega L/S_b - c^2/\omega V} \right)^2} \right)$$

where S_b is the area of the neck, L is the effective length of the neck, V is the volume of the helmholtz resonator, and S is the area of the pipe. It is interesting to note that the power transmission coefficient is zero when the frequency is that of the resonance frequency of the helmholtz. This can be explained by the fact that at resonance the volume velocity in the neck is large with a phase such that all the incident wave is reflected back to the source [1].

The zero power transmission coefficient location is given by:

$$f_c = \left(\frac{c}{2\pi} \right) \sqrt{\left(\frac{S_b}{LV} \right)}$$

This frequency value has powerful implications. If a system has the majority of noise at one frequency component, the system can be "tuned" using the above equation, with a helmholtz resonator, to perfectly attenuate any transmitted power (see examples below).

Adfil - UNREGISTERED




Figure 15 Helmholtz Resonator as a Muffler, $f = 60$ Hz

Adfil - UNREGISTERED




Figure 16 Helmholtz Resonator as a Muffler, $f = f_c$

5.3.4 Design

If the long wavelength assumption is valid, typically a combination of methods described above are used to design a filter. A specific design procedure is outlined for a helmholtz resonator, and other basic filters follow a similar procedure (see <http://www.silex.com/pdfs/Exhaust%20Silencers.pdf> 1⁴).

Two main metrics need to be identified when designing a helmholtz resonator [3]:

1. Resonance frequency desired: $f_c = \frac{c}{2\pi} \frac{\sqrt{C_o}}{V}$ where $C_o = \frac{S}{L}$.
2. - Transmission loss: $\frac{\sqrt{C_o V}}{2S} = \text{const}$ based on TL level. This constant is found from a TL graph (see HR⁵ pp. 6).

⁴ <http://en.wikibooks.org/wiki/%201>

⁵ [http://mecheng.osu.edu/~selamet/docs/2003_JASA_113\(4\)_1975-1985_helmholtz_ext_neck.pdf](http://mecheng.osu.edu/~selamet/docs/2003_JASA_113(4)_1975-1985_helmholtz_ext_neck.pdf)

This will result in two equations with two unknowns which can be solved for the unknown dimensions of the helmholtz resonator. It is important to note that flow velocities degrade the amount of transmission loss at resonance and tend to move the resonance location upwards [3].

In many situations, the long wavelength approximation is not valid and alternative methods must be examined. These are much more mathematically rigorous and require a complete understanding acoustics involved. Although the mathematics involved are not shown, common filters used are given in the section that follows.

5.4 Actual filter design

As explained previously, there are two main types of filters used in practice: absorptive and reactive. The benefits and drawback of each will be briefly explained, along with their relative applications (see Absorptive Mufflers⁶).

5.4.1 Absorptive

These are mufflers which incorporate sound absorbing materials to transform acoustic energy into heat. Unlike reactive mufflers which use destructive interference to minimize radiated sound power, absorptive mufflers are typically straight through pipes lined with multiple layers of absorptive materials to reduce radiated sound power. The most important property of absorptive mufflers is the attenuation constant. Higher attenuation constants lead to more energy dissipation and lower radiated sound power.

Advantages of Absorptive Mufflers [3]:

(1) - High amount of absorption at larger frequencies.(2) - Good for applications involving broadband (constant across the spectrum) and narrowband⁷ noise.(3) - Reduced amount of back pressure compared to reactive mufflers.

Disadvantages of Absorptive Mufflers [3]:

(1) - Poor performance at low frequencies.(2) - Material can degrade under certain circumstances (high heat, etc.).

⁶ http://en.wikibooks.org/wiki/Engineering%20Acoustics%2FSpecific%20application-automobile%20muffler%23Absorptive_muffler

⁷ <http://en.wikipedia.org/wiki/narrowband>

Examples




Figure 17 Absorptive Muffler

There are a number of applications for absorptive mufflers. The most well known application is in race cars, where engine performance is desired. Absorptive mufflers don't create a large amount of back pressure (as in reactive mufflers) to attenuate the sound, which leads to higher muffler performance. It should be noted however, that the radiate sound is much higher. Other applications include plenum chambers (large chambers lined with absorptive materials, see picture below), lined ducts, and ventilation systems.

5.4.2 Reactive

Reactive mufflers use a number of complex passages (or lumped elements) to reduce the amount of acoustic energy transmitted. This is accomplished by a change in impedance at the intersections, which gives rise to reflected waves (and effectively reduces the amount of transmitted acoustic energy). Since the amount of energy transmitted is minimized, the

reflected energy back to the source is quite high. This can actually degrade the performance of engines and other sources. Opposite to absorptive mufflers, which dissipate the acoustic energy, reactive mufflers keep the energy contained within the system. See #The_reflector_muffler Reactive Mufflers⁸ for more information.

Advantages of Reactive Mufflers [3]:

- (1) - High performance at low frequencies.
- (2) - Typically give high insertion loss, IL, for stationary tones.
- (3) - Useful in harsh conditions.

Disadvantages of Reactive Mufflers [3]:

- (1) - Poor performance at high frequencies.
- (2) - Not desirable characteristics for broadband noise.

Examples




Figure 18 Reflective Muffler

Reactive mufflers are the most widely used mufflers in combustion engines <http://www.eiwilliams.com/steel/index.php?p=EngineSilencers#All> ⁹. Reactive mufflers are very efficient in low frequency applications (especially since simple lumped element analysis can be applied). Other application areas include: harsh environments (high temperature/velocity engines, turbines, etc.), specific frequency attenuation (using a helmholtz like device, a specific frequency can be toned to give total attenuation of radiated sound power), and a need for low radiated sound power (car mufflers, air conditioners, etc.).

⁸ <http://en.wikibooks.org/wiki/Engineering%20Acoustics%2FCar%20Mufflers>

⁹ <http://en.wikibooks.org/wiki/%201>

5.4.3 Performance

There are 3 main metrics used to describe the performance of mufflers; Noise Reduction, Insertion Loss, and Transmission Loss. Typically when designing a muffler, 1 or 2 of these metrics is given as a desired value.

Noise Reduction (NR)

Defined as the difference between sound pressure levels on the source and receiver side. It is essentially the amount of sound power reduced between the location of the source and termination of the muffler system (it doesn't have to be the termination, but it is the most common location) [3].

$$NR = (L_{p1} - L_{p2})$$

where L_{p1} and L_{p2} is sound pressure levels at source and receiver respectively. Although NR is easy to measure, pressure typically varies at source side due to standing waves [3].

Insertion Loss (IL)

Defined as difference of sound pressure level at the receiver with and without sound attenuating barriers. This can be realized, in a car muffler, as the difference in radiated sound power with just a straight pipe to that with an expansion chamber located in the pipe. Since the expansion chamber will attenuate some of the radiate sound power, the pressure at the receiver with sound attenuating barriers will be less. Therefore, a higher insertion loss is desired [3].

$$IL = (L_{p,without} - L_{p,with})$$

where $L_{p,without}$ and $L_{p,with}$ are pressure levels at receiver without and with a muffler system respectively. Main problem with measuring IL is that the barrier or sound attenuating system needs to be removed without changing the source [3].

Transmission Loss (TL)

Defined as the difference between the sound power level of the incident wave to the muffler system and the transmitted sound power. For further information see <http://freespace.virgin.net/mark.davidson3/TL/TL.html> Transmission Loss¹⁰ [3].

$$TL = 10 \log \left(\frac{1}{\tau} \right) \text{ with } \tau = \left(\frac{I_t}{I_i} \right)$$

where I_t and I_i are the transmitted and incident wave power respectively. From this expression, it is obvious the problem with measure TL is decomposing the sound field into incident and transmitted waves which can be difficult to do for complex systems (analytically).

¹⁰ <http://en.wikibooks.org/wiki/%20Transmission%20Loss>

Examples

(1) - For a plenum chamber (see figure below):

$$TL = -10 \log \left(S \left(\frac{\cos \theta}{2\pi d^2} + \frac{1-\alpha}{\alpha S_w} \right) \right) \text{ in dB}$$

where α is average absorption coefficient.




Figure 19 Plenum Chamber




Figure 20 Transmission Loss vs. Theta

(2) - For an expansion (see figure below):

$$NR = 10 \log \left[\frac{1}{2} \left| e^{-ikx_s} + \left(\frac{1-S}{1+S} \right) e^{ikx_s} \right|^2 (1+S)^2 \right]$$

$$IL = 10 \log \left[\frac{(1+S)^2}{4} \right]$$

$$TL = 10 \log \left[\frac{(1+S)^2}{4S} \right]$$

where $S = \left(\frac{A_2}{A_1} \right)$




Figure 21 Expansion in Infinite Pipe




Figure 22 NR, IL, & TL for Expansion

(3) - For a helmholtz resonator (see figure below):

$$TL = 10 \log \left[1 + \left(\frac{\left(\frac{c}{2S_b} \right)}{\omega LS - \left(\frac{c^2}{\omega V} \right)} \right)^2 \right] \text{ in dB}$$




Figure 23 Helmholtz Resonator




Figure 24 TL for Helmholtz Resonator

gdnr

5.5 Links

1. Muffler/silencer applications and descriptions of performance criteria <http://www.silex.com/pdfs/Exhaust%20Silencers.pdf> Exhaust Silencers¹¹
2. Engineering Acoustics, Purdue University - ME 513¹².
3. Sound Propagation Animations¹³
4. Exhaust Muffler Design¹⁴
5. Project Proposal¹⁵ & Outline¹⁶

5.6 References

1. Fundamentals of Acoustics; Kinsler *et al.*, John Wiley & Sons, 2000
2. Acoustics; Pierce, Acoustical Society of America, 1989
3. - ME 413 Noise Control, Dr. Mongeau, Purdue University

¹¹ <http://en.wikibooks.org/wiki/%20Exhaust%20Silencers>

¹² <http://widget.ecn.purdue.edu/~me513/>

¹³ <http://widget.ecn.purdue.edu/~me513/animate.html>

¹⁴ <http://myfwc.com/boating/airboat/Section3.pdf>

¹⁵ <http://en.wikibooks.org/wiki/Engineering%20Acoustics%2FFilter%20Design%20Proposal>

¹⁶ <http://en.wikibooks.org/wiki/Engineering%20Acoustics%2FFilter%20Design%20Outline>

6 Flow-induced oscillations of a Helmholtz resonator

=Active Control=



Figure 25

6.1 Introduction

The principle of active control of noise, is to create destructive interferences using a secondary source of noise. Thus, any noise can theoretically disappear. But as we will see in the following sections, only low frequencies noises can be reduced for usual applications, since the amount of secondary sources required increases very quickly with frequency. Moreover, predictable noises are much easier to control than unpredictable ones. The reduction can reach up to 20dB for the best cases. But since good reduction can only be reached for low frequencies, the perception we have of the resulting sound is not necessarily as good as the theoretical reduction. This is due to psychoacoustics considerations, which will be discussed later on.

6.2 Fundamentals of active control of noise

6.2.1 Control of a monopole by another monopole

Even for the free space propagation of an acoustic wave created by a punctual source it is difficult to reduce noise in a large area, using active noise control, as we will see in the section.

In the case of an acoustic wave created by a monopolar source, the Helmholtz equation becomes:

$$\Delta p + k^2 p = -j\omega\rho_0 q$$

where q is the flow of the noise sources.

The solution for this equation at any M point is:

$$p_p(M) = \frac{j\omega\rho_0 q_p}{4\pi} \frac{e^{-jkr_p}}{r_p}$$

where the p mark refers to the primary source.

Let us introduce a secondary source in order to perform active control of noise. The acoustic pressure at that same M point is now:

$$p(M) = \frac{j\omega\rho_0 q_p}{4\pi} \frac{e^{-jkr_p}}{r_p} + \frac{j\omega\rho_0 q_s}{4\pi} \frac{e^{-jkr_s}}{r_s}$$

It is now obvious that if we chose $q_s = -q_p \frac{r_s}{r_p} e^{-jk(r_p - r_s)}$ there is no more noise at the M point. This is the most simple example of active control of noise. But it is also obvious that if the pressure is zero in M , there is no reason why it should also be zero at any other N point. This solution only allows to reduce noise in one very small area.

However, it is possible to reduce noise in a larger area far from the source, as we will see in this section. In fact the expression for acoustic pressure far from the primary source can be approximated by:

$$p(M) = \frac{j\omega\rho_0}{4\pi} \frac{e^{-jkr_p}}{r_p} (q_p + q_s e^{-jkD \cos\theta})$$




Figure 26 Control of a monopole by another monopole

As shown in the previous section we can adjust the secondary source in order to get no noise in M . In that case, the acoustic pressure in any other N point of the space remains low if the primary and secondary sources are close enough. More precisely, it is possible to have a pressure close to zero in the whole space if the M point is equally distant from the two sources and if: $D < \lambda/6$ where D is the distance between the primary and secondary sources. As we will see later on, it is easier to perform active control of noise with more than one source controlling the primary source, but it is of course much more expensive.

A commonly admitted estimation of the number of secondary sources which are necessary to reduce noise in an R radius sphere, at a frequency f is:

$$N = \frac{36\pi R^2 f^2}{c^2}$$

This means that if you want no noise in a one meter diameter sphere at a frequency below 340Hz, you will need 30 secondary sources. This is the reason why active control of noise works better at low frequencies.

6.2.2 Active control for waves propagation in ducts and enclosures

This section requires from the reader to know the basis of modal propagation theory, which will not be explained in this article.

Ducts

For an infinite and straight duct with a constant section, the pressure in areas without sources can be written as an infinite sum of propagation modes:

$$p(x, y, z, \omega) = \sum_{n=1}^N a_n(\omega) \phi_n(x, y) e^{-jk_n z}$$

where ϕ are the eigen functions of the Helmholtz equation and a represent the amplitudes of the modes.

The eigen functions can either be obtained analytically, for some specific shapes of the duct, or numerically. By putting pressure sensors in the duct and using the previous equation, we get a relation between the pressure matrix P (pressure for the various frequencies) and the A matrix of the amplitudes of the modes. Furthermore, for linear sources, there is a relation between the A matrix and the U matrix of the signal sent to the secondary sources: $A_s = KU$ and hence: $A = A_p + A_s = A_p + KU$.

Our purpose is to get: $A=0$, which means: $A_p + KU = 0$. This is possible every time the rank of the K matrix is bigger than the number of the propagation modes in the duct.

Thus, it is theoretically possible to have no noise in the duct in a very large area not too close from the primary sources if there are more secondary sources than propagation modes in the duct. Therefore, it is obvious that active noise control is more appropriate for low frequencies. In fact the more the frequency is low, the less propagation modes there will be in the duct. Experiences show that it is in fact possible to reduce the noise from over 60dB.

Enclosures

The principle is rather similar to the one described above, except the resonance phenomenon has a major influence on acoustic pressure in the cavity. In fact, every mode that is not resonant in the considered frequency range can be neglected. In a cavity or enclosure, the number of these modes rise very quickly as frequency rises, so once again, low frequencies are more appropriate. Above a critical frequency, the acoustic field can be considered as diffuse. In that case, active control of noise is still possible, but it is theoretically much more complicated to set up.

6.2.3 Active control and psychoacoustics

As we have seen, it is possible to reduce noise with a finite number of secondary sources. Unfortunately, the perception of sound of our ears does not only depend on the acoustic pressure (or the decibels). In fact, it sometimes happen that even though the number of decibels has been reduced, the perception that we have is not really better than without active control.

6.3 Active control systems

Since the noise that has to be reduced can never be predicted exactly, a system for active control of noise requires an auto adaptable algorithm. We have to consider two different ways of setting up the system for active control of noise depending on whether it is possible or not to detect the noise from the primary source before it reaches the secondary sources. If this is possible, a feed forward technique will be used (aircraft engine for example). If not a feed back technique will be preferred.

6.3.1 Feedforward

In the case of a feed forward, two sensors and one secondary source are required. The sensors measure the sound pressure at the primary source (detector) and at the place we want noise to be reduced (control sensor). Furthermore, we should have an idea of what the noise from the primary source will become as he reaches the control sensor. Thus we approximately know what correction should be made, before the sound wave reaches the control sensor (forward). The control sensor will only correct an eventual or residual error. The feedforward technique allows to reduce one specific noise (aircraft engine for example) without reducing every other sound (conversations, ...). The main issue for this technique is that the location of the primary source has to be known, and we have to be sure that this sound will be detected beforehand. Therefore portative systems based on feed forward are impossible since it would require having sensors all around the head.




Figure 27 Feedforward System

6.3.2 Feedback

In that case, we do not exactly know where the sound comes from; hence there is only one sensor. The sensor and the secondary source are very close from each other and the correction is done in real time: as soon as the sensor gets the information the signal is treated by a filter which sends the corrected signal to the secondary source. The main issue with feedback is that every noise is reduced and it is even theoretically impossible to have a standard conversation.




Figure 28 Feedback System

6.4 Applications

6.4.1 Noise cancelling headphone

Usual headphones become useless when the frequency gets too low. As we have just seen active noise cancelling headphones require the feedback technique since the primary sources can be located all around the head. This active control of noise is not really efficient at high frequencies since it is limited by the Larsen effect. Noise can be reduced up to 30dB at a frequency range between 30Hz and 500Hz.

6.4.2 Active control for cars

Noise reduction inside cars can have a significant impact on the comfort of the driver. There are three major sources of noise in a car: the motor, the contact of tires on the road, and the aerodynamic noise created by the air flow around the car. In this section, active control for each of those sources will be briefly discussed.

Motor noise

This noise is rather predictable since it is a consequence of the rotation of the pistons in the motor. Its frequency is not exactly the motor's rotational speed though. However, the frequency of this noise is in between 20Hz and 200Hz, which means that an active control is

theoretically possible. The following pictures show the result of an active control, both for low and high regime.




Figure 29 Low regime

Even though these results show a significant reduction of the acoustic pressure, the perception inside the car is not really better with this active control system, mainly for psychoacoustics reasons which were mentioned above. Moreover such a system is rather expensive and thus are not used in commercial cars.

Tires noise

This noise is created by the contact between the tires and the road. It is a broadband noise which is rather unpredictable since the mechanisms are very complex. For example, the different types of roads can have a significant impact on the resulting noise. Furthermore, there is a cavity around the tires, which generate a resonance phenomenon. The first frequency is usually around 200Hz. Considering the multiple causes for that noise and its unpredictability, even low frequencies become hard to reduce. But since this noise is broadband, reducing low frequencies is not enough to reduce the overall noise. In fact an active control system would mainly be useful in the case of an unfortunate amplification of a specific mode.

Aerodynamic noise

This noise is a consequence of the interaction between the air flow around the car and the different appendixes such as the rear views for example. Once again, it is an unpredictable broadband noise, which makes it difficult to reduce with an active control system. However, this solution can become interesting in the case an annoying predictable resonance would appear.

6.4.3 Active control for aeronautics

The noise of aircraft propellers is highly predictable since the frequency is quite exactly the rotational frequency multiplied by the number of blades. Usually this frequency is around some hundreds of Hz. Hence, an active control system using the feedforward technique provides very satisfying noise reductions. The main issues are the cost and the weigh of such a system. The fan noise on aircraft engines can be reduced in the same manner.

6.5 Further reading

w:active noise control¹

- "Active Noise Control"² at Dirac delta.

¹ <http://en.wikipedia.org/wiki/active%20noise%20control>

² <http://www.diracdeltaco.uk/science/source/a/c/active%20noise%20control/source.html>

7 Anechoic and reverberation rooms

1. REDIRECT Acoustics/Anechoic and Reverberation Rooms¹

¹ Chapter 7 on page 49

8 Basic Room Acoustic Treatments



Figure 30

8.1 Introduction

Many people use one or two rooms in their living space as "theatrical" rooms where theater or music room activities commence. It is a common misconception that adding speakers to the room will enhance the quality of the room acoustics. There are other simple things that can be done to increase the room's acoustics to produce sound that is similar to "theater" sound. This site will take you through some simple background knowledge on acoustics and then explain some solutions that will help improve sound quality in a room.

8.2 Room sound combinations

The sound you hear in a room is a combination of direct sound and indirect sound. Direct sound will come directly from your speakers while the other sound you hear is reflected off of various objects in the room.




Figure 31

The Direct sound is coming right out of the TV to the listener, as you can see with the heavy black arrow. All of the other sound is reflected off surfaces before they reach the listener.

8.3 Good and bad reflected sound

Have you ever listened to speakers outside? You might have noticed that the sound is thin and dull. This occurs because when sound is reflected, it is fuller and louder than it would if it were in an open space. So when sound is reflected, it can add a fullness, or spaciousness. The bad part of reflected sound occurs when the reflections amplify some notes, while cancelling out others, making the sound distorted. It can also affect tonal quality and create an echo-like effect. There are three types of reflected sound, pure reflection, absorption, and diffusion. Each reflection type is important in creating a "theater" type acoustic room.




Figure 32

8.3.1 Reflected sound

Reflected sound waves, good and bad, affect the sound you hear, where it comes from, and the quality of the sound when it gets to you. The bad news when it comes to reflected sound is standing waves¹.

These waves are created when sound is reflected back and forth between any two parallel surfaces in your room, ceiling and floor or wall to wall.

Standing waves can distort noises 300Hz and down. These noises include the lower mid frequency and bass ranges. Standing waves tend to collect near the walls and in corners of a room, these collecting standing waves are called room resonance modes.

Finding your room resonance modes

First, specify room dimensions (length, width, and height). **Then follow this example:**

¹ <http://en.wikibooks.org/wiki/standing%20waves>

To Find the Main Resonance Mode :

$$F = \frac{c}{2 * D}$$


c = speed of sound (air = 1130 ft/s)

F = Frequency of Resonance Mode (Hz)

D = Distance between parallel walls (ft)

EXAMPLE

Room (23'*11'*8')



$$F = \frac{1130}{2 * 23} = 25\text{Hz}$$

Main Mode = $F = 25\text{Hz}$

Weaker Modes at multiples of Main Mode

$2 * 25, 3 * 25 \dots$

Do this for each room dimension (l, w, h)

Resonance Mode Frequencies appearing in more than one dimension will be trouble frequencies.

Figure 33




Figure 34

Mode	Length (23ft)	Width (11 ft)	Height (8 ft)
1	25	51	71
2	50	102	141
3	75	153	212
4	100	204	282
5	150	255	355
6	200	308	
7	250	357	
8	300		

Resonance Mode Frequencies appearing in more than one dimension will be trouble frequencies. In this example these trouble frequencies will be 50, 100, and 355 Hz.

Figure 35

Working with room resonance modes to increase sound quality

There are some room dimensions that produce the largest amount of standing waves.

1. Cube
2. Room with 2 out of the three dimensions equal
3. Rooms with dimensions that are multiples of each other

Move chairs or sofas away from the walls or corners to reduce standing wave effects

8.3.2 Absorbed

The sound that humans hear is actually a form of acoustic energy. Different materials absorb different amounts of this energy at different frequencies. When considering room acoustics, there should be a good mix of high frequency absorbing materials and low frequency absorbing materials. A table including information on how different common household absorb sound can be found [here](#)².

8.3.3 Diffused sound

Using devices that diffuse sound is a fairly new way of increasing acoustic performance in a room. It is a means to create sound that appears to be "live". They can replace echo-like reflections without absorbing too much sound.

Some ways of determining where diffusive items should be placed were found on this [website](#)³.

1. If you have carpet or drapes already in your room, use diffusion to control side wall reflections.
2. A bookcase filled with odd-sized books makes an effective diffuser.
3. Use absorptive material on room surfaces between your listening position and your front speakers, and treat the back wall with diffusive material to re-distribute the reflections.

8.4 How to find overall trouble spots in a room

Every surface in a room does not have to be treated in order to have good room acoustics. Here is a simple method of finding trouble spots in a room.

1. Grab a friend to hold a mirror along the wall near a certain speaker at speaker height.
2. The listener sits in a spot of normal viewing.
3. The friend then moves slowly toward the listening position (stay along the wall).
4. Mark each spot on the wall where the listener can see any of the room speakers in the mirror.
5. Congratulations! These are the trouble spots in the room that need an absorptive material in place. Don't forget that diffusive material can also be placed in those positions.

8.5 References

- [Acoustic Room Treatment Articles](#)⁴

² http://www.crutchfield.com/learn/learningcenter/home/speakers_roomacoustics.html

³ http://www.crutchfieldadvisor.com/S-hpU9sw2hgbG/learningcenter/home/speakers_roomacoustics.html?page=4:

⁴ http://www.ecoustics.com/Home/Accessories/Acoustic_Room_Treatments/Acoustic_Room_Treatment_Articles/

- Room Acoustics: Acoustic Treatments⁵
- Home Improvement: Acoustic Treatments⁶
- Crutchfield Advisor⁷

5 <http://www.audioholics.com/techtips/roomacoustics/roomacoustictreatments.php>
6 http://www.diynetwork.com/diy/hi_family_room/article/0,2037,DIY_13912_3471072,00.html
7 http://www.crutchfieldadvisor.com/S-hpU9sw2hgbG/learningcenter/home/speakers_roomacoustics.html?page=1

9 Human Vocal Fold




Figure 36

9.1 Physiology of vocal fold

Human vocal fold is a set of lip-like tissues located inside the larynx¹, and is the source of sound for a human and many animals.

The Larynx is located at the top of trachea. It is mainly composed of cartilages and muscles, and the largest cartilage, thyroid, is well known as the "Adam's Apple."

The organ has two main functions; to act as the last protector of the airway, and to act as a sound source for voice. This page focuses on the latter function.

Links on Physiology:

- Discover The Larynx²

9.2 Voice production

Although the science behind sound production for a vocal fold is complex, it can be thought of as similar to a brass player's lips, or a whistle made out of grass. Basically, vocal folds (or lips or a pair of grass) make a constriction to the airflow, and as the air is forced through

¹ <http://en.wikipedia.org/wiki/Larynx>

² http://sprojects.mmi.mcgill.ca/larynx/notes/n_frames.htm

the narrow opening, the vocal folds oscillate. This causes a periodical change in the air pressure, which is perceived as sound.

Vocal Folds Video³

When the airflow is introduced to the vocal folds, it forces open the two vocal folds which are nearly closed initially. Due to the stiffness of the folds, they will then try to close the opening again. And now the airflow will try to force the folds open etc... This creates an oscillation of the vocal folds, which in turn, as I stated above, creates sound. However, this is a damped oscillation, meaning it will eventually achieve an equilibrium position and stop oscillating. So how are we able to "sustain" sound?

As it will be shown later, the answer seems to be in the changing shape of vocal folds. In the opening and the closing stages of the oscillation, the vocal folds have different shapes. This affects the pressure in the opening, and creates the extra pressure needed to push the vocal folds open and sustain oscillation. This part is explained in more detail in the "Model" section.

This flow-induced oscillation, as with many fluid mechanics problems, is not an easy problem to model. Numerous attempts to model the oscillation of vocal folds have been made, ranging from a single mass-spring-damper system to finite element models. In this page I would like to use my single-mass model to explain the basic physics behind the oscillation of a vocal fold.

Information on vocal fold models: National Center for Voice and Speech⁴

³ http://www.entusa.com/normal_larynx.htm

⁴ <http://www.ncvs.org/ncvs/tutorials/voiceprod/tutorial/model.html>

9.3 Model




Figure 37 Figure 1: Schematics

The most simple way of simulating the motion of vocal folds is to use a single mass-spring-damper system as shown above. The mass represents one vocal fold, and the second vocal fold is assumed to be symmetry about the axis of symmetry. Position 3 represents a location immediately past the exit (end of the mass), and position 2 represents the glottis (the region between the two vocal folds).

9.3.1 The pressure force

The major driving force behind the oscillation of vocal folds is the pressure in the glottis. The Bernoulli's equation from fluid mechanics states that:

$$P_1 + \frac{1}{2}\rho U^2 + \rho gh = \text{Constant} \quad \text{EQN 1}$$

Neglecting potential difference and applying EQN 1 to positions 2 and 3 of Figure 1,

$$P_2 + \frac{1}{2}\rho U_2^2 = P_3 + \frac{1}{2}\rho U_3^2 \quad \text{EQN 2}$$

Note that the pressure and the velocity at position 3 cannot change. This makes the right hand side of EQN 2 constant. Observation of EQN 2 reveals that in order to have oscillating pressure at 2, we must have oscillation velocity at 2. The flow velocity inside the glottis can be studied through the theories of the orifice flow.

The constriction of airflow at the vocal folds is much like an orifice flow with one major difference: with vocal folds, the orifice profile is continuously changing. The orifice profile for the vocal folds can open or close, as well as change the shape of the opening. In Figure 1, the profile is converging, but in another stage of oscillation it takes a diverging shape.

The orifice flow is described by Blevins as:

$$U = C \frac{2(P_1 - P_3)}{\rho} \text{ EQN 3}$$

Where the constant C is the orifice coefficient, governed by the shape and the opening size of the orifice. This number is determined experimentally, and it changes throughout the different stages of oscillation.

Solving equations 2 and 3, the pressure force throughout the glottal region can be determined.

9.3.2 The Collision Force

As the video of the vocal folds shows, vocal folds can completely close during oscillation. When this happens, the Bernoulli equation fails. Instead, the collision force becomes the dominating force. For this analysis, Hertz collision model was applied.

$$F_H = k_H \delta^{3/2} (1 + b_H \delta') \text{ EQN 4}$$

where

$$k_H = \frac{4}{3} \frac{E}{1 - \mu_H^2} \sqrt{r}$$

Here delta is the penetration distance of the vocal fold past the line of symmetry.

9.4 Simulation of the model

The pressure and the collision forces were inserted into the equation of motion, and the result was simulated.




Figure 38 Figure 2: Area Opening and Volumetric Flow Rate

Figure 2 shows that an oscillating volumetric flow rate was achieved by passing a constant airflow through the vocal folds. When simulating the oscillation, it was found that the collision force limits the amplitude of oscillation rather than drive the oscillation. Which tells us that the pressure force is what allows the sustained oscillation to occur.

9.5 The acoustic output

This model showed that the changing profile of glottal opening causes an oscillating volumetric flow rate through the vocal folds. This will in turn cause an oscillating pressure past the vocal folds. This method of producing sound is unusual, because in most other means of sound production, air is compressed periodically by a solid such as a speaker cone.

Past the vocal folds, the produced sound enters the vocal tract. Basically this is the cavity in the mouth as well as the nasal cavity. These cavities act as acoustic filters, modifying the character of the sound. These are the characters that define the unique voice each person produces.

9.6 Related links

- FEA Model⁵
- Two Mass Model⁶

9.7 References

1. Fundamentals of Acoustics; Kinsler et al, John Wiley & Sons, 2000
2. Acoustics: An introduction to its Physical Principles and Applications; Pierce, Allan D., Acoustical Society of America, 1989.
3. Blevins, R.D. (1984). Applied Fluid Dynamics Handbook. Van Nostrand Reinhold Co. 81-82.
4. Titze, I. R. (1994). Principles of Voice Production. Prentice-Hall, Englewood Cliffs, NJ.
5. Lucero, J. C., and Koenig, L. L. (2005). Simulations of temporal patterns of oral airflow in men and women using a two-mass model of the vocal folds under dynamic control, Journal of the Acoustical Society of America 117, 1362-1372.
6. Titze, I.R. (1988). The physics of small-amplitude oscillation of the vocal folds. Journal of the Acoustical Society of America 83, 1536-1552

5 <http://biorobotics.harvard.edu/pubs/gunter-jasa-pub.pdf>

6 <http://www.mat.unb.br/~lucero/JAS001362.pdf>

10 Threshold of Hearing/Pain



Figure 39




Figure 40 Fig. 1: The Fletcher-Munson equal-loudness contours. The lowest of the curves is the ATH.

The **threshold of hearing** is the Sound pressure level SPL of 20 μPa (micropascals) = 2×10^{-5} pascal (Pa). This low threshold of amplitude (strength or sound pressure level) is frequency dependent. See the frequency curve in Fig. 2 below

The **absolute threshold of hearing** (ATH) is the minimum amplitude (level or strength) of a pure tone that the average ear with normal hearing can hear in a noiseless environment.

The **threshold of pain** is the SPL beyond which sound becomes unbearable for a human listener. This threshold varies only slightly with frequency. Prolonged exposure to sound pressure levels in excess of the threshold of pain can cause physical damage, potentially leading to hearing impairment.

Different values for the threshold of pain:

Threshold of pain

SPL	sound pressure
120 dBSPL	20 Pa
130 dBSPL	63 Pa
134 dBSPL	100 Pa
137.5 dBSPL	150 Pa
140 dBSPL	200 Pa

The **Threshold of hearing** is frequency dependent, and typically shows a minimum (indicating the ear's maximum sensitivity) at frequencies between 1 kHz and 5 kHz. A typical ATH curve is pictured in Fig. 1. The absolute threshold of hearing represents the lowest curve amongst the set of equal-loudness contours, with the highest curve representing the threshold of pain.

In psychoacoustic audio compression, the ATH is used, often in combination with masking curves, to calculate which spectral components are inaudible and may thus be ignored in the coding process; any part of an audio spectrum which has an amplitude (level or strength) below the ATH may be removed from an audio signal without any audible change to the signal.

The ATH curve rises with age as the human ear becomes more insensitive to sound, with the greatest changes occurring at frequencies higher than 2 kHz. Curves for subjects of various age groups are illustrated in Fig. 2. The data is from the United States *Occupational Health and Environment Control, Standard Number:1910.95 App F*

../Human Vocal Fold/¹ - **Acoustics**² - ../How an Acoustic Guitar Works/³

4

1 Chapter 9 on page 59
 2 <http://en.wikibooks.org/wiki/Acoustics>
 3 <http://en.wikibooks.org/wiki/..%2F..%2FHow%20an%20Acoustic%20Guitar%20Works%2F>
 4 <http://en.wikibooks.org/wiki/Category%3AAcoustics%20%28book%29>

11 Musical Acoustics Applications

12 Microphone Technique



Figure 41

12.1 General technique

1. A microphone should be used whose frequency response will suit the frequency range of the voice or instrument being recorded.
2. Vary microphone positions and distances until you achieve the monitored sound that you desire.
3. In the case of poor room acoustics, place the microphone very close to the loudest part of the instrument being recorded or isolate the instrument.
4. Personal taste is the most important component of microphone technique. Whatever sounds right to you, *is* right.

12.2 Types of microphones

12.2.1 Dynamic microphones

These are the most common general-purpose microphones. They do not require power to operate. If you have a microphone that is used for live performance, it is probably a dynamic mic.

They have the advantage that they can withstand very high sound pressure levels (high volume) without damage or distortion, and tend to provide a richer, more intense sound

than other types. Traditionally, these mics did not provide as good a response on the highest frequencies (particularly above 10 kHz), but some recent models have come out that attempt to overcome this limitation.

In the studio, dynamic mics are often used for high sound pressure level instruments such as drums, guitar amps and brass instruments. Models that are often used in recording include the Shure SM57 and the Sennheiser MD421.

12.2.2 Condenser microphones

These microphones are often the most expensive microphones a studio owns. They require power to operate, either from a battery or phantom power, provided using the mic cable from an external mixer or pre-amp. These mics have a built-in pre-amplifier that uses the power. Some vintage microphones have a tube amplifier, and are referred to as tube condensers.

While they cannot withstand the very high sound pressure levels that dynamic mics can, they provide a flatter frequency response, and often the best response at the highest frequencies. Not as good at conveying intensity, they are much better at providing a balanced accurate sound.

Condenser mics come with a variety of sizes of transducers. They are usually grouped into smaller format condensers, which often are long cylinders about the size of a nickel coin in diameter, and larger format condensers, the transducers of which are often about an inch in diameter or slightly larger.

In the studio, condenser mics are often used for instruments with a wide frequency range, such as an acoustic piano, acoustic guitar, voice, violin, cymbals, or an entire band or chorus. On louder instruments they do not use close miking with condensers. Models that are often used in recording include the Shure SM81 (small format), AKG C414 (large format) and Neumann U87 (large format).

12.2.3 Ribbon microphones

Ribbon microphones are often used as an alternative to condenser microphones. Some modern ribbon microphones do not require power, and some do. The first ribbon microphones, developed at RCA in the 1930s, required no power, were quite fragile and could be destroyed by just blowing air through them. Modern ribbon mics are much more resilient, and can be used with the same level of caution as condenser mics.

Ribbon microphones provide a warmer sound than a condenser mic, with a less brittle top end. Some vocalists (including Paul McCartney) prefer them to condenser mics. In the studio they are used on vocals, violins, and even drums. Popular models for recording include the Royer R121 and the AEA R84.

12.3 Working distance

12.3.1 Close miking

When miking at a distance of 1 inch to about 1 foot from the sound source, it is considered close miking. This technique generally provides a tight, present sound quality and does an effective job of isolating the signal and excluding other sounds in the acoustic environment.

Bleed

Bleeding occurs when the signal is not properly isolated and the microphone picks up another nearby instrument. This can make the mixdown process difficult if there are multiple voices on one track. Use the following methods to prevent leakage:

- Place the microphones closer to the instruments.
- Move the instruments farther apart.
- Put some sort of acoustic barrier between the instruments.
- Use directional microphones.

A B miking

The A B miking distance rule (ratio 3 - 1) is a general rule of thumb for close miking. To prevent phase anomalies and bleed, the microphones should be placed at least three times as far apart as the distance between the instrument and the microphone.




Figure 42 A B Miking

12.3.2 Distant miking

Distant miking refers to the placement of microphones at a distance of 3 feet or more from the sound source. This technique allows the full range and balance of the instrument to develop and it captures the room sound. This tends to add a live, open feeling to the recorded sound, but careful consideration needs to be given to the acoustic environment.

12.3.3 Accent miking

Accent miking is a technique used for solo passages when miking an ensemble. A soloist needs to stand out from an ensemble, but placing a microphone too close will sound unnaturally present compared the distant miking technique used with the rest of the ensemble. Therefore, the microphone should be placed just close enough to the soloist so that the signal can be mixed effectively without sounding completely excluded from the ensemble.

12.3.4 Ambient miking

Ambient miking is placing the microphones at such a distance that the room sound is more prominent than the direct signal. This technique is used to capture audience sound or the natural reverberation of a room or concert hall.

12.4 Stereo and surround technique

12.4.1 Stereo

Stereo miking is simply using two microphones to obtain a stereo left-right image of the sound. A simple method is the use of a spaced pair, which is placing two identical microphones several feet apart and using the difference in time and amplitude to create the image. Great care should be taken in the method as phase anomalies can occur due to the signal delay. This risk of phase anomaly can be reduced by using the X/Y method, where the two microphones are placed with the grills as close together as possible without touching. There should be an angle of 90 to 135 degrees between the mics. This technique uses only amplitude, not time, to create the image, so the chance of phase discrepancies is unlikely.




Figure 43 Spaced Pair




Figure 44 X/Y Method

12.4.2 Surround

To take advantage of 5.1 sound or some other surround setup, microphones may be placed to capture the surround sound of a room. This technique essentially stems from stereo technique with the addition of more microphones. Because every acoustic environment is different, it is difficult to define a general rule for surround miking, so placement becomes dependent on experimentation. Careful attention must be paid to the distance between microphones and potential phase anomalies.

12.5 Placement for varying instruments

12.5.1 Amplifiers

When miking an amplified speaker, such as for electric guitars, the mic should be placed 2 to 12 inches from the speaker. Exact placement becomes more critical at a distance of less than 4 inches. A brighter sound is achieved when the mic faces directly into the center of the speaker cone and a more mellow sound is produced when placed slightly off-center. Placing off-center also reduces amplifier noise.

A bigger sound can often be achieved by using two mics. The first mic should be a dynamic mic, placed as described in the previous paragraph. Add to this a condenser mic placed at least 3 times further back (remember the 3:1 rule), which will pickup the blended sound of all speakers, as well as some room ambience. Run the mics into separate channels and combine them to your taste.

12.5.2 Brass instruments

High sound-pressure levels are produced by brass instruments due to the directional characteristics of mid to mid-high frequencies. Therefore, for brass instruments such as trumpets, trombones, and tubas, microphones should face slightly off of the bell's center at a distance of one foot or more to prevent overloading from wind blasts.

12.5.3 Guitars

Technique for acoustic guitars is dependent on the desired sound. Placing a microphone close to the sound hole will achieve the highest output possible, but the sound may be bottom-heavy because of how the sound hole resonates at low frequencies. Placing the mic slightly off-center at 6 to 12 inches from the hole will provide a more balanced pickup. Placing the mic closer to the bridge with the same working distance will ensure that the full range of the instrument is captured.

A technique that some engineers use places a large-format condenser mic 12-18 inches away from the 12th fret of the guitar, and a small-format condenser very close to the strings nearby. Combining the two signals can produce a rich tone.

12.5.4 Pianos

Ideally, microphones would be placed 4 to 6 feet from the piano to allow the full range of the instrument to develop before it is captured. This isn't always possible due to room noise, so the next best option is to place the microphone just inside the open lid. This applies to both grand and upright pianos.

12.5.5 Percussion

One overhead microphone can be used for a drum set, although two are preferable. If possible, each component of the drum set should be miked individually at a distance of 1 to 2 inches as if they were their own instrument. This also applies to other drums such as congas and bongos. For large, tuned instruments such as xylophones, multiple mics can be used as long as they are spaced according to the 3:1 rule. Typically, dynamic mics are used for individual drum miking, while small-format condensers are used for the overheads.

12.5.6 Voice

Standard technique is to put the microphone directly in front of the vocalist's mouth, although placing slightly off-center can alleviate harsh consonant sounds (such as "p") and prevent overloading due to excessive dynamic range.

12.5.7 Woodwinds

A general rule for woodwinds is to place the microphone around the middle of the instrument at a distance of 6 inches to 2 feet. The microphone should be tilted slightly towards the bell or sound hole, but not directly in front of it.

12.6 Sound Propagation

It is important to understand how sound propagates due to the nature of the acoustic environment so that microphone technique can be adjusted accordingly. There are four basic ways that this occurs:

12.6.1 Reflection

Sound waves are reflected by surfaces if the object is as large as the wavelength of the sound. It is the cause of echo (simple delay), reverberation (many reflections cause the sound to continue after the source has stopped), and standing waves (the distance between two parallel walls is such that the original and reflected waves in phase reinforce one another).

12.6.2 Absorption

Sound waves are absorbed by materials rather than reflected. This can have both positive and negative effects depending on whether you desire to reduce reverberation or retain a live sound.

12.6.3 Diffraction

Objects that may be between sound sources and microphones must be considered due to diffraction. Sound will be stopped by obstacles that are larger than its wavelength. Therefore, higher frequencies will be blocked more easily than lower frequencies.

12.6.4 Refraction

Sound waves bend as they pass through mediums with varying density. Wind or temperature changes can cause sound to seem like it is literally moving in a different direction than expected.

12.7 Sources

- Huber, Dave Miles, and Robert E. Runstein. *Modern Recording Techniques*. Sixth Edition. Burlington: Elsevier, Inc., 2005.
- Shure, Inc. (2003). *Shure Product Literature*. Retrieved November 28, 2005, from <http://www.shure.com/scripts/literature/literature.aspx>.

13 Microphone Design and Operation



Figure 45

13.1 Introduction

Microphones are devices which convert pressure fluctuations into electrical signals. There are two main methods of accomplishing this task that are used in the mainstream entertainment industry. They are known as dynamic microphones and condenser microphones. Piezoelectric crystals can also be used as microphones but are not commonly used in the entertainment industry. For further information on piezoelectric transducers [Click Here](#)¹.

13.2 Dynamic microphones

This type of microphone converts pressure fluctuations into electrical current. These microphones work by means of the principle known as Faraday's Law. The principle states that when an electrical conductor is moved through a magnetic field, an electrical current is induced within the conductor. The magnetic field within the microphone is created using permanent magnets and the conductor is produced in two common arrangements.

¹ http://en.wikibooks.org/wiki/Acoustic:Piezoelectric_Transducers




Figure 46 Figure 1: Sectional View of Moving-Coil Dynamic Microphone

The first conductor arrangement is made of a coil of wire. The wire is typically copper and is attached to a circular membrane or piston usually made from lightweight plastic or occasionally aluminum. The impinging pressure fluctuation on the piston causes it to move in the magnetic field and thus creates the desired electrical current. Figure 1 provides a sectional view of a moving-coil microphone.




Figure 47 Figure 2: Dynamic Ribbon Microphone

The second conductor arrangement is a ribbon of metallic foil suspended between magnets. The metallic ribbon is what moves in response to a pressure fluctuation and in the same manner, an electrical current is produced. Figure 2 provides a sectional view of a ribbon microphone. In both configurations, dynamic microphones follow the same principles as acoustical transducers. For further information about transducers [Click Here](#)².

13.3 Condenser microphones

This type of microphone converts pressure fluctuations into electrical potentials through the use of changing an electrical capacitor. This is why condenser microphones are also known as capacitor microphones. An electrical capacitor is created when two charged electrical conductors are placed at a finite distance from each other. The basic relation that describes capacitors is:

$$Q=C \cdot V$$

where Q is the electrical charge of the capacitor's conductors, C is the capacitance, and V is the electric potential between the capacitor's conductors. If the electrical charge of the conductors is held at a constant value, then the voltage between the conductors will be inversely proportional to the capacitance. Also, the capacitance is inversely proportional to the distance between the conductors. Condenser microphones utilize these two concepts.

² http://en.wikibooks.org/wiki/Acoustic:Acoustic_Transducers_-_The_Loudspeaker




Figure 48 Figure 3: Sectional View of Condenser Microphone

The capacitor in a condenser microphone is made of two parts: the diaphragm and the back plate. Figure 3 shows a section view of a condenser microphone. The diaphragm is what moves due to impinging pressure fluctuations and the back plate is held in a stationary position. When the diaphragm moves closer to the back plate, the capacitance increases and therefore a change in electric potential is produced. The diaphragm is typically made of metallic coated Mylar. The assembly that houses both the back plate and the diaphragm is commonly referred to as a capsule.

To keep the diaphragm and back plate at a constant charge, an electric potential must be presented to the capsule. There are various ways of performing this operation. The first of which is by simply using a battery to supply the needed DC potential to the capsule. A simplified schematic of this technique is displayed in figure 4. The resistor across the leads of the capsule is very high, in the range of 10 mega ohms, to keep the charge on the capsule close to constant.




Figure 49 Figure 4: Internal Battery Powered Condenser Microphone

Another technique of providing a constant charge on the capacitor is to supply a DC electric potential through the microphone cable that carries the microphones output signal. Standard

microphone cable is known as XLR cable and is terminated by three pin connectors. Pin one connects to the shield around the cable. The microphone signal is transmitted between pins two and three. Figure 5 displays the layout of dynamic microphone attached to a mixing console via XLR cable.




Figure 50 Figure 5: Dynamic Microphone Connection to Mixing Console via XLR Cable

Phantom Supply/Powering (Audio Engineering Society, DIN 45596): The first and most popular method of providing a DC potential through a microphone cable is to supply +48 V to both of the microphone output leads, pins 2 and 3, and use the shield of the cable, pin 1, as the ground to the circuit. Because pins 2 and 3 see the same potential, any fluctuation of the microphone powering potential will not affect the microphone signal seen by the attached audio equipment. This configuration can be seen in figure 6. The +48 V will be stepped down at the microphone using a transformer and provide the potential to the back plate and diaphragm in a similar fashion as the battery solution. In fact, 9, 12, 24, 48 or 52 V can be supplied, but 48 V is the most frequent.

48 Volt Phantom Powering:

12 Volt T-Powering:





Figure 51 Figure 6: Condenser Microphone Powering Techniques

The second method of running the potential through the cable is to supply 12 V between pins 2 and 3. This method is referred to as **T-powering** (also known as Tonaderspeisung, AB powering; DIN 45595). The main problem with T-powering is that potential fluctuation in the powering of the capsule will be transmitted into an audio signal because the audio equipment analyzing the microphone signal will not see a difference between a potential change across pins 2 and 3 due to a pressure fluctuation and one due to the power source electric potential fluctuation.

Finally, the diaphragm and back plate can be manufactured from a material that maintains a fixed charge. These microphones are termed electrets. In early electret designs, the charge

on the material tended to become unstable over time. Recent advances in science and manufacturing have allowed this problem to be eliminated in present designs.

13.4 Conclusion

Two branches of microphones exist in the entertainment industry. Dynamic microphones are found in the moving-coil and ribbon configurations. The movement of the conductor in dynamic microphones induces an electric current which is then transformed into the reproduction of sound. Condenser microphones utilize the properties of capacitors. Creating the charge on the capsule of condenser microphones can be accomplished by battery, phantom powering, T-powering, and by using fixed charge materials in manufacturing.

13.5 References

- Sound Recording Handbook. Woram, John M. 1989.
- Handbook of Recording Engineering Fourth Edition. Eargle, John. 2003.

13.6 Microphone manufacturer links

- AKG³
- Audio Technica⁴
- Audix⁵
- While Brüel & Kjær⁶ produces microphones for measurement purposes, DPA⁷ is the equipment sold for recording purposes
- Electrovoice⁸
- Josephson Engineering⁹
- Neumann¹⁰ (currently a subsidiary of Sennheiser)
- Rode¹¹
- Schoeps¹²
- Sennheiser¹³
- Shure¹⁴
- Wharfedale¹⁵

3 <http://www.akgusa.com/>

4 <http://www.audio-technica.com/cms/site/c35da94027e94819/index.html>

5 <http://www.audixusa.com/>

6 http://www.bkhome.com/bk_home.asp

7 <http://www.dpamicrophones.com/>

8 <http://www.electrovoice.com/>

9 <http://www.josephson.com/>

10 http://www.neumannusa.com/mat_dev/FLift/open.asp

11 <http://www.rode.com.au/>

12 <http://www.schoeps.de/>

13 <http://www.sennheiser.com/>

14 <http://www.shure.com/>

15 <http://www.wharfedalepro.com/>

14 Acoustic Loudspeaker



Figure 52

The purpose of the acoustic transducer is to convert electrical energy into acoustic energy. Many variations of acoustic transducers exist, although the most common is the moving coil-permanent magnet transducer. The classic loudspeaker is of the moving coil-permanent magnet type.

The classic electrodynamic loudspeaker driver can be divided into three key components:

1. The Magnet Motor Drive System
2. The Loudspeaker Cone System
3. The Loudspeaker Suspension




Figure 53 Figure 1 Cut-away of a moving coil-permanent magnet loudspeaker

14.1 The Magnet Motor Drive System

The main purpose of the Magnet Motor Drive System is to establish a symmetrical magnetic field in which the voice coil will operate. The Magnet Motor Drive System is comprised of a front focusing plate, permanent magnet, back plate, and a pole piece. In figure 2, the assembled drive system is illustrated. In most cases, the back plate and the pole piece are built into one piece called the yoke. The yoke and the front focusing plate are normally made of a very soft cast iron. Iron is a material that is used in conjunction with magnetic

structures because the iron is easily saturated when exposed to a magnetic field. Notice in figure 2, that an air gap was intentionally left between the front focusing plate and the yoke. The magnetic field is coupled through the air gap. The magnetic field strength (B) of the air gap is typically optimized for uniformity across the gap. [1]

Figure 2 Permanent Magnet Structure

When a coil of wire with a current flowing is placed inside the permanent magnetic field, a force is produced. B is the magnetic field strength, l is the length of the coil, and I is the current flowing through the coil. The electro-magnetic force is given by the expression of Laplace :

$$d\underline{F} = I \underline{dl} \times \underline{B}$$

\underline{B} and \underline{dl} are orthogonal, so the force is obtained by integration on the length of the wire (Re is the radius of a spire, n is the number of spires and \underline{e}_x is on the axis of the coil):

$$\underline{F} = 2\pi R_e B n I \underline{e}_x$$

This force is directly proportional to the current flowing through the coil.




Figure 54

Figure 3 Voice Coil Mounted in Permanent Magnetic Structure

The coil is excited with the AC signal that is intended for sound reproduction, when the changing magnetic field of the coil interacts with the permanent magnetic field then the coil moves back and forth in order to reproduce the input signal. The coil of a loudspeaker is known as the voice coil.

14.2 The loudspeaker cone system

On a typical loudspeaker, the cone serves the purpose of creating a larger radiating area allowing more air to be moved when excited by the voice coil. The cone serves a piston that is excited by the voice coil. The cone then displaces air creating a sound wave. In an ideal environment, the cone should be infinitely rigid and have zero mass, but in reality neither is true. Cone materials vary from carbon fiber, paper, bamboo, and just about any other

material that can be shaped into a stiff conical shape. The loudspeaker cone is a very critical part of the loudspeaker. Since the cone is not infinitely rigid, it tends to have different types of resonance modes form at different frequencies, which in turn alters and colors the reproduction of the sound waves. The shape of the cone directly influences the directivity and frequency response of the loudspeaker. When the cone is attached to the voice coil, a large gap above the voice coil is left exposed. This could be a problem if foreign particles make their way into the air gap of the voice coil and the permanent magnet structure. The solution to this problem is to place what is known as a dust cap on the cone to cover the air gap. Below a figure of the cone and dust cap are shown.




Figure 55

Figure 6 Cone and Dust Cap attached to Voice Coil

The speed of the cone can be expressed with an equation of a mass-spring system with a damping coefficient ξ :

$$m \frac{dv}{dt} + \xi v + k \int v dt = Bli$$

The current intensity i and the speed v can also be related by this equation (U is the voltage, R the electrical resistance and L_b the inductance) :

$$L_b \frac{di}{dt} + Ri = U - Blv$$

By using a harmonic solution, the expression of the speed is :

$$v = \frac{Bli}{\xi + j(m\omega - \frac{k}{\omega})}$$

The electrical impedance can be determined as the ratio of the voltage on the current intensity :

$$Z = \frac{U}{i} = R + jL\omega + \frac{B^2 l^2}{\xi + j(m\omega - \frac{k}{\omega})}$$

The frequency response of the loudspeaker can be plotted.




Figure 56

Figure 7 Electrical impedance

A phenomena of electrical resonance is observable around the frequency of 100 Hz. Besides, the inductance of the coil makes the impedance increase from the frequency of 400 Hz. So the range of frequency where the loudspeaker is used is 100 - 4000 Hz

14.3 The loudspeaker suspension

Most moving coil loudspeakers have a two piece suspension system, also known as a flexure system. The combination of the two flexures allows the voice coil to maintain linear travel as the voice coil is energized and provide a restoring force for the voice coil system. The two piece system consists of large flexible membrane surrounding the outside edge of the cone, called the surround, and an additional flexure connected directly to the voice coil, called the spider. The surround has another purpose and that is to seal the loudspeaker when mounted in an enclosure. Commonly, the surround is made of a variety of different materials, such as, folded paper, cloth, rubber, and foam. Construction of the spider consists of different woven cloth or synthetic materials that are compressed to form a flexible membrane. The following two figures illustrate where the suspension components are physically at on the loudspeaker and how they function as the loudspeaker operates.




Figure 57

Figure 8 Loudspeaker Suspension System


**Figure 58**

Figure 9 Moving Loudspeaker

14.4 Modeling the loudspeaker as a lumped system

Before implementing a loudspeaker into a specific application, a series of parameters characterizing the loudspeaker must be extracted. The equivalent circuit of the loudspeaker is key when developing enclosures. The circuit models all aspects of the loudspeaker through an equivalent electrical, mechanical, and acoustical circuit. Figure 9 shows how the three equivalent circuits are connected. The electrical circuit is comprised of the DC resistance

of the voice coil, R_e , the imaginary part of the voice coil inductance, L_e , and the real part of the voice coil inductance, R_{evc} . The mechanical system has electrical components that model different physical parameters of the loudspeaker. In the mechanical circuit, M_m is the electrical capacitance due to the moving mass, C_m is the electrical inductance due to the compliance of the moving mass, and R_m is the electrical resistance due to the suspension system. In the acoustical equivalent circuit, M_a models the air mass and R_a models the radiation impedance[2]. This equivalent circuit allows insight into what parameters change the characteristics of the loudspeaker. Figure 10 shows the electrical input impedance as a function of frequency developed using the equivalent circuit of the loudspeaker.




Figure 59

Figure 9 Loudspeaker Analogous Circuit




Figure 60

Figure 10 Electrical Input Impedance

14.5 The acoustical enclosure

14.5.1 Function of the enclosure

The loudspeaker emits two waves : a front wave and a back wave. With a reflection on a wall, the back wave can be added with the front wave and produces destructive interferences. As a result, the sound pressure level in the room is not uniform. At certain positions, the interaction is additive, and the sound pressure level is higher. On the contrary, certain positions offer destructive interaction between the waves and the sound pressure level is lower.




Figure 61

Figure 11 Loudspeaker without baffle producing destructive interferences

The solution is to put a baffle round the loudspeaker in order to prevent the back wave from interfering with the front wave. The sound pressure level is uniform in the room and the quality of the loudspeaker is higher.




Figure 62

Figure 12 Loudspeakers with infinite baffle and enclosure

14.5.2 Loudspeaker-external fluid interaction

The external fluid exerts a pressure on the membrane of the loudspeaker cone. This additive force can be evaluate as an additive mass and an additive damping in the equation of vibration of the membrane.

$$-(m + MS)\omega^2\xi + i\omega(C + RS)\xi + K\xi = fe^{i\omega t}$$

When the fluid is the air, this additive mass and additive damping are negligible. For example, at the frequency of 1000 Hz, the additive mass is 3g.

14.5.3 Loudspeaker-internal fluid interaction

The volume of air in the enclosure constitutes an additive stiffness. This is called the acoustic load. In low frequencies, this additive stiffness can be four times the stiffness of the loudspeaker cone. The internal air stiffness is very high because of the boundary conditions inside the enclosure. The walls impose a condition of zero airspeed that makes the stiffness increase.

Figure 13 Stiffness of the loudspeaker cone and stiffness of the internal air

The stiffness of the internal air (in red) is fourth time higher than the stiffness of the loudspeaker cone (in blue). That is why the design of the enclosure is relevant in order to improve the quality of the sound and avoid a decrease of the sound pressure level in the room at some frequencies.

14.6 References

1. The Loudspeaker Design Cookbook 5th Edition; Dickason, Vance., Audio Amateur Press, 1997.
2. Beranek, L. L. Acoustics. 2nd ed. Acoustical Society of America, Woodbridge, NY. 1993.

15 Sealed Box Subwoofer Design

15.1 Introduction

A sealed or closed box baffle is the most basic but often the cleanest sounding sub-woofer box design. The sub-woofer box in its most simple form, serves to isolate the back of the speaker from the front, much like the theoretical infinite baffle. The sealed box provides simple construction and controlled response for most sub-woofer applications. The slow low end roll-off provides a clean transition into the extreme frequency range. Unlike ported boxes, the cone excursion is reduced below the resonant frequency of the box and driver due to the added stiffness provided by the sealed box baffle.

Closed baffle boxes are typically constructed of a very rigid material such as MDF (medium density fiber board) or plywood .75 to 1 inch thick. Depending on the size of the box and material used, internal bracing may be necessary to maintain a rigid box. A rigid box is important to design in order to prevent unwanted box resonance.

As with any acoustics application, the box must be matched to the loudspeaker driver for maximum performance. The following will outline the procedure to tune the box or maximize the output of the sub-woofer box and driver combination.

15.2 Closed baffle circuit

The sealed box enclosure for sub-woofers can be modeled as a lumped element system if the dimensions of the box are significantly shorter than the shortest wavelength reproduced by the sub-woofer. Most sub-woofer applications are crossed over around 80 to 100 Hz. A 100 Hz wave in air has a wavelength of about 11 feet. Sub-woofers typically have all dimensions much shorter than this wavelength, thus the lumped element system analysis is accurate. Using this analysis, the following circuit represents a sub-woofer enclosure system.




Figure 63

where all of the following parameters are in the mechanical mobility analog

V_e - voltage supply

R_e - electrical resistance

M_m - driver mass

C_m - driver compliance

R_m - resistance

R_{Ar} - rear cone radiation resistance into the air

X_{Af} - front cone radiation reactance into the air

R_{Br} - rear cone radiation resistance into the box

X_{Br} - rear cone radiation reactance into the box

15.3 Driver parameters

In order to tune a sealed box to a driver, the driver parameters must be known. Some of the parameters are provided by the manufacturer, some are found experimentally, and some are found from general tables. For ease of calculations, all parameters will be represented in the SI units meter/kilogram/second. The parameters that must be known to determine the size of the box are as follows:

f_0 - driver free-air resonance

C_{MS} - mechanical compliance of the driver

S_D - effective area of the driver

Resonance of the driver

The resonance of the driver is usually either provided by the manufacturer or must be found experimentally. It is a good idea to measure the resonance frequency even if it is provided by the manufacturer to account for inconsistent manufacturing processes.

The following diagram shows verba and the setup for finding resonance:

Where voltage V_1 is held constant and the variable frequency source is varied until V_2 is a maximum. The frequency where V_2 is a maximum is the resonance frequency for the driver.

Mechanical compliance

By definition compliance is the inverse of stiffness or what is commonly referred to as the spring constant. The compliance of a driver can be found by measuring the displacement of the cone when known masses are placed on the cone when the driver is facing up. The compliance would then be the displacement of the cone in meters divided by the added weight in newtons.

Effective area of the driver

The physical diameter of the driver does not lead to the effective area of the driver. The effective diameter can be found using the following diagram:




Figure 64

From this diameter, the area is found from the basic area of a circle equation.

15.4 Acoustic compliance

From the known mechanical compliance of the cone, the acoustic compliance can be found from the following equation:

$$C_{AS} = C_{MS}S_D^2$$

From the driver acoustic compliance, the box acoustic compliance is found. This is where the final application of the sub-woofer is considered. The acoustic compliance of the box will determine the percent shift upwards of the resonant frequency. If a large shift is desired for high SPL applications, then a large ratio of driver to box acoustic compliance would be required. If a more flattened response is desired for high fidelity applications, then a lower ratio of driver to box acoustic compliance would be required. Specifically, the ratios can be found in the following figure using line (b) as reference.

$$C_{AS} = C_{AB} * r$$

r - driver to box acoustic compliant ratio




Figure 65

15.5 Sealed box design

Volume of box

The volume of the sealed box can now be found from the box acoustic compliance. The following equation is used to calculate the box volume

$$V_B = C_{AB} * \gamma$$

Box dimensions

From the calculated box volume, the dimensions of the box can then be designed. There is no set formula for finding the dimensions of the box, but there are general guidelines to be

followed. If the driver was mounted in the center of a square face, the waves generated by the cone would reach the edges of the box at the same time, thus when combined would create a strong diffracted wave in the listening space. In order to best prevent this, the driver should be either be mounted offset of a square face, or the face should be rectangular.

The face of the box which the driver is set in should not be a square.

16 Miscellaneous Applications

17 Bass-Reflex Enclosure Design




Figure 66

Bass-reflex enclosures improve the low-frequency response of loudspeaker systems. Bass-reflex enclosures are also called "vented-box design" or "ported-cabinet design". A bass-reflex

enclosure includes a vent or port between the cabinet and the ambient environment. This type of design, as one may observe by looking at contemporary loudspeaker products, is still widely used today. Although the construction of bass-reflex enclosures is fairly simple, their design is not simple, and requires proper tuning. This reference focuses on the technical details of bass-reflex design. General loudspeaker information can be found [here](#)¹.

17.1 Effects of the Port on the Enclosure Response

Before discussing the bass-reflex enclosure, it is important to be familiar with the simpler sealed enclosure system performance. As the name suggests, the sealed enclosure system attaches the loudspeaker to a sealed enclosure (except for a small air leak included to equalize the ambient pressure inside). Ideally, the enclosure would act as an acoustical compliance element, as the air inside the enclosure is compressed and rarified. Often, however, an acoustic material is added inside the box to reduce standing waves, dissipate heat, and other reasons. This adds a resistive element to the acoustical lumped-element model. A non-ideal model of the effect of the enclosure actually adds an acoustical mass element to complete a series lumped-element circuit given in Figure 1. For more on sealed enclosure design, see the [Sealed Box Subwoofer Design](#)² page.

Figure 1. Sealed enclosure acoustic circuit.

In the case of a bass-reflex enclosure, a port is added to the construction. Typically, the port is cylindrical and is flanged on the end pointing outside the enclosure. In a bass-reflex enclosure, the amount of acoustic material used is usually much less than in the sealed enclosure case, often none at all. This allows air to flow freely through the port. Instead, the larger losses come from the air leakage in the enclosure. With this setup, a lumped-element acoustical circuit has the form shown in the diagram below.




Figure 67

¹ <http://en.wikipedia.org/wiki/Loudspeaker>

² <http://en.wikibooks.org/wiki/Engineering%20Acoustics%2FSealed%20Box%20Subwoofer%20Design>

Figure 2. Bass-reflex enclosure acoustic circuit.

In this figure, Z_{RAD} represents the radiation impedance of the outside environment on the loudspeaker diaphragm. The loading on the rear of the diaphragm has changed when compared to the sealed enclosure case. If one visualizes the movement of air within the enclosure, some of the air is compressed and rarified by the compliance of the enclosure, some leaks out of the enclosure, and some flows out of the port. This explains the parallel combination of M_{AP} , C_{AB} , and R_{AL} . A truly realistic model would incorporate a radiation impedance of the port in series with M_{AP} , but for now it is ignored. Finally, M_{AB} , the acoustical mass of the enclosure, is included as discussed in the sealed enclosure case. The formulas which calculate the enclosure parameters are listed in Appendix B³.

It is important to note the parallel combination of M_{AP} and C_{AB} . This forms a Helmholtz resonator (click here for more information⁴). Physically, the port functions as the “neck” of the resonator and the enclosure functions as the “cavity.” In this case, the resonator is driven from the piston directly on the cavity instead of the typical Helmholtz case where it is driven at the “neck.” However, the same resonant behavior still occurs at the enclosure resonance frequency, f_B . At this frequency, the impedance seen by the loudspeaker diaphragm is large (see Figure 3 below). Thus, the load on the loudspeaker reduces the velocity flowing through its mechanical parameters, causing an anti-resonance condition where the displacement of the diaphragm is a minimum. Instead, the majority of the volume velocity is actually emitted by the port itself instead of the loudspeaker. When this impedance is reflected to the electrical circuit, it is proportional to $1/Z$, thus a minimum in the impedance seen by the voice coil is small. Figure 3 shows a plot of the impedance seen at the terminals of the loudspeaker. In this example, f_B was found to be about 40 Hz, which corresponds to the null in the voice-coil impedance.




Figure 68

Figure 3. Impedances seen by the loudspeaker diaphragm and voice coil.

3 http://en.wikibooks.org/wiki/Engineering%20Acoustics%2FBass_Reflex_Enclosure_Design%23Appendix_B%3A_Enclosure_Parameter_Formulas%20

4 <http://en.wikibooks.org/wiki/Engineering%20Acoustics%2FAcoustics%20of%20pipes%2C%20enclosures%2C%20and%20cavities%20at%20low%20frequency%23Examples%20of%20Electro-Acoustical%20Analogies>

17.2 Quantitative Analysis of Port on Enclosure

The performance of the loudspeaker is first measured by its velocity response, which can be found directly from the equivalent circuit of the system. As the goal of most loudspeaker designs is to improve the bass response (leaving high-frequency production to a tweeter), low frequency approximations will be made as much as possible to simplify the analysis. First, the inductance of the voice coil, L_E , can be ignored as long as $\omega \ll R_E/L_E$. In a typical loudspeaker, L_E is of the order of 1 mH, while R_E is typically 8Ω , thus an upper frequency limit is approximately 1 kHz for this approximation, which is certainly high enough for the frequency range of interest.

Another approximation involves the radiation impedance, Z_{RAD} . It can be shown [1] that this value is given by the following equation (in acoustical ohms):

$$Z_{RAD} = \frac{\rho_0 c}{\pi a^2} \left[\left(1 - \frac{J_1(2ka)}{ka} \right) + j \frac{H_1(2ka)}{ka} \right]$$

Where $J_1(x)$ and $H_1(x)$ are types of Bessel functions. For small values of ka ,

$$J_1(2ka) \approx ka \quad \text{and} \quad H_1(2ka) \approx \frac{8(ka)^2}{3\pi} \quad \Rightarrow \quad Z_{RAD} \approx j \frac{8\rho_0\omega}{3\pi^2 a} = jM_{A1}$$

Hence, the low-frequency impedance on the loudspeaker is represented with an acoustic mass M_{A1} [1]. For a simple analysis, R_E , M_{MD} , C_{MS} , and R_{MS} (the transducer parameters, or *Thiele-Small* parameters) are converted to their acoustical equivalents. All conversions for all parameters are given in Appendix A⁵. Then, the series masses, M_{AD} , M_{A1} , and M_{AB} , are lumped together to create M_{AC} . This new circuit is shown below.




Figure 69

Figure 4. Low-Frequency Equivalent Acoustic Circuit

Unlike sealed enclosure analysis, there are multiple sources of volume velocity that radiate to the outside environment. Hence, the diaphragm volume velocity, U_D , is not analyzed

⁵ http://en.wikibooks.org/wiki/Engineering%20Acoustics%2FBass_Reflex_Enclosure_Design%23Appendix_A%3A_Equivalent_Circuit_Parameters%20

but rather $U_0 = U_D + U_P + U_L$. This essentially draws a “bubble” around the enclosure and treats the system as a source with volume velocity U_0 . This “lumped” approach will only be valid for low frequencies, but previous approximations have already limited the analysis to such frequencies anyway. It can be seen from the circuit that the volume velocity flowing *into* the enclosure, $U_B = -U_0$, compresses the air inside the enclosure. Thus, the circuit model of Figure 3 is valid and the relationship relating input voltage, V_{IN} to U_0 may be computed.

In order to make the equations easier to understand, several parameters are combined to form other parameter names. First, ω_B and ω_S , the enclosure and loudspeaker resonance frequencies, respectively, are:

$$\omega_B = \frac{1}{\sqrt{M_{AP}C_{AB}}} \qquad \omega_S = \frac{1}{\sqrt{M_{AC}C_{AS}}}$$

Based on the nature of the derivation, it is convenient to define the parameters ω_0 and h , the Helmholtz tuning ratio:

$$\omega_0 = \sqrt{\omega_B\omega_S} \qquad h = \frac{\omega_B}{\omega_S}$$

A parameter known as the *compliance ratio* or *volume ratio*, α , is given by:

$$\alpha = \frac{C_{AS}}{C_{AB}} = \frac{V_{AS}}{V_{AB}}$$

Other parameters are combined to form what are known as *quality factors*:

$$Q_L = R_{AL}\sqrt{\frac{C_{AB}}{M_{AP}}} \qquad Q_{TS} = \frac{1}{R_{AE}+R_{AS}}\sqrt{\frac{M_{AC}}{C_{AS}}}$$

This notation allows for a simpler expression for the resulting transfer function [1]:

$$\frac{U_0}{V_{IN}} = G(s) = \frac{(s^3/\omega_0^4)}{(s/\omega_0)^4 + a_3(s/\omega_0)^3 + a_2(s/\omega_0)^2 + a_1(s/\omega_0) + 1}$$

where

$$a_1 = \frac{1}{Q_L\sqrt{h}} + \frac{\sqrt{h}}{Q_{TS}} \qquad a_2 = \frac{\alpha+1}{h} + h + \frac{1}{Q_LQ_{TS}} \qquad a_3 = \frac{1}{Q_{TS}\sqrt{h}} + \frac{\sqrt{h}}{Q_L}$$

17.3 Development of Low-Frequency Pressure Response

It can be shown [2] that for $ka < 1/2$, a loudspeaker behaves as a spherical source. Here, a represents the radius of the loudspeaker. For a 15” diameter loudspeaker in air, this low frequency limit is about 150 Hz. For smaller loudspeakers, this limit increases. This limit

dominates the limit which ignores L_E , and is consistent with the limit that models Z_{RAD} by M_{A1} .

Within this limit, the loudspeaker emits a volume velocity U_0 , as determined in the previous section. For a simple spherical source with volume velocity U_0 , the far-field pressure is given by [1]:

$$p(r) \simeq j\omega\rho_0U_0\frac{e^{-jkr}}{4\pi r}$$

It is possible to simply let $r = 1$ for this analysis without loss of generality because distance is only a function of the surroundings, not the loudspeaker. Also, because the transfer function magnitude is of primary interest, the exponential term, which has a unity magnitude, is omitted. Hence, the pressure response of the system is given by [1]:

$$\frac{p}{V_{IN}} = \frac{\rho_0 s}{4\pi} \frac{U_0}{V_{IN}} = \frac{\rho_0 Bl}{4\pi S_D R_E M_A S} H(s)$$

Where $H(s) = sG(s)$. In the following sections, design methods will focus on $|H(s)|^2$ rather than $H(s)$, which is given by:

$$|H(s)|^2 = \frac{\Omega^8}{\Omega^8 + (a_3^2 - 2a_2)\Omega^6 + (a_2^2 + 2 - 2a_1a_3)\Omega^4 + (a_1^2 - 2a_2)\Omega^2 + 1} \quad \Omega = \frac{\omega}{\omega_0}$$

This also implicitly ignores the constants in front of $|H(s)|$ since they simply scale the response and do not affect the shape of the frequency response curve.

17.4 Alignments

A popular way to determine the ideal parameters has been through the use of alignments. The concept of alignments is based upon filter theory. Filter development is a method of selecting the poles (and possibly zeros) of a transfer function to meet a particular design criterion. The criteria are the desired properties of a magnitude-squared transfer function, which in this case is $|H(s)|^2$. From any of the design criteria, the poles (and possibly zeros) of $|H(s)|^2$ are found, which can then be used to calculate the numerator and denominator. This is the “optimal” transfer function, which has coefficients that are matched to the parameters of $|H(s)|^2$ to compute the appropriate values that will yield a design that meets the criteria.

There are many different types of filter designs, each which have trade-offs associated with them. However, this design is limited because of the structure of $|H(s)|^2$. In particular, it has the structure of a fourth-order high-pass filter with all zeros at $s = 0$. Therefore, only those filter design methods which produce a low-pass filter with only poles will be acceptable methods to use. From the traditional set of algorithms, only Butterworth and Chebyshev low-pass filters have only poles. In addition, another type of filter called a quasi-Butterworth

filter can also be used, which has similar properties to a Butterworth filter. These three algorithms are fairly simple, thus they are the most popular. When these low-pass filters are converted to high-pass filters, the $s \rightarrow 1/s$ transformation produces s^8 in the numerator.

More details regarding filter theory and these relationships can be found in numerous resources, including [5].

17.5 Butterworth Alignment

The Butterworth algorithm is designed to have a *maximally flat* pass band. Since the slope of a function corresponds to its derivatives, a flat function will have derivatives equal to zero. Since as flat of a pass band as possible is optimal, the ideal function will have as many derivatives equal to zero as possible at $s = 0$. Of course, if all derivatives were equal to zero, then the function would be a constant, which performs no filtering.

Often, it is better to examine what is called the *loss function*. Loss is the reciprocal of gain, thus

$$|\hat{H}(s)|^2 = \frac{1}{|H(s)|^2}$$

The loss function can be used to achieve the desired properties, then the desired gain function is recovered from the loss function.

Now, applying the desired Butterworth property of maximal pass-band flatness, the loss function is simply a polynomial with derivatives equal to zero at $s = 0$. At the same time, the original polynomial must be of degree eight (yielding a fourth-order function). However, derivatives one through seven can be equal to zero if [3]

$$|\hat{H}(\Omega)|^2 = 1 + \Omega^8 \Rightarrow |H(\Omega)|^2 = \frac{1}{1 + \Omega^8}$$

With the high-pass transformation $\Omega \rightarrow 1/\Omega$,

$$|H(\Omega)|^2 = \frac{\Omega^8}{\Omega^8 + 1}$$

It is convenient to define $\Omega = \omega/\omega_{3dB}$, since $\Omega = 1 \Rightarrow |H(s)|^2 = 0.5$ or -3 dB. This definition allows the matching of coefficients for the $|H(s)|^2$ describing the loudspeaker response when $\omega_{3dB} = \omega_0$. From this matching, the following design equations are obtained [1]:

$$a_1 = a_3 = \sqrt{4 + 2\sqrt{2}} \qquad a_2 = 2 + \sqrt{2}$$

17.6 Quasi-Butterworth Alignment

The quasi-Butterworth alignments do not have as well-defined of an algorithm when compared to the Butterworth alignment. The name “quasi-Butterworth” comes from the fact that the transfer functions for these responses appear similar to the Butterworth ones, with (in general) the addition of terms in the denominator. This will be illustrated below. While there are many types of quasi-Butterworth alignments, the simplest and most popular is the 3rd order alignment (QB3). The comparison of the QB3 magnitude-squared response against the 4th order Butterworth is shown below.

$$|H_{QB3}(\omega)|^2 = \frac{(\omega/\omega_{3dB})^8}{(\omega/\omega_{3dB})^8 + B^2(\omega/\omega_{3dB})^2 + 1} \qquad |H_{B4}(\omega)|^2 = \frac{(\omega/\omega_{3dB})^8}{(\omega/\omega_{3dB})^8 + 1}$$

Notice that the case $B = 0$ is the Butterworth alignment. The reason that this QB alignment is called 3rd order is due to the fact that as B increases, the slope approaches 3 dec/dec instead of 4 dec/dec, as in 4th order Butterworth. This phenomenon can be seen in Figure 5.




Figure 70

Figure 5: 3rd-Order Quasi-Butterworth Response for

$$0.1 \leq B \leq 3$$

Equating the system response $|H(s)|^2$ with $|H_{QB3}(s)|^2$, the equations guiding the design can be found [1]:

$$B^2 = a_1^2 - 2a_2 \quad a_2^2 + 2 = 2a_1a_3 \quad a_3 = \sqrt{2a_2} \quad a_2 > 2 + \sqrt{2}$$

17.7 Chebyshev Alignment

The Chebyshev algorithm is an alternative to the Butterworth algorithm. For the Chebyshev response, the maximally-flat passband restriction is abandoned. Now, a *ripple*, or fluctuation is allowed in the pass band. This allows a steeper transition or roll-off to occur. In this type of application, the low-frequency response of the loudspeaker can be extended beyond what can be achieved by Butterworth-type filters. An example plot of a Chebyshev high-pass response with 0.5 dB of ripple against a Butterworth high-pass response for the same ω_{3dB} is shown below.




Figure 71

Figure 6: Chebyshev vs. Butterworth High-Pass Response.

The Chebyshev response is defined by [4]:

$$|\hat{H}(j\Omega)|^2 = 1 + \epsilon^2 C_n^2(\Omega)$$

$C_n(\Omega)$ is called the *Chebyshev polynomial* and is defined by [4]:

$$C_n(\Omega) = \begin{cases} \cos[n\cos^{-1}(\Omega)] & |\Omega| < 1 \\ \cosh[n\cosh^{-1}(\Omega)] & |\Omega| > 1 \end{cases}$$

Fortunately, Chebyshev polynomials satisfy a simple recursion formula [4]:

$$C_0(x) = 1 \quad C_1(x) = x \quad C_n(x) = 2xC_{n-1} - C_{n-2}$$

For more information on Chebyshev polynomials, see the Wolfram Mathworld: Chebyshev Polynomials⁶ page.

When applying the high-pass transformation to the 4th order form of $|\hat{H}(j\Omega)|^2$, the desired response has the form [1]:

$$|H(j\Omega)|^2 = \frac{1 + \epsilon^2}{1 + \epsilon^2 C_4^2(1/\Omega)}$$

The parameter ϵ determines the ripple. In particular, the magnitude of the ripple is $10\log[1 + \epsilon^2]$ dB and can be chosen by the designer, similar to B in the quasi-Butterworth case. Using the recursion formula for $C_n(x)$,

$$C_4\left(\frac{1}{\Omega}\right) = 8\left(\frac{1}{\Omega}\right)^4 - 8\left(\frac{1}{\Omega}\right)^2 + 1$$

Applying this equation to $|H(j\Omega)|^2$ [1],

$$\Rightarrow |H(\Omega)|^2 = \frac{\frac{1+\epsilon^2}{64\epsilon^2}\Omega^8}{\frac{1+\epsilon^2}{64\epsilon^2}\Omega^8 + \frac{1}{4}\Omega^6 + \frac{5}{4}\Omega^4 - 2\Omega^2 + 1}$$

$$\Omega = \frac{\omega}{\omega_n}$$

$$\omega_n = \frac{\omega_{3dB}}{2} \sqrt{2 + \sqrt{2 + 2\sqrt{2 + \frac{1}{\epsilon^2}}}}$$

Thus, the design equations become [1]:

$$\omega_0 = \omega_n \sqrt[8]{\frac{64\epsilon^2}{1+\epsilon^2}} \quad k = \tanh\left[\frac{1}{4}\sinh^{-1}\left(\frac{1}{\epsilon}\right)\right] \quad D = \frac{k^4 + 6k^2 + 1}{8}$$

⁶ <http://mathworld.wolfram.com/ChebyshevPolynomialoftheFirstKind.html>

$$a_1 = \frac{k\sqrt{4+2\sqrt{2}}}{\sqrt[3]{D}}, \quad a_2 = \frac{1+k^2(1+\sqrt{2})}{\sqrt{D}}, \quad a_3 = \frac{a_1}{\sqrt{D}} \left[1 - \frac{1-k^2}{2\sqrt{2}} \right]$$

17.8 Choosing the Correct Alignment

With all the equations that have already been presented, the question naturally arises, “Which one should I choose?” Notice that the coefficients a_1 , a_2 , and a_3 are not simply related to the parameters of the system response. Certain combinations of parameters may indeed invalidate one or more of the alignments because they cannot realize the necessary coefficients. With this in mind, general guidelines have been developed to guide the selection of the appropriate alignment. This is very useful if one is designing an enclosure to suit a particular transducer that cannot be changed.

The general guideline for the Butterworth alignment focuses on Q_L and Q_{TS} . Since the three coefficients a_1 , a_2 , and a_3 are a function of Q_L , Q_{TS} , h , and α , fixing one of these parameters yields three equations that uniquely determine the other three. In the case where a particular transducer is already given, Q_{TS} is essentially fixed. If the desired parameters of the enclosure are already known, then Q_L is a better starting point.

In the case that the rigid requirements of the Butterworth alignment cannot be satisfied, the quasi-Butterworth alignment is often applied when Q_{TS} is not large enough. The addition of another parameter, B , allows more flexibility in the design.

For Q_{TS} values that are too large for the Butterworth alignment, the Chebyshev alignment is typically chosen. However, the steep transition of the Chebyshev alignment may also be utilized to attempt to extend the bass response of the loudspeaker in the case where the transducer properties can be changed.

In addition to these three popular alignments, research continues in the area of developing new algorithms that can manipulate the low-frequency response of the bass-reflex enclosure. For example, a 5th order quasi-Butterworth alignment has been developed [6]. Another example [7] applies root-locus techniques to achieve results. In the modern age of high-powered computing, other researchers have focused their efforts in creating computerized optimization algorithms that can be modified to achieve a flatter response with sharp roll-off or introduce quasi-ripples which provide a boost in sub-bass frequencies [8].

17.9 References

- [1] Leach, W. Marshall, Jr. *Introduction to Electroacoustics and Audio Amplifier Design*. 2nd ed. Kendall/Hunt, Dubuque, IA. 2001.
- [2] Beranek, L. L. *Acoustics*. 2nd ed. Acoustical Society of America, Woodbridge, NY. 1993.
- [3] DeCarlo, Raymond A. “The Butterworth Approximation.” Notes from ECE 445. Purdue University. 2004.
- [4] DeCarlo, Raymond A. “The Chebyshev Approximation.” Notes from ECE 445. Purdue University. 2004.

- [5] VanValkenburg, M. E. *Analog Filter Design*. Holt, Rinehart and Winston, Inc. Chicago, IL. 1982.
- [6] Kreutz, Joseph and Panzer, Joerg. "Derivation of the Quasi-Butterworth 5 Alignments." *Journal of the Audio Engineering Society*. Vol. 42, No. 5, May 1994.
- [7] Rutt, Thomas E. "Root-Locus Technique for Vented-Box Loudspeaker Design." *Journal of the Audio Engineering Society*. Vol. 33, No. 9, September 1985.
- [8] Simeonov, Lubomir B. and Shopova-Simeonova, Elena. "Passive-Radiator Loudspeaker System Design Software Including Optimization Algorithm." *Journal of the Audio Engineering Society*. Vol. 47, No. 4, April 1999.

17.10 Appendix A: Equivalent Circuit Parameters

Name	Electrical Equivalent	Mechanical Equivalent	Acoustical Equivalent
Voice-Coil Resistance	R_E	$R_{ME} = \frac{(Bl)^2}{R_E}$	$R_{AE} = \frac{(Bl)^2}{R_E S_D^2}$
Driver (Speaker) Mass	See C_{MEC}	M_{MD}	$M_{AD} = \frac{M_{MD}}{S_D^2}$
Driver (Speaker) Suspension Compliance	$L_{CES} = (Bl)^2 C_{MS}$	C_{MS}	$C_{AS} = S_D^2 C_{MS}$
Driver (Speaker) Suspension Resistance	$R_{ES} = \frac{(Bl)^2}{R_{MS}}$	R_{MS}	$R_{AS} = \frac{R_{MS}}{S_D^2}$
Enclosure Compliance	$L_{CEB} = \frac{(Bl)^2 C_{AB}}{S_D^2}$	$C_{MB} = \frac{C_{AB}}{S_D^2}$	C_{AB}
Enclosure Air-Leak Losses	$R_{EL} = \frac{(Bl)^2}{S_D^2 R_{AL}}$	$R_{ML} = S_D^2 R_{AL}$	R_{AL}
Acoustic Mass of Port	$C_{MEP} = \frac{S_D^2 M_{AP}}{(Bl)^2}$	$M_{MP} = S_D^2 M_{AP}$	M_{AP}
Enclosure Mass Load	See C_{MEC}	See M_{MC}	M_{AB}
Low-Frequency Radiation Mass Load	See C_{MEC}	See M_{MC}	M_{A1}
Combination Mass Load	$C_{MEC} = \frac{S_D^2 M_{AC}}{(Bl)^2}$ $= \frac{S_D^2 (M_{AB} + M_{A1}) + M_{MD}}{(Bl)^2}$	$M_{MC} = S_D^2 (M_{AB} + M_{A1}) + M_{MD}$	$M_{AC} = M_{AD} + M_{AB} + M_{A1}$ $= \frac{M_{MD}}{S_D^2} + M_{AB} + M_{A1}$

17.11 Appendix B: Enclosure Parameter Formulas




Figure 72

Figure 7: Important dimensions of bass-reflex enclosure.

Based on these dimensions [1],

$$C_{AB} = \frac{V_{AB}}{\rho_0 c_0^2}$$

$$B = \frac{d}{3} \left(\frac{S_D}{S_B} \right)^2 \sqrt{\frac{\pi}{S_D}} + \frac{8}{3\pi} \left[1 - \frac{S_D}{S_B} \right]$$

$$M_{AB} = \frac{B \rho_{eff}}{\pi a}$$

$$\rho_0 \leq \rho_{eff} \leq \rho_0 \left(1 - \frac{V_{fill}}{V_B} \right) + \rho_{fill} \frac{V_{fill}}{V_B}$$

$$V_{AB} = V_B \left[1 - \frac{V_{fill}}{V_B} \right] \left[1 + \frac{\gamma - 1}{1 + \gamma \left(\frac{V_B}{V_{fill}} - 1 \right) \frac{\rho_0 c_{air}}{\rho_{fill} c_{fill}}} \right]$$

$V_B = hwd$ (inside enclosure volume)

$S_B = wh$ (inside area of the side the speaker is mounted on)

c_{air} = specific heat of air at constant volume

c_{fill} = specific heat of filling at constant volume ($V_{filling}$)

ρ_0 = mean density of air (about 1.3 kg/m³)

ρ_{fill} = density of filling

γ = ratio of specific heats for air (1.4)

c_0 = speed of sound in air (about 344 m/s)

ρ_{eff} = effective density of enclosure. If little or no filling (acceptable assumption in a bass-reflex system but not for sealed enclosures), $\rho_{eff} \approx \rho_0$

18 Polymer-Film Acoustic Filters



Figure 73

18.1 Introduction

Acoustic filters are used in many devices such as mufflers, noise control materials (absorptive and reactive), and loudspeaker systems to name a few. Although the waves in simple (single-medium) acoustic filters usually travel in gases such as air and carbon-monoxide (in the case of automobile mufflers) or in materials such as fiberglass, polyvinylidene fluoride (PVDF) film, or polyethylene (Saran Wrap), there are also filters that couple two or three distinct media together to achieve a desired acoustic response. General information about basic acoustic filter design can be perused at the following wikibook page http://en.wikibooks.org/wiki/Acoustic_Filter_Design_%26_Implementation Acoustic Filter Design & Implementation¹. The focus of this article will be on acoustic filters that use multilayer air/polymer film-coupled media as its acoustic medium for sound waves to propagate through; concluding with an example of how these filters can be used to detect and extrapolate audio frequency information in high-frequency "carrier" waves that carry an audio signal. However, before getting into these specific type of acoustic filters, we need to briefly discuss how sound waves interact with the medium(media) in which it travels and how these factors can play a role when designing acoustic filters.

¹ <http://en.wikibooks.org/wiki/%20%20Acoustic%20Filter%20Design%20%26%20Implementation>

18.2 Changes in Media Properties Due to Sound Wave Characteristics

As with any system being designed, the filter response characteristics of an acoustic filter are tailored based on the frequency spectrum of the input signal and the desired output. The input signal may be infrasonic (frequencies below human hearing), sonic (frequencies within human hearing range), or ultrasonic (frequencies above human hearing range). In addition to the frequency content of the input signal, the density, and, thus, the characteristic impedance of the medium (media) being used in the acoustic filter must also be taken into account. In general, the characteristic impedance Z_0 for a particular medium is expressed as...

$$Z_0 = \pm \rho_0 c \quad (Pa \cdot s/m)$$

where

$$\begin{aligned} \pm \rho_0 &= \text{(equilibrium) density of medium} \quad (kg/m^3) \\ c &= \text{speed of sound in medium} \quad (m/s) \end{aligned}$$

The characteristic impedance is important because this value simultaneously gives an idea of how fast or slow particles will travel as well as how much mass is "weighting down" the particles in the medium (per unit area or volume) when they are excited by a sound source. The speed in which sound travels in the medium needs to be taken into consideration because this factor can ultimately affect the time response of the filter (i.e. the output of the filter may not radiate or attenuate sound fast or slow enough if not designed properly). The intensity I_A of a sound wave is expressed as...

$$I_A = \frac{1}{T} \int_0^T pu \quad dt = \pm \frac{P^2}{2\rho_0 c} \quad (W/m^2).$$

I_A is interpreted as the (time-averaged) rate of energy transmission of a sound wave through a unit area normal to the direction of propagation, and this parameter is also an important factor in acoustic filter design because the characteristic properties of the given medium can change relative to intensity of the sound wave traveling through it. In other words, the reaction of the particles (atoms or molecules) that make up the medium will respond differently when the intensity of the sound wave is very high or very small relative to the size of the control area (i.e. dimensions of the filter, in this case). Other properties such as the elasticity and mean propagation velocity (of a sound wave) can change in the acoustic medium as well, but focusing on frequency, impedance, and/or intensity in the design process usually takes care of these other parameters because most of them will inevitably be dependent on the aforementioned properties of the medium.

18.3 Why Coupled Acoustic Media in Acoustic Filters?

In acoustic transducers, media coupling is employed in acoustic transducers to either increase or decrease the impedance of the transducer, and, thus, control the intensity and speed of the signal acting on the transducer while converting the incident wave, or initial excitation sound wave, from one form of energy to another (e.g. converting acoustic energy to electrical

energy). Specifically, the impedance of the transducer is augmented by inserting a solid structure (not necessarily rigid) between the transducer and the initial propagation medium (e.g. air). The reflective properties of the inserted medium is exploited to either increase or decrease the intensity and propagation speed of the incident sound wave. It is the ability to alter, and to some extent, control, the impedance of a propagation medium by (periodically) inserting (a) solid structure(s) such as thin, flexible films in the original medium (air) and its ability to concomitantly alter the frequency response of the original medium that makes use of multilayer media in acoustic filters attractive. The reflection factor and transmission factor \hat{R} and \hat{T} , respectively, between two media, expressed as...

$$\hat{R} = \frac{\text{pressure of reflected portion of incident wave}}{\text{pressure of incident wave}} = \frac{\rho c - Z_{in}}{\rho c + Z_{in}}$$

and

$$\hat{T} = \frac{\text{pressure of transmitted portion of incident wave}}{\text{pressure of incident wave}} = 1 + \hat{R}$$

are the tangible values that tell how much of the incident wave is being reflected from and transmitted through the junction where the media meet. Note that Z_{in} is the (total) input impedance seen by the incident sound wave upon just entering an air-solid acoustic media layer. In the case of multiple air-columns as shown in Fig. 2, Z_{in} is the aggregate impedance of each air-column layer seen by the incident wave at the input. Below in Fig. 1, a simple illustration explains what happens when an incident sound wave propagating in medium (1) and comes in contact with medium (2) at the junction of the both media ($x=0$), where the sound waves are represented by vectors.

As mentioned above, an example of three such successive air-solid acoustic media layers is shown in Fig. 2 and the electroacoustic equivalent circuit for Fig. 2 is shown in Fig. 3 where $L = \rho_s h_s =$ (density of solid material)(thickness of solid material) = unit-area (or volume) mass, $Z = \rho c =$ characteristic acoustic impedance of medium, and $\beta = k = \omega/c =$ wavenumber. Note that in the case of a multilayer, coupled acoustic medium in an acoustic filter, the impedance of each air-solid section is calculated by using the following general purpose impedance ratio equation (also referred to as transfer matrices)...

$$\frac{Z_a}{Z_0} = \frac{\left(\frac{Z_b}{Z_0}\right) + j \tan(kd)}{1 + j \left(\frac{Z_b}{Z_0}\right) \tan(kd)}$$

where Z_b is the (known) impedance at the edge of the solid of an air-solid layer (on the right) and Z_a is the (unknown) impedance at the edge of the air column of an air-solid layer.

18.4 Effects of High-Intensity, Ultrasonic Waves in Acoustic Media in Audio Frequency Spectrum

When an ultrasonic wave is used as a carrier to transmit audio frequencies, three audio effects are associated with extrapolating the audio frequency information from the carrier wave: (a) beating effects, (b) parametric array effects, and (c) radiation pressure.

Beating occurs when two ultrasonic waves with distinct frequencies f_1 and f_2 propagate in the same direction, resulting in amplitude variations which consequently make the audio signal information go in and out of phase, or “beat”, at a frequency of $f_1 - f_2$.

Parametric array http://en.wikipedia.org/wiki/Parametric_array²<http://> effects occur when the intensity of an ultrasonic wave is so high in a particular medium that the high displacements of particles (atoms) per wave cycle changes properties of that medium so that it influences parameters like elasticity, density, propagation velocity, etc. in a non-linear fashion. The results of parametric array effects on modulated, high-intensity, ultrasonic waves in a particular medium (or coupled media) is the generation and propagation of audio frequency waves (not necessarily present in the original audio information) that are generated in a manner similar to the nonlinear process of amplitude demodulation commonly inherent in diode circuits (when diodes are forward biased).

Another audio effect that arises from high-intensity ultrasonic beams of sound is a static (DC) pressure called radiation pressure. Radiation pressure is similar to parametric array effects in that amplitude variations in the signal give rise to audible frequencies via amplitude demodulation. However, unlike parametric array effects, radiation pressure fluctuations that generate audible signals from amplitude demodulation can occur due to any low-frequency modulation and not just from pressure fluctuations occurring at the modulation frequency ω_M or beating frequency $f_1 - f_2$.

18.5 An Application of Coupled Media in Acoustic Filters

Figs. 1 - 3 were all from a research paper entitled New Type of Acoustics Filter Using Periodic Polymer Layers for Measuring Audio Signal Components Excited by Amplitude-Modulated High_Intensity Ultrasonic Waves³ submitted to the Audio Engineering Society (AES) by Minoru Todo, Primary Innovator at Measurement Specialties, Inc., in the October 2005 edition of the AES Journal. Figs. 4 and 5 below, also from this paper, are illustrations of test setups referred to in this paper. Specifically, Fig. 4 is a test setup used to measure the transmission (of an incident ultrasonic sound wave) through the acoustic filter described by Figs. 1 and 2. Fig. 5 is a block diagram of the test setup used for measuring radiation pressure, one of the audio effects mentioned in the previous section. It turns out that out of all of the audio effects mentioned in the previous section that are caused by high-intensity ultrasonic waves propagating in a medium, sound waves produced from radiated pressure are the hardest to detect when microphones and preamplifiers are used in the detection/receiver system. Although nonlinear noise artifacts occur due to overloading of

2 <http://en.wikibooks.org/wiki/>

3 <http://web.ics.purdue.edu/~vgant/AcousticFilterPaper.pdf>

the preamplifier present in the detection/receiver system, the bulk of the nonlinear noise comes from the inherent nonlinear noise properties of microphones. This is true because all microphones, even specialized measurement microphones designed for audio spectrum measurements that have sensitivity well beyond the threshold of hearing, have nonlinearities artifacts that (periodically) increase in magnitude with respect to increase at ultrasonic frequencies. These nonlinearities essentially mask the radiation pressure generated because the magnitude of these nonlinearities are orders of magnitude greater than the radiation pressure. The acoustic (low-pass) filter referred to in this paper was designed in order to filter out the "detrimental" ultrasonic wave that was inducing high nonlinear noise artifacts in the measurement microphones. The high-intensity, ultrasonic wave was producing radiation pressure (which is audible) within the initial acoustic medium (i.e. air). By filtering out the ultrasonic wave, the measurement microphone would only detect the audible radiation pressure that the ultrasonic wave was producing in air. Acoustic filters like these could possibly be used to detect/receive any high-intensity, ultrasonic signal that may carry audio information which may need to be extrapolated with an acceptable level of fidelity.

18.6 References

- [1] Minoru Todo, "New Type of Acoustic Filter Using Periodic Polymer Layers for Measuring Audio Signal Components Excited by Amplitude-Modulated High-Intensity Ultrasonic Waves," *Journal of Audio Engineering Society*, Vol. 53, pp. 930-41 (2005 October)
- [2] *Fundamentals of Acoustics*; Kinsler et al, John Wiley & Sons, 2000
- [3] ME 513 Course Notes, Dr. Luc Mongeau, Purdue University
- [4] <http://www.ieee-uffc.org/archive/uffc/trans/Toc/abs/02/t0270972.htm>

Created by Valdez L. Gant

19 Noise in Hydraulic Systems




Figure 74

19.1 Noise in Hydraulic Systems

Hydraulic systems are the most preferred source of power transmission in most of the industrial and mobile equipments due to their power density, compactness, flexibility, fast response and efficiency. The field hydraulics and pneumatics is also known as 'Fluid Power Technology'. Fluid power systems have a wide range of applications which include industrial, off-road vehicles, automotive systems, and aircraft. But, one of the main problems with the hydraulic systems is the noise generated by them. The health and safety issues relating to noise have been recognized for many years and legislation is now placing clear demands on manufacturers to reduce noise levels [1]. Hence, noise reduction in hydraulic systems demands lot of attention from the industrial as well as academic researchers. It needs a good understanding of how the noise is generated and propagated in a hydraulic system in order to reduce it.

19.2 Sound in fluids

The speed of sound in fluids can be determined using the following relation.

$$c = \sqrt{\frac{K}{\rho}}$$

where K - fluid bulk modulus, ρ - fluid density, c - velocity of sound

Typical value of bulk modulus range from **2e9 to 2.5e9 N/m²**. For a particular oil, with a density of **889 kg/m³**,

speed of sound $c = \sqrt{\frac{2e9}{889}} = 1499.9m/s$

19.3 Source of Noise

The main source of noise in hydraulic systems is the pump which supplies the flow. Most of the pumps used are positive displacement pumps. Of the positive displacement pumps, axial piston swash plate type is mostly preferred due to their reliability and efficiency.

The noise generation in an axial piston pump can be classified under two categories (i) fluidborne noise and (ii) Structureborne noise

19.4 Fluidborne Noise (FBN)

Among the positive displacement pumps, highest levels of FBN are generated by axial piston pumps and lowest levels by screw pumps and in between these lie the external gear pump and vane pump [1]. The discussion in this page is mainly focused on **axial piston swash plate type pumps**. An axial piston pump has a fixed number of displacement chambers arranged in a circular pattern separated from each other by an angular pitch equal to $\phi = \frac{360}{n}$ where n is the number of displacement chambers. As each chamber discharges a specific volume of fluid, the discharge at the pump outlet is sum of all the discharge from the individual chambers. The discontinuity in flow between adjacent chambers results in a kinematic flow ripple. The amplitude of the kinematic ripple can be theoretical determined given the size of the pump and the number of displacement chambers. The kinematic ripple is the main cause of the fluidborne noise. The kinematic ripples is a theoretical value. The actual **flow ripple** at the pump outlet is much larger than the theoretical value because the **kinematic ripple** is combined with a **compressibility component** which is due to the fluid compressibility. These ripples (also referred as flow pulsations) generated at the pump are transmitted through the pipe or flexible hose connected to the pump and travel to all parts of the hydraulic circuit.

The pump is considered an ideal flow source. The pressure in the system will be decided by resistance to the flow or otherwise known as system load. The flow pulsations result in pressure pulsations. The pressure pulsations are superimposed on the mean system pressure. Both the **flow and pressure pulsations** easily travel to all part of the circuit and affect the performance of the components like control valve and actuators in the system and make the component vibrate, sometimes even resonate. This vibration of system components adds to the noise generated by the flow pulsations. The transmission of FBN in the circuit is discussed under transmission below.

A typical axial piston pump with 9 pistons running at 1000 rpm can produce a sound pressure level of more than 70 dBs.

19.5 Structureborne Noise (SBN)

In swash plate type pumps, the main sources of the structureborne noise are the fluctuating forces and moments of the swash plate. These fluctuating forces arise as a result of the varying pressure inside the displacement chamber. As the displacing elements move from suction stroke to discharge stroke, the pressure varies accordingly from few bars to few hundred bars. These pressure changes are reflected on the displacement elements (in this case, pistons) as forces and these force are exerted on the swash plate causing the swash plate to vibrate. This vibration of the swash plate is the main cause of **structureborne noise**. There are other components in the system which also vibrate and lead to structureborne noise, but the swash is the major contributor.




Figure 75

Fig. 1 shows an exploded view of axial piston pump. Also the flow pulsations and the oscillating forces on the swash plate, which cause FBN and SBN respectively are shown for one revolution of the pump.

19.6 Transmission

19.6.1 FBN

The transmission of FBN is a complex phenomenon. Over the past few decades, considerable amount of research had gone into mathematical modeling of pressure and flow transient in the circuit. This involves the solution of wave equations, with piping treated as a distributed parameter system known as a transmission line [1] & [3].

Lets consider a simple pump-pipe-loading valve circuit as shown in Fig. 2. The pressure and flow ripple at any location in the pipe can be described by the relations:

$$P = Ae^{-ikx} + Be^{+ikx}$$

.....(1)

$$Q = \frac{1}{Z_0}(Ae^{-ikx} - Be^{+ikx})$$

.....(2)

where A and B are frequency dependent complex coefficients which are directly proportional to pump (source) flow ripple, but also functions of the source impedance Z_s , characteristic impedance of the pipe Z_0 and the termination impedance Z_t . These impedances, usually vary as the system operating pressure and flow rate changes, can be determined experimentally.

For complex systems with several system components, the pressure and flow ripples are estimated using the transformation matrix approach. For this, the system components can be treated as lumped impedances (a throttle valve or accumulator), or distributed impedances (flexible hose or silencer). Various software packages are available today to predict the pressure pulsations.

19.6.2 SBN

The transmission of SBN follows the classic source-path-noise model. The vibrations of the swash plate, the main cause of SBN, are transferred to the pump casing which encloses all the rotating group in the pump including displacement chambers (also known as cylinder block), pistons, and the swash plate. The pump case, apart from vibrating itself, transfers the vibration down to the mount on which the pump is mounted. The mount then passes the vibrations down to the main mounted structure or the vehicle. Thus the SBN is transferred from the swash plate to the main structure or vehicle via pumpcasing and mount.

Some of the machine structures, along the path of transmission, are good at transmitting this vibrational energy and they even resonate and reinforce it. By converting only a fraction of 1% of the pump structureborne noise into sound, a member in the transmission path could radiate more ABN than the pump itself [4].

19.7 Airborne noise (ABN)

Both FBN and SBN , impart high fatigue loads on the system components and make them vibrate. All of these vibrations are radiated as **airborne noise** and can be heard by a human operator. Also, the flow and pressure pulsations make the system components such as a control valve to resonate. This vibration of the particular component again radiates airborne noise.

19.8 Noise reduction

The reduction of the noise radiated from the hydraulic system can be approached in two ways.

(i) **Reduction at Source** - which is the reduction of noise at the pump. A large amount of open literature are available on the reduction techniques with some techniques focusing on reducing FBN at source and others focusing on SBN. Reduction in FBN and SBN at the source has a large influence on the ABN that is radiated. Even though, a lot of progress had been made in reducing the FBN and SBN separately, the problem of noise in hydraulic systems is not fully solved and lot need to be done. The reason is that the FBN and SBN are interrelated, in a sense that, if one tried to reduce the FBN at the pump, it tends to affect the SBN characteristics. Currently, one of the main researches in noise reduction in pumps, is a systematic approach in understanding the coupling between FBN and SBN and targeting them simultaneously instead of treating them as two separate sources. Such an unified approach, demands not only well trained researchers but also sophisticated computer based mathematical model of the pump which can accurately output the necessary results for optimization of pump design. The amplitude of fluid pulsations can be reduced, at the source, with the use of an hydraulic attenuator(5).

(ii) **Reduction at Component level** - which focuses on the reduction of noise from individual component like hose, control valve, pump mounts and fixtures. This can be accomplished by a suitable design modification of the component so that it radiates least amount of noise. Optimization using computer based models can be one of the ways.

19.9 Hydraulic System noise




Figure 76

Fig.3 Domain of hydraulic system noise generation and transmission (Figure recreated from [1])

19.10 References

1. *Designing Quieter Hydraulic Systems - Some Recent Developments and Contributions*, Kevin Edge, 1999, Fluid Power: Forth JHPS International Symposium.
2. *Fundamentals of Acoustics* L.E. Kinsler, A.R. Frey, A.B.Coppens, J.V. Sanders. Fourth Edition. John Wiley & Sons Inc.
3. *Reduction of Axial Piston Pump Pressure Ripple* A.M. Harrison. PhD thesis, University of Bath. 1997
4. *Noise Control of Hydraulic Machinery* Stan Skaistis, 1988. MARCEL DEKKER , INC.
- 5 *Hydraulic Power System Analysis*, A. Akers, M. Gassman, & R. Smith, Taylor & Francis, New York, 2006, ISBN: 0-8247-9956-9

20 Noise from Cooling Fans



Figure 77

20.1 Proposal

As electric/electronic devices get smaller and functional, the noise of cooling device becomes important. This page will explain the origins of noise generation from small axial cooling fans used in electronic goods like desktop/laptop computers. The source of fan noises includes aerodynamic noise as well as operating sound of the fan itself. This page will be focused on the aerodynamic noise generation mechanisms.

20.2 Introduction

If one opens a desktop computer, they may find three (or more) fans. For example, a fan is typically found on the heat sink of the CPU, in the back panel of the power supply unit, on the case ventilation hole, on the graphics card, and even on the motherboard chipset if it is a recent one. Computer noise which annoys many people is mostly due to cooling fans, if the hard drive(s) is fairly quiet. When Intel Pentium processors were first introduced, there was no need to have a fan on the CPU, however, contemporary CPUs cannot function even for several seconds without a cooling fan. As CPU densities increase, the heat transfer for nominal operation requires increased airflow, which causes more and more noise. The type of fans commonly used in desktop computers are axial fans, and centrifugal blowers in

laptop computers. Several fan types are shown here (pdf format)¹. Different fan types have different characteristics of noise generation and performance. The axial flow fan is mainly considered in this page.

20.3 Noise Generation Mechanisms

The figure below shows a typical noise spectrum of a 120 mm diameter electronic device cooling fan. One microphone was used at a point 1 m from the upstream side of the fan. The fan has 7 blades, 4 struts for motor mounting and operates at 13V. Certain amount of load is applied. The blue plot is background noise of anechoic chamber, and the green one is sound loudness spectrum when the fan is running.




Figure 78

(*BPF = Blade Passing Frequency)

1 <http://www.etrinet.com/tech/pdf/aerodynamics.pdf>

Each noise elements shown in this figure is caused by one or more of following generation mechanisms.

20.3.1 Blade Thickness Noise - Monopole (But very weak)

Blade thickness noise is generated by volume displacement of fluid. A fan blade has its thickness and volume. As the rotor rotates, the volume of each blade displaces fluid volume, then they consequently fluctuate pressure of near field, and noise is generated. This noise is tonal at the running frequency and generally very weak for cooling fans, because their RPM is relatively low. Therefore, thickness of fan blades hardly affects to electronic cooling fan noise.

(This kind of noise can become severe for high speed turbomachines like helicopter rotors.)

20.3.2 Tonal Noise by Aerodynamic Forces - Dipole

Uniform Inlet Flow (Negligible)

The sound generation due to uniform and steady aerodynamic force has a characteristic very similar to the blade thickness noise. It is very weak for low speed fans, and depends on fan RPM. Since some steady blade forces are necessary for a fan to do its duty even in an ideal condition, this kind of noise is impossible to avoid. It is known that this noise can be reduced by increasing the number of blades.

Non-uniform Inlet Flow

Non-uniform (still steady) inlet flow causes non-uniform aerodynamic forces on blades as their angular positions change. This generates noise at blade passing frequency and its harmonics. It is one of the major noise sources of electronic cooling fans.

Rotor-Casing interaction

If the fan blades are very close to a structure which is not symmetric, unsteady interaction forces to blades are generated. Then the fan experiences a similar running condition as lying in non-uniform flow field. See Acoustics/Rotor Stator Interactions² for details.

Impulsive Noise (Negligible)

This noise is caused by the interaction between a blade and blade-tip-vortex of the preceding blade, and not severe for cooling fans.

² <http://en.wikibooks.org/wiki/Acoustics%2FRotor%20Stator%20Interactions>

Rotating Stall

Click here³ to read the definition and an aerodynamic description of **stall**.

The noise due to stall is a complex phenomenon that occurs at low flow rates. For some reason, if flow is locally disturbed, it can cause stall on one of the blades. As a result, the upstream passage on this blade is partially blocked. Therefore, the mean flow is diverted away from this passage. This causes increasing of the angle of attack on the closest blade at the upstream side of the originally stalled blade, the flow is again stalled there. On the other hand, the other side of the first blade is un-stalled because of reduction of flow angle.




Figure 79

repeatedly, the stall cell turns around the blades at about 30~50% of the running frequency, and the direction is opposite to the blades. This series of phenomenon causes unsteady blade forces, and consequently generates noise and vibrations.

³ http://en.wikipedia.org/wiki/Stall_%2528flight%2529

Non-uniform Rotor Geometry

Asymmetry of rotor causes noise at the rotating frequency and its harmonics (not blade passing frequency obviously), even when the inlet flow is uniform and steady.

Unsteady Flow Field

Unsteady flow causes random forces on the blades. It spreads the discrete spectrum noises and makes them continuous. In case of low-frequency variation, the spread continuous spectral noise is around rotating frequency, and narrowband noise is generated. The stochastic velocity fluctuations of inlet flow generates broadband noise spectrum. The generation of random noise components is covered by the following sections.

20.3.3 Random Noise by Unsteady Aerodynamic Forces

Turbulent Boundary Layer

Even in the steady and uniform inlet flow, there exist random force fluctuations on the blades. That is from turbulent blade boundary layer. Some noise is generated for this reason, but dominant noise is produced by the boundary layer passing the blade trailing edge. The blade trailing edges scatter the non-propagating near-field pressure into a propagatable sound field.

Incident Turbulent

Velocity fluctuations of the intake flow with a stochastic time history generate random forces on blades, and a broadband spectrum noise.

Vortex Shedding

For some reason, a vortex can separate from a blade. Then the circulating flow around the blade starts to be changed. This causes non-uniform forces on blades, and noises. A classical example for this phenomenon is 'Karman vortex street'⁴. (some images and animations⁵.) Vortex shedding mechanism can occur in a laminar boundary layer of low speed fan and also in a turbulent boundary layer of high frequency fan.

Flow Separation

Flow separation causes stall explained above. This phenomenon can cause random noise, which spreads all the discrete spectrum noises, and turns the noise into broadband.

4 <http://www.galleryoffluidmechanics.com/vortex/karman.htm>

5 <http://www2.icfd.co.jp/menu1/karmanvortex/karman.html>

Tip Vortex

Since cooling fans are ducted axial flow machines, the annular gap between the blade tips and the casing is important parameter for noise generation. While rotating, there is another flow through the annular gap due to pressure difference between upstream and downstream of fan. Because of this flow, tip vortex is generated through the gap, and broadband noise increases as the annular gap gets bigger.

20.4 Installation Effects

Once a fan is installed, even though the fan is well designed acoustically, unexpected noise problem can come up. It is called as installation effects, and two types are applicable to cooling fans.

20.4.1 Effect of Inlet Flow Conditions

A structure that affects the inlet flow of a fan causes installation effects. For example Hoppe & Neise [3] showed that with and without a bellmouth nozzle at the inlet flange of 500mm fan can change the noise power by 50dB (This application is for much larger and noisier fan though).

20.4.2 Acoustic Loading Effect

This effect is shown on duct system applications. Some high performance graphic cards apply duct system for direct exhaustion.

The sound power generated by a fan is not only a function of its impeller speed and operating condition, but also depends on the acoustic impedances of the duct systems connected to its inlet and outlet. Therefore, fan and duct system should be matched not only for aerodynamic noise reasons but also because of acoustic considerations.

20.5 Closing Comment

Noise reduction of cooling fans has some restrictions:

1. Active noise control is not economically effective. 80mm cooling fans are only 5~10 US dollars. It is only applicable for high-end electronic products.
2. Restricting certain aerodynamic phenomenon for noise reduction can cause serious performance reduction of the fan. Increasing RPM of the fan is of course much more dominant factor for noise.

Different stories of fan noise are introduced at some of the linked sites below like active RPM control or noise comparison of various bearings used in fans. If blade passing noise is dominant, a muffler would be beneficial.

20.6 Links to Interesting Sites about Fan Noise

Some practical issue of PC noise are presented at the following sites.

Cooling Fan Noise Comparison - Sleeve Bearing vs. Ball Bearing (pdf format)⁶

Brief explanation of fan noise origins and noise reduction suggestions⁷

Effect of sweep angle comparison⁸

Comparisons of noise from various 80mm fans⁹

Noise reduction of a specific desktop case¹⁰

Noise reduction of another specific desktop case¹¹

Informal study for noise from CPU cooling fan¹²

Informal study for noise from PC case fans¹³

Active fan speed optimizators for minimum noise from desktop computers¹⁴

- Some general fan noise reduction techniques¹⁵
- Brüel & Kjær - acoustic testing device company. Various applications are presented in "applications" tap¹⁶
- "Fan Noise Solutions"¹⁷ by cpemma

6 http://www.silentpcreview.com/files/ball_vs_sleeve_bearing.pdf

7 http://www.jmcproducts.com/cooling_info/noise.shtml

8 <http://www.ansys.com/industries/tm-fan-noise.htm>

9 <http://www.directron.com/noise.html>

10 http://www.xlr8yourmac.com/G4ZONE/G4_fan_noise.html

11 http://www.xlr8yourmac.com/systems/quicksilver_noise/quieting_quicksilver_noise.html

12 <http://www.roberthancock.com/dell/fannoise.htm>

13 <http://www.cpemma.co.uk/>

14 http://www.tomshardware.com/2004/06/15/fighting_fan_noise_pollution/index.html

15 <http://www.diracdelta.co.uk/science/source/f/a/fan%20noise/source.html>

16 <http://www.bkhome.com/>

17 <http://cpemma.co.uk/>

- [How To Build A Computer/Quiet PC](http://en.wikibooks.org/wiki/How_to_Build_a_Computer/Quiet_PC)¹⁸

20.7 References

- [1] Neise, W., and Michel, U., "Aerodynamic Noise of Turbomachines"
- [2] Anderson, J., "Fundamentals of Aerodynamics", 3rd edition, 2001, McGrawHill
- [3] Hoppe, G., and Neise, W., "Vergleich verschiedener Gerauschmessverfahren für Ventilatoren. Forschungsbericht FLT 3/1/31/87, Forschungsvereinigung für Luft- und Trocknungstechnik e. V., Frankfurt/Main, Germany"

¹⁸ http://en.wikibooks.org/wiki/How_to_Build_a_Computer/Quiet_PC

21 Piezoelectric Transducers



Figure 80

22 Introduction

Piezoelectricity from the Greek word "piezo" means pressure electricity. Certain crystalline substances generate electric charges under mechanical stress and conversely experience a mechanical strain in the presence of an electric field. The piezoelectric effect describes a situation where the transducing material senses input mechanical vibrations and produces a charge at the frequency of the vibration. An AC voltage causes the piezoelectric material to vibrate in an oscillatory fashion at the same frequency as the input current.

Quartz is the best known single crystal material with piezoelectric properties. Strong piezoelectric effects can be induced in materials with an ABO_3 , Perovskite crystalline structure. 'A' denotes a large divalent metal ion such as lead and 'B' denotes a smaller tetravalent ion such as titanium or zirconium.

For any crystal to exhibit the piezoelectric effect, its structure must have no center of symmetry. Either a tensile or compressive stress applied to the crystal alters the separation between positive and negative charge sites in the cell causing a net polarization at the surface of the crystal. The polarization varies directly with the applied stress and is direction dependent so that compressive and tensile stresses will result in electric fields of opposite voltages.

23 Vibrations & Displacements

Piezoelectric ceramics have non-centrosymmetric unit cells below the Curie temperature and centrosymmetric unit cells above the Curie temperature. Non-centrosymmetric structures provide a net electric dipole moment. The dipoles are randomly oriented until a strong DC electric field is applied causing permanent polarization and thus piezoelectric properties.

A polarized ceramic may be subjected to stress causing the crystal lattice to distort changing the total dipole moment of the ceramic. The change in dipole moment due to an applied stress causes a net electric field which varies linearly with stress.

24 Dynamic Performance

The dynamic performance of a piezoelectric material relates to how it behaves under alternating stresses near the mechanical resonance. The parallel combination of C2 with L1, C1, and R1 in the equivalent circuit below control the transducers reactance which is a function of frequency.

24.1 Equivalent Electric Circuit

24.2 Frequency Response

The graph below shows the impedance of a piezoelectric transducer as a function of frequency. The minimum value at f_n corresponds to the resonance while the maximum value at f_m corresponds to anti-resonance. ^{Superscript text}*Italic text*

25 Resonant Devices

Non resonant devices may be modeled by a capacitor representing the capacitance of the piezoelectric with an impedance modeling the mechanically vibrating system as a shunt in the circuit. The impedance may be modeled as a capacitor in the non resonant case which allows the circuit to reduce to a single capacitor replacing the parallel combination.

For resonant devices the impedance becomes a resistance or static capacitance at resonance. This is an undesirable effect. In mechanically driven systems this effect acts as a load on the transducer and decreases the electrical output. In electrically driven systems this effect shunts the driver requiring a larger input current. The adverse effect of the static capacitance experienced at resonant operation may be counteracted by using a shunt or series inductor resonating with the static capacitance at the operating frequency.

26 Applications

26.1 Mechanical Measurement

Because of the dielectric leakage current of piezoelectrics they are poorly suited for applications where force or pressure have a slow rate of change. They are, however, very well suited for highly dynamic measurements that might be needed in blast gauges and accelerometers.

26.2 Ultrasonic

High intensity ultrasound applications utilize half wavelength transducers with resonant frequencies between 18 kHz and 45 kHz. Large blocks of transducer material is needed to generate high intensities which makes manufacturing difficult and is economically impractical. Also, since half wavelength transducers have the highest stress amplitude in the center the end sections act as inert masses. The end sections are often replaced with metal plates possessing a much higher mechanical quality factor giving the composite transducer a higher mechanical quality factor than a single-piece transducer.

The overall electro-acoustic efficiency is:

Q_{m0} = unloaded mechanical quality factor
 Q_E = electric quality factor
 Q_L = quality factor due to the acoustic load alone

The second term on the right hand side is the dielectric loss and the third term is the mechanical loss.

Efficiency is maximized when:

then: $\eta_{\max} = 1 - \frac{2}{k_{\text{eff}}\sqrt{Q_E Q_{m0}}} \quad (k_{\text{eff}}\sqrt{Q_E Q_{m0}} \ll 1)$

The maximum ultrasonic efficiency is described by: $I_{w\max} = \frac{1}{2}(\omega_5 u_l)_{\max}^2 \rho_{mw} \nu_w (W/m^2)$

Applications of ultrasonic transducers include:

Welding of plastics
Atomization of liquids
Ultrasonic drilling
Ultrasonic cleaning
Ultrasonic foils in the paper machine wet end for more uniform fibre distribution
Ultrasound
Non-destructive testing
etc.

27 More Information and Source of Information

MorganElectroCeramics¹

Ultra Technology²

1 <http://morganelectroceramics.com>

2 <http://www.ultratechnology.se>

28 Contributors

Edits	User
1	A7N8X ¹
32	Adrignola ²
2	Alejo2083 ³
4	Avicennasis ⁴
1	BenTels ⁵
1	Blubricks ⁶
3	Boehm ⁷
73	Booby ⁸
1	Bpuklich ⁹
1	Brunz ¹⁰
1	Darklama ¹¹
2	Dbolton ¹²
2	Derbeth ¹³
2	Dirk Hünninger ¹⁴
1	Egmason ¹⁵
8	Erusse estelinya ¹⁶
1	Ewen ¹⁷
4	GianniG46 ¹⁸
1	Gks ¹⁹
14	Hagindaz ²⁰
1	Herbythyme ²¹

-
- 1 <http://en.wikibooks.org/w/index.php?title=User:A7N8X>
 - 2 <http://en.wikibooks.org/w/index.php?title=User:Adrignola>
 - 3 <http://en.wikibooks.org/w/index.php?title=User:Alejo2083>
 - 4 <http://en.wikibooks.org/w/index.php?title=User:Avicennasis>
 - 5 <http://en.wikibooks.org/w/index.php?title=User:BenTels>
 - 6 <http://en.wikibooks.org/w/index.php?title=User:Blubricks>
 - 7 <http://en.wikibooks.org/w/index.php?title=User:Boehm>
 - 8 <http://en.wikibooks.org/w/index.php?title=User:Booby>
 - 9 <http://en.wikibooks.org/w/index.php?title=User:Bpuklich>
 - 10 <http://en.wikibooks.org/w/index.php?title=User:Brunz>
 - 11 <http://en.wikibooks.org/w/index.php?title=User:Darklama>
 - 12 <http://en.wikibooks.org/w/index.php?title=User:Dbolton>
 - 13 <http://en.wikibooks.org/w/index.php?title=User:Derbeth>
 - 14 http://en.wikibooks.org/w/index.php?title=User:Dirk_H%C3%BCnniger
 - 15 <http://en.wikibooks.org/w/index.php?title=User:Egmason>
 - 16 http://en.wikibooks.org/w/index.php?title=User:Erusse_estelinya
 - 17 <http://en.wikibooks.org/w/index.php?title=User:Ewen>
 - 18 <http://en.wikibooks.org/w/index.php?title=User:GianniG46>
 - 19 <http://en.wikibooks.org/w/index.php?title=User:Gks>
 - 20 <http://en.wikibooks.org/w/index.php?title=User:Hagindaz>
 - 21 <http://en.wikibooks.org/w/index.php?title=User:Herbythyme>

16 Inhuman14²²
4 J Park²³
1 Jechasteen²⁴
37 Jguk²⁵
5 Jomegat²⁶
1 Jpginn²⁷
1 Netspin²⁸
6 QuiteUnusual²⁹
2 Reece³⁰
5 Remimais³¹
1 Sethwoodworth³²
3 Siddharthpramod³³
1 Sigma 7³⁴
15 Tannersf³⁵
1 Tbackstr³⁶
2 Thenub314³⁷
3 TreborA³⁸
1 Trotskylite³⁹
1 Vancegloster⁴⁰
3 Voxhumana⁴¹
3 WP137⁴²
10 Webaware⁴³
1 Xania⁴⁴

22 <http://en.wikibooks.org/w/index.php?title=User:Inhuman14>
23 http://en.wikibooks.org/w/index.php?title=User:J_Park
24 <http://en.wikibooks.org/w/index.php?title=User:Jechasteen>
25 <http://en.wikibooks.org/w/index.php?title=User:Jguk>
26 <http://en.wikibooks.org/w/index.php?title=User:Jomegat>
27 <http://en.wikibooks.org/w/index.php?title=User:Jpginn>
28 <http://en.wikibooks.org/w/index.php?title=User:Netspin>
29 <http://en.wikibooks.org/w/index.php?title=User:QuiteUnusual>
30 <http://en.wikibooks.org/w/index.php?title=User:Reece>
31 <http://en.wikibooks.org/w/index.php?title=User:Remimais>
32 <http://en.wikibooks.org/w/index.php?title=User:Sethwoodworth>
33 <http://en.wikibooks.org/w/index.php?title=User:Siddharthpramod>
34 http://en.wikibooks.org/w/index.php?title=User:Sigma_7
35 <http://en.wikibooks.org/w/index.php?title=User:Tannersf>
36 <http://en.wikibooks.org/w/index.php?title=User:Tbackstr>
37 <http://en.wikibooks.org/w/index.php?title=User:Thenub314>
38 <http://en.wikibooks.org/w/index.php?title=User:TreborA>
39 <http://en.wikibooks.org/w/index.php?title=User:Trotskylite>
40 <http://en.wikibooks.org/w/index.php?title=User:Vancegloster>
41 <http://en.wikibooks.org/w/index.php?title=User:Voxhumana>
42 <http://en.wikibooks.org/w/index.php?title=User:WP137>
43 <http://en.wikibooks.org/w/index.php?title=User:Webaware>
44 <http://en.wikibooks.org/w/index.php?title=User:Xania>

List of Figures

- GFDL: Gnu Free Documentation License. <http://www.gnu.org/licenses/fdl.html>
- cc-by-sa-3.0: Creative Commons Attribution ShareAlike 3.0 License. <http://creativecommons.org/licenses/by-sa/3.0/>
- cc-by-sa-2.5: Creative Commons Attribution ShareAlike 2.5 License. <http://creativecommons.org/licenses/by-sa/2.5/>
- cc-by-sa-2.0: Creative Commons Attribution ShareAlike 2.0 License. <http://creativecommons.org/licenses/by-sa/2.0/>
- cc-by-sa-1.0: Creative Commons Attribution ShareAlike 1.0 License. <http://creativecommons.org/licenses/by-sa/1.0/>
- cc-by-2.0: Creative Commons Attribution 2.0 License. <http://creativecommons.org/licenses/by/2.0/>
- cc-by-2.0: Creative Commons Attribution 2.0 License. <http://creativecommons.org/licenses/by/2.0/deed.en>
- cc-by-2.5: Creative Commons Attribution 2.5 License. <http://creativecommons.org/licenses/by/2.5/deed.en>
- cc-by-3.0: Creative Commons Attribution 3.0 License. <http://creativecommons.org/licenses/by/3.0/deed.en>
- GPL: GNU General Public License. <http://www.gnu.org/licenses/gpl-2.0.txt>
- LGPL: GNU Lesser General Public License. <http://www.gnu.org/licenses/lgpl.html>
- PD: This image is in the public domain.
- ATTR: The copyright holder of this file allows anyone to use it for any purpose, provided that the copyright holder is properly attributed. Redistribution, derivative work, commercial use, and all other use is permitted.
- EURO: This is the common (reverse) face of a euro coin. The copyright on the design of the common face of the euro coins belongs to the European Commission. Authorised is reproduction in a format without relief (drawings, paintings, films) provided they are not detrimental to the image of the euro.
- LFK: Lizenz Freie Kunst. <http://artlibre.org/licence/lal/de>
- CFR: Copyright free use.

- EPL: Eclipse Public License. <http://www.eclipse.org/org/documents/epl-v10.php>

Copies of the GPL, the LGPL as well as a GFDL are included in chapter Licenses⁴⁵. Please note that images in the public domain do not require attribution. You may click on the image numbers in the following table to open the webpage of the images in your webbrowser.

⁴⁵ Chapter 29 on page 163

1	Original uploader was Booby ⁴⁶ at en.wikibooks ⁴⁷	PD
2	Original uploader was Booby ⁴⁸ at en.wikibooks ⁴⁹	PD
3	Original uploader was Booby ⁵⁰ at en.wikibooks ⁵¹	PD
4	Original uploader was Booby ⁵² at en.wikibooks ⁵³	PD
5	A7N8X ⁵⁴	cc-by-sa-3.0
6	Original uploader was Booby ⁵⁵ at en.wikibooks ⁵⁶	PD
7	Original uploader was Booby ⁵⁷ at en.wikibooks ⁵⁸	PD
8	Original uploader was Booby ⁵⁹ at en.wikibooks ⁶⁰	PD
9		PD
10		PD
11		PD
12		PD
13		PD
14		PD
15	Original uploader was Mpspence ⁶¹ at en.wikibooks ⁶²	PD
16		PD
17		PD
18		GFDL
19		PD
20		PD
21		PD
22		PD
23		PD
24		PD
25	Original uploader was Booby ⁶³ at en.wikibooks ⁶⁴	PD
26	Original uploader was Booby ⁶⁵ at en.wikibooks ⁶⁶	PD
27	Original uploader was Booby ⁶⁷ at en.wikibooks ⁶⁸	PD

46 <http://en.wikibooks.org/wiki/%3Awikibooks%3Aen%3AUser%3ABooby>

47 <http://en.wikibooks.org>

48 <http://en.wikibooks.org/wiki/%3Awikibooks%3Aen%3AUser%3ABooby>

49 <http://en.wikibooks.org>

50 <http://en.wikibooks.org/wiki/%3Awikibooks%3Aen%3AUser%3ABooby>

51 <http://en.wikibooks.org>

52 <http://en.wikibooks.org/wiki/%3Awikibooks%3Aen%3AUser%3ABooby>

53 <http://en.wikibooks.org>

54 <http://en.wikibooks.org/wiki/User%3AA7N8X>

55 <http://en.wikibooks.org/wiki/%3Awikibooks%3Aen%3AUser%3ABooby>

56 <http://en.wikibooks.org>

57 <http://en.wikibooks.org/wiki/%3Awikibooks%3Aen%3AUser%3ABooby>

58 <http://en.wikibooks.org>

59 <http://en.wikibooks.org/wiki/%3Awikibooks%3Aen%3AUser%3ABooby>

60 <http://en.wikibooks.org>

61 <http://en.wikibooks.org/wiki/%3Awikibooks%3Aen%3AUser%3AMpspence>

62 <http://en.wikibooks.org>

63 <http://en.wikibooks.org/wiki/%3Awikibooks%3Aen%3AUser%3ABooby>

64 <http://en.wikibooks.org>

65 <http://en.wikibooks.org/wiki/%3Awikibooks%3Aen%3AUser%3ABooby>

66 <http://en.wikibooks.org>

67 <http://en.wikibooks.org/wiki/%3Awikibooks%3Aen%3AUser%3ABooby>

68 <http://en.wikibooks.org>

28	Original uploader was Booby ⁶⁹ at en.wikibooks ⁷⁰	PD
29	Original uploader was Booby ⁷¹ at en.wikibooks ⁷²	PD
30	Original uploader was Booby ⁷³ at en.wikibooks ⁷⁴	PD
31		PD
32		PD
33		PD
34		PD
35		PD
36	Original uploader was Booby ⁷⁵ at en.wikibooks ⁷⁶	PD
37		PD
38		PD
39	Original uploader was Booby ⁷⁷ at en.wikibooks ⁷⁸	PD
40	Oarih ⁷⁹	GFDL
41	Original uploader was Booby ⁸⁰ at en.wikibooks ⁸¹	PD
42		GFDL
43		GFDL
44		GFDL
45	Original uploader was Booby ⁸² at en.wikibooks ⁸³	PD
46	Original uploader was Doktorcik ⁸⁴ at en.wikibooks ⁸⁵	GFDL
47		GFDL
48		GFDL
49		GFDL
50		GFDL
51		GFDL
52	Original uploader was Booby ⁸⁶ at en.wikibooks ⁸⁷	PD
53		GFDL
54		GFDL
55		GFDL
56		PD
57		GFDL
58		GFDL
59		GFDL
60		GFDL

- 69 <http://en.wikibooks.org/wiki/%3Awikibooks%3Aen%3AUser%3ABooby>
70 <http://en.wikibooks.org>
71 <http://en.wikibooks.org/wiki/%3Awikibooks%3Aen%3AUser%3ABooby>
72 <http://en.wikibooks.org>
73 <http://en.wikibooks.org/wiki/%3Awikibooks%3Aen%3AUser%3ABooby>
74 <http://en.wikibooks.org>
75 <http://en.wikibooks.org/wiki/%3Awikibooks%3Aen%3AUser%3ABooby>
76 <http://en.wikibooks.org>
77 <http://en.wikibooks.org/wiki/%3Awikibooks%3Aen%3AUser%3ABooby>
78 <http://en.wikibooks.org>
79 <http://en.wikibooks.org/wiki/User%3AOarih>
80 <http://en.wikibooks.org/wiki/%3Awikibooks%3Aen%3AUser%3ABooby>
81 <http://en.wikibooks.org>
82 <http://en.wikibooks.org/wiki/%3Awikibooks%3Aen%3AUser%3ABooby>
83 <http://en.wikibooks.org>
84 <http://en.wikibooks.org/wiki/%3Awikibooks%3Aen%3AUser%3ADoktorcik>
85 <http://en.wikibooks.org>
86 <http://en.wikibooks.org/wiki/%3Awikibooks%3Aen%3AUser%3ABooby>
87 <http://en.wikibooks.org>

61		PD
62		PD
63		PD
64		PD
65		PD
66		GFDL
67		PD
68		PD
69		PD
70		PD
71		PD
72		PD
73	Original uploader was Booby ⁸⁸ at en.wikibooks ⁸⁹	PD
74	Original uploader was Booby ⁹⁰ at en.wikibooks ⁹¹	PD
75		PD
76		PD
77	Original uploader was Booby ⁹² at en.wikibooks ⁹³	PD
78		GFDL
79		GFDL
80	Original uploader was Booby ⁹⁴ at en.wikibooks ⁹⁵	PD

88 <http://en.wikibooks.org/wiki/%3Awikibooks%3Aen%3AUser%3ABooby>

89 <http://en.wikibooks.org>

90 <http://en.wikibooks.org/wiki/%3Awikibooks%3Aen%3AUser%3ABooby>

91 <http://en.wikibooks.org>

92 <http://en.wikibooks.org/wiki/%3Awikibooks%3Aen%3AUser%3ABooby>

93 <http://en.wikibooks.org>

94 <http://en.wikibooks.org/wiki/%3Awikibooks%3Aen%3AUser%3ABooby>

95 <http://en.wikibooks.org>

29 Licenses

29.1 GNU GENERAL PUBLIC LICENSE

Version 3, 29 June 2007

Copyright © 2007 Free Software Foundation, Inc.
<<http://fsf.org/>>

Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed. Preamble

The GNU General Public License is a free, copyleft license for software and other kinds of works.

The licenses for most software and other practical works are designed to take away your freedom to share and change the works. By contrast, the GNU General Public License is intended to guarantee your freedom to share and change all versions of a program—to make sure it remains free software for all its users. We, the Free Software Foundation, use the GNU General Public License for most of our software; it applies also to any other work released this way by its authors. You can apply it to your programs, too.

When we speak of free software, we are referring to freedom, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for them if you wish), that you receive source code or can get it if you want it, that you can change the software or use pieces of it in new free programs, and that you know you can do these things.

To protect your rights, we need to prevent others from denying you these rights or asking you to surrender the rights. Therefore, you have certain responsibilities if you distribute copies of the software, or if you modify it: responsibilities to respect the freedom of others.

For example, if you distribute copies of such a program, whether gratis or for a fee, you must pass on to the recipients the same freedoms that you received. You must make sure that they, too, receive or can get the source code. And you must show them these terms so they know their rights.

Developers that use the GNU GPL protect your rights with two steps: (1) assert copyright on the software, and (2) offer you this License giving you legal permission to copy, distribute and/or modify it.

For the developers' and authors' protection, the GPL clearly explains that there is no warranty for this free software. For both users' and authors' sake, the GPL requires that modified versions be marked as changed, so that their problems will not be attributed erroneously to authors of previous versions.

Some devices are designed to deny users access to install or run modified versions of the software inside them, although the manufacturer can do so. This is fundamentally incompatible with the aim of protecting users' freedom to change the software. The systematic pattern of such abuse occurs in the area of products for individuals to use, which is precisely where it is most unacceptable. Therefore, we have designed this version of the GPL to prohibit the practice for those products. If such problems arise substantially in other domains, we stand ready to extend this provision to those domains in future versions of the GPL, as needed to protect the freedom of users.

Finally, every program is threatened constantly by software patents. States should not allow patents to restrict development and use of software on general-purpose computers, but in those that do, we wish to avoid the special danger that patents applied to a free program could make it effectively proprietary. To prevent this, the GPL assures that patents cannot be used to render the program non-free.

The precise terms and conditions for copying, distribution and modification follow. TERMS AND CONDITIONS 0. Definitions.

"This License" refers to version 3 of the GNU General Public License.

"Copyright" also means copyright-like laws that apply to other kinds of works, such as semiconductor masks.

"The Program" refers to any copyrightable work licensed under this License. Each licensee is addressed as "you". "Licensees" and "recipients" may be individuals or organizations.

To "modify" a work means to copy from or adapt all or part of the work in a fashion requiring copyright permission, other than the making of an exact copy. The resulting work is called a "modified version" of the earlier work or a work "based on" the earlier work.

A "covered work" means either the unmodified Program or a work based on the Program.

To "propagate" a work means to do anything with it that, without permission, would make you directly or secondarily liable for infringement under applicable copyright law, except executing it on a computer or modifying a private copy. Propagation includes copying, distribution (with or without modification), making available to the public, and in some countries other activities as well.

To "convey" a work means any kind of propagation that enables other parties to make or receive copies. Mere interaction with a user through a computer

network, with no transfer of a copy, is not conveying.

An interactive user interface displays "Appropriate Legal Notices" to the extent that it includes a convenient and prominently visible feature that (1) displays an appropriate copyright notice, and (2) tells the user that there is no warranty for the work (except to the extent that warranties are provided), that licensees may convey the work under this License, and how to view a copy of this License. If the interface presents a list of user commands or options, such as a menu, a prominent item in the list meets this criterion. 1. Source Code.

The "source code" for a work means the preferred form of the work for making modifications to it. "Object code" means any non-source form of a work.

A "Standard Interface" means an interface that either is an official standard defined by a recognized standards body, or, in the case of interfaces specified for a particular programming language, one that is widely used among developers working in that language.

The "System Libraries" of an executable work include anything, other than the work as a whole, that (a) is included in the normal form of packaging a Major Component, but which is not part of that Major Component, and (b) serves only to enable use of the work with that Major Component, or to implement a Standard Interface for which an implementation is available to the public in source code form. A "Major Component", in this context, means a major essential component (kernel, window system, and so on) of the specific operating system (if any) on which the executable work runs, or a compiler used to produce the work, or an object code interpreter used to run it.

The "Corresponding Source" for a work in object code form means all the source code needed to generate, install, and (for an executable work) run the object code and to modify the work, including scripts to control those activities. However, it does not include the work's System Libraries, or general-purpose tools or generally available free programs which are used unmodified in performing those activities but which are not part of the work. For example, Corresponding Source includes interface definition files associated with source files for the work, and the source code for shared libraries and dynamically linked subprograms that the work is specifically designed to require, such as by intimate data communication or control flow between those subprograms and other parts of the work.

The Corresponding Source need not include anything that users can regenerate automatically from other parts of the Corresponding Source.

The Corresponding Source for a work in source code form is that same work. 2. Basic Permissions.

All rights granted under this License are granted for the term of copyright on the Program, and are irrevocable provided the stated conditions are met. This License explicitly affirms your unlimited permission to run the unmodified Program. The output from running a covered work is covered by this License only if the output, given its content, constitutes a covered work. This License acknowledges your rights of fair use or other equivalent, as provided by copyright law.

You may make, run and propagate covered works that you do not convey, without conditions so long as your license otherwise remains in force. You may convey covered works to others for the sole purpose of having them make modifications exclusively for you, or provide you with facilities for running those works, provided that you comply with the terms of this License in conveying all material for which you do not control copyright. Those thus making or running the covered works for you must do so exclusively on your behalf, under your direction and control, on terms that prohibit them from making any copies of your copyrighted material outside their relationship with you.

Conveying under any other circumstances is permitted solely under the conditions stated below. Sublicensing is not allowed; section 10 makes it unnecessary. 3. Protecting Users' Legal Rights From Anti-Circumvention Law.

No covered work shall be deemed part of an effective technological measure under any applicable law fulfilling obligations under article 11 of the WIPO copyright treaty adopted on 20 December 1996, or similar laws prohibiting or restricting circumvention of such measures.

When you convey a covered work, you waive any legal power to forbid circumvention of technological measures to the extent such circumvention is effected by exercising rights under this License with respect to the covered work, and you disclaim any intention to limit operation or modification of the work as a means of enforcing, against the work's users, your or third parties' legal rights to forbid circumvention of technological measures. 4. Conveying Verbatim Copies.

You may convey verbatim copies of the Program's source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice; keep intact all notices stating that this License and any non-permissive terms added in accord with section 7 apply to the code; keep intact all notices of the absence of any warranty; and give all recipients a copy of this License along with the Program.

You may charge any price or no price for each copy that you convey, and you may offer support or warranty protection for a fee. 5. Conveying Modified Source Versions.

You may convey a work based on the Program, or the modifications to produce it from the Program, in the form of source code under the terms of section 4, provided that you also meet all of these conditions:

* a) The work must carry prominent notices stating that you modified it, and giving a relevant date. * b) The work must carry prominent notices stating that it is released under this License and any conditions added under section 7. This requirement modifies the requirement in section 4 to "keep intact all notices". * c) You must license the entire work, as a whole, under this License to anyone who comes into possession of a copy. This License will therefore apply, along with any applicable section 7 additional terms, to the whole of the work, and all its parts, regardless of how they are packaged. This License gives no permission to license the work in any other way, but it does not invalidate such permission if you have separately received it. * d) If the work has interactive user interfaces, each must display Appropriate Legal Notices; however, if the Program has interactive interfaces that do not display Appropriate Legal Notices, your work need not make them do so.

A compilation of a covered work with other separate and independent works, which are not by their nature extensions of the covered work, and which are not combined with it such as to form a larger program, in or on a volume of a storage or distribution medium, is called an "aggregate" if the compilation and its resulting copyright are not used to limit the access or legal rights of the compilation's users beyond what the individual works permit. Inclusion of a covered work in an aggregate does not cause this License to apply to the other parts of the aggregate. 6. Conveying Non-Source Forms.

You may convey a covered work in object code form under the terms of sections 4 and 5, provided that you also convey the machine-readable Corresponding Source under the terms of this License, in one of these ways:

* a) Convey the object code in, or embodied in, a physical product (including a physical distribution medium), accompanied by the Corresponding Source fixed on a durable physical medium customarily used for software interchange. * b) Convey the object code in, or embodied in, a physical product (including a physical distribution medium), accompanied by a written offer, valid for at least three years and valid for as long as you offer spare parts or customer support for that product model, to give anyone who possesses the object code either (1) a copy of the Corresponding Source for all the software in the product that is covered by this License, on a durable physical medium customarily used for software interchange, for a price no more than your reasonable cost of physically performing this conveying of source, or (2) access to copy the Corresponding Source from a network server at no charge. * c) Convey individual copies of the object code with a copy of the written offer to provide the Corresponding Source. This alternative is allowed only occasionally and noncommercially, and only if you received the object code with such an offer, in accord with subsection 6b. * d) Convey the object code by offering access from a designated place (gratis or for a charge), and offer equivalent access to the Corresponding Source in the same way through the same place at no further charge. You need not require recipients to copy the Corresponding Source along with the object code. If the place to copy the object code is a network server, the Corresponding Source may be on a different server (operated by you or a third party) that supports equivalent copying facilities, provided you maintain clear directions next to the object code saying where to find the Corresponding Source. Regardless of what server hosts the Corresponding Source, you remain obligated to ensure that it is available for as long as needed to satisfy these requirements. * e) Convey the object code using peer-to-peer transmission, provided you inform other peers where the object code and Corresponding Source of the work are being offered to the general public at no charge under subsection 6d.

A separable portion of the object code, whose source code is excluded from the Corresponding Source as a System Library, need not be included in conveying the object code work.

A "User Product" is either (1) a "consumer product", which means any tangible personal property which is normally used for personal, family, or household purposes, or (2) anything designed or sold for incorporation into a dwelling. In determining whether a product is a consumer product, doubtful cases shall be resolved in favor of coverage. For a particular product received by a particular user, "normally used" refers to a typical or common use of that class of product, regardless of the status of the particular user or of the way in which the particular user actually uses, or expects or is expected to use, the product. A product is a consumer product regardless of whether the product has substantial commercial, industrial, or non-consumer uses, unless such uses represent the only significant mode of use of the product.

"Installation Information" for a User Product means any methods, procedures, authorization keys, or other information required to install and execute modified versions of a covered work in that User Product from a modified version of its Corresponding Source. The information must suffice to ensure that the continued functioning of the modified object code is in no case prevented or interfered with solely because modification has been made.

If you convey an object code work under this section in, or with, or specifically for use in, a User Product, and the conveying occurs as part of a transaction in which the right of possession and use of the User Product is transferred to the recipient in perpetuity or for a fixed term (regardless of how the transaction is characterized), the Corresponding Source conveyed under this section must be accompanied by the Installation Information. But this requirement does not apply if neither you nor any third party retains the ability to install modified object code on the User Product (for example, the work has been installed in ROM).

The requirement to provide Installation Information does not include a requirement to continue to provide support service, warranty, or updates for a work that has been modified or installed by the recipient, or for the User Product in which it has been modified or installed. Access to a network may be denied when the modification itself materially and adversely affects the operation of the network or violates the rules and protocols for communication across the network.

Corresponding Source conveyed, and Installation Information provided, in accord with this section must be in a format that is publicly documented (and with an implementation available to the public in source code form), and must require no special password or key for unpacking, reading or copying. 7. Additional Terms.

"Additional permissions" are terms that supplement the terms of this License by making exceptions from one or more of its conditions. Additional permissions that are applicable to the entire Program shall be treated as though they were included in this License, to the extent that they are valid under applicable law. If additional permissions apply only to part of the Program, that part may be used separately under those permissions, but the entire Program remains governed by this License without regard to the additional permissions.

When you convey a copy of a covered work, you may at your option remove any additional permissions from that copy, or from any part of it. (Additional permissions may be written to require their own removal in certain cases when you modify the work.) You may place additional permissions on material, added by you to a covered work, for which you have or can give appropriate copyright permission.

Notwithstanding any other provision of this License, for material you add to a covered work, you may (if authorized by the copyright holders of that material) supplement the terms of this License with terms:

* a) Disclaiming warranty or limiting liability differently from the terms of sections 15 and 16 of this License; or * b) Requiring preservation of specified reasonable legal notices or author attributions in that material or in the Appropriate Legal Notices displayed by works containing it; or * c) Prohibiting misrepresentation of the origin of that material, or requiring that modified versions of such material be marked in reasonable ways as different from the original version; or * d) Limiting the use for publicity purposes of names of licensors or authors of the material; or * e) Declining to grant rights under trademark law for use of some trade names, trademarks, or service marks; or * f) Requiring indemnification of licensors and authors of that material by anyone who conveys the material (or modified versions of it) with contractual assumptions of liability to the recipient, for any liability that these contractual assumptions directly impose on those licensors and authors.

All other non-permissive additional terms are considered "further restrictions" within the meaning of section 10. If the Program as you received it, or any part of it, contains a notice stating that it is governed by this License along with a term that is a further restriction, you may remove that term. If a license document contains a further restriction but permits relicensing or conveying under this License, you may add to a covered work material governed by the terms of that license document, provided that the further restriction does not survive such relicensing or conveying.

If you add terms to a covered work in accord with this section, you must place, in the relevant source files, a statement of the additional terms that apply to those files, or a notice indicating where to find the applicable terms.

Additional terms, permissive or non-permissive, may be stated in the form of a separately written license, or stated as exceptions; the above requirements apply either way. 8. Termination.

You may not propagate or modify a covered work except as expressly provided under this License. Any attempt otherwise to propagate or modify it is void, and will automatically terminate your rights under this License (including any patent licenses granted under the third paragraph of section 11).

However, if you cease all violation of this License, then your license from a particular copyright holder is reinstated (a) provisionally, unless and until the copyright holder explicitly and finally terminates your license, and (b) permanently, if the copyright holder fails to notify you of the violation by some reasonable means prior to 60 days after the cessation.

Moreover, your license from a particular copyright holder is reinstated permanently if the copyright holder notifies you of the violation by some reasonable means, this is the first time you have received notice of violation of this License (for any work)

from that copyright holder, and you cure the violation prior to 30 days after your receipt of the notice.

Termination of your rights under this section does not terminate the licenses of parties who have received copies or rights from you under this License. If your rights have been terminated and not permanently reinstated, you do not qualify to receive new licenses for the same material under section 10. 9. Acceptance Not Required for Having Copies.

You are not required to accept this License in order to receive or run a copy of the Program. Ancillary propagation of a covered work occurring solely as a consequence of using peer-to-peer transmission to receive a copy likewise does not require acceptance. However, nothing other than this License grants you permission to propagate or modify any covered work. These actions infringe copyright if you do not accept this License. Therefore, by modifying or propagating a covered work, you indicate your acceptance of this License to do so. 10. Automatic Licensing of Downstream Recipients.

Each time you convey a covered work, the recipient automatically receives a license from the original licensors, to run, modify and propagate that work, subject to this License. You are not responsible for enforcing compliance by third parties with this License.

An "entity transaction" is a transaction transferring control of an organization, or substantially all assets of one, or subdividing an organization, or merging organizations. If propagation of a covered work results from an entity transaction, each party to that transaction who receives a copy of the work also receives whatever licenses to the work the party's predecessor in interest had or could give under the previous paragraph, plus a right to possession of the Corresponding Source of the work from the predecessor in interest if the predecessor has it or can get it with reasonable efforts.

You may not impose any further restrictions on the exercise of the rights granted or affirmed under this License. For example, you may not impose a license fee, royalty, or other charge for exercise of rights granted under this License, and you may not initiate litigation (including a cross-claim or counterclaim in a lawsuit) alleging that any patent claim is infringed by making, using, selling, offering for sale, or importing the Program or any portion of it. 11. Patents.

A "contributor" is a copyright holder who authorizes use under this License of the Program or a work on which the Program is based. The work thus licensed is called the contributor's "contributor version".

A contributor's "essential patent claims" are all patent claims owned or controlled by the contributor, whether already acquired or hereafter acquired, that would be infringed by some manner, permitted by this License, of making, using, or selling its contributor version, but do not include claims that would be infringed only as a consequence of further modification of the contributor version. For purposes of this definition, "control" includes the right to grant patent sublicenses in a manner consistent with the requirements of this License.

Each contributor grants you a non-exclusive, worldwide, royalty-free patent license under the contributor's essential patent claims, to make, use, sell, offer for sale, import and otherwise run, modify and propagate the contents of its contributor version.

29.2 GNU Free Documentation License

Version 1.3, 3 November 2008

Copyright © 2000, 2001, 2002, 2007, 2008 Free Software Foundation, Inc. <<http://fsf.org/>>

Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed. 0. PREAMBLE

The purpose of this License is to make a manual, textbook, or other functional and useful document "free" in the sense of freedom: to assure everyone the effective freedom to copy and redistribute it, with or without modifying it, either commercially or noncommercially. Secondly, this License preserves for the author and publisher a way to get credit for their work, while not being considered responsible for modifications made by others.

This License is a kind of "copyleft", which means that derivative works of the document must themselves be free in the same sense. It complements the GNU General Public License, which is a copyleft license designed for free software.

We have designed this License in order to use it for manuals for free software, because free software needs free documentation: a free program should come with manuals providing the same freedoms that the software does. But this License is not limited to software manuals; it can be used for any textual work, regardless of subject matter or whether it is published as a printed book. We recommend this License principally for works whose purpose is instruction or reference. 1. APPLICABILITY AND DEFINITIONS

This License applies to any manual or other work, in any medium, that contains a notice placed by the copyright holder saying it can be distributed under the terms of this License. Such a notice grants a world-wide, royalty-free license, unlimited in duration, to use that work under the conditions stated herein. The "Document", below, refers to any such manual or work. Any member of the public is a licensee, and is addressed as "you". You accept the license if you copy, modify or distribute the work in a way requiring permission under copyright law.

A "Modified Version" of the Document means any work containing the Document or a portion of it, either copied verbatim, or with modifications and/or translated into another language.

A "Secondary Section" is a named appendix or a front-matter section of the Document that deals exclusively with the relationship of the publishers or

In the following three paragraphs, a "patent license" is any express agreement or commitment, however denominated, not to enforce a patent (such as an express permission to practice a patent or covenant not to sue for patent infringement). To "grant" such a patent license to a party means to make such an agreement or commitment not to enforce a patent against the party.

If you convey a covered work, knowingly relying on a patent license, and the Corresponding Source of the work is not available for anyone to copy, free of charge and under the terms of this License, through a publicly available network server or other readily accessible means, then you must either (1) cause the Corresponding Source to be so available, or (2) arrange to deprive yourself of the benefit of the patent license for this particular work, or (3) arrange, in a manner consistent with the requirements of this License, to extend the patent license to downstream recipients. "Knowingly relying" means you have actual knowledge that, but for the patent license, your conveying the covered work in a country, or your recipient's use of the covered work in a country, would infringe one or more identifiable patents in that country that you have reason to believe are valid.

If, pursuant to or in connection with a single transaction or arrangement, you convey, or propagate by procuring conveyance of, a covered work, and grant a patent license to some of the parties receiving the covered work authorizing them to use, propagate, modify or convey a specific copy of the covered work, then the patent license you grant is automatically extended to all recipients of the covered work and works based on it.

A patent license is "discriminatory" if it does not include within the scope of its coverage, prohibits the exercise of, or is conditioned on, the exercise of one or more of the rights that are specifically granted under this License. You may not convey a covered work if you are a party to an arrangement with a third party that is in the business of distributing software, under which you make payment to the third party based on the extent of your activity of conveying the work, and under which the third party grants, to any of the parties who would receive the covered work from you, a discriminatory patent license (a) in connection with copies of the covered work conveyed by you (or copies made from those copies), or (b) primarily for and in connection with specific products or compilations that contain the covered work, unless you entered into that arrangement, or that patent license was granted, prior to 28 March 2007.

Nothing in this License shall be construed as excluding or limiting any implied license or other defenses to infringement that may otherwise be available to you under applicable patent law. 12. No Surrender of Others' Freedom.

If conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot convey a covered work so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not convey it at all. For example, if you agree to terms that obligate you to collect a royalty for further conveying from those to whom you convey the Program, the only way you could satisfy both those terms and this License would be to refrain entirely from conveying the Program. 13. Use with the GNU Affero General Public License.

authors of the Document to the Document's overall subject (or to related matters) and contains nothing that could fall directly within that overall subject (The Document is in part a textbook of mathematics, a Secondary Section may not explain any mathematics.) The relationship could be a matter of historical connection with the subject or with related matters, or of legal, commercial, philosophical, ethical or political position regarding them.

The "Invariant Sections" are certain Secondary Sections whose titles are designated, as being those of Invariant Sections, in the notice that says that the Document is released under this License. If a section is not fit the above definition of Secondary then it is not allowed to be designated as Invariant. The Document may contain zero or more Invariant Sections. If the Document does not identify any Invariant Sections then there are none.

The "Cover Texts" are certain short passages of text that are listed, as Front-Cover Texts or Back-Cover Texts, in the notice that says that the Document is released under this License. A Front-Cover Text may be at most 5 words, and a Back-Cover Text may be at most 25 words.

A "Transparent" copy of the Document means a machine-readable copy, represented in a format whose specification is available to the general public, that is suitable for revising the document straightforwardly with generic text editors or (for images composed of pixels) generic paint programs or (for drawings created with vector graphics editors) and that is suitable for input to text formatters or for automatic translation to a variety of formats suitable for input to text formatters. A copy made in an otherwise Transparent file format whose markup, or absence of markup, has been arranged to thwart or discourage subsequent modification by readers is not Transparent. An image format is not Transparent if used for any substantial amount of text. A copy that is not "Transparent" is called "Opaque".

Examples of suitable formats for Transparent copies include plain ASCII without markup, Texinfo input format, LaTeX input format, SGML or XML using a publicly available DTD, and standard-conforming simple HTML, PostScript or PDF designed for human modification. Examples of transparent image formats include PNG, XCF and JPG. Opaque formats include proprietary formats that can be read and edited only by proprietary word processors, SGML or XML for which the DTD and/or processing tools are not generally available, and the machine-generated HTML, PostScript or

Notwithstanding any other provision of this License, you have permission to link or combine any covered work with a work licensed under version 3 of the GNU Affero General Public License into a single combined work, and to convey the resulting work. The terms of this License will continue to apply to the part which is the covered work, but the special requirements of the GNU Affero General Public License, section 13, concerning interaction through a network will apply to the combination as such. 14. Revised Versions of this License.

The Free Software Foundation may publish revised and/or new versions of the GNU General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.

Each version is given a distinguishing version number. If the Program specifies that a certain numbered version of the GNU General Public License "or any later version" applies to it, you have the option of following the terms and conditions either of the numbered version or of any later version published by the Free Software Foundation. If the Program does not specify a version number of the GNU General Public License, you may choose any version ever published by the Free Software Foundation.

If the Program specifies that a proxy can decide which future versions of the GNU General Public License can be used, that proxy's public statement of acceptance of a version permanently authorizes you to choose that version for the Program.

Later license versions may give you additional or different permissions. However, no additional obligations are imposed on any author or copyright holder as a result of your choosing to follow a later version. 15. Disclaimer of Warranty.

THERE IS NO WARRANTY FOR THE PROGRAM, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE PROGRAM "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE PROGRAM IS WITH YOU. SHOULD THE PROGRAM PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION. 16. Limitation of Liability.

IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MODIFIES AND/OR CONVEYS THE PROGRAM AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE PROGRAM (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE PROGRAM TO OPERATE WITH ANY OTHER PROGRAMS), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. 17. Interpretation of Sections 15 and 16.

If the disclaimer of warranty and limitation of liability provided above cannot be given local legal ef-

fect according to their terms, reviewing courts shall apply local law that most closely approximates an absolute waiver of all civil liability in connection with the Program, unless a warranty or assumption of liability accompanies a copy of the Program in return for a fee.

END OF TERMS AND CONDITIONS How to Apply These Terms to Your New Programs

If you develop a new program, and you want it to be of the greatest possible use to the public, the best way to achieve this is to make it free software which everyone can redistribute and change under these terms.

To do so, attach the following notices to the program. It is safest to attach them to the start of each source file to most effectively state the exclusion of warranty; and each file should have at least the "copyright" line and a pointer to where the full notice is found.

```
<one line to give the program's name and a brief idea of what it does.> Copyright (C) <year>
<name of author>
```

This program is free software; you can redistribute it and/or modify it under the terms of the GNU General Public License as published by the Free Software Foundation, either version 3 of the License, or (at your option) any later version.

This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License for more details.

You should have received a copy of the GNU General Public License along with this program. If not, see <<http://www.gnu.org/licenses/>>.

Also add information on how to contact you by electronic and paper mail.

If the program does terminal interaction, make it output a short notice like this when it starts in an interactive mode:

```
<program> Copyright (C) <year> <name of author>
This program comes with ABSOLUTELY NO WARRANTY; for details type 'show w'. This is free software, and you are welcome to redistribute it under certain conditions; type 'show c' for details.
```

The hypothetical commands 'show w' and 'show c' should show the appropriate parts of the General Public License. Of course, your program's commands might be different; for a GUI interface, you would use an "about box".

You should also get your employer (if you work as a programmer) or school, if any, to sign a "copyright disclaimer" for the program, if necessary. For more information on this, and how to apply and follow the GNU GPL, see <<http://www.gnu.org/licenses/>>.

The GNU General Public License does not permit incorporating your program into proprietary programs. If your program is a subroutine library, you may consider it more useful to permit linking proprietary applications with the library. If this is what you want to do, use the GNU Lesser General Public License instead of this License. But first, please read <<http://www.gnu.org/philosophy/why-not-lgpl.html>>.

PDF produced by some word processors for output purposes only.

The "Title Page" means, for a printed book, the title page itself, plus such following pages as are needed to hold, legibly, the material this License requires to appear in the title page. For works in formats which do not have any title page as such, "Title Page" means the text near the most prominent appearance of the work's title, preceding the beginning of the body of the text.

The "publisher" means any person or entity that distributes copies of the Document to the public.

A section "Entitled XYZ" means a named subunit of the Document whose title either is precisely XYZ or contains XYZ in parentheses following text that translates XYZ in another language. (Here XYZ stands for a specific section name mentioned below, such as "Acknowledgements", "Dedications", "Endorsements", or "History".) To "Preserve the Title" of such a section when you modify the Document means that it remains a section "Entitled XYZ" according to this definition.

The Document may include Warranty Disclaimers next to the notice which states that this License applies to the Document. These Warranty Disclaimers are considered to be included by reference in this License, but only as regards disclaiming warranties; any other implication that these Warranty Disclaimers may have is void and has no effect on the meaning of this License. 2. VERBATIM COPYING

You may copy and distribute the Document in any medium, either commercially or noncommercially, provided that this License, the copyright notices, and the license notice saying this License applies to the Document are reproduced in all copies, and that you add no other conditions whatsoever to those of this License. You may not use technical measures to obstruct or control the reading or further copying of the copies you make or distribute. However, you may accept compensation in exchange for copies. If you distribute a large enough number of copies you must also follow the conditions in section 3.

You may also lend copies, under the same conditions stated above, and you may publicly display copies. 3. COPYING IN QUANTITY

If you publish printed copies (or copies in media that commonly have printed covers) of the Document, numbering more than 100, and the Document's license notice requires Cover Texts, you

must enclose the copies in covers that carry, clearly and legibly, all these Cover Texts: Front-Cover Texts on the front cover, and Back-Cover Texts on the back cover. Both covers must also clearly and legibly identify you as the publisher of these copies. The front cover must present the full title with all words of the title equally prominent and visible. You may add other material on the covers in addition. Copying with changes limited to the covers, as long as they preserve the title of the Document and satisfy these conditions, can be treated as verbatim copying in other respects.

If the required texts for either cover are too voluminous to fit legibly, you should put the first ones listed (as many as fit reasonably) on the actual cover, and continue the rest onto adjacent pages.

If you publish or distribute Opaque copies of the Document numbering more than 100, you must either include a machine-readable Transparent copy along with each Opaque copy, or state in or with each Opaque copy a computer-network location from which the general network-using public has access to download using public-standard network protocols a complete Transparent copy of the Document, free of added material. If you use the latter option, you must take reasonably prudent steps, when you begin distribution of Opaque copies in quantity, to ensure that this Transparent copy will remain thus accessible at the stated location until at least one year after the last time you distribute an Opaque copy (directly or through your agents or retailers) of that edition of the public.

It is requested, but not required, that you contact the authors of the Document well before redistributing any large number of copies, to give them a chance to provide you with an updated version of the Document. 4. MODIFICATIONS

You may copy and distribute a Modified Version of the Document under the conditions of sections 2 and 3 above, provided that you release the Modified Version under precisely this License, with the Modified Version filling the role of the Document, thus licensing distribution and modification of the Modified Version to whoever possesses a copy of it. In addition, you must do these things in the Modified Version:

* A. Use in the Title Page (and on the covers, if any) a title distinct from that of the Document, and from those of previous versions (which should, if there were any, be listed in the History section of the Document). You may use the same title as a previous version if the original publisher of that version gives permission. * B. List on the Title

Page, as authors, one or more persons or entities responsible for authorship of the modifications in the Modified Version, together with at least five of the principal authors of the Document (all of its principal authors, if it has fewer than five), unless they release you from this requirement. * C. State on the Title page the name of the publisher of the Modified Version, as the publisher. * D. Preserve all the copyright notices of the Document. * E. Add an appropriate copyright notice for your modifications adjacent to the other copyright notices. * F. Include, immediately after the copyright notices, a license notice giving the public permission to use the Modified Version under the terms of this License, in the form shown in the Addendum below. * G. Preserve in that license notice the full lists of Invariant Sections and required Cover Texts given in the Document's license notice. * H. Include an unaltered copy of this License. * I. Preserve the section Entitled "History". Preserve its Title, and add to it an item stating at least the title, year, new authors, and publisher of the Modified Version as given on the Title Page. If there is no section Entitled "History" in the Document, create one stating the title, year, authors, and publisher of the Document as given on its Title Page, then add an item describing the Modified Version as stated in the previous sentence. * J. Preserve the network location, if any, given in the Document for public access to a Transparent copy of the Document, and likewise the network locations given in the Document for previous versions it was based on. These may be placed in the "History" section. You may omit a network location for a work that was published at least four years before the Document itself, or if the original publisher of the version it refers to gives permission. * K. For any section Entitled "Acknowledgements" or "Dedications", Preserve the Title of the section, and preserve in the section all the substance and tone of each of the contributor acknowledgements and/or dedications given therein. * L. Preserve all the Invariant Sections of the Document, unaltered in their text and in their titles. Section numbers or the equivalent are not considered part of the section titles. * M. Delete any section Entitled "Endorsements". Such a section may not be included in the Modified Version. * N. Do not retitle any existing section to be Entitled "Endorsements" or to conflict in title with any Invariant Section. * O. Preserve any Warranty Disclaimers.

If the Modified Version includes new front-matter sections or appendices that qualify as Secondary Sections and contain no material copied from the Document, you may at your option designate some or all of these sections as invariant. To do this, add their titles to the list of Invariant Sections in the Modified Version's license notice. These titles must be distinct from any other section titles.

You may add a section Entitled "Endorsements", provided it contains nothing but endorsements of your Modified Version by various parties—for example, statements of peer review or that the text has been approved by an organization as the authoritative definition of a standard.

You may add a passage of up to five words as a Front-Cover Text, and a passage of up to 25 words as a Back-Cover Text, to the end of the list of Cover Texts in the Modified Version. Only one passage of Front-Cover Text and one of Back-Cover Text may be added by (or through arrangements made by) any one entity. If the Document already includes a cover text for the same cover, previously added by you or by arrangement made by the same entity you are acting on behalf of, you may not add an-

other; but you may replace the old one, on explicit permission from the previous publisher that added the old one.

The author(s) and publisher(s) of the Document do not by this License give permission to use their names for publicity for or to assert or imply endorsement of any Modified Version. 5. COMBINING DOCUMENTS

You may combine the Document with other documents released under this License, under the terms defined in section 4 above for modified versions, provided that you include in the combination all of the Invariant Sections of all of the original documents, unmodified, and list them all as Invariant Sections of your combined work in its license notice, and that you preserve all their Warranty Disclaimers.

The combined work need only contain one copy of this License, and multiple identical Invariant Sections may be replaced with a single copy. If there are multiple Invariant Sections with the same name but different contents, make the title of each such section unique by adding at the end of it, in parentheses, the name of the original author or publisher of that section if known, or else a unique number. Make the same adjustment to the section titles in the list of Invariant Sections in the license notice of the combined work.

In the combination, you must combine any sections Entitled "History" in the various original documents, forming one section Entitled "History"; likewise combine any sections Entitled "Acknowledgements", and any sections Entitled "Dedications". You must delete all sections Entitled "Endorsements". 6. COLLECTIONS OF DOCUMENTS

You may make a collection consisting of the Document and other documents released under this License, and replace the individual copies of this License in the various documents with a single copy that is included in the collection, provided that you follow the rules of this License for verbatim copying of each of the documents in all other respects.

You may extract a single document from such a collection, and distribute it individually under this License, provided you insert a copy of this License into the extracted document, and follow this License in all other respects regarding verbatim copying of that document. 7. AGGREGATION WITH INDEPENDENT WORKS

A compilation of the Document or its derivatives with other separate and independent documents or works, in or on a volume of a storage or distribution medium, is called an "aggregate" if the copyright resulting from the compilation is not used to limit the legal rights of the compilation's users beyond what the individual works permit. When the Document is included in an aggregate, this License does not apply to the other works in the aggregate which are not themselves derivative works of the Document.

If the Cover Text requirement of section 3 is applicable to these copies of the Document, then if the Document is less than one half of the entire aggregate, the Document's Cover Texts may be placed on covers that bracket the Document within the aggregate, or the electronic equivalent of covers if the Document is in electronic form. Otherwise they must appear on printed covers that bracket the whole aggregate. 8. TRANSLATION

The "Corresponding Application Code" for a Combined Work means the object code and/or source code for the Application, including any data and utility programs needed for reproducing the Combined Work from the Application, but excluding the System Libraries of the Combined Work. 1. Exception to Section 3 of the GNU GPL.

You may convey a covered work under sections 3 and 4 of this License without being bound by section 3 of the GNU GPL. 2. Conveying Modified Versions.

If you modify a copy of the Library, and, in your modifications, a facility refers to a function or data to be supplied by an Application that uses the facility (other than as an argument passed when the facility is invoked), then you may convey a copy of the modified version:

* a) under this License, provided that you make a good faith effort to ensure that, in the event an Application does not supply the function or data, the facility still operates, and performs whatever part of its purpose remains meaningful, or * b) under the GNU GPL, with none of the additional permissions of this License applicable to that copy.

3. Object Code Incorporating Material from Library Header Files.

The object code form of an Application may incorporate material from a header file that is part of the Library. You may convey such object code under terms of your choice, provided that, if the incorporated material is not limited to numerical parameters, data structure layouts and accessors, or small macros, inline functions and templates (ten or fewer lines in length), you do both of the following:

* a) Give prominent notice with each copy of the object code that the Library is used in it and that the Library and its use are covered by this License. * b) Accompany the object code with a copy of the GNU GPL and this license document.

Translation is considered a kind of modification, so you may distribute translations of the Document under the terms of section 4. Replacing Invariant Sections with translations requires special permission from their copyright holders, but you may include translations of some or all Invariant Sections in addition to the original versions of these Invariant Sections. You may include a translation of this License, and all the license notices in the Document, and any Warranty Disclaimers, provided that you also include the original English version of this License and the original versions of those notices and disclaimers. In case of a disagreement between the translation and the original version of this License or a notice or disclaimer, the original version will prevail.

If a section in the Document is Entitled "Acknowledgements", "Dedications", or "History", the requirement (section 4) to Preserve its Title (section 1) will typically require changing the actual title. 9. TERMINATION

You may not copy, modify, sublicense, or distribute the Document except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense, or distribute it is void, and will automatically terminate your rights under this License.

However, if you cease all violation of this License, then your license from a particular copyright holder is reinstated (a) provisionally, unless and until the copyright holder explicitly and finally terminates your license, and (b) permanently, if the copyright holder fails to notify you of the violation by some reasonable means prior to 60 days after the cessation.

Moreover, your license from a particular copyright holder is reinstated permanently if the copyright holder notifies you of the violation by some reasonable means, this is the first time you have received notice of violation of this License (for any work) from that copyright holder, and you cure the violation prior to 30 days after your receipt of the notice.

Termination of your rights under this section does not terminate the licenses of parties who have received copies or rights from you under this License. If your rights have been terminated and not permanently reinstated, receipt of a copy of some or all of the same material does not give you any rights to use it. 10. FUTURE REVISIONS OF THIS LICENSE

The Free Software Foundation may publish new, revised versions of the GNU Free Documentation License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns. See <http://www.gnu.org/copyleft/>.

Each version of the License is given a distinguishing version number. If the Document specifies that a particular numbered version of this License "or any later version" applies to it, you have the option of following the terms and conditions either of that specified version or of any later version that has been published (not as a draft) by the Free Software Foundation. If the Document does not specify a version number of this License, you may choose any version ever published (not as a draft) by the Free Software Foundation. If the Document specifies that a proxy can decide which future versions of

this License can be used, that proxy's public statement of acceptance of a version permanently authorizes you to choose that version for the Document. 11. RELICENSING

"Massive Multiauthor Collaboration Site" (or "MMC Site") means any World Wide Web server that publishes copyrightable works and also provides prominent facilities for anybody to edit those works. A public wiki that anybody can edit is an example of such a server. A "Massive Multiauthor Collaboration" (or "MMC") contained in the site means any set of copyrightable works thus published on the MMC site.

"CC-BY-SA" means the Creative Commons Attribution-Share Alike 3.0 license published by Creative Commons Corporation, a not-for-profit corporation with a principal place of business in San Francisco, California, as well as future copyleft versions of that license published by that same organization.

"Incorporate" means to publish or republish a Document, in whole or in part, as part of another Document.

An MMC is "eligible for relicensing" if it is licensed under this License, and if all works that were first published under this License somewhere other than this MMC, and subsequently incorporated in whole or in part into the MMC, (1) had no cover texts or invariant sections, and (2) were thus incorporated prior to November 1, 2008.

The operator of an MMC Site may republish an MMC contained in the site under CC-BY-SA on the same site at any time before August 1, 2009, provided the MMC is eligible for relicensing. ADDENDUM: How to use this License for your documents

To use this License in a document you have written, include a copy of the License in the document and put the following copyright and license notices just after the title page:

Copyright (C) YEAR YOUR NAME. Permission is granted to copy, distribute and/or modify this document under the terms of the GNU Free Documentation License, Version 1.3 or any later version published by the Free Software Foundation; with no Invariant Sections, no Front-Cover Texts, and no Back-Cover Texts. A copy of the license is included in the section entitled "GNU Free Documentation License".

If you have Invariant Sections, Front-Cover Texts and Back-Cover Texts, replace the "with ... Texts." line with this:

with the Invariant Sections being LIST THEIR TITLES, with the Front-Cover Texts being LIST, and with the Back-Cover Texts being LIST.

If you have Invariant Sections without Cover Texts, or some other combination of the three, merge those two alternatives to suit the situation.

If your document contains nontrivial examples of program code, we recommend releasing these examples in parallel under your choice of free software license, such as the GNU General Public License, to permit their use in free software.

29.3 GNU Lesser General Public License

GNU LESSER GENERAL PUBLIC LICENSE

Version 3, 29 June 2007

Copyright © 2007 Free Software Foundation, Inc. <<http://fsf.org/>>

Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed.

This version of the GNU Lesser General Public License incorporates the terms and conditions of version 3 of the GNU General Public License, supplemented by the additional permissions listed below. 0. Additional Definitions.

As used herein, "this License" refers to version 3 of the GNU Lesser General Public License, and the "GNU GPL" refers to version 3 of the GNU General Public License.

"The Library" refers to a covered work governed by this License, other than an Application or a Combined Work as defined below.

An "Application" is any work that makes use of an interface provided by the Library, but which is not otherwise based on the Library. Defining a subclass of a class defined by the Library is deemed a mode of using an interface provided by the Library.

A "Combined Work" is a work produced by combining or linking an Application with the Library. The particular version of the Library with which the Combined Work was made is also called the "Linked Version".

The "Minimal Corresponding Source" for a Combined Work means the Corresponding Source for the Combined Work, excluding any source code for portions of the Combined Work that, considered in isolation, are based on the Application, and not on the Linked Version.

The "Corresponding Application Code" for a Combined Work means the object code and/or source code for the Application, including any data and utility programs needed for reproducing the Combined Work from the Application, but excluding the System Libraries of the Combined Work. 1. Exception to Section 3 of the GNU GPL.

You may convey a covered work under sections 3 and 4 of this License without being bound by section 3 of the GNU GPL. 2. Conveying Modified Versions.

If you modify a copy of the Library, and, in your modifications, a facility refers to a function or data to be supplied by an Application that uses the facility (other than as an argument passed when the facility is invoked), then you may convey a copy of the modified version:

* a) under this License, provided that you make a good faith effort to ensure that, in the event an Application does not supply the function or data, the facility still operates, and performs whatever part of its purpose remains meaningful, or * b) under the GNU GPL, with none of the additional permissions of this License applicable to that copy.

3. Object Code Incorporating Material from Library Header Files.

The object code form of an Application may incorporate material from a header file that is part of the Library. You may convey such object code under terms of your choice, provided that, if the incorporated material is not limited to numerical parameters, data structure layouts and accessors, or small macros, inline functions and templates (ten or fewer lines in length), you do both of the following:

* a) Give prominent notice with each copy of the object code that the Library is used in it and that the Library and its use are covered by this License. * b) Accompany the object code with a copy of the GNU GPL and this license document.

4. Combined Works.

You may convey a Combined Work under terms of your choice that, taken together, effectively do not restrict modification of the portions of the Library contained in the Combined Work and reverse engineering for debugging such modifications, if you also do each of the following:

* a) Give prominent notice with each copy of the Combined Work that the Library is used in it and that the Library and its use are covered by this License. * b) Accompany the Combined Work with a copy of the GNU GPL and this license document. * c) For a Combined Work that displays copyright notices during execution, include the copyright notice for the Library among these notices, as well as a reference directing the user to the copies of the GNU GPL and this license document. * d) Do one of the following: o 1) Convey the Minimal Corresponding Source under the terms of this License, and the Corresponding Application Code in a form suitable for, and under terms that permit, the user to recombine or relink the Application with a modified version of the Linked Version to produce a modified Combined Work, in the manner specified by section 6 of the GNU GPL for conveying Corresponding Source. o 2) Use a suitable shared library mechanism for linking with the Library. A suitable mechanism is one that (a) uses at run time a copy of the Library already present on the user's computer system, and (b) will operate properly with a modified version of the Library that is interface-compatible with the Linked Version. * e) Provide Installation Information, but only if you would otherwise be required to provide such information under section 6 of the GNU GPL, and only to the extent that such information is necessary to install and execute a modified version of the Combined Work produced by recombining or relinking the Application with a modified version of the Linked Version. (If you use option 4d, the Installation Information must accompany the Minimal Corresponding Source and Corresponding Application Code. If you use option 4e, you must provide the Installation Information in the manner specified by section 6 of the GNU GPL for conveying Corresponding Source.)

5. Combined Libraries.

You may place library facilities that are a work based on the Library side by side in a single library together with other library facilities that are not Applications and are not covered by this License, and convey such a combined library under terms of your choice, if you do both of the following:

* a) Accompany the combined library with a copy of the same work based on the Library, uncombined with any other library facilities, conveyed under the terms of this License. * b) Give prominent notice with the combined library that part of it is a work based on the Library, and explaining where to find the accompanying uncombined form of the same work.

6. Revised Versions of the GNU Lesser General Public License.

The Free Software Foundation may publish revised and/or new versions of the GNU Lesser General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.

Each version is given a distinguishing version number. If the Library as you received it specifies that a certain numbered version of the GNU Lesser General Public License "or any later version" applies to it, you have the option of following the terms and conditions either of that published version or of any later version published by the Free Software Foundation. If the Library as you received it does not specify a version number of the GNU Lesser General Public License, you may choose any version of the GNU Lesser General Public License ever published by the Free Software Foundation.

If the Library as you received it specifies that a proxy can decide whether future versions of the GNU Lesser General Public License shall apply, that proxy's public statement of acceptance of any version is permanent authorization for you to choose that version for the Library.