



TERMINALS OF ECU



I30419

Symbols (Terminals No.)	Wiring Color	Condition	STD Voltage (V)
+B ↔ GND (C14-2 ↔ C14-16)	B-W ↔ W-B	Ignition switch ON	10 - 16
STP- ↔ GND (C14-3 ↔ C14-16)	G-W ↔ W-B	Depress brake pedal	10 - 16
		Release brake pedal	Below 1
D ↔ GND (C14-4 ↔ C14-16)	L ↔ W-B	<ul style="list-style-type: none"> • Depress clutch pedal (M/T) • Shift to except D position (A/T) 	Below 1
		<ul style="list-style-type: none"> • Release clutch pedal (M/T) • Shift to D position (A/T) 	10 - 16
PI ↔ GND (C14-5 ↔ C14-16)	G-R ↔ W-B	Ignition switch ON Cruise control main switch button ON	Below 1.2
		Ignition switch ON Cruise control main switch button OFF	10 - 16
ECT (A/T) ↔ GND (C14-6 ↔ C14-16)	L ↔ W-B	During driving Gear position 3rd	Below 1
		During driving Gear position O/D	8 - 16
MC ↔ GND (C14-7 ↔ C14-16)	R-L ↔ W-B	During cruise control driving COAST switch held ON	9 - 15
		During cruise control driving ACC switch held ON	Below 1
L ↔ GND (C14-8 ↔ C14-16)	G-O ↔ W-B	During cruise control driving	9 - 15
		Except during cruise control driving	Below 1
TC ↔ GND (C14-10 ↔ C14-16)	P-B ↔ W-B	Ignition switch ON	10 - 16
		Ignition switch ON Connect terminals Tc and CG of DLC3	Below 2
CCS ↔ GND (C14-11 ↔ C14-16)	G-Y ↔ W-B	Ignition switch ON	10 - 16
		Ignition switch ON Cruise control main switch button held ON	Below 0.5
		Ignition switch ON CANCEL switch held ON	6.6 - 11.4
		Ignition switch ON SET/COAST switch held ON	4.5 - 8.1
		Ignition switch ON RES/ACC switch held ON	2.3 - 4.5

SPD ↔ GND (C14-12 ↔ C14-16)	V-W ↔ W-B	Engine start → Car stoppage.	Below 1.5 → 4.7 - 16
		During driving (Pulse generated).	3 - 7
IDL ↔ GND (C14-13 ↔ C14-16)	L-W ↔ W-B	Ignition switch ON Throttle valve fully opened.	10 - 16
		Ignition switch ON Throttle valve fully closed.	Below 1.5
OD (A/T) ↔ GND (C14-14 ↔ C14-16)	R-Y ↔ W-B	During cruise control driving O/D switch ON.	0 - 16 (*1)
		During cruise control driving O/D switch OFF (3rd driving)	Below 1
MO ↔ GND (C14-15 ↔ C14-16)	R-G ↔ W-B	During cruise control driving ACC switch held ON	9 - 15
		During cruise control driving COAST switch held ON	Below 1
GND ↔ Body Ground (C14-16 ↔ Body Ground)	W-B ↔ Body Ground	Constant	Below 1



Oscilloscope wave (*1)

HINT:

- Terminal: OD - GND
- Gauge set: 5 V / DIV, 50 ms / DIV
- Condition: During cruise control driving O/D switch ON.