CRUISE CONTROL SYSTEM HOW TO PROCEED WITH TROUBLESHOOTING

0526X-05

1	VEHICLE BROUGHT TO WORKSHOP	
\geq	-	
2	CUSTOMER PROBLEM ANALYSIS (See page 05–744)	
3	CHECK AND CLEAR DTC (See page 05–745)	
4	PROBLEM SYMPTOM CONFIRMATION	
	SYMPTOM DOES NOT OCCUR (GO TO STEP 5)	
	SYMPTOM OCCUR (GO TO STEP 6)	
5	SYMPTOM SIMULATION (See page 01–20)	
6	DTC CHECK (See page 05–745)	
	MALFUNCTION CODE (GO TO STEP 7)	
	NORMAL CODE (GO TO STEP 8)	
7	DTC CHART (See page 05–750)	
	GO TO STEP 9	
8	PROBLEM SYMPTOMS TABLE (See page 05–754)	

9 0	CIRCUIT INSPECTION (See page 05–755 – 05–788)
10 I	DENTIFICATION OF PROBLEM
11 F	PARTS INSPECTION
\sim	
12 F	REPAIR
·	
13 0	CONFIRMATION TEST
END	