

PROBLEM SYMPTOMS TABLE

Symptom	Suspected Area	See page
All doors are not operated by driver's door key cylinder interlocked with key	<ol style="list-style-type: none">1. Door lock control switch2. Front door lock assy LH3. Wire harness4. Integration relay	05-677
Key confinement prevention function does not work properly (Unlock warning switch circuit)	<ol style="list-style-type: none">1. Un-lock warning switch assy2. Front door courtesy lamp switch assy3. Wire harness4. Integration relay	05-682