

POWER DOOR LOCK CONTROL SYSTEM

HOW TO PROCEED WITH TROUBLESHOOTING

057TD-01

1	VEHICLE BROUGHT IN
----------	---------------------------



2	CUSTOMER PROBLEM ANALYSIS CHECK AND SYMPTOM CHECK (See page 05-671)
----------	--



3	PROBLEM SYMPTOMS TABLE (See page 05-676)
----------	---

- (a) Without applicable symptoms, proceed to "A"
- (b) With applicable symptoms, proceed to "B"

B	GO TO STEP 5
----------	---------------------



4	PERFORM TROUBLESHOOTING IN THE FOLLOWING METHOD, DEPENDING ON MALFUNCTION SYMPTOM
----------	--

- (a) Terminals of ECU (See page [05-673](#))
- (b) Inspection (See page [73-3](#))
- (c) On-vehicle inspection (See page [73-1](#))

5	ADJUSTMENT, REPAIR OR REPLACEMENT
----------	--



END
