

PROBLEM SYMPTOMS TABLE

Symptom	Suspected area	See page
Only wireless control function is inoperative (Prepare new or normal transmitter of the same type vehicle)	<ol style="list-style-type: none"> 1. Transmitter battery 2. Door control transmitter 3. Door control receiver 4. Unlock warning switch 5. Integration relay 6. Wire harness 	05-692