


LICENSE PLATE LAMP ASSY REPLACEMENT

650GX-01

1. REMOVE LUGGAGE COMPARTMENT LOCK CYLINDER & KEY SET(See Page 76-16)
2. REMOVE LUGGAGE COMPARTMENT DOOR GARNISH OUTSIDE(See Page 76-16)



3. REMOVE LICENSE PLATE LAMP ASSY
 - (a) Pull the license plate light assy to the side of vehicle as shown in the illustration and release the claw.
 - (b) Disconnect the connector and remove the license plate light assy.

4. INSTALL SYMBOL EMBLEM(See Page 76-16)