

WIPER AND WASHER SYSTEM

PROBLEM SYMPTOMS TABLE

6606Y-01

1. WIPER AND WASHER SYSTEM

Symptom	Suspect Area	See page
Front wipers do not operate.	<ol style="list-style-type: none"> 1. IG1 Relay 2. WIPER Fuse 3. Front Wiper Switch 4. Wire Harness 	<p>–</p> <p>–</p> <p>66-3</p> <p>–</p>
Front wipers do not operate in LO or HI.	<ol style="list-style-type: none"> 1. Front Wiper Switch 2. Front Wiper Motor 3. Wire Harness 	<p>66-3</p> <p>66-3</p> <p>–</p>
Front wipers do not operate in INT.	<ol style="list-style-type: none"> 1. Front Wiper Switch 2. Front Wiper Motor 3. Wire Harness 	<p>66-3</p> <p>66-3</p> <p>–</p>
Front washer motor does not operate.	<ol style="list-style-type: none"> 1. WIPER Fuse 2. Front Washer Switch 3. Front Washer Motor 4. Wire Harness 	<p>–</p> <p>66-3</p> <p>66-2</p> <p>–</p>
Front wipers do not operate when washer switch is in the ON position.	<ol style="list-style-type: none"> 1. Front Wiper Switch 2. Front Wiper Motor 3. Wire Harness 	<p>66-3</p> <p>66-3</p> <p>–</p>
Washer fluid does not operate.	<ol style="list-style-type: none"> 1. Washer Hose and Nozzle 	<p>–</p>
<ul style="list-style-type: none"> • When the wiper switch is OFF, the wiper blade does not retract or the retract position is wrong. • The wiper blade is in contact with the body. 	<ol style="list-style-type: none"> 1. Wiper Motor (wiper arm and blade set position) 	<p>66-6</p>