



WINDSHIELD WIPER SWITCH ASSY REPLACEMENT

66073-01



1. REMOVE STEERING COLUMN COVER LWR

- (a) Remove 3 screws and steering column cover LWR.



2. REMOVE WINDSHIELD WIPER SWITCH ASSY

- (a) Disconnect the connector of the windshield wiper switch.
(b) Release the claw and pull out the windshield wiper switch assy as shown in the illustration.

NOTICE:

Pressing the claw hard breaks the claw.