

PROBLEM SYMPTOMS TABLE

Symptom	Suspected Area	See page
Horn does not sound	2. Horn button switch 3. Low pitched horn 4. HORN relay 5. Wire harness	- 69-3 69-3 -