

CLUTCH SWITCH ASSY

REPLACEMENT

82025-01

1. REMOVE CLUTCH SWITCH ASSY
 - (a) Disconnect the connector.
 - (b) Loosen the nut and remove the clutch switch assy.