


CRUISE CONTROL ECU ASSY

REPLACEMENT

82023-01

1. REMOVE METER HOOD SUB-ASSY(See page 71-17)
2. REMOVE COMBINATION METER ASSY(See page 71-17)



3. REMOVE CRUISE CONTROL ECU ASSY
 - (a) Disconnect the connector.
 - (b) Remove the screw and cruise control ECU assy.