
ENGINE ON-VEHICLE INSPECTION

HINT:

- Inspect these items on a cooled down engine.
- 1. INSPECT DRIVE BELT (See page 14–4)
- 2. REPLACE SPARK PLUGS (See page 18–1)



3. INSPECT AIR FILTER

- (a) Remove the air filter.
- (b) Visually check that the air filter is not excessively damaged, dirty or oily.

Peplace the air filter if necessary.

(c) Clean the filter with compressed air.

- First blow from the inside of the filter thoroughly then repeat from the outside.
- (d) Reinstall the air filter.
- 4. REPLACE AIR FILTER
- (a) Replace the air filter with a new one.
- 5. REPLACE ENGINE OIL AND OIL FILTER (See page 17–10)
- 6. REPLACE ENGINE COOLANT (See page 16–7)
- 7. INSPECT GASKET IN FUEL TANK CAP (See page 12–1)
- 8. INSPECT FUEL LINES AND CONNECTIONS, FUEL TANK VAPOR VENT SYSTEM HOSES AND FUEL TANK BANDS
- (a) Visually check the fuel lines for cracks, leakage, loose connections, deformation and tank band looseness.
- 9. INSPECT EXHAUST PIPES AND MOUNTINGS
- (a) Visually check the pipes, hangers and connections for severe corrosion, leaks and damage.
- 10. INSPECT VALVE CLEARANCE (See page 14–5)

9900Y-13