

BARSKA's Accu-Lock System utilizes a coil spring positioned within the scope to securely lock the inner tube. This coil positioning system allows the scope to stay locked dead-on to the target shot after shot and minimizes the zero maintenance of the scope for pinpoint accuracy (See image). It is not necessary to adjust the Accu-Lock System manually and **NO ADJUSTMENT KEY IS REQUIRED**. Once you have zeroed your scope using the windage and elevation adjustments, the scope will maintain the zero setting until it is necessary for you to re-adjust the scope.



Accu-Lock System