

# ***KHANSHOTGUNS***



**OWNERS MANUAL FOR 12 GAUGE PUMP SHOTGUN**

***KHANSHOTGUNS***

**Thank you for choosing KHANSHOTGUNS 12 Gauge pump-action shotgun**

Your pump-action shotgun represents a piece of rich history of quality firearms design and manufacture. During the manufacturing process, we have endeavored to incorporate the very finest in material, craftsmanship and, with a reasonable amount of care, your gun will provide many years of pleasure and dependable service.

Thank You  
Khanshotguns

## **KHANSHOTGUN**

### **Safety Warnings**

Regardless of your familiarity or experience with firearms, don't assume that you have no need to study this manual.

The safe handling of firearms requires specialized training, discipline and caution. Firearms, by their nature and intended function, are deadly instruments. Accidental death or serious injury can result if they are handled improperly or carelessly.

A person with a gun in his possession has a full-time responsibility. He must KNOW how to keep and use his firearm safely, and then must always TAKE the necessary precautions. He cannot guess; he cannot forget. This responsibility is his alone. It cannot be passed off to someone else.

Remember: No gun can be made accident-proof. A gun is just a machine, with no judgement of its own. It responds to your actions, whether wise or foolish. The only truly effective safety device is the mind of a cautious shooter who never forgets that a moment's carelessness can produce permanent tragedy.

**IMPORTANT** - Our shotguns are designed, manufactured and proof-tested for use with fresh factory loaded ammunition. Improperly loaded shells are dangerous.

Khanshotguns does not assume responsibility for damages or injury caused by reload or improperly loaded ammunition. This shotgun should not be used with broken, missing or altered parts.

This shotgun is chambered for 12 gauge, 3" cartridges. It can fire both 2 3/4" and 3" cartridges.

### **WARRANTY**

"This product is under manufacturer's warranty which covers defects in materials and / or workmanship for one full year after date of original new gun retail purchase."

All warranty repairs will be completed by Century International Arms, Inc. 236 Bryce Blvd, Georgia, VT 05454. The company is not responsible for any misuse of the product. A request for a Return Authorization number is required by calling 1-800-527-1252.

### **Commandments of Firearm Safety**

A good hunter is a safe hunter. He knows there is no place for horseplay in hunting. He learns and obeys the commandments of firearms safety and insists that his companions know and follow them too. Every hunter-whether novice or experienced outdoorsman should review these commandments before each hunting season to be sure that his gun handling, both at home and in the field, sets a good example for others.

1. Don't rely on your gun's safety. Treat every gun as if it were loaded and ready to fire. Install gunlock when not in use.
2. Don't shoot unless absolutely sure of your target and what is beyond it.
3. Always be sure the barrel is clear of obstructions.
4. Never point your gun at anything you do not want to shoot. Watch your muzzle so the other person doesn't have to.
5. Never leave your gun unattended unless you unload it first.
6. Avoid alcoholic beverages both before and during shooting.
7. Never carry a loaded gun when you climb a tree, cross a fence, jump a ditch or go through areas where you are apt to slip or trip.
8. Never shoot at a hard, flat surface or the surface of water. Make sure you have a safe backstop.
9. Carry only empty guns, taken down or with the action open, into your camp, car or home.
10. Store locked guns and ammunition separately, beyond the reach of children.
11. Never insert a shell of the incorrect gauge in any shotgun and use shell of correct length

## GENERAL SPECIFICATIONS OF 12 GAUGE PUMP-ACTION SHOTGUN

MODEL	12 GAUGE PUMP-ACTION MODEL
GAUGE	12
BARREL LENGTH	51cm-20"
RECEIVER	ALUMINIUM 7075 T-6
CHAMBER	3"
CHOKE	CYLINDER BORE
STOCK	SYNTHETIC
FOREND	SYNTHETIC
TOP RIB	NO
MAGAZINE CAP.	4+1
WEIGHT	6 lbs 8 oz

### MANUAL TRIGGER SAFETY


Before loading the gun, make sure the manual trigger safety is on. To activate the manual trigger safety, press the manual safety button on the side of the trigger guard from the left side of the gun to the right. When the trigger safety is "on" the button will protrude from the right side of the trigger guard. When the trigger safety is "off", the button will protrude from the left side of the trigger guard, and the red band around the button will be visible. The manual trigger safety is intended only to lock the trigger. It is not a substitute for safe gun handling.

### KHAN CENTURION PUMP ACTION SHOTGUN

The Khan Centurion Pump action shotgun is manufactured with the latest computerized machinery to industry standards using the finest material and craftsmanship. The end result is a reliable, light weight shotgun that looks great and will provide the owner with many years of reliable service.

### TECHNICAL OPERATION


The Centurion Pump action KHAN SHOTGUN is manually operated by use of a slide action forearm. After firing the shooter manually pulls the slide to the rear, the expended shell is extracted, the hammer re cocks and the empty shell is ejected. When the forearm is pushed forward another shell is loaded into the chamber. The gun is now ready to fire again.



MANUAL TRIGGER SAFETY

## **KHANSHOTGUNS**

### CARTRIDGE LOADING



Point the muzzle in a safe direction and ensure that the safety is in the safe position  
Depress the slide release button (fig 3) and pull the forearm (slide) to the rear, (fig 2)

Note: If you wish to load the firearm with the maximum number of shells, or fire a single round, load the first shell through the ejection port located on the right side of the receiver. Close the action by moving the forearm completely forward.

Insert cartridge into the magazine tube one at a time from the bottom of the receiver until the magazine is full or the number of rounds desired is loaded, (fig 1)

#### **FIRING**

Mount the shotgun firmly to your shoulder and point the front bead on your intended target.

Move the safety button to the fire position and pull the trigger.

After firing pull the slide to the rear, which ejects the spent shell and cocks the hammer. Move the slide briskly to the forward position until seated. This reloads a shell into the chamber from the magazine tube and the shotgun is ready to fire again.



#### **UNLOADING**

Place the safety in the safe position with the muzzle pointed in a safe direction and the finger off the trigger.

Depress the action lock lever and pull the forearm rearward slowly.

Remove the live shell through the ejection port by hand, (fig 4)

Continue pulling completely to the rear to release the next cartridge onto the elevator. Turn the gun over until the ejection port is facing down and the cartridge falls into your hand. Insert your thumb into the bottom of the receiver and depress the cartridge stop to release the remaining shells one at a time from the magazine tube. Visually check the magazine and chamber to ensure they are empty.