# SNAKE CHARMER

# UNIQUE 410 Ga. SHOTGUN

Fishing • Hunting • Camping • Back-Packing • Survival • Home Defense • Truck or Jeep Gun



1602 Stemmons Freeway · Suite D · Carrollton, Texas 75006 214/245-3115 · 214/242-2792

# CLEANING AND CARE

The barrel and frame are made of stainless steel so as to be rust resistant; they are NOT rust-proof. Normal care and cleaning procedures should be followed after use, leaving a light film of oil on the surface of the steel. The stocks are molded of high impact ABS plastics and some cleaning solutions will have an adverse affect on their surface. Dirt and mud can be removed from the stocks with a rag dampened with water.

## SAFETY RULES

- 1. NEVER cock the shotgun until you are ready to fire it.
- 2. NEVER keep the chamber loaded.
- NEVER use your shotgun without first examining the barrel to be sure it is free of any obstructions.
- NEVER attempt to fire the shotgun until the breech is closed and securely locked in position.
- NEVER rest your finger on the trigger while the shotgun is loaded or cocked.
- 6. NEVER snap your shotgun on an empty chamber.
- NEVER point your shotgun at another person or object that you do not intend to shoot.

# H. KOON, INC.

MFG PLANT: 2640 NORTHAVEN, SUITE 101, DALLAS, TEXAS 75229 OFFICES: 1602 STEMMONS, SUITE D, CARROLLTON, TEXAS 75006



# OWNER'S INSTRUCTIONS

#### WARNING

410 GAUGE ONLY. The manufacturer intends this shotgun to use standard factory ammunition of 410 gauge. No warrantees of any kind are given or should be implied. No liabilities of any kind are assumed by the manufacturer and owners should only use at his/her own risk.

Although your Snake Charmer is chambered for any factory 410 gauge ammunition, the 2½ inch length is recommended. The storage area in the butt stock will only accommodate the 2½ inch length.

### **ASSEMBLY**

- Remove the forend stock from the barrel by removing the screw located in the bottom of the stock.
- 2. Remove the pivoting screw from the frame using a dime or penny.
- Place the barrel unit in the frame in a breeched position until the %" holes are in alignment.
- 4. Insert the pivoting screw and tighten.
- 5. Close the breech; the release latch should securely lock it in place.
- 6. Replace the forend stock and tighten the forend screw.
- 7. Open and close the breech several times to be sure the release latch securely locks the breech in a closed position.

#### HALF-COCK SAFETY

The Snake Charmer has manually operated half-cock hammer safety system. To place the hammer in a safe position, it is pulled back slightly from the fired position until the safety notch is engaged by the trigger and the hammer no longer rests on the firing pin. PULLING THE TRIGGER RELEASES THE SAFETY. To fire the shotgun, the hammer is pulled all the way to the rear until the trigger engages the hammer in the sear notch. PULLING THE TRIGGER RELEASES THE HAMMER TO FIRE THE SHOTGUN.



- 2. Barrel Nut
- 3. Undercarriage
- 4. Extractor
- 5. Extractor Pin
- 6. Extractor Spring
- 7. Forend Stock
- 8. Forend Screw
- 9. Butt Stock
- 10. Butt Stock Slide
- 11. Butt Stock Screw
- 12. Hammer
- 13. Hammer Spring
- 14. Hammer Pin
- 15. Firing Pin
- 16. Firing Pin Stop
- 17. Firing Pin Spring
- 18. Frame
- 19. Pivoting Screw
- 20. Release Latch
- 21. Release Latch Pin
- 22. Release Latch Spring
- 23. Trigger
- 24. Trigger Pin
- 25. Trigger Guard
- 26. Trigger Guard Pins (2)

