

## Warning:

This product is classified as a lethal weapon. Failure to read and properly execute the instructions and warnings in this manual could result in serious injury, death or damage to property.

Do not attempt to practice loading or unloading with live ammunition without a thorough understanding of the safe operation of this firearm.

Always treat a firearm as if it were fully loaded.

Always store and carry this product empty, with the hammer forward on an empty chamber. Failure to do so could result in an unintentional discharge.

Always use an approved and effective trigger locking device where children are present.

Keep out of reach of children.

When you squeeze the trigger, you must expect the pistol to fire and take full responsibility for your actions.

Always wear safety glasses for shooting and cleaning your firearm.

Read carefully the entire manual before attempting to use this product.

## Main Features:

### Specifications:

Caliber: .45 ACP

Weight: 40 OZ

Length: 8 and 3/4"

Width: 1.290"

Height: 5"

Barrel length: 5 inches

Tolerance: all parts precision fit

Trigger pull: 4 pounds

Capacity: 8+1, 7+1

### Special options available:

Tritium night sights

Hard chrome

Valtro's black poly tek seal

Valtro reserves right to change specifications and improve products at any time.

## Safety Rules

Notice: Valtro USA Inc. and its representatives shall not be responsible for any death, physical and/or mental injury or property damage that is the result of the proper or improper use of this product.

1. Always treat this and any other firearm as if it is loaded.
2. Never point this or any other firearm at anything you do not intend to shoot. Always keep the muzzle pointed in a safe direction.
3. Never accept anyone's word that a firearm is unloaded. Check it yourself with your finger off the trigger and the muzzle pointed in a safe direction. Remove the magazine, lock the slide open and visually check to ensure that

no round is present in the chamber.

4. Always make sure the pistol is unloaded with the slide locked open before laying it down or handing it to someone else.
5. Never carry any pistol cocked, loaded and ready to fire as this practice could easily result in an unintentional discharge.
6. Always ensure that this firearm is in proper working condition and that no internal parts have been damaged as a result of corrosion, improper maintenance, damage or dropping. If any evidence of these conditions exists, have the pistol inspected by a competent gunsmith prior to use. Never use your pistol if it fails to function properly.
7. Never leave a loaded pistol unattended.
8. Always make sure that your backstop is adequate to stop your bullets before you begin firing.
9. Make sure all other shooters and bystanders are well away from the ejection pot. Empty cases are ejected under pressure, are hot and can cause injury if someone is struck.
10. Always obey all range rules.
11. Always wear adequate hearing and eye protection when using any firearm.
12. While on the range, be sure to carry this pistol cleared, and chamber empty with the slide locked open and muzzle pointed in a safe direction until ready to shoot. Always assume that any firearm is ready to fire.
13. Always ensure that barrel and action are clear of obstructions. Shooting a blocked or obstructed firearm can result in serious injury, death and damage to the weapon.
14. Never drink alcoholic beverages or take drugs and medicines prior to or during shooting or handling of this or any other firearm.
15. Seek your doctor's advice if you are taking medicine prior to engaging in any shooting activity.
16. Keep the safety on when the pistol is loaded and cocked until ready to fire. Immediately unload and clear the pistol when the shooting sequence has been completed.
17. Never shoot at any hard or flat surfaces such as rocks or water. The resulting ricochets could result in physical injury, death or property damage.
18. Never put your finger in the trigger guard until you are ready to fire.
19. Always ensure the pistol is unloaded before cleaning and wear safety glasses.
20. Never force a jammed action. This could cause a round to explode resulting in physical injury and damage the pistol.
21. If the pistol fails to fire when the trigger is pulled, as a result of slow primer ignition (hangfire), keep muzzle pointed downrange for a minimum of 30 seconds. If the round does not fire, remove the magazine, clear the weapon and examine the ejected, unfired cartridge. If the indent from the firing pin is off center, light or absent, take the pistol to a competent gunsmith. If the indent appears normal compared to similar rounds, assume a faulty round, separate from other cartridges, reload and continue shooting.
22. Never use this pistol in any manner other than that for which it was specifically intended.
23. Never indulge in "horseplay" while holding any firearm as it may accidentally discharge.