1.

INSPECTION



INSPECT OUTER MIRROR SWITCH ASSY

- (a) Inspect the mirror switch continuity.
 - (1) Left side for left/right adjustment switch: Inspect the mirror switch continuity.

Standard (Left side):

Terminal No.	Switch position	Specified condition
-	OFF	No continuity
$\begin{array}{c} 4 \Leftrightarrow 8 \\ 6 \Leftrightarrow 7 \end{array}$	UP	Continuity
$\begin{array}{c} 4 \Leftrightarrow 7 \\ 6 \Leftrightarrow 8 \end{array}$	DOWN	Continuity
$5 \Leftrightarrow 8 \\ 6 \Leftrightarrow 7$	LEFT	Continuity
$5 \Leftrightarrow 7$ $6 \Leftrightarrow 8$	RIGHT	Continuity

If the result is not as specified, replace the switch assembly.(2) Right side for left/right adjustment switch:

 Right side for left/right adjustment switch: Inspect the mirror switch continuity.

Standard (Right side):

Terminal No.	Switch position	Specified condition
-	OFF	No continuity
$3 \Leftrightarrow 8 \\ 6 \Leftrightarrow 7$	UP	Continuity
$ \begin{array}{c} 3 \Leftrightarrow 7 \\ 6 \Leftrightarrow 8 \end{array} $	DOWN	Continuity
$\begin{array}{c} 2 \Leftrightarrow 8 \\ 6 \Leftrightarrow 7 \end{array}$	LEFT	Continuity
$\begin{array}{c} 2 \Leftrightarrow 7 \\ 6 \Leftrightarrow 8 \end{array}$	RIGHT	Continuity

If the result is not as specified, replace the switch assembly.

700GV-01

2.





INSPECT OUTER REAR VIEW MIRROR ASSY LH

- (a) Disconnect the outer rear view mirror assembly LH connector.
- (b) Inspect the mirror motor operation.
 - (1) Apply battery voltage as shown in the table. **Standard:**

Battery connection	Mirror operation
Positive (+) \Leftrightarrow MV (3) Negative (-) \Leftrightarrow Com (2)	Turn upward (A)
Positive (+) \Leftrightarrow Com (2) Negative (-) \Leftrightarrow MV (3)	Turn downward (B)
Positive (+) \Leftrightarrow Com (2) Negative (-) \Leftrightarrow MH (1)	Turn left (C)
Positive (+) \Leftrightarrow MH (1) Negative (–) \Leftrightarrow Com (2)	Turn right (D)

If the result is not as specified, replace the mirror assembly.

3. INSPECT OUTER REAR VIEW MIRROR ASSY RH

- (a) Disconnect the outer rear view mirror assembly RH connector.
- (b) Inspect the mirror motor operation.
 - (1) Apply battery voltage as shown in the table.Standard:

Battery connection	Mirror operation
Positive (+) \Leftrightarrow MV (3) Negative (-) \Leftrightarrow Com (2)	Turn upward (A)
Positive (+) \Leftrightarrow Com (2) Negative (–) \Leftrightarrow MV (3)	Turn downward (B)
Positive (+) \Leftrightarrow Com (2) Negative (–) \Leftrightarrow MH (1)	Turn right (D)
Positive (+) \Leftrightarrow MH (1) Negative (-) \Leftrightarrow Com (2)	Turn left (C)

If the result is not as specified, replace the mirror assembly.