


M OVERALL ELECTRICAL WIRING DIAGRAM

* The system shown here is an EXAMPLE ONLY. It is different to the actual circuit shown in the wiring diagram section.

HOW TO READ THIS SECTION



[A] : System Title


[B] : Indicates the wiring color.

Wire colors are indicated by an alphabetical code.

- | | | |
|------------|------------|------------------|
| B = Black | W = White | BR = Brown |
| L = Blue | V = Violet | SB = Sky Blue |
| R = Red | G = Green | LG = Light Green |
| P = Pink | Y = Yellow | GR = Gray |
| O = Orange | | |

The first letter indicates the basic wire color and the second letter indicates the color of the stripe.

Example: L - Y




[C] : The position of the parts is the same as shown in the wiring diagram and wire routing.


[D] : Indicates the pin number of the connector. The numbering system is different for female and male connectors.

Example : Numbered in order from upper left to lower right

Numbered in order from upper right to lower left



Female



Male


The numbering system for the overall wiring diagram is the same as above

[E] : Indicates a Relay Block. No shading is used and only the Relay Block No. is shown to distinguish it from the J/B.

Example :  Indicates Relay Block No.1


[F] : Junction Block (The number in the circle is the J/B No. and the connector code is shown beside it). Junction Blocks are shaded to clearly separate them from other parts.

Example:



[G] : Indicates related system.

[H] : Indicates the wiring harness and wiring harness connector. The wiring harness with male terminal is shown with arrows (↘). Outside numerals are pin numbers.



[I] : () is used to indicate different wiring and connector, etc. when the vehicle model, engine type, or specification is different.

[J] : Indicates a shielded cable.



[K] : Indicates and located on ground point.

[L] : The same code occurring on the next page indicates that the wire harness is continuous.

SYSTEM INDEX

SYSTEMS	LOCATION	SYSTEMS	LOCATION
ABS	12-2	Light Reminder Buzzer	19-3
Air Conditioning	26-2	Moon Roof	18-3
Automatic Glare-Resistant EC Mirror with Compass	14-4	Power Outlet	21-3
Back-Up Light	10-8	Power Source	1~27-1
Charging	2-2	Power Window	17-2
Cigarette Lighter	21-2	Radiator Fan	25-3
Clock	21-2	Radio and Player	23-2
Combination Meter	24-2	Rear Window Defogger	22-2
Cruise Control	11-2	Remote Control Mirror	20-2
Door Lock Control	15-2	Seat Belt Warning	19-2
Electronically Controlled Transmission	10-2	Shift Lock	18-4
Engine Control	3-2	SRS	13-2
Fog Light	4-8	Starting	1-2
Headlight	4-3	Stop Light	7-2
Heater	27-2	Taillight	6-2
Horn	21-4	Turn Signal and Hazard Warning Light	5-2
Ignition	1-3	TVIP System	16-2
Illumination	8-2	Wiper and Washer	14-2
Interior Light	9-2	Wireless Door Lock Control	15-8
Key Reminder Buzzer	19-4		