



THE BOILER

by

Stephen Christie

FOR BOILER MAKERS, MARINE and STATIONARY
ENGINEERS, MACHINISTS and STEAMUSERS

BOILER

RULES AND TABLES

used in the

CONSTRUCTION, TESTING

AND OPERATION OF STEAM

BOILERS

Rules Comprehensive and Exemplified

Gauge for a Boiler 72" x 18'

Pounds Pressure

Temperature

Tonnage

NEW

PUBLICATION

1908


Stephen Christie

LIBRARY
OF THE
UNIVERSITY
OF
CALIFORNIA

CHRISTIE PUBLISHING CO., CHICAGO, ILL.

Engineers

Contemplating Taking Examinations Will Find This Work Indispensable



TJ285
C5

GENERAL

Copyright, 1908

by

STEPHEN CHRISTIE



PREFACE.

THE writer, after many years of experience in connection with boilers, as a boiler maker, master boiler maker, and boiler inspector, has, in his vocation, found it necessary to use rules, tables and formulas in conjunction with his work and duties and has profited by those of older and wider experience in the craft and, having had ample opportunity, inclination and resource for research for comprehensive, concise and condensed formulas and rules governing his daily duties, has compiled this work.

The author does not claim originality ; it is the intention to make the subject as clear as possible, to make it a pleasant study so that the layman can master the many rules that may seem too intricate and attention has been given to the most practical part of estimating values in connection with steam boiler designing.

Many valuable and scientific books have treated the subject of steam boilers and some exhaustively and from them I have learned. I have quoted from those authors' fund of information and from personal experience, and it will be my aim to make this compilation clear and free from any technicalities that would in a measure confuse the student and sincerely hope it may accomplish the mission intended, to interest those whose duties, labors and interests are in connection with the steam boiler.

STEPHEN CHRISTIE.

CHAPTER I.

MATERIALS.

It has been stated by historians that Tubal Cain was an iron worker, no doubt an artificer in plow shares and pruning hooks, but that in remote antiquity, when metals were few in number and knowledge of their uses limited, and it is doubtful if the steam boiler was among the articles made.

Historians record the nature of metals during those early ages as gold, silver, brass, iron, tin and lead, and also state that bronze had been in use before iron, thus we may favor doubt about boilers of some description being in use during those ages of antiquity.

Aristotle seems to be the earliest authority quoted on the subject of iron, saying "that iron was purified from acoria by melting, and after repeated treatments by melting became purified." What state of purification in relation to iron working tools or metals was not stated.

Daimachus, an early writer on the subject mentions different kinds of steel and the purposes to which they were used, and severally suited, viz.:

Chalybdie for carpenter tools.

Lacedaemonian for files and drills and stone cutters' tools.

Lydian for knives and razors.

Thus ancient history records some notice of materials used in boiler construction, but it is doubtful if ancient process of manufacturers or knowledge of material construction brought it up to anything like the state of perfection that could be used in steam boilers of today.

This chapter was not intended to treat on metallurgy only to touch upon materials as now used in these days of high pressure boilers.

Manufacturers assume great responsibilities in selecting material for boilers, hence care in selection.

Boiler making today is a science, demanding scientific education and knowledge gained by research, investigation and reasoning.

The writer can go back mentally to the days when boiler making was apparently in its infancy, this when comparing the boilers of to-

day with the demands for power and when the very low pressures were then well suited to the low grade material manufactured; designs crude, seams out of all proportions, bracing out of reasoning, and the ignorant mechanic, whose only evidence of work was strong in arm, wrought defects without thought of effects.

There is evolution and revolution in boiler making today.

High pressures are necessary, also care in selecting materials and designing boilers. The construction for the demands today are high pressures; due to competition, economy and fuel and space. It is necessary then to have all parts equal in strength, different parts favored with material of specific quality, such as braces, tubes, fire sheets, where circulation is least; corrosion, expansion, contraction or pitting active will necessitate increased thickness of plate; again, to secure complete circulation, combustion of fuel, etc.; to arrange heating surface in proportion to grate area and steam space, to make the form of boiler such that it can be constructed without mechanical difficulty or great expense.

Designs must be made to give strength, durability under the action of hot gases and corrosive elements, to be accessible, for cleaning, repairing and to provide safety appliance of ample proportions and applied properly. Thus the necessity of the greater education in boiler designing and construction and knowledge of material used.

Material for boiler purposes as well as other uses invariably contains in combination some proportion of various elements, and although these may appear small, have very marked influence upon its strength, ductility and working qualities, thus making it necessary to have both chemical as well as physical tests. In the manufacturing of boiler material the process of carburization changes the nature and properties of contained carbon, thus wrought iron contains from 5 per cent to only a trace per cent of carbon, and steel including all kinds of iron contains not more than 1.75 per cent of carbon and varies in fusibility, hardness, susceptibility to tempering and malleability. The first two properties being increased by increase of carbon, while the others are diminished.

All ores go through the process of reduction, and the more impurities they contain the greater amount of work is necessary to treat them; these include carbonic acid, water, combustible and earthy matter.

CAST IRON.

In cast iron these qualities looked for are taken from the fuel and mode of smelting, this materially as much as the character of ore. To convert cast iron into bar, forged or malleable iron, it has to be refined by smelting with coke or charcoal; this process eliminates the oxygen and carbon which may be left, thus bringing it to a state of refined metal, this is forged under hammer, passed through roll and drawn into bars, cut in lengths and formed into bundles or piles, again reheated and once more hammered and rolled into any shape. Cast iron has in its makeup carbon-silicon; this is a slag and its presence makes iron and steel hard and brittle, but up to 6 per cent is harmless providing 3 per cent. of manganese is present with it. Manganese, of which 5 per cent is sufficient to make iron cold short, is valuable in iron to be converted into steel.

Sulphur and phosphorus, when 8 per cent is present, make iron and steel crystallized and unfits it for plate for boiler purposes.

Arsenic increases the hardness in steel at the expense of toughness, as does carbon with it in form of graphite. The gray iron contains most graphite and carbon, making it more fusible and softer than white iron. The latter contains more combined carbon; these constituents vary, thus having various influence on the mechanical properties, and, after repeated fusings, loses its carbon.

THE ELEMENTS IN CAST IRON ARE AS FOLLOWS:

ELEMENTS.	PERCENTAGE.
Combined carbon.15 to 1.25 per cent
Graphite.	1.85 to 3.25 " "
Silicon.15 to 5. " "
Sulphur.	0 to .05 " "
Phosphorus.	0 to 1.3 " "
Manganese.	0 to 1.5 " "
Iron.	90. to 95. " "

Cast iron is not reliable for boiler construction unless for very low pressure, while it resists corrosion it is brittle and to get strength great thickness is necessary.

From cast iron to steel, plate is susceptible to the widest variation in its character; cast iron as extracted from ore, is melted with comparative facility and according to mode of operation in foundry, may be rendered so hard that it requires special tools to work it.

This metal by treatment with heat and air is converted into great tensile strength and ductility, still soft and easily worked into shapes without fracture.

The difference in molecular construction between cast and malleable iron is, the cast iron contains a larger proportion of carbon and some silicon, the malleable iron practically none—thus to produce steel the cast iron is melted first, then wrought iron and steel scraps are added by degrees (these in equal proportion), then an addition of spiegeleisen is added with manganese; as soon as this metal ceases to flow it is removed and poured into moulds, reheated and rolled into plate.

WROUGHT IRON.

Wrought iron is made by the process called puddling to eliminate the graphite and combined carbon from the pig iron, leaving sufficient to give strength in this new combination. In operation the mass is heated and kneaded by the paddles into blooms, and these are compressed under a hammer to remove the slag, again heated, rolled out and further squeezed by passing through rolls, thus forming a puddle bar. These bars are broken up and worked by hammering and rolling more or less according to degree of purity and strength required, thus iron plates retain the fibrous quality imparted to the bar, but owing to the secretion of cinder scale between the layers (thus producing blisters), careful tests are necessary by eye or hammer.

Wrought iron, while possessing great tenacity combined with toughness and ductility is well adapted to resist sudden strains.

While the puddle bars are going through the rolls oxide of iron is formed in scales, caused by the hot iron coming in contact with the air; these scales are collected for the puddling furnace, with use being that of absorbing the carbon from the iron.

The wrought iron is Lamina in its construction, is ductile and has a tensile strength varying up to 55,000 pounds per square inch and a ductility to 40 per cent; its uses in boiler construction are in tubes, rivets, braces and for reinforcement. One objectional feature in iron plates is the smallness of plate that can be manufactured without chance of blistering or lamination; another is the excess of labor due to more seams, thus reducing the strength of boiler.

The great advantages steel has over wrought iron are, plate can

be made in sizes of larger dimensions, boilers can be made of lighter material, greater power of conductivity of heat can be secured, but it necessitates greater care in flanging the material and in fitting up.

MATERIAL.

Average crushing and breaking strains of iron and steel:

Breaking strain of wrought iron	23 tons
Crushing " " " "	17 "
Breaking strain of cast iron.	7½ "
Crushing " " " "	50 "
Breaking strain of steel bars	55 "
Crushing " " " "	110 "

this per square inch of section.

STEEL PLATE.

Steel is a carburet of iron and the earliest invention of same was prepared by fusion and not by cementation ; in this later process the metal is surrounded by charcoál, and thus it draws its supply of carbon, the molecules of iron taking up the latter.

Since that early process there have been several methods employed to produce the steel, viz.:

- 1st Direct from ores.
- 2nd By addition of carbon and malleable iron.
- 3rd By the partial decarburization of pig iron.
- 4th By diluting the carbon in pig iron and the addition of malleable iron.

Steel plate is termed mild steel, low steel and high steel, which contains a high percentage of carbon. The following table will show the proportion of carbon and corresponding hardness:

NO. OF HARDNESS.	PER CENT OF CARBON.	OBSERVATION.
1	1.58 to 1.38.....	cannot be welded.
2	1.38 to 1.12.....	welds easily and used for chisels.
3	1.12 to .88.....	used for cutting tools.
4	.88 to .62.....	mild steel for tires, etc.
5	.62 to .38 and }	tempers slightly, steel for boiler plates.
6	.38 to .15 }	
7	.15 to .05.....	does not temper, used for machinery.

Steel and iron, like all other metals, are composed of atoms grouped in molecules, and any force that alters the relations of the atoms in the molecules modifies the physical properties of the metal. thus in heating, cooling and crushing the physical properties of metals vary with its degree of purity.

Density of a metal is dependent on the intimacy of the contact between the molecules and is influenced by temperature and rate of cooling; its density can be augmented by hammering or any compressing stress; pressure on all sides increases its density.

Malleability is the property of permanently extending in all directions without rupture by pressure produced by slow stress or by impact.

Ductility is the property that enables metal to be worked into flanges or drawn into wire, and this ductility increases with increased temperature.

Tenacity is a property possessed by metals in varying degree, it is the resisting, the separating of the molecules after the limit of elasticity has passed.

Hardness is the resistance offered by the molecules of a substance to their separation by penetrating action of another substance.

Brittleness is the sudden interruption of molecules, cohesion, when substances are subjected to the action of some extraneous force, such as a blow or change of temperature and largely influenced by purity of metal.

Elasticity is the power a body possesses of resuming its original form after removal of an external force which has changed its form, and to measure the strength of metals it is necessary to determine:

First.—The greatest stress the metal can sustain within the limits of elasticity.

Second.—The total extent of strain before rupture takes place.

Third.—The ultimate tensile strength or maximum stress the metals can sustain without rupture.

The difference between steel and iron is seen when subjected to a high temperature and suddenly cooled by plunging in cold water. The iron is affected very little while the steel becomes hardened.

A chemical test to distinguish iron from steel is by placing a drop of diluted nitric acid upon a clean surface of the metal; a greenish-gray stain appears upon iron; on the steel a black spot, this latter is due to the separation of carbon.

The processes of making boiler plate are the Siemens-Martin or open hearth process, and by the Bessemer converter. The latter is costly. The former offers better facilities for testing the quality

while still in a molten state and its character modified at will by addition of such material required to produce desired results. While the Bessemer process is not as desirable owing to its not offering facilities for testing or adjustment. The elements that increase tensile strength will reduce ductility, as carbon increases strength up to a certain limit then beyond excess reduces it, as a certain limit separates steel from cast iron.

The hardening elements are carbon, silicon, manganese and phosphorus.

Manganese steel contains a high percentage of the latter, having a little carbon and is avoided in boiler construction.

The qualities in steel for boilers are homogeneity, tenacity, elasticity and ductility; distinct from steel used for other purposes boiler plate should be tough and not of such a character that it might harden under the action of sudden great changes of temperature.

Steel is structural and chemical, it is a compound or an alloy of elements, silver, tungsten, chromium, titanium, silicon and cyanogen. It forms an intermediate link between ordinary cast iron and wrought iron, uniting with the properties of both and its distinguishness or characteristic is its capability of being hardened or softened by rapid or slow cooling.

TABLE SHOWING COMPARISONS OF IRON AND STEEL:

	I R O N .		S T E E L .	
	SWEDISH.	PENN.	MILD.	VERY MILD.
Carbon.....	.087	.067	.238	.009
Silicon.....	.56	.020	.105	.163
Sulphur.....	.005	.001	.012	.009
Phosphorus.....075	.034	.084
Manganese.....009	.184	.620
Iron.....	99.220	99.828	99.427	99.115

U. S. GOVERNMENT SPECIFICATIONS FOR MATERIAL.

Fire-box steel should show a tensile strength of not less than 52,000 pounds, and not over 62,000 pounds per square inch, an elastic limit not less than one-half ($\frac{1}{2}$) the ultimate strength, elongation 25 per cent and tested as follows: Cold and quench bends

180 degrees flat on itself without fracture on outside of bent portion, not over .04 per cent of sulphur or .04 per cent phosphorus.

Flange steel to show a tensile strength of from 55,000 to 65,000 pounds per square inch, elastic limit not less than one-half of its ultimate strength, elongation 25 per cent, cold and quench bends 180 degrees flat on itself, without fracture on one side of bent portion and not over .04 per cent of phosphorus and not over .05 per cent of sulphur.

Extra soft steel to show a tensile strength of 45,000 to 55,000 pounds per square inch, elastic limit not less than one-half its ultimate strength, elongation 28 per cent, cold and quench bends 180 degrees flat on itself without fracture on outside of bent portion, not over .04 per cent of sulphur or phosphorus.

Plates and steel rivets to be made by the open hearth process and tests to be made to determine tensile strength, ductility, elasticity, elongation; physical and chemical tests to be made at place of manufacture, all plates to be plainly stamped at corner near center. Material for stay bolts and braces to have a tensile strength of not less than 46,000 pounds per square inch when made of iron and not less than 55,000 pounds when made of steel.

Steel rivet material to have a tensile strength of 50,000 to 60,000 pounds per square inch of sectional area and elastic limit not less than one-half the ultimate strength, a bending test as follows at 180 degrees flat on itself without fracture on outside portion; elongation 26 per cent.


Iron rivet material to have a tensile strength of 40,000 pounds per square inch.

SPECIFICATION AND TESTING OF MATERIALS.

The U. S. Government rules as specified for the construction of boilers coming under federal supervision are as follows:

“That iron or steel plate intended for construction of boiler to be used in steam vessels shall be stamped in at least five different places by the manufacturer at place where made, viz., at corners about eight inches from edges and near center and with number of pounds per square inch of tensile strength; it will be the sectional inch and which must not be less than 45,000 pounds for iron or 50,000 pounds

for steel; from plates shall be taken coupons and prepared, by plain-
ing edges, these test pieces shall be at least 16 inches in length and
from one and one-half (1½) inches to three and one-half (3½)
inches in width at ends, which ends shall join by an easy fillet,
a straight in the center of at least 9 inches in length and 1 inch in
width, in form to the following diagram marked with light prick
punch marks at distances one inch apart, spaced so as to give 8
inches in length."



The strain necessary to break the test pieces as described is taken
as the proportion of the T S (tensile strength) per square inch.

EXAMPLES.

Test piece or coupon reduced to smallest part is one-fourth of a
square inch and is broken at 15,000 pounds.

$$\begin{array}{r} 15000 \\ \quad 4 \\ \hline 60000 \text{ TS per square inch} \end{array}$$

To determine the elongation, the part cut out in test piece
marked at inch sections and the force necessary to break it asunder
is the proportionate part of the T S per square inch, and distance
stretched represents percentage of elongation.

EXAMPLE.

To find percentage of elongation in a test piece. Coupon 8"
before testing, elongated to 10½."

$$\begin{array}{r} 10.5 = 10\frac{1}{2}'' \text{ after testing} \\ 8 \quad = \text{before testing} \\ \hline 10.5) 2.500 \text{ (23 per cent of elongation)} \\ \quad 2 \quad 10 \\ \hline \quad 400 \\ \quad 315 \\ \hline \quad 85 \end{array}$$

Test piece 1 $\frac{5}{8}$ x $\frac{3}{8}$ breaks at 34,000 pounds.

1.625
.375
<hr/>
8125
11375
4875
<hr/>
.609375)340000000 (55829 lbs. TS
3045
<hr/>
3550
3045
<hr/>
5050
4872
<hr/>
1780
1218
<hr/>
5620
5481
<hr/>
139

Strain necessary to break a test piece is the proportionate part of the tensile strength per square inch.

A piece of plate sectional area .5 square inch breaks at 30,000 pounds.

.5000)300000000 (60000 lbs. TS
300000
<hr/>
000

TABLE.

Showing width of plate expressed in 100th of an inch that will equal one quarter of one square inch of section of the various thickness of plate.

Example.—If plate is $\frac{1}{4}$ inch in thickness the width should be 100th of an inch wide to equal one quarter of one square inch of section or as follows:

$\frac{3}{16}$ x 133.	$\frac{5}{16}$ x 80
$\frac{1}{2}$ x 119.	$\frac{3}{8}$ x 76
$\frac{3}{4}$ x 109.	$\frac{1}{2}$ x 71
$\frac{7}{8}$ x 100.	$\frac{3}{4}$ x 67
$\frac{15}{16}$ x 96.	$\frac{7}{8}$ x 57
$\frac{15}{8}$ x 86.	$\frac{1}{2}$ x 50

Only steel plates manufactured by what is known as the basic or acid open hearth process will be allowed to be used in the construction of boilers for marine purposes and manufacturer shall furnish a certificate with each order of steel tested stating technical process by which said steel was manufactured, this is not intended to apply to plates used in construction of Bessemer steel tubes.

No plate made by acid process shall contain more than 0.06 per cent of phosphorus or 0.04 per cent of sulphur, and no plate made by the basic process shall contain more than .04 per cent of sulphur or phosphorus. This to be determined by analysis by the manufacturer.

Steel plates must have a tensile strength not less than 55,000 pounds and not over 75,000 pounds per square inch of section, but boilers whose construction is commenced after June 30, 1905, where plate will come in contact with fire either in use or in course of construction of the boiler the tensile strength shall not be more than 70,000 pounds per square inch of section.

No plate shall be stamped with a greater tensile strength than 70,000.

Elongation shall show at least 25 per cent in a length of 2 inches for thickness to one-fourth ($\frac{1}{4}$) inclusive in a length of 4 inches for over one-fourth to seven-sixteenths inch, inclusive; in a length of 6 inches for all plates over seven-sixteenths inch. The sample must show a reduction of sectional area as follows:

At least 50 per cent for thickness over one-half to three-fourths inch inclusive, 45 per cent for thickness over one-half to three-fourths inclusive, and 32.5 per cent for thickness over three-fourths of an inch.

Quenching and bending test pieces shall be at least 12 inches in length and from 1 to $3\frac{1}{2}$ inches in width. The sides where sheared or planed must not be rounded, but the edges may have the sharpness taken off with a fine file. The test piece shall be heated to a cherry red (as seen in a dark place) and then plunged into water at a temperature of about 82 degrees F. Thus prepared the sample shall be bent to a curve, the inner radius of which is not greater than one and one-half times the thickness of the sample without cracks or flaws, the ends must be parallel after bending.

Iron plates when tested must show a tensile strength of not less than 45,000 pounds and not over 60,000 pounds per square inch of

sectional area and show an elongation of at least 15 per cent in a length of 8 inches and a reduction of area as follows: For plate having 45,000 T S 15 per cent, and for each additional 1,000 pounds up to 55,000 add 1 per cent; for samples over 55,000 pounds up to 60,000 T S 25 per cent shall be required; a bending test as follows: a piece 12 inches in length and from 1 to 3½ inches in width, the edge not to be rounded, then bent cold to an angle of 90 degrees to a curve the inner radius of which no greater than one and one-half times the thickness of the sample without cracks or flaws."

The chemical or analytical test is for the purpose to show right proportions of elements and properties useful in the material's make-up, for specific purposes, and if free from those whose presence are bad, a certain proportion of carbon gives it a given degree of strength, while a small percentage of sulphur will render it useless for boiler purposes. The effect of the latter and phosphorus is crystalization of metal.

Plates are usually ordered by thickness, but there are occasions when weight is defined rather than the thickness and rejected unless up to demands. The effects sometimes are that owing to the plates being made of large dimensions and cut up to demands for smaller sizes some of uneven thickness are left; this is due to the process of rolling, the center of rolls expanding, thus leaving center of plate thicker; while rolls are turned in center to obviate this effect the heating of rolls must offset the turning down.

BOILER DESIGNING.

Boiler designing is a science and much depends on the accuracy of details.

Modern engines, higher pressure, and that potent factor of the times, competition, demand the greatest efficiency from fuel and engine.

But a few years ago comparatively, the rule was "thumb" in the designing of a boiler, of "what had been done" without any reasoning; this apparently when we see some of the boilers now in use; plates, seams, rivets, location of same, brace design, number, and method of attaching them, tubes, size, number and distribution; domes, their ratio to boiler, old-time makers and engineers said, "one-fifth the size of boiler was a fair ratio;" all giving evidence that

it was no defined rule from reasoning, but following what had been done. Today the designing of a boiler is a problem to be worked out, solved by factors entering into the matter; location, space economy, fuel economy, engine design and efficiency, arrangement of furnaces that available heat can be most completely absorbed and utilized, effects of contraction and expansion, the various types of boiler must be considered for their niche of maximum usefulness, for often times one will excel in certain duties and fail in another. Requirements must be looked into and the one factor, location, would change a design completely, for instance, where space is limited, cost and life may be sacrificed, another where fuel would be for life, again, locations where fuel must be sacrificed, where water is bad, and a design must be made to suit the accessibilities to clean. Again, an illustration of what must be considered, and the sacrifice for demands and conditions to obtain results, is the fire engine boiler, life, cost, fuel, and access to clean and repair, all for quick steaming qualities. Then grate proportion for heating surface in different types of boiler, and the necessity of steam space and tube arrangement to avoid obstruction of steam passages that retard circulation; points which in early boiler designing were badly neglected.

Increased pressure has been demanded due to space and type of engine would often times vary proportions.

The power of boilers today is estimated from an evaporative measure, not from the old-time commercial rating, i. e., so many square feet of heating surface per H. P., leaving design or type out of the question. Thus we see the importance of boiler designing. The earliest known steam generator was a sphere. In the boiler of Worcester and Papin and Savery the flue encircled the outside of shell. Newcomen substituted that by having a hemispherical top and flat arch or bottom. The wagon boiler designed by Watt resembled a wagon and hence its name. Boilers have been made in many and various forms, classified by designer's name, their uses or form. Today boilers are generally classed as internal, external, water tube, pipe, and sectional (the latter used extensively for heating), each class usually bearing a name incident to their use, such as locomotive or marine, again boilers are further classed as vertical, horizontal, tubular, cylinder and flue.

CHAPTER II.

SELECTION OF BOILER.

In estimating the power of a boiler it was formerly a custom to have a certain number of square feet of heating surface to represent a H. P. (horse power) and the different types were supposed to have better or inferior efficiencies due to design for instance.

The cylinder type of boiler was reckoned from a unit of 10 square feet of heating surface per horse power, the horizontal tubular type, 12 to 15 square feet; the reason for the difference was the former type of boiler's heating surface was considered as all active and exposed to the highest temperature, while the latter had the heating surface of tubes that was exposed to the waste gases after coming in contact with the bottom thus a lower temperature, while as a fact the tubes were thinner and had more conductivity for heat; thus 15 square feet was considered the unit of measurement for that type.

Internal fire boilers were measured from the 10 square feet standard.

But as fuels now are valued by their heating values, the amount of water they will evaporate per pound of class fuel, so with the boiler, it must be measured from its efficiency from an evaporative point, other factors entering into its performances are hardness of water and temperature of feed water.

As the subject of the steam boiler is one that can be treated almost inexhaustibly, it is the writer's intention to devote this work to boiler rules and tables governing their construction.

ENGINE POWER.

Power, or as it is mechanically expressed, heat, is measured, and the unit of this measurement is the amount of heat which will raise the temperature of one pound of water one degree F at its point of greatest density (39 deg. F.). The number of heat units in one pound of water at any given temperature is called the "Heat in liquid," when heat is applied to water in open vessel the temperature

will rise until its boiling point is reached, beyond this point no increase of temperature will result; the heat absorbed being employed in transforming the water from liquid to steam; this is called the "heat of vaporization," and diminishes as the temperature and pressure increases. The "heat in liquid," added to the "heat of vaporization," is equal to the total heat. The ratio of the amount of heat required to make one pound of steam under any given conditions to that required to make a pound of steam from and at 212° is called the "factor of evaporation."

This factor is found by subtracting the heat units in one pound of the feed water at the given temperature from the heat units or total heat of one pound of the steam at the given pressure, and dividing the result by 965.7, which is the heat of vaporization, or number of heat units required to evaporate one pound of water at 212° into steam at 212°.

The total number of pounds of water to be evaporated per hour under a given steam pressure multiplied by its particular factor of evaporating gives us the "equivalent evaporation," from and at 212°, or in other words, the amount of water which would have been evaporated, with the same amount of fuel, had the feed water been at 212 degrees and the pressure that of the atmosphere.

Assuming an engine to be one of 200 H. P. and the boiler to be selected according to the commercial rating of boilers. The given data to determine from would be:

200 HP engine,
 engine taking 20 lbs. of steam per HP per hour
 120 absolute pressure (by gauge 105)
 190° temperature of feed water
 the evaporation of 34.5 lbs. of water at 212°.

As stated, the number of pounds of water to be evaporated to produce a horse power from an engine will be computed from the type of engine used. See table of engine efficiencies, Standards of Steam Engine.

TABLE OF STANDARD OF STEAM ENGINES.

TYPE OF BOILERS.		TYPE OF ENGINES.				
Pounds of water evaporated in a common Horizontal Tubular boiler per lbs. of coal burned, 7 to 8 lbs.	Pounds of water evaporated in a modern water tube boiler per lbs. of coal burned, 9 to 10 lbs.	Simple non-condensing automatic cut-off engine, steam pressure 80 to 90 lbs.	Simple condensing automatic cut-off engines, steam pressure 80 to 90 lbs.	Compound non-condensing engines, steam pressure 130 to 140 lbs.	Compound condensing engines, steam pressure 120 to 140 lbs.	Triple cylinder expansion engines, steam pressures 140 to 160 lbs.
Water consumption of different types of engines per 1 HP per hour.		32 lbs.	22 lbs.	20 lbs.	16 lbs.	13 lbs.
Coal consumption per 1 HP per hour with a modern water tube boiler.		3½ lbs.	2½ lbs.	2¼ lbs.	1¾ lbs.	1¼ lbs.
Coal consumption per 1 HP per hour with a common HT boiler.		4 lbs.	3 lbs.	2¾ lbs.	2¼ lbs.	1¾ lbs.

RULES FOR CALCULATION.

THE CIRCLE.

Multiply diameter by 3.1416 to find circumference. Multiply circumference by .31831 to find diameter. Multiply square of diameter by .7854 to find area. Multiply the square root of area by 1.12837 to find diameter. Multiply diameter by .8862 to find side of a square equal to area. Multiply diameter by .7071—product is side of an inscribed square.

Rule to find area of a circular ring formed by two concentric circles: Multiply the sum of the two diameters by their difference and the product by .7854—the result is area. Multiply radius by 6.2831 to find circumference.

Rule to find area of a section of a circle: Multiply one-half the length of arc by the radius of circle.

Rule to find area of a sector: Multiply length of arc by the radius and divide the product by 2 for the area.

EXAMPLE:

50'' = length of arc of sector
 30'' = radius

$$\begin{array}{r} \hline 2)1500 \\ \hline \end{array}$$

750 = area of sector

Rule to find area of a triangle: Multiply base by height and divide the product by 2 for the area.

EXAMPLE:

38'' = base of triangle
 20'' = height of triangle

$$\begin{array}{r} \hline 2)760 \\ \hline \end{array}$$

380 = area of triangle

Rule to find area of a segment of a circle: Subtract area of triangle from area of sector. The result will be the area of segment.

EXAMPLE:

750 = area of sector
 380 = area of triangle

$$\begin{array}{r} \hline 370 = \text{area of segment} \\ \hline \end{array}$$

Rule to find one dimension of triangle when area and one dimension is given: Double the area and divide by given dimension.

Rule to find area of triangle when dimensions of three sides are given: From half the sum of the three sides, subtract each side separately; multiply the half sum and the three remainders together; the square root of the product is the area.

Rule to find hypotenuse of a triangle when dimensions of base and perpendicular are given: Extract the square root of the sum of the squares of the base and the perpendicular; the result is the length of hypotenuse.

Rule to find the base or perpendicular when hypotenuse is given: Extract the square root of the difference between the square of the squares of the base and the perpendicular; the result is the required side.

QUADRILATERALS.

Rule to find area of a parallelogram: Multiply base by altitude.

Rule to find area of a trapezoid: Multiply one-half sum of the parallel sides by the altitude.

Rule to find area of a trapezium: Multiply the diagonal by one-half sum of the perpendiculars drawn to it from the vertices of opposite angle.

Rule to find area of a rectangle: Multiply length by width.

Doubling the diameter of a circle increases its area four times.

The side of a square multiplied by 1.128 equals diameter of circle of equal area.

Rule to find volume of a pyramid or cone: Multiply the area of the base by one-third the altitude.

Rule to find the convex surface of a frustrum of a pyramid or of a cone: Multiply the sum of the perimeters or of the circumference by one-half the slant height.

Rule to find the volume of a frustrum of a pyramid or of a cone: To the sum of the areas of both bases add the square root of the product and multiply this sum by one-third of the altitude.

THE SPHERE.

Rule to find the surface of a sphere: Multiply the diameter by the circumference of a great circle of a sphere.


Rule to find the volume of a sphere: Multiply the surface by $1/6$ of the diameter or $1/3$ of the radius.

Rule to find the three dimensions of a rectangular solid, the volume and ratio of the dimensions being given: First, divide the volume by the product of the terms proportional to the three dimensions, and extract the cube root of the quotient. Second, multiply the root obtained by each proportional term; the products will be the corresponding side.

Rule to find solidity of a sphere: Multiply cube of diameter by .5236.

Rule to find surface of a ball: Multiply square of diameter by 3.1416.

A TRAPEZOID.



A plane four sided figure having two of the opposite sides parallel to each other.

Rule to find area of a trapezoid whose sides are 26" and 14" altitude 10": Multiply one-half the sums of parallel sides by the altitude.

EXAMPLE:

$$\begin{array}{r}
 26'' \\
 14 \\
 \hline
 2)40 \\
 \hline
 20 \\
 10 \\
 \hline
 200 \text{ area of trapezoid}
 \end{array}$$

SOLIDS.

Rule to find volume of a prism or cylinder: Multiply area of the base by the altitude.

Rule to find convex surface of a prism or cylinder: Multiply the perimeter or circumference of the base by the altitude.

SIGNS USED IN MATHEMATICAL CALCULATIONS.

- π Ratio of circumference of a circle to a diam., as 3.1416
- = Equal, as 12 inches = 1 foot
- +
- Plus, addition, as $2 + 4 = 6$
-
- Minus, subtraction, as $8 - 4 = 4$
- \times
- Multiply, as $4 \times 4 = 16$
- \div
- Divide, as $10 \div 2 = 5$
- : : :
- Proportion, as $2 : 4 :: 8 : 16$; or 2 is to 4 as 8 is to 16
- $\sqrt{\quad}$
- Square root is required; cube root, $\sqrt[3]{27} = 3$
- 5^2
- Number is to be squared, $5^2 = 25$
- 5^3
- Number is to be cubed, $5^3 = 125$
- .
- Decimal point, as $.1 = \frac{1}{10}$; $.14 = \frac{14}{100}$
- ()
- Parenthesis, all numbers between to be taken as one
- $\frac{\quad}{\quad}$
- Vinculum signifies the numbers over which it is placed are to be taken together.
- °
- Degrees
- '
- Minutes or feet
- "
- Seconds or inches

A coefficient is a prescribed amount to make up for any defects reducing the strength of plate due to punching, caulking, etc.

A factor of safety is the difference between the safe working and bursting pressures.

CIRCUMFERENCES AND AREAS OF CIRCLES.

OF ONE INCH.				OF INCHES OR FEET.					
Fract.	Dec.	Circ.	Area	Dia.	Circ.	Area	Dia.	Circ.	Area.
1-64	.015625	.04909	.00019	1	3.1416	.7854	64	201.06	3216.99
1-32	.03125	.09818	.00077	2	6.2832	3.1416	65	204.20	3318.31
3-64	.046875	.14726	.00173	3	9.4248	7.0686	66	207.34	3421.19
1-16	.0625	.19635	.00307	4	12.5664	12.5664	67	210.49	3525.65
5-64	.078125	.24545	.00479	5	15.7080	19.635	68	213.63	3631.68
3-32	.09375	.29452	.00690	6	18.850	28.274	69	216.77	3739.28
7-64	.109375	.34363	.00939	7	21.991	38.485	70	219.91	3848.45
1-8	.125	.39270	.01227	8	25.133	50.266	71	223.05	3959.19
9-64	.140625	.44181	.01553	9	28.274	63.617	72	226.19	4171.50
5-32	.15625	.49087	.01917	10	31.416	78.540	73	229.34	4185.39
11-64	.171875	.53999	.02320	11	34.558	95.033	74	232.48	4300.84
3-16	.1875	.58905	.02761	12	37.699	113.1	75	235.62	4417.86
13-64	.203125	.63817	.03241	13	40.841	132.73	76	238.76	4536.46
7-32	.21875	.68722	.03758	14	43.982	153.94	77	241.90	4656.63
15-64	.234375	.73635	.04314	15	47.124	176.71	78	245.04	4778.36
1-4	.25	.78540	.04909	16	50.265	201.06	79	248.19	4901.67
17-64	.265625	.83453	.05542	17	53.407	226.98	80	251.33	5026.55
9-32	.28125	.88357	.06213	18	56.549	254.47	81	254.47	5153.
19-64	.296875	.93271	.06922	19	59.690	283.53	82	257.61	5281.02
5-16	.3125	.98175	.07670	20	62.832	314.16	83	260.75	5410.61
21-64	.328125	1.0309	.08456	21	65.973	346.36	84	263.89	5541.77
11-32	.34375	1.0799	.09281	22	69.115	380.13	85	267.04	5674.50
23-64	.359375	1.1291	.10144	23	72.257	415.48	86	270.18	5808.80
3-8	.375	1.1781	.11045	24	75.398	452.39	87	273.32	5944.68
25-64	.390625	1.2273	.11984	25	78.540	490.87	88	276.46	6082.12
13-32	.40625	1.2763	.12962	26	81.681	530.93	89	279.60	6221.14
27-64	.421875	1.3254	.13979	27	84.823	572.56	90	282.74	6361.73
7-16	.4375	1.3744	.15033	28	87.965	615.75	91	285.88	6503.88
29-64	.453125	1.4236	.16126	29	91.106	660.52	92	289.03	6647.61
15-32	.46875	1.4726	.17257	30	94.248	706.86	93	292.17	6792.91
31-64	.484375	1.5218	.18427	31	97.389	754.77	94	295.31	6939.78
1-2	.5	1.5708	.19635	32	100.53	804.25	95	298.45	7088.22
33-64	.515625	1.6199	.20880	33	103.67	855.30	96	301.59	7238.23
17-32	.53125	1.6690	.22166	34	106.81	907.92	97	304.73	7389.81
35-64	.546875	1.7181	.23489	35	109.96	962.11	98	307.88	7542.96
9-16	.5625	1.7671	.24850	36	113.10	1017.88	99	311.02	7697.69
37-64	.578125	1.8163	.26248	37	116.24	1075.21	100	314.16	7853.99
19-32	.59375	1.8653	.27688	38	119.38	1134.11	101	317.30	8011.85
39-64	.609375	1.9145	.29164	39	122.52	1194.59	102	320.44	8171.28
5-8	.625	1.9635	.30680	40	125.66	1256.64	103	323.58	8332.29
41-64	.640625	2.0127	.32232	41	128.81	1320.25	104	326.73	8494.87
21-32	.65625	2.0617	.33824	42	131.95	1385.44	105	329.87	8659.01
43-64	.671875	2.1108	.35453	43	135.09	1452.20	106	333.01	8824.73
11-16	.6875	2.1598	.37122	44	138.23	1520.53	107	336.15	8992.02
45-64	.703125	2.2090	.38828	45	141.37	1590.43	108	339.29	9160.88
23-32	.71875	2.2580	.40574	46	144.51	1661.90	109	342.43	9331.32
47-64	.734375	2.3072	.42356	47	147.65	1734.94	110	345.58	9503.32
3-4	.75	2.3562	.44179	48	150.80	1809.56	111	348.72	9676.89
49-64	.765625	2.4054	.45253	49	153.94	1885.74	112	351.86	9852.03
25-32	.78125	2.4544	.47937	50	157.08	1963.50	113	355.	10028.75
51-64	.796875	2.5036	.49872	51	160.22	2042.82	114	358.14	10207.03
13-16	.8125	2.5525	.51849	52	163.36	2123.72	115	361.28	10386.89
53-64	.828125	2.6017	.53862	53	166.50	2206.18	116	364.42	10568.32
27-32	.84375	2.6507	.55914	54	169.65	2290.22	117	367.57	10751.32
55-64	.859375	2.6999	.58003	55	172.79	2375.83	118	370.71	10935.88
7-8	.875	2.7489	.60132	56	175.93	2463.01	119	373.85	11122.02
57-64	.890625	2.7981	.62298	57	179.07	2551.76	120	376.99	11309.73
29-32	.90625	2.8471	.64504	58	182.21	2642.08	121	380.13	11499.01
59-64	.921875	2.8963	.66746	59	185.35	2733.97	122	383.27	11699.87
15-16	.9375	2.9452	.69029	60	188.50	2827.43	123	386.42	11882.29
61-64	.953125	2.9945	.71349	61	191.64	2922.47	124	389.56	12076.28
31-32	.96875	3.0434	.73708	62	194.78	3019.07	125	392.70	12271.85
63-64	.984375	3.0928	.76097	63	197.92	3117.25	126	395.84	12468.98

SELECTION OF BOILER.

AREAS OF CIRCLES FROM $\frac{1}{32}$ INCH UP TO 10 INCHES IN DIAMETER, ADVANCING BY THIRTY-SECONDS OF AN INCH.

INCHES.

	0"	1"	2"	3"	4"	5"	6"	7"	8"	9"	
0		.7854	3.1416	7.068	12.56	19.63	28.27	38.48	50.26	63.62	0
$\frac{1}{32}$.000767	.8352	3.240	7.216	12.76	19.88	28.57	38.83	50.66	64.06	$\frac{1}{32}$
$\frac{1}{16}$.00306	.8866	3.341	7.366	12.96	20.13	28.87	39.17	51.05	64.50	$\frac{1}{16}$
$\frac{3}{32}$.0069	.9395	3.443	7.516	13.16	20.38	29.16	39.52	51.45	64.95	$\frac{3}{32}$
$\frac{1}{8}$.0123	.9940	3.546	7.669	13.36	20.63	29.46	39.87	51.85	65.40	$\frac{1}{8}$
$\frac{5}{32}$.0192	1.050	3.651	7.824	13.57	20.88	29.77	40.22	52.25	65.84	$\frac{5}{32}$
$\frac{3}{16}$.0276	1.107	3.758	7.970	13.77	21.13	30.07	40.57	52.65	66.30	$\frac{3}{16}$
$\frac{1}{4}$.0376	1.166	3.866	8.137	13.98	21.39	30.37	40.93	53.05	66.75	$\frac{1}{4}$
	.0491	1.227	3.976	8.295	14.19	21.65	30.68	41.28	53.46	67.20	$\frac{1}{4}$
$\frac{9}{32}$.0621	1.289	4.087	8.456	14.40	21.91	30.99	41.64	53.86	67.65	$\frac{9}{32}$
$\frac{5}{16}$.0767	1.353	4.199	8.618	14.61	22.17	31.30	42.00	54.27	68.11	$\frac{5}{16}$
$\frac{3}{8}$.0928	1.418	4.314	8.781	14.82	22.43	31.61	42.36	54.68	68.57	$\frac{3}{8}$
	.1104	1.484	4.430	8.946	15.03	22.69	31.92	42.72	55.09	69.03	$\frac{3}{8}$
$\frac{7}{16}$.1296	1.553	4.547	9.112	15.25	22.95	32.23	43.08	55.50	69.49	$\frac{7}{16}$
$\frac{1}{2}$.1503	1.623	4.666	9.280	15.47	23.22	32.55	43.45	55.91	69.95	$\frac{1}{2}$
	.1725	1.694	4.786	9.450	15.68	23.49	32.86	43.81	56.33	70.42	$\frac{1}{2}$
	.1963	1.767	4.908	9.621	15.90	23.76	33.18	44.18	56.74	70.88	$\frac{1}{2}$
$\frac{9}{16}$.2216	1.840	5.032	9.794	16.13	24.03	33.50	44.55	57.16	71.35	$\frac{9}{16}$
$\frac{5}{8}$.2485	1.917	5.157	9.968	16.35	24.30	33.82	44.92	57.58	71.82	$\frac{5}{8}$
	.2770	1.994	5.283	10.14	16.57	24.58	34.15	45.29	58.00	72.29	$\frac{5}{8}$
	.3067	2.073	5.411	10.32	16.80	24.85	34.47	45.66	58.43	72.76	$\frac{5}{8}$
$\frac{11}{16}$.3382	2.154	5.541	10.50	17.03	25.13	34.80	46.04	58.85	73.23	$\frac{11}{16}$
$\frac{3}{4}$.3712	2.236	5.672	10.68	17.26	25.41	35.12	46.41	59.28	73.71	$\frac{3}{4}$
	.4057	2.319	5.805	10.86	17.49	25.68	35.45	46.79	59.70	74.18	$\frac{3}{4}$
	.4417	2.405	5.939	11.04	17.72	25.97	35.78	47.17	60.13	74.66	$\frac{3}{4}$
$\frac{13}{16}$.4793	2.492	6.075	11.23	17.95	26.25	36.11	47.55	60.56	75.14	$\frac{13}{16}$
$\frac{7}{8}$.5184	2.581	6.212	11.41	18.19	26.53	36.45	47.94	60.99	75.62	$\frac{7}{8}$
	.5591	2.669	6.351	11.60	18.43	26.82	36.79	48.32	61.24	76.10	$\frac{7}{8}$
	.6013	2.761	6.491	11.79	18.66	27.11	37.12	48.71	61.86	76.59	$\frac{7}{8}$
$\frac{25}{32}$.6450	2.854	6.633	11.98	18.91	27.40	37.46	49.09	62.30	77.07	$\frac{25}{32}$
$\frac{15}{16}$.6903	2.948	6.777	12.18	19.15	27.69	37.80	49.48	62.74	77.56	$\frac{15}{16}$
$\frac{31}{32}$.7370	3.044	6.922	12.37	19.39	27.98	38.14	49.87	63.18	78.05	$\frac{31}{32}$

DECIMALS OF A FOOT FOR EACH $\frac{1}{32}$ ND OF AN INCH.

INCH	0"	1"	2"	3"	4"	5"	6"	7"	8"	9"	10"	11"
0	0	.0833	.1667	.2500	.3333	.4167	.5000	.5833	.6667	.7500	.8333	.9167
$\frac{1}{32}$.0026	.0859	.1693	.2526	.3359	.4193	.5026	.5859	.6693	.7526	.8359	.9193
$\frac{2}{32}$.0052	.0885	.1719	.2552	.3385	.4219	.5052	.5885	.6719	.7552	.8385	.9219
$\frac{3}{32}$.0078	.0911	.1745	.2578	.3411	.4245	.5078	.5911	.6745	.7578	.8411	.9245
$\frac{4}{32}$.0104	.0937	.1771	.2604	.3437	.4271	.5104	.5937	.6771	.7604	.8437	.9271
$\frac{5}{32}$.0130	.0964	.1797	.2630	.3464	.4297	.5130	.5964	.6797	.7630	.8464	.9297
$\frac{6}{32}$.0156	.0990	.1823	.2656	.3490	.4323	.5156	.5990	.6823	.7656	.8490	.9323
$\frac{7}{32}$.0182	.1016	.1849	.2682	.3516	.4349	.5182	.6016	.6849	.7682	.8516	.9349
$\frac{8}{32}$.0208	.1042	.1875	.2708	.3542	.4375	.5208	.6042	.6875	.7708	.8542	.9375
$\frac{9}{32}$.0234	.1068	.1901	.2734	.3568	.4401	.5234	.6068	.6901	.7734	.8568	.9401
$\frac{10}{32}$.0260	.1094	.1927	.2760	.3594	.4427	.5260	.6094	.6927	.7760	.8594	.9427
$\frac{11}{32}$.0286	.1120	.1953	.2786	.3620	.4453	.5286	.6120	.6953	.7786	.8620	.9453
$\frac{12}{32}$.0312	.1146	.1979	.2812	.3646	.4479	.5312	.6146	.6979	.7812	.8646	.9479
$\frac{13}{32}$.0339	.1172	.2005	.2839	.3672	.4505	.5339	.6172	.7005	.7839	.8672	.9505
$\frac{14}{32}$.0365	.1198	.2031	.2865	.3698	.4531	.5365	.6198	.7031	.7865	.8698	.9531
$\frac{15}{32}$.0391	.1224	.2057	.2891	.3724	.4557	.5391	.6224	.7057	.7891	.8724	.9557
$\frac{16}{32}$.0417	.1250	.2083	.2917	.3750	.4583	.5417	.6250	.7083	.7917	.8750	.9583
$\frac{17}{32}$.0443	.1276	.2109	.2943	.3776	.4609	.5443	.6276	.7109	.7943	.8776	.9609
$\frac{18}{32}$.0469	.1302	.2135	.2969	.3802	.4635	.5469	.6302	.7135	.7969	.8802	.9635
$\frac{19}{32}$.0495	.1328	.2161	.2995	.3828	.4661	.5495	.6328	.7161	.7995	.8828	.9661
$\frac{20}{32}$.0521	.1354	.2188	.3021	.3854	.4688	.5521	.6354	.7188	.8021	.8854	.9688
$\frac{21}{32}$.0547	.1380	.2214	.3047	.3880	.4714	.5547	.6380	.7214	.8047	.8880	.9714
$\frac{22}{32}$.0573	.1406	.2240	.3073	.3906	.4740	.5573	.6406	.7240	.8073	.8906	.9740
$\frac{23}{32}$.0599	.1432	.2266	.3099	.3932	.4766	.5599	.6432	.7266	.8099	.8932	.9766
$\frac{24}{32}$.0625	.1458	.2292	.3125	.3958	.4792	.5625	.6458	.7292	.8125	.8958	.9792
$\frac{25}{32}$.0651	.1484	.2318	.3151	.3984	.4818	.5651	.6484	.7318	.8151	.8984	.9818
$\frac{26}{32}$.0677	.1510	.2344	.3177	.4010	.4844	.5677	.6510	.7344	.8177	.9010	.9844
$\frac{27}{32}$.0703	.1536	.2370	.3203	.4036	.4870	.5703	.6536	.7370	.8203	.9036	.9870
$\frac{28}{32}$.0729	.1562	.2396	.3229	.4062	.4896	.5729	.6562	.7396	.8229	.9062	.9896
$\frac{29}{32}$.0755	.1589	.2422	.3255	.4089	.4922	.5755	.6589	.7422	.8255	.9089	.9922
$\frac{30}{32}$.0781	.1615	.2448	.3281	.4115	.4948	.5781	.6615	.7448	.8281	.9115	.9948
$\frac{31}{32}$.0807	.1641	.2474	.3307	.4141	.4974	.5807	.6641	.7474	.8307	.9141	.9974
1												1.0000

HORSE POWER MEASUREMENT.

In calculating the H. P. boiler required for a given engine it is customary to calculate what amount of water would be evaporated per hour at the temperature of 212 atmospheric pressure.

The ratio of the amount of heat required to make one pound of steam under any given condition to that required to make a pound of steam from 212° is called the factor of evaporation, and this is found by subtracting the heat units in one pound of the feed water at the given temperature, from the heat units in one pound of steam at the given pressure, and dividing the result by 965.7, which is the heat of evaporation, or number of heat units required to evaporate one pound of water at 212° into steam of 212°.

The number of pounds of water to be evaporated per hour under a given steam pressure, multiplied by its particular factor of evaporation, gives the factor of evaporation from and at 212° (or the amount of water which would have been evaporated with the same amount of fuel, had the feed water been at 212 degrees atmospheric pressure.

Hence it is first necessary to find the amount of water the engine is to use per hour; then the factor of evaporation and the product of these two will be the equivalent from and at 212°; 34½ pounds of water at 212° evaporated into steam at atmospheric pressure equals a horse power; dividing the equivalent evaporation by 34½ gives the horse power required.

Rule to find capacity of boiler for any engine, this according to the commercial rating of boilers: Multiply the horse power of the engine by the number of pounds of steam the engine will consume per indicated horse power per hour and call this product No. 1; from the number of heat units contained in one pound of the steam at absolute pressure subtract the number of heat units in one pound of feed water, and divide by 965.7 to get factor of evaporation, and call this product No. 2; multiply product No. 1 by product No. 2 and divide by 34½ (the number of pounds of water evaporated from and at 212°, to develop one horse power), and this product will be the required commercial rating of boiler.

LEGEND:

E	= Power of engine
L	= Lbs. of steam per horse power
P	= Pressure
T	= Temperature of feed water
W	= Water to be evaporated per HP per hour
TSH	= Total heat units in steam
HU	= Heat units in feed water
HE	= Heat of evaporation
FE	= Factor of evaporation
W of W	= Weight of water used per HP per hour

FORMULA:

$$\frac{E \times L \times (TSH - HU \div 965.7)}{34\frac{1}{2}} = \text{commercial rating of boiler.}$$

THE BOILER.

No. 1 200 HP engine
 20 No. of lbs. of steam per HP per hour
 4000 = the weight in lbs. of water used per hour

No. 2
 Heat units to evaporate one lb. of water at 212° into steam at 212° =

1217.9445	= total heat of given steam
190.643	= heat units in feed water
<hr/>	
965.7)	1027.3015 (1.063 factor of evaporation
	965 7
<hr/>	
	61 601
	57 942
<hr/>	
	3 6595
	2 8971
<hr/>	
	7624

1.063 factor of evaporation = product No. 2
 4000 weight of water in lb. use per hour = product No. 1
 4252.000 the equivalent evaporation from and at 212° F.

Weight of water required per hour per HP for high pressure engine =

34.5)	4252.000 (123.24 commercial HP of boiler required
	345
<hr/>	
	802
	690
<hr/>	
	1120
	1035
<hr/>	
	850
	690
<hr/>	
	1600
	1380
<hr/>	
	220

This example was figured on a basis of 34½ lbs. of water per engine HP. The consumption of steam of modern engine, per HP, varies in limits, depending on type of engine.

PROPERTIES OF STEAM.

The temperature at which water is converted into steam varies with the pressure. At atmospheric the steaming point is 212 degrees F., less at low pressure and higher at higher pressure. When water reaches the boiling point, further addition of heat effects no change in temperature, the heat absorbed in producing steam having the same temperature and pressure as that at which it is

evaporated. The heat thus absorbed is known as the latent heat, so called because it produces effects other than those of change of temperature. The amount of heat rendered latent by each pound of water in becoming steam varies with the pressure, decreasing as the pressure rises. The latent heat added to the sensible heat (this latter as shown by the thermometer) gives the total heat, this term used to designate the number of heat units contained in one pound of steam above a given temperature. Total heat is calculated from 32 degrees F. as the total heat is greater the higher the pressure; the amount of fuel necessary to evaporate a pound of water increases with the pressure; saturated steam cannot be superheated in contact with water, that is, its temperature cannot be raised above the point normal to the pressure, neither can it be cooled without change of pressure, for any loss of heat is compensated by the latent heat of the steam which is condensed.

Saturated steam is that which has the minimum temperature at which it can exist as a vapor under the given pressure.

Superheated steam has a temperature higher than that of saturation at the same pressure. The same pressure above vacuum is the gauge pressure plus 14.7 pounds.

TABLE
PRESSURE OF STEAM AT DIFFERENT TEMPERATURES.

Pounds pressure per square inch above vacuum	Temperature Fahr.	Heat units in water above 32°	Latent heat in Heat of Vaporization	Total heat units above 32°	Volume of one pound in cubic foot
1	101.99	70.0	1043.0	1113.1	334.5
5	162.34	130.7	1000.8	1131.5	73.21
10	193.25	161.9	979.0	1140.9	38.15
15	213.03	181.8	965.1	1146.9	26.14
20	227.95	196.9	954.6	1151.5	19.91
25	240.04	209.1	946.0	1155.1	16.13
30	250.72	219.4	938.9	1158.3	13.59
35	259.19	228.4	932.6	1161.0	11.75
40	267.13	236.4	927.0	1163.4	10.37
45	274.29	243.6	922.0	1165.6	9.285
50	280.85	250.2	917.4	1167.6	8.418
55	286.89	256.3	913.1	1169.4	7.698
60	292.51	261.9	909.3	1171.2	7.097
65	297.77	267.2	905.5	1172.7	6.583
70	302.71	272.2	902.1	1174.3	6.143
75	307.38	276.9	898.8	1175.7	5.760

PRESSURE OF STEAM AT DIFFERENT TEMPERATURES.

Pounds pressure per square inch above vacuum	Temperature Fahr.	Heat units in water above 32°	Latent heat in Heat of Vaporization	Total heat units above 32°	Volume of one pound cubic foot
80	311.80	281.4	895.6	1177.0	5.426
85	316.02	285.8	892.5	1178.3	5.126
90	320.04	290.0	889.6	1179.6	4.859
95	323.89	294.0	886.7	1180.7	4.619
100	327.58	297.9	884.0	1181.9	4.403
105	331.13	301.6	881.3	1182.9	4.205
110	334.56	305.2	878.8	1184.0	4.026
115	337.86	308.7	876.3	1185.0	3.862
120	341.05	312.0	874.0	1186.0	3.711
125	344.13	315.2	871.7	1186.9	3.572
130	347.12	318.4	869.4	1187.8	3.444
135	350.03	321.4	867.3	1188.7	3.323
140	352.85	324.4	865.1	1189.5	3.212
145	355.59	327.2	863.2	1190.4	3.107
150	358.26	330.0	861.0	1191.2	3.011
155	360.86	332.7	859.3	1192.0	2.919
160	363.40	335.4	857.4	1192.8	2.833
165	365.88	338.0	855.6	1193.6	2.751
170	368.29	340.5	853.8	1194.3	2.676
175	370.65	343.0	852.0	1195.0	2.603
180	372.97	345.4	850.3	1195.7	2.535
185	375.23	347.8	848.6	1196.4	2.470
190	377.44	350.1	847.0	1197.1	2.408
195	379.61	352.4	845.3	1197.7	2.349
200	381.73	354.6	843.8	1198.4	2.294
205	383.82	356.8	842.2	1199.0	2.241
210	385.87	358.9	840.7	1199.6	2.190
215	387.88	361.0	839.2	1200.2	2.142
220	389.84	363.0	837.8	1200.8	2.096
225	391.79	365.1	836.3	1201.4	2.051
250	400.99	374.7	829.5	1204.2	1.854
275	409.50	383.6	823.2	1206.8	1.691
300	417.42	391.9	817.4	1209.3	1.553
325	424.82	399.6	811.9	1211.5	1.437
350	431.90	406.9	806.8	1213.7	1.337
375	438.40	414.2	801.5	1215.7	1.250
400	445.15	421.4	796.3	1217.7	1.172
500	466.57	444.3	779.9	1224.2	.939

ENGINE NOTES.

Steam at atmospheric pressure flows into a *Vacuum* at the rate of about 1,550 feet per second, and into the *Atmosphere* at the rate of 650 feet per second.

The specific gravity of steam (at atmospheric pressure) is .411, that of air at 34 deg. Fahrenheit, and .0006 that of water at same temperature.

33000 minute foot pounds equal 1 H. P.

396000 minute inch pounds equal 1 H. P.

A cubic inch of water evaporated under atmospheric pressure is approximately converted into 1 cubic foot of steam.

The horse power of boilers, as per standard adopted by the Am. S. M. E., is 30 pounds water evaporated per hour at a pressure of 70 pounds per square inch and from a temperature of 100 degrees Fahr.

Well designed boilers, under successful operation, will evaporate from 7 to 10 pounds of water per pound of first-class coal.

Each square foot of heating surface is considered sufficient to evaporate $3\frac{1}{2}$ pounds of water; therefore, for an engine using 30 pounds of water per horse power per hour, each horse power of the engine requires **8.75** square feet heating surface in the boiler.

On one square foot of fire grate can be burned on an average from 10 to 12 pounds hard coal, or 18 to 35 pounds soft coal, per hour, with natural draft.

Two and one-quarter pounds of dry wood is equal to 1 pound of average quality soft coal.

Condensing engines require from 20 to 30 times the amount of feed water for condensing purposes; approximately for most engines, 1 to $1\frac{1}{2}$ gallons condensing water per minute per indicated horse power, depending on temperature of injection water.

Surface condensers for compound steam engines require about 2 square feet of cooling surface per horse power; ordinary engines will require more surface according to their economy in the use of steam. It is absolutely necessary that the air pump should be set lower than the condenser for satisfactory results.

The effect of a good air pump and condenser should be to get 25 inches of vacuum and to make available about 10 pounds more mean effective pressure with the same terminal pressure, or to give the same mean effective pressure with a correspondingly less terminal pressure. Approximately, a good condenser will save one-fourth of the fuel consumed, or, in other words, increase the power of the engine one-fourth, the fuel consumption remaining the same.

One pound of water evaporated from, and at 212° F. is equivalent to 965.7 British thermal units.

The evaporation of 30 pounds of water per hour, from a temper-

THE BOILER.

ature of 100° F., into steam at 70 pounds gauge pressure = one H. P. This is equivalent to 34½ pounds of water from and at 212° F.

A common rule to find horse power on an engine: Multiply area of piston by pressure per square inch and by length of stroke and again by number of revolutions per minute; divide this sum by constant 16500.

LEGEND:

P = pressure = 100 lbs.
 A = area of piston = 78.5400
 S = length of stroke in feet = 1 ft.
 R = number of revolutions = 70
 C = constant = 16500

FORMULA:

$$\frac{A \times P \times S \times R}{C} = \text{H.P.}$$

EXAMPLE:

78.5400 = area of piston
 100 = lbs. pressure

7854.0000
 1 ft. stroke

7854.0000
 70 = number of revolutions

constant = 16500) 549780.0000 (33.3 = horse power
 49500

54780
 49500

52800
 49500

3300

THE THERMOMETER.

To convert Fahrenheit degrees to centigrade, subtract 32 degrees from number of degrees Fahrenheit; multiply the sum by 5 and divide product by 9.

LEGEND:

F = Fahrenheit = 32°
 C = Centigrade = 100°
 R = Reaumur = 80°

FORMULA:

$$\frac{5 \times (F - 32)}{9} = \text{Centigrade}$$

EXAMPLE:

212 = degrees Fahrenheit

$$\begin{array}{r} 32 \\ \hline 180 \\ 5 \cdot \\ \hline 9)900 \end{array}$$

100 = Centigrade

To convert Centigrade degrees to Fahrenheit: Multiply the number of degrees centigrade by 9, divide result by 5 and add 32 to quotient.

FORMULA:

$$\frac{9 \times C}{5} + 32 = \text{Fahrenheit}$$

EXAMPLE:

100 = degrees Centigrade

$$\begin{array}{r} 9 \\ \hline 5)900 \\ \hline 180 \\ 32 \text{ to be added} \end{array}$$

212 = degrees Fahrenheit

To convert Fahrenheit degrees to Reaumur subtract from number of degrees Fahrenheit 32; multiply result by 4 and divide product by 9.

FORMULA:

$$\frac{4 \times (F - 32)}{9} = \text{Reaumur}$$

EXAMPLE:

212 = degrees Fahrenheit

$$\begin{array}{r} 32 \\ \hline 180 \\ 4 \\ \hline 9)720 \end{array}$$

80 = degrees Reaumur

To convert Reaumur degrees to Fahrenheit: Multiply number of degrees of Reaumur by 9; divide product by 4 and add 32 to quotient.

FORMULA:

$$\frac{9 \times R}{4} + 32 = \text{Fahrenheit}$$

EXAMPLE:

80 = degrees Reaumur

$$\begin{array}{r} 9 \\ \hline 4)720 \\ \hline 180 \\ 32 \text{ to be added} \end{array}$$

212 = degrees Fahrenheit

THE BOILER.

COMPARISONS OF THERMOMETER SCALES.

Fahrenheit	Centigrade	Reaumur	Fahrenheit	Centigrade	Reaumur
— 4	—20	—16	113	45	36
+ 5	15	12	112	50	40
14	10	8	131	55	44
23	5	4	140	60	48
32	0	0	149	65	52
41	+ 5	+ 4	158	70	56
50	10	8	167	75	60
59	15	12	176	80	64
68	20	16	185	85	68
77	25	20	194	90	72
86	30	24	203	95	76
95	35	28	212	100	80
104	40	32
BOILING POINT	BOILING POINT	BOILING POINT	FREEZING POINT	FREEZING POINT	FREEZING POINT
212	100	80	32	0	0

CHAPTER III.

BOILER CONSTRUCTION.

Boiler construction can be classed as one of the highest among crafts. In old-time boiler making holes were punched leaving initial fractures around edge of holes and often times, when assembling joints, holes were found out of alignment, and to admit a rivet the plate had to be cut by reaming to make the holes coincide, thus reducing the percentage of strength, at best, very low. Today drilled holes are specified by reliable authorities and followed up by reputable boiler makers. Modern machinery of today has developed a wonderful improvement in the craft; it has taken the place of old-time hand methods; accuracy, efficiency and strength have been gained; improved tools to facilitate work, brain and not all muscle employed by the mechanics; he reasons, conceives, then executes with these modern conveniences; his aim is to produce results, betterment of his work. Flanging machines have added factors to safety; that old methods of flanging were not conducive to good effects or results is now apparent; for when the part of work to be flanged was heated, hammered, reheated and hammered again—hot and cold—often resulting in defects in plates that made them unfit for use, time and material would be wasted. With the modern flanging machine time is saved, expense lessened and work turned out as near perfect as possible, one heat and the cooling having an annealing effect, general and gradual, gang punches adjusted accurately, time and labor saved and the efficiency of joint holes not impaired.

Rivet machinery with its power of compression ensures strength of rivet joints and lessens the effect of injury to plate by caulking as done by the old-time hand riveted joint, especially when left to the novice, defects were developed and material operated on was destroyed.

Electric cranes and air lifts are found necessary for facilitating work by aiding in assembling or fitting up parts of boilers under construction.

Thus we find boiler making today one of the scientific mechanical crafts and with the expectations that work carried out as designed produce the best results.

This book will give general rules and tables used in the construction of the steam boiler and governing their use in safety.

RIVETS AND RIVETING.

In designing a joint like any part of the construction of boilers, care in calculation and proportioning of rivet are very essential. Shearing strength and ductility are important factors; perfect alignment of holes, size of same, and method of making same, must not be overlooked.

On the driving of a rivet will depend much. Without going into the details on the subject of riveting it may be well to say that in the old-time methods of hand riveting the structural makeup of a rivet was changed; when the rivet should have been finished, the many repeated blows soon changed its nature, and, unnecessary to say, "it was near finished." But improved machinery has wrought changes and with it the changing of rivet material—this in turn has provided a larger factor of safety using old rules, and has provided greater efficiency by lighter material.

The heating of rivet to proper degree of heat is another important measure and with modern forges as used this can be accomplished with no difficulty or more than ordinary attention.

TABLE OF RIVETS AND BOLTS WITHOUT NUTS IN 100 LBS.

Average number.

Length of Rivets.	DIAMETER OF RIVETS.								
	¼	⅕	⅜	⅞	½	⅝	⅔	¾	⅞
½	8000	5100	3200	1900
⅝	7000	4500	2900	1800
¾	6300	4100	2373	1476	1103	642
⅞	5700	3700	2190	1371	1030	604
1	5200	3400	2034	1280	968	571	400	345	...
1⅛	4700	3100	1898	1200	910	541	382	322	208
1¼	4400	2900	1780	1129	862	514	365	311	206
1⅝	4100	2700	1675	1066	815	489	350	295	204
1½	4000	2500	1582	1010	776	462	335	284	201
1⅞	3800	2300	1498	960	740	446	324	275	199
1¾	3500	2200	1424	914	707	428	311	266	192
1⅞	3400	2000	1356	872	672	411	302	257	185
2	3000	1900	1295	834	648	395	293	249	178
2⅞	1238	800	623	381	285	240	172
2¼	2800	1800	1187	768	599	367	277	233	167
2⅝	1139	738	577	354	269	226	162
2½	2500	1700	1095	711	556	343	261	219	157
2⅞	1052	687	537	332	253	212	152
2¾	1017	662	519	321	245	206	148
2⅞	982	636	503	311	237	201	144
3	949	611	487	302	230	196	140
3¼	890	581	459	285	218	186	132
3½	837	548	433	270	208	177	126
3¾	791	519	411	257	198	168	120
3⅞	395	250	195	165	119
4	749	400	390	244	189	161	115
4¼	372	233	180	155	110
4½	355	223	172	149	105
4¾	339	214	166	143	101
5	325	205	160	136	97
5¼	312	197	154	131	94
5½	300	190	149	127	91
5¾	289	183	144	123	88
6	279	177	139	118	85

The measurement of a cone or button head rivet is taken under the head; rivets for counter sunk holes measured over all.

Safe loads for any number of iron rivets from one to ten, ranging in diameter from 1/2 inch to 1 3/8 inches, assuming a shearing strength of 42,000 pounds for iron rivets in single shear, as determined by experiments conducted by the Master Steam Boilermakers' Association and reported and endorsed at the 1906 convention of that Association.

Diam. of Rivet.	Diam. of Hole.	Area of Hole.	SHEARING STRENGTH OF IRON RIVETS AT 42,000 LBS. PER SQUARE INCH.									
			1 Rivet.	2 Rivets.	3 Rivets.	4 Rivets.	5 Rivets.	6 Rivets.	7 Rivets.	8 Rivets.	9 Rivets.	10 Rivets.
1/2	5/8	.2485	10,437	20,874	31,311	41,748	52,185	62,622	73,059	83,496	93,933	104,370
5/8	3/4	.3068	12,885	25,770	38,655	51,540	64,425	77,310	90,195	103,080	115,965	128,850
3/4	7/8	.3712	15,590	31,180	46,770	62,360	77,950	93,540	109,130	124,720	140,310	155,900
7/8	1	.4417	18,551	37,102	55,653	74,204	92,755	111,306	129,857	148,408	166,959	185,510
1	1 1/8	.5185	21,777	43,554	65,331	87,108	108,885	130,662	152,439	174,216	195,993	217,770
1 1/8	1 1/4	.6013	25,254	50,508	75,762	101,016	126,270	151,524	176,778	202,032	227,286	252,540
1 1/4	1 1/2	.6902	28,988	57,976	86,964	115,952	144,940	173,928	202,916	231,904	260,892	289,880
1 1/2	1 5/8	.7854	32,986	65,972	98,958	131,944	164,930	197,916	230,902	263,888	296,874	329,860
1 5/8	1 3/4	.8866	37,237	74,474	111,711	148,948	186,185	223,422	260,659	297,896	335,133	372,370
1 3/4	1 7/8	.9940	41,748	83,496	125,244	166,992	208,740	250,488	292,236	333,984	375,732	417,480
1 7/8	2	1.1079	46,515	93,030	139,545	186,060	232,575	279,090	325,605	372,120	418,635	465,150
2	2 1/8	1.2271	51,538	103,076	154,614	206,152	257,690	309,228	360,766	412,304	463,842	515,380
2 1/8	2 1/4	1.3529	56,822	113,644	170,466	227,288	284,110	340,932	397,754	454,576	511,398	568,220
2 1/4	2 1/2	1.4848	62,361	124,722	187,083	249,444	311,805	374,166	436,527	498,888	561,249	623,610
2 1/2	2 3/8	1.6229	68,162	136,324	204,486	272,648	340,810	408,972	477,134	545,296	613,458	681,620

Safe loads for any number of steel rivets from one to ten, ranging in diameter from 1/2 inch. to 1 3/8 inches, assuming a shearing strength of 45,000 pounds for steel rivets in single shear, as determined by experiments conducted by the Master Steam Boilermakers' Association and reported and endorsed at the 1906 convention of that Association.

SHEARING STRENGTH OF STEEL RIVETS AT 45,000 LBS. PER SQUARE INCH.												
Diam. of Rivet,	Diam. of Hole,	Area of Hole,	1 Rivet.	2 Rivets.	3 Rivets.	4 Rivets.	5 Rivets.	6 Rivets.	7 Rivets.	8 Rivets.	9 Rivets.	10 Rivets.
1/2	9/16	.2485	11,182	22,364	33,546	44,728	55,910	67,092	78,274	89,456	100,638	111,820
5/8	11/16	.3068	13,806	27,612	41,418	55,224	69,030	82,836	96,642	110,448	124,254	138,060
3/4	1 1/16	.3712	16,704	33,408	50,112	66,816	83,520	100,224	116,928	133,632	150,336	167,040
7/8	1 1/8	.4417	19,876	39,752	59,628	79,504	99,380	119,256	139,132	159,008	178,884	198,760
1	1 1/4	.5185	23,332	46,664	69,996	93,328	116,660	139,992	163,324	186,656	209,988	233,320
1 1/8	1 3/8	.6013	27,058	54,116	81,174	108,232	135,290	162,348	189,406	216,464	243,522	270,580
1 1/4	1 1/2	.6902	31,059	62,118	93,177	124,236	155,295	186,354	217,413	248,472	279,531	310,590
1 1/2	1 5/8	.7854	35,343	70,686	106,029	141,372	176,715	212,058	247,401	282,744	318,087	353,430
1 3/8	1 3/4	.8866	39,888	79,776	119,664	159,552	199,440	239,328	279,216	319,104	358,992	398,880
1 3/4	1 7/8	.9940	44,730	89,460	134,190	178,920	223,650	268,380	313,110	357,840	402,570	447,300
1 7/8	2	1.1075	49,837	99,674	149,511	199,348	249,185	299,022	348,859	398,696	448,533	498,370
2	2 1/16	1.2271	55,219	110,438	165,657	220,876	276,095	331,314	386,533	441,752	496,971	552,190
2 1/16	2 1/8	1.3529	60,880	121,760	182,640	243,520	304,400	365,280	426,160	487,040	547,920	608,800
2 1/8	2 1/4	1.4848	66,816	133,632	200,448	267,264	334,080	400,896	467,712	534,528	601,344	668,160
2 1/4	2 3/8	1.6229	73,030	146,060	219,090	292,120	365,150	438,180	511,210	584,240	657,270	730,300

NOTE: In calculating the strength of rivets in the above tables, the diameter of the driven rivet, or in other words, the diameter of the hole, has been used in all cases

WEIGHT OF CIRCULAR BOILER HEADS.

Diameter in Inches	THICKNESS IN INCHES												
	1/8	1/4	3/8	1/2	5/8	3/4	7/8	1	1 1/8	1 1/4	1 1/2	1 3/4	
15	7	11	18	25	29								
17	8	12	20	28	33								
18	9	14	23	32	36								
19	10	15	25	34	39								
20	11	17	28	37	42								
22	12	19	31	40	45								
24	14	22	37	46	51								
25	15	22	37	45	52								
26	16	24	41	49	57								
28	18	26	44	53	62								
29	19	29	47	57	67								
30	21	31	51	62	72								
32	22	33	55	66	77								
34	24	36	60	71	83								
36	25	38	64	76	89								
38	27	41	69	81	95								
40	29	43	74	86	101								
42	31	46	80	92	108								
44	33	49	86	98	115								
46	35	52	92	105	122								
48	37	55	98	113	130								
50	39	58	104	121	138								
52	41	61	110	128	146	162	178	194	210	225	240	255	270
54	43	64	116	136	154	172	190	207	225	242	259	276	293
56	45	66	122	142	163	182	201	220	239	258	277	296	315
58	47	68	128	152	175	195	215	235	254	274	294	314	334
60	49	71	134	162	186	206	226	246	266	286	306	326	346
62	51	74	140	172	199	220	240	260	280	300	320	340	360
64	53	77	146	180	213	234	254	274	294	314	334	354	374
66	55	80	152	190	223	244	264	284	304	324	344	364	384
68	57	82	158	200	234	256	276	296	316	336	356	376	396
70	59	85	164	210	244	268	288	308	328	348	368	388	408
72	61	88	170	220	254	280	300	320	340	360	380	400	420
74	63	91	176	230	264	292	312	332	352	372	392	412	432
76	65	94	182	240	274	308	328	348	368	388	408	428	448
78	67	97	188	250	284	318	338	358	378	398	418	438	458
80	69	100	194	260	294	328	348	368	388	408	428	448	468
82	71	103	200	270	304	338	358	378	398	418	438	458	478
84	73	106	206	280	314	348	368	388	408	428	448	468	488
86	75	109	212	290	324	358	378	398	418	438	458	478	498
88	77	112	218	300	334	368	388	408	428	448	468	488	508
90	79	115	224	310	344	378	398	418	438	458	478	498	518
92	81	118	230	320	354	388	408	428	448	468	488	508	528
94	83	121	236	330	364	398	418	438	458	478	498	518	538
96	85	124	242	340	374	408	428	448	468	488	508	528	548
98	87	127	248	350	384	418	438	458	478	498	518	538	558
100	89	130	254	360	394	428	448	468	488	508	528	548	568
102	91	133	260	370	404	438	458	478	498	518	538	558	578
104	93	136	266	380	414	448	468	488	508	528	548	568	588
106	95	139	272	390	424	458	478	498	518	538	558	578	598
108	97	142	278	400	434	468	488	508	528	548	568	588	608
110	99	145	284	410	444	478	498	518	538	558	578	598	618
112	101	148	290	420	454	488	508	528	548	568	588	608	628
114	103	151	296	430	464	498	518	538	558	578	598	618	638
116	105	154	302	440	474	508	528	548	568	588	608	628	648
118	107	157	308	450	484	518	538	558	578	598	618	638	658
120	109	160	314	460	494	528	548	568	588	608	628	648	668
122	111	163	320	470	504	538	558	578	598	618	638	658	678
124	113	166	326	480	514	548	568	588	608	628	648	668	688
126	115	169	332	490	524	558	578	598	618	638	658	678	698
128	117	172	338	500	534	568	588	608	628	648	668	688	708
130	119	175	344	510	544	578	598	618	638	658	678	698	718
132	121	178	350	520	554	588	608	628	648	668	688	708	728
134	123	181	356	530	564	598	618	638	658	678	698	718	738
136	125	184	362	540	574	608	628	648	668	688	708	728	748
138	127	187	368	550	584	618	638	658	678	698	718	738	758
140	129	190	374	560	594	628	648	668	688	708	728	748	768
142	131	193	380	570	604	638	658	678	698	718	738	758	778
144	133	196	386	580	614	648	668	688	708	728	748	768	788
146	135	199	392	590	624	658	678	698	718	738	758	778	798
148	137	202	398	600	634	668	688	708	728	748	768	788	808
150	139	205	404	610	644	678	698	718	738	758	778	798	818
152	141	208	410	620	654	688	708	728	748	768	788	808	828
154	143	211	416	630	664	698	718	738	758	778	798	818	838
156	145	214	422	640	674	708	728	748	768	788	808	828	848
158	147	217	428	650	684	718	738	758	778	798	818	838	858
160	149	220	434	660	694	728	748	768	788	808	828	848	868
162	151	223	440	670	704	738	758	778	798	818	838	858	878
164	153	226	446	680	714	748	768	788	808	828	848	868	888
166	155	229	452	690	724	758	778	798	818	838	858	878	898
168	157	232	458	700	734	768	788	808	828	848	868	888	908
170	159	235	464	710	744	778	798	818	838	858	878	898	918
172	161	238	470	720	754	788	808	828	848	868	888	908	928
174	163	241	476	730	764	798	818	838	858	878	898	918	938
176	165	244	482	740	774	808	828	848	868	888	908	928	948
178	167	247	488	750	784	818	838	858	878	898	918	938	958
180	169	250	494	760	794	828	848	868	888	908	928	948	968
182	171	253	500	770	804	838	858	878	898	918	938	958	978
184	173	256	506	780	814	848	868	888	908	928	948	968	988
186	175	259	512	790	824	858	878	898	918	938	958	978	998
188	177	262	518	800	834	868	888	908	928	948	968	988	1008
190	179	265	524	810	844	878	898	918	938	958	978	998	1018
192	181	268	530	820	854	888	908	928	948	968	988	1008	1028
194	183	271	536	830	864	898	918	938	958	978	998	1018	1038
196	185	274	542	840	874	908	928	948	968	988	1008	1028	1048
198	187	277	548	850	884	918	938	958	978	998	1018	1038	1058
200	189	280	554	860	894	928	948	968	988	1008	1028	1048	1068
202	191	283	560	870	904	938	958	978	998	1018	1038	1058	1088
204	193	286	566	880	914	948	968	988	1008	1028	1048	1068	1108
206	195	289	572	890	924	958	978	998	1018	1038	1058	1078	1128
208	197	292	578	900	934	968	988	1008	1028	1048	1068	1088	1148
210	199	295	584	910	944	978	998	1018	1038	1058	1078	1098	1168
212	201	298	590	920	954	988	1008	1028	1048	1068	1088	1108	1188
214	203	301	596	930	964	998	1018	1038	1058	1078	1098	1118	1208
216	205	304	602	940	974	1008	1028	1048	1068	1088	1108	1128	1228
218	207	307	608	950	984	1018	1038	1058	1078	1098	1118	1138	1248
220	209	310	614	960	994	1028	1048	1068	1088	1108	1128	1148	1268
222	211	313	620	970	1004	1038	1058	1078	1098	1118	1138	1158	1288
224	213	316	626	980	1014	1048	1068	1088	1108	1128	1148	1168	1308
226	215	319	632	990	1024	1058	1078	1098	1118	1138			

BOILER CONSTRUCTION.

WEIGHT OF CIRCULAR BOILER HEADS.

Diameter in Inches	THICKNESS IN INCHES													
	1/8	1/4	3/8	1/2	5/8	3/4	7/8	1	1 1/8	1 1/4	1 1/2	1 3/4	2	
55	128	170	213	255	298	341	383	426	468	511	554	597	640	683
56	132	177	221	265	309	352	397	441	485	529	572	616	659	703
57	137	183	229	274	319	363	407	452	496	540	584	628	672	716
58	142	189	237	284	329	372	416	461	505	549	593	637	681	725
59	147	196	245	294	343	387	431	476	520	564	608	652	696	740
60	152	204	254	305	356	402	447	492	536	580	624	668	712	756
61	157	212	264	317	370	417	462	507	551	595	639	683	727	771
62	162	220	275	328	382	431	476	521	565	609	653	697	741	785
63	167	228	282	338	392	441	486	531	575	619	663	707	751	795
64	172	235	291	349	407	456	501	546	590	634	678	722	766	810
65	177	243	300	360	420	470	515	560	604	648	692	736	780	824
66	182	251	310	371	432	482	527	572	616	660	704	748	792	836
67	187	258	319	383	447	497	542	587	631	675	719	763	807	851
68	192	265	328	394	459	509	554	600	644	688	732	776	820	864
69	197	271	338	408	474	524	569	614	658	702	746	790	834	878
70	202	279	348	428	497	547	592	637	681	725	769	813	857	901
71	207	287	358	440	512	562	607	652	696	740	784	828	872	916
72	212	295	368	452	526	576	621	666	710	754	798	842	886	930
73	217	303	379	464	539	589	634	679	723	767	811	855	899	943
74	222	311	389	477	553	603	648	693	737	781	825	869	913	957
75	227	320	400	489	566	616	661	706	750	794	838	882	926	970
76	232	328	410	502	580	630	675	720	764	808	852	896	940	984
77	237	337	421	516	595	645	690	735	779	823	867	911	955	999
78	242	345	432	532	612	662	707	752	796	840	884	928	972	1016
79	247	355	443	550	630	680	725	770	814	858	902	946	990	1034
80	252	364	455	566	646	696	741	786	830	874	918	962	1006	1050
81	257	373	467	580	660	710	755	800	844	888	932	976	1020	1064
82	262	382	479	594	674	724	769	814	858	902	946	990	1034	1078
83	267	391	491	608	688	738	783	828	872	916	960	1004	1048	1092
84	272	400	503	620	700	750	795	840	884	928	972	1016	1060	1104
85	277	409	516	636	716	766	811	856	900	944	988	1032	1076	1120
86	282	418	529	654	734	784	829	874	918	962	1006	1050	1094	1138
87	287	427	542	672	752	802	847	892	936	980	1024	1068	1112	1156
88	292	436	555	692	772	822	867	912	956	1000	1044	1088	1132	1176
89	297	445	568	712	792	842	887	932	976	1020	1064	1108	1152	1196
90	302	454	581	732	812	862	907	952	996	1040	1084	1128	1172	1216
91	307	463	594	752	832	882	927	972	1016	1060	1104	1148	1192	1236
92	312	472	607	772	852	902	947	992	1036	1080	1124	1168	1212	1256
93	317	481	620	792	872	922	967	1012	1056	1100	1144	1188	1232	1276
94	322	490	633	812	892	942	987	1032	1076	1120	1164	1208	1252	1296
95	327	499	646	832	912	962	1007	1052	1096	1140	1184	1228	1272	1316
96	332	508	659	852	932	982	1027	1072	1116	1160	1204	1248	1292	1336
97	337	517	672	872	952	1002	1047	1092	1136	1180	1224	1268	1312	1356
98	342	526	685	892	972	1022	1067	1112	1156	1200	1244	1288	1332	1376
99	347	535	698	912	992	1042	1087	1132	1176	1220	1264	1308	1352	1396
100	352	544	711	932	1012	1062	1107	1152	1196	1240	1284	1328	1372	1416
101	357	553	724	952	1032	1082	1127	1172	1216	1260	1304	1348	1392	1436
102	362	562	737	972	1052	1102	1147	1192	1236	1280	1324	1368	1412	1456
103	367	571	750	992	1072	1122	1167	1212	1256	1300	1344	1388	1432	1476
104	372	580	763	1012	1092	1142	1187	1232	1276	1320	1364	1408	1452	1496
105	377	589	776	1032	1112	1162	1207	1252	1296	1340	1384	1428	1472	1516
106	382	598	789	1052	1132	1182	1227	1272	1316	1360	1404	1448	1492	1536
107	387	607	802	1072	1152	1202	1247	1292	1336	1380	1424	1468	1512	1556
108	392	616	815	1092	1172	1222	1267	1312	1356	1400	1444	1488	1532	1576
109	397	625	828	1112	1192	1242	1287	1332	1376	1420	1464	1508	1552	1596
110	402	634	841	1132	1212	1262	1307	1352	1396	1440	1484	1528	1572	1616
111	407	643	854	1152	1232	1282	1327	1372	1416	1460	1504	1548	1592	1636
112	412	652	867	1172	1252	1302	1347	1392	1436	1480	1524	1568	1612	1656
113	417	661	880	1192	1272	1322	1367	1412	1456	1500	1544	1588	1632	1676
114	422	670	893	1212	1292	1342	1387	1432	1476	1520	1564	1608	1652	1696
115	427	679	906	1232	1312	1362	1407	1452	1496	1540	1584	1628	1672	1716
116	432	688	919	1252	1332	1382	1427	1472	1516	1560	1604	1648	1692	1736
117	437	697	932	1272	1352	1402	1447	1492	1536	1580	1624	1668	1712	1756
118	442	706	945	1292	1372	1422	1467	1512	1556	1600	1644	1688	1732	1776
119	447	715	958	1312	1392	1442	1487	1532	1576	1620	1664	1708	1752	1796
120	452	724	971	1332	1412	1462	1507	1552	1596	1640	1684	1728	1772	1816
121	457	733	984	1352	1432	1482	1527	1572	1616	1660	1704	1748	1792	1836
122	462	742	997	1372	1452	1502	1547	1592	1636	1680	1724	1768	1812	1856
123	467	751	1010	1392	1472	1522	1567	1612	1656	1700	1744	1788	1832	1876
124	472	760	1023	1412	1492	1542	1587	1632	1676	1720	1764	1808	1852	1896
125	477	769	1036	1432	1512	1562	1607	1652	1696	1740	1784	1828	1872	1916
126	482	778	1049	1452	1532	1582	1627	1672	1716	1760	1804	1848	1892	1936
127	487	787	1062	1472	1552	1602	1647	1692	1736	1780	1824	1868	1912	1956
128	492	796	1075	1492	1572	1622	1667	1712	1756	1800	1844	1888	1932	1976
129	497	805	1088	1512	1592	1642	1687	1732	1776	1820	1864	1908	1952	1996
130	502	814	1101	1532	1612	1662	1707	1752	1796	1840	1884	1928	1972	2016
131	507	823	1114	1552	1632	1682	1727	1772	1816	1860	1904	1948	1992	2036
132	512	832	1127	1572	1652	1702	1747	1792	1836	1880	1924	1968	2012	2056
133	517	841	1140	1592	1672	1722	1767	1812	1856	1900	1944	1988	2032	2076
134	522	850	1153	1612	1692	1742	1787	1832	1876	1920	1964	2008	2052	2096
135	527	859	1166	1632	1712	1762	1807	1852	1896	1940	1984	2028	2072	2116
136	532	868	1179	1652	1732	1782	1827	1872	1916	1960	2004	2048	2092	2136
137	537	877	1192	1672	1752	1802	1847	1892	1936	1980	2024	2068	2112	2156
138	542	886	1205	1692	1772	1822	1867	1912	1956	2000	2044	2088	2132	2176
139	547	895	1218	1712	1792	1842	1887	1932	1976	2020	2064	2108	2152	2196
140	552	904	1231	1732	1812	1862	1907	1952	1996	2040	2084	2128	2172	2216
141	557	913	1244	1752	1832	1882	1927	1972	2016	2060	2104	2148	2192	2236
142	562	922	1257	1772	1852	1902	1947	1992	2036	2080	2124	2168	2212	2256
143	567	931	1270	1792	1872	1922	1967	2012	2056	2100	2144	2188	2232	2276
144	572	940	1283	1812	1892	1942	1987	2032	2076	2120	2164	2208	2252	2296
145	577	949	1296	1832	1912	1962	2007	2052	2096	2140	2184	2228	2272	2316
146	582	958	1309	1852	1932	1982	2027	2072						

WEIGHT OF CIRCULAR BOILER HEADS.

Diameter in Inches	THICKNESS IN INCHES													
	$\frac{1}{8}$	$\frac{1}{4}$	$\frac{3}{8}$	$\frac{1}{2}$	$\frac{5}{8}$	$\frac{3}{4}$	$\frac{7}{8}$	1	1 1/8	1 1/4	1 1/2	1 3/4	2	
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115

Heads below heavy line will run heavier than the weight given.

ESTIMATING THE WEIGHT OF STEEL PLATES.

The table of the weight of steel plates is based upon the assumption that one cubic inch of rolled steel weighs .2833 pounds and that this is increased, by the springage of the rolls, by a certain percentage depending upon the width and thickness of the plate and which is assumed to be in accordance with a table given here-with:

PERCENTAGE OF INCREASE OF DENSITY OF ROLLED STEEL PLATES.

THICKNESS OF PLATE. Inch.	WIDTH OF PLATE.			
	Up to 75 Inches. Per cent.	75 to 100 Inches. Per cent.	100 to 115 Inches. Per cent.	Over 115 Inches. Per cent.
$\frac{1}{4}$	10	14	18	..
$\frac{5}{16}$	8	12	16	..
$\frac{3}{8}$	7	10	13	17
$\frac{7}{16}$	6	8	10	13
$\frac{1}{2}$	5	7	9	12
$\frac{9}{16}$	4½	6½	8½	11
$\frac{5}{8}$	4	6	8	10
Over $\frac{5}{8}$	3½	5	6½	9

To illustrate the method used in calculating the table following this article, we will calculate the estimated weight of a $\frac{1}{4}$ " plate 38" wide and 138" long. Multiplying these three dimensions together gives us the number of cubic inches of steel in the plate as follows: $\frac{1}{4} \times 38 \times 138 = 1311$. As the increase in density is 10 per cent for this size plate, according to the table, we add 10 per cent to the weight of one cubic inch of steel (.2833) as follows: $.2833 \times .10 = .02833$ and $.2833 + .02833 = .31163$ — the weight in pounds of one cubic inch of steel in this particular plate. Multiplying the number of cubic inches in the plate (1311) by this gives us the weight of the plate in pounds as follows: $1311 \times .3116 = 408.55 =$ weight of plate in pounds. Taking the nearest unit makes it 409, which agrees with the table, but no allowance has been made here for springage of the rolls and in using this table the percentage given in the table above must be added. By so doing we get a result which will agree very closely with the table.

WEIGHT PER SQUARE FOOT OF ROLLED STEEL PLATE NOT ALLOWING FOR
SPRINGAGE OF ROLLS.

Thickness of Plate, inches.	Pounds per Sq. Foot.	Thickness of Plate, inches	Pounds per Sq. Foot.
$\frac{1}{32}$	1.2748	$\frac{5}{8}$	25.497
$\frac{1}{16}$	2.5496	$\frac{11}{16}$	28.047
$\frac{3}{32}$	3.8244	$\frac{3}{4}$	30.596
$\frac{1}{8}$	5.0992	$\frac{13}{16}$	33.146
$\frac{3}{16}$	6.3740	$\frac{7}{8}$	35.696
$\frac{1}{4}$	7.6488	$\frac{15}{16}$	38.245
$\frac{5}{16}$	8.9236	1.....	40.795
$\frac{3}{8}$	10.199	$1\frac{1}{16}$	43.344
$\frac{7}{16}$	11.474	$1\frac{1}{8}$	45.894
$\frac{1}{2}$	12.749	$1\frac{3}{16}$	48.444
$\frac{5}{8}$	14.024	$1\frac{1}{4}$	50.993
$\frac{3}{4}$	15.299	$1\frac{5}{8}$	53.543
$\frac{7}{8}$	16.574	$1\frac{3}{4}$	56.092
$\frac{15}{16}$	17.849	$1\frac{7}{8}$	58.642
$\frac{1}{8}$	19.124	$1\frac{1}{2}$	61.192
$\frac{1}{4}$	20.398	$1\frac{3}{4}$	71.390
$\frac{1}{8}$	22.948	$1\frac{7}{8}$	76.489
		2.....	81.588

The weight per square foot of $\frac{1}{4}$ " plate as given by this table is 10.199 and in a piece of 38" \times 138", according to the first table, the increase would be 10 per cent, making the increase $10.199 \times .10 = 1.0199$. Adding the increase to the weight per square foot given in the table makes it 11.2189 as follows: $10.199 + 1.0199 = 11.2189$. The area of the plate in square feet is obtained by multiplying its width by its length in inches and dividing by 144 the number of square inches in a square foot, as follows: $38 \times 138 = 5244 =$ number of square inches in plate. Dividing this by 144 gives us the area of the plate in square feet, as follows: $5244 \div 144 = 36.417 =$ number of square feet in plate. Multiplying this by the weight per square foot as calculated above (11.219) gives us the weight of the plate as follows: $36.417 \times 11.219 = 408.56 =$ weight of plate in pounds. This agrees practically with the table given below and the weight calculated by the other method at the beginning of this article.

WEIGHT OF STEEL BOILER PLATES.

		¼" PLATE.	
Size.	Weight, Pounds.	Size.	Weight, Pounds.
26 × 120.....	243	50 × 138.....	538
26 × 138.....	280	54 × 120.....	505
30 × 120.....	280	57 × 138.....	613
30 × 138.....	323	57 × 143.....	635
36 × 120.....	337	57 × 156.....	693
36 × 138.....	387	60 × 98.....	458
38 × 120.....	355	60 × 120.....	561
38 × 138.....	409	60 × 138.....	645
40 × 120.....	374	64¾ × 138.....	696
40 × 138.....	430	64¾ × 143.....	721
40 × 143.....	446	64¾ × 156.....	787
42 × 120.....	393	64¾ × 175.....	883
42 × 138.....	452	64¾ × 194.....	979
43 × 138.....	462	72 × 98.....	550
43 × 143.....	479	72 × 120.....	673
43 × 156.....	523	72 × 138.....	774
44 × 120.....	411	72 × 143.....	802
44 × 138.....	473	72 × 156.....	875
46 × 120.....	430	72 × 175.....	982
46 × 138.....	495	72 × 194.....	1088
48 × 120.....	449	84 × 98.....	665
48 × 138.....	516	84 × 120.....	814
49 × 98.....	374	84 × 138.....	936
49 × 138.....	552	84 × 143.....	970
49 × 143.....	572	84 × 156.....	1058
49 × 156.....	624	84 × 175.....	1187
50 × 120.....	467	84 × 194.....	1316

		⅝" PLATE.	
26 × 80.....	199	49 × 143.....	670
26 × 90.....	223	49 × 156.....	731
26 × 99.....	246	49 × 175.....	820
26 × 120.....	298	49 × 194.....	909
26 × 138.....	343	50 × 120.....	574
30 × 80.....	229	50 × 138.....	660
30 × 90.....	258	54 × 120.....	620
30 × 99.....	284	57 × 80.....	436
30 × 120.....	344	57 × 90.....	490
30 × 138.....	396	57 × 99.....	540
36 × 80.....	275	57 × 138.....	752
36 × 90.....	310	57 × 143.....	779
36 × 99.....	341	57 × 156.....	850
36 × 120.....	413	57 × 175.....	954
36 × 138.....	475	57 × 194.....	1057
38 × 80.....	291	60 × 120.....	688
38 × 90.....	327	60 × 138.....	792
38 × 99.....	360	64¾ × 90.....	557
38 × 120.....	435	64¾ × 99.....	613
38 × 138.....	501	64¾ × 138.....	854
40 × 80.....	306	64¾ × 143.....	885
40 × 90.....	344	64¾ × 156.....	966
40 × 99.....	379	64¾ × 175.....	1083

THE BOILER.

		$\frac{5}{16}$ " PLATE.	
Size.	Weight, Pounds.	Size.	Weight, Pounds.
40 × 120.....	459	64 $\frac{3}{4}$ × 194.....	1201
40 × 138.....	528	72 $\frac{1}{2}$ × 99.....	686
42 × 120.....	482	72 $\frac{1}{2}$ × 120.....	832
42 × 138.....	554	72 $\frac{1}{2}$ × 138.....	957
43 × 80.....	329	72 $\frac{1}{2}$ × 143.....	991
43 × 90.....	370	72 $\frac{1}{2}$ × 156.....	1081
43 × 99.....	407	72 $\frac{1}{2}$ × 175.....	1213
43 × 138.....	567	72 $\frac{1}{2}$ × 194.....	1345

		$\frac{3}{8}$ " PLATE.	
30 × 120.....	499	72 $\frac{1}{2}$ × 108 $\frac{1}{2}$	894
36 × 120.....	491	72 $\frac{1}{2}$ × 118.....	972
36 × 138.....	565	72 $\frac{1}{2}$ × 212 $\frac{1}{2}$	1751
40 × 120.....	546	72 $\frac{1}{2}$ × 231 $\frac{1}{2}$	1908
40 × 138.....	627	84 × 108 $\frac{1}{2}$	1065
44 × 120.....	600	84 × 118.....	1158
44 × 138.....	690	84 × 194.....	1904
48 × 120.....	655	84 × 212 $\frac{1}{2}$	2086
48 × 138.....	753	84 × 231 $\frac{1}{2}$	2282
50 × 120.....	682	96 × 108 $\frac{1}{2}$	1217
50 × 138.....	784	96 × 118.....	1324
54 × 120.....	737	96 × 194.....	2176
54 × 138.....	847	96 × 212 $\frac{1}{2}$	2384
60 × 120.....	818	96 × 231 $\frac{1}{2}$	2597
60 × 138.....	941	107 $\frac{1}{2}$ × 108 $\frac{1}{2}$	1400
64 $\frac{3}{4}$ × 118.....	869	107 $\frac{1}{2}$ × 118.....	1523
64 $\frac{3}{4}$ × 194.....	1428	107 $\frac{1}{2}$ × 194.....	3504
64 $\frac{3}{4}$ × 212 $\frac{1}{2}$	1564	107 $\frac{1}{2}$ × 212 $\frac{1}{2}$	2742
64 $\frac{3}{4}$ × 231 $\frac{1}{2}$	1704	107 $\frac{1}{2}$ × 231 $\frac{1}{2}$	2988
65 $\frac{3}{4}$ × 108 $\frac{1}{4}$	799		

		$\frac{7}{16}$ " PLATE.	
36 × 120.....	568	60 × 120.....	946
40 × 120.....	631	72 × 120.....	1135
48 × 120.....	757		

		$\frac{1}{2}$ " PLATE.	
36 × 120.....	643	60 × 120.....	1071
40 × 120.....	714	72 × 120.....	1285
48 × 120.....	857		

		$\frac{3}{4}$ " PLATE.	
36 × 120.....	950	60 × 120.....	1583
40 × 120.....	1056	72 × 120.....	1900
48 × 120.....	1267		

		$\frac{7}{8}$ " PLATE.	
40 × 112.....	1149	53 × 133.....	1809
40 × 154 $\frac{1}{2}$	1996	53 × 154.....	2094
53 × 112.....	1523		

TABLES OF WIDTH, LENGTH AND THICKNESS OF PLATES THAT CAN BE MADE FOR BOILER PURPOSES, ALSO DIAMETER OF HEADS.

Thickness.	Diameter of Heads.	Width and Length of Plate.	
		Width.	Length.
$\frac{1}{4}$	115	114''	200''
$\frac{5}{16}$	120	126''	240''
$\frac{3}{8}$	126	140''	180''
$\frac{7}{16}$	126	140''	180''
$\frac{1}{2}$	126	144''	180''
$\frac{5}{8}$	126	144''	180''

Longer lengths can be made but would be less in width.

Rules adopted by the Association of American Steel Manufacturers: "When ordering plates 12½ pounds to square foot or heavier, up to 100 inches wide, by weight, they shall not average more than 2½ per cent above or below the theoretical weight, when 100 inches and over the limit is 5 per cent."

TABLE OF ALLOWANCES FOR OVERWEIGHT FOR RECTANGULAR PLATE WHEN ORDERED BY GAUGE.

Thickness of Plate.	WIDTH OF PLATE.				
	Up to 50 inches.	50 inches and above.	Up to 75 inches.	75 inches to 100 in.	over 100 inches.
$\frac{1}{8}$ up to $\frac{3}{16}$	10 per ct.	15 per ct.
$\frac{3}{16}$ up to $\frac{1}{4}$	8½ " "	12½ " "
$\frac{1}{4}$ up to $\frac{5}{16}$	7 " "	10 " "
$\frac{5}{16}$	10 per ct.	14 per ct.	18 per ct.
$\frac{3}{8}$	8 " "	12 " "	16 " "
$\frac{7}{16}$	7 " "	10 " "	13 " "
$\frac{1}{2}$	6 " "	8 " "	10 " "
$\frac{5}{8}$	5 " "	7 " "	9 " "
over $\frac{1}{2}$	4½ " "	6½ " "	8½ " "
over $\frac{5}{8}$	4 " "	6 " "	8 " "
over $\frac{3}{4}$	3½ " "	5 " "	6½ " "

THE BOILER.

DOME PLATE ALLOWANCES.

Diameter of Domes.	DIAMETER OF SHELLS.								
	30	36	42	48	54	60	66	72	84
20	6¼	5½	5¼
22	7¼	6¼	5¾	5¼
24	8½	7¼	6½	5¾	5½
26	...	8¼	7¼	6½	6
28	...	9½	8	7¼	6½	6
30	...	10¾	9	8	7¼	6¾	6¼	5¾	5¼
32	10	8¾	8	7¼	6¾	6¼	5¾
34	9¾	8¾	8	7¼	7	6
36	10¾	9½	8½	8	7¼	6½
38	10¼	9½	8¾	8	7
40	10¼	9½	9¾	7½
42	11¼	10¼	10	8
44	11	10½	9
46	12¼	10¾	9½
48	13	11½	10

The above table is based on single riveting, and the allowances named are those commonly used in figuring the finished length of domes. For double riveting add 2 inches.

BOILER CONSTRUCTION.

STANDARD BOILER TUBES.

Outside Diameter. Inches.	Inside Diameter. Inches.	THICKNESS.		CIRCUMFERENCE.		TRANSVERSE AREAS.			EXTERNAL HEATING SURFACE.		Nominal Weight per Foot. Pounds.
		Inches.	Nearest B. W. G.	External, Inches.	Internal, Inches.	External, Square In.	Internal, Square In.	Metal, Square In.	Per Foot of Tube Length, Sq. Feet.	Tube Length, per Sq. Foot, Feet.	
2	1.810	.095	13	6.283	5.686	3.1416	2.5730	.5686	.5236	1.909	1.91
2 1/4	2.060	.095	13	7.069	6.472	3.9761	3.3329	.6432	.5891	1.698	2.16
2 1/2	2.282	.109	12	7.854	7.169	4.9087	4.0899	.8188	.6545	1.528	2.75
2 3/4	2.532	.109	12	8.639	7.954	5.9396	5.0349	.9047	.7200	1.389	3.04
3	2.782	.109	12	9.425	8.740	7.0686	6.0787	.9899	.7854	1.273	3.33
3 1/4	3.010	.120	11	10.210	9.456	8.2958	7.1157	1.1801	.8508	1.175	3.96
3 1/2	3.260	.120	11	10.996	10.242	9.6211	8.3469	1.274	.9163	1.091	4.28
3 3/4	3.510	.120	11	11.781	11.027	11.045	9.6762	1.369	.9818	1.018	4.60
4	3.732	.134	10	12.566	11.724	12.566	10.939	1.627	1.0472	.955	5.47
4 1/2	4.232	.134	10	14.137	13.295	15.904	14.066	1.838	1.1781	.849	6.17
5	4.704	.148	9	15.708	14.778	19.635	17.379	2.256	1.3090	.764	7.58
6	5.670	.165	8	18.850	17.813	28.274	25.249	3.025	1.5708	.637	10.16
7	6.670	.165	8	21.991	20.954	38.485	34.941	3.544	1.8326	.546	11.90
8	7.670	.165	8	25.133	24.096	50.265	46.204	4.061	2.0944	.477	13.65

Rule to find number of square feet of heating surface in tubes:
 Multiply the number of tubes by the diameter of a tube in inches and by its length in feet, and by .2618 constant.

LEGEND:
 D = Tubes 4"
 L = Length = 16'
 N = Number = 44
 C = Constant = .2618

FORMULA:
 $N \times D \times L \times .2618$ (constant) = heating surface

EXAMPLE:

44 = number of tubes
 4 = diameter in inches

176
 16 = length in feet

1056
 176

2816
 .2618 = constant

22528
 2816
 16896
 5632

737.2288 = total square feet of heating surface in 44 4" tubes.

HEATING SURFACE OF BOILER TUBES.

Diameter X 3.1416 = circumference X 12 = number of square inches in tube one foot of length ÷ 144 = number of square feet (in decimals) one foot of length.

EXAMPLE:

2 inch tube one foot in length:
 $2 \times 3.1416 = 6.2832 \times 12 = 75.3984$

144 = .5236 of a square foot

TABLE.

Diam. in.	Multipl'r	Diam. in.	Multipl'r	Diam. in.	Multipl'r	Diam. in.	Multipl'r
1	.2618	11½	3.0107	32	8.3776	53	13.8754
1¼	.3272	11¾	3.0761	32½	8.5085	53½	14.0063
1½	.3927	12	3.1416	33	8.6394	54	14.1372
1¾	.4581	12½	3.2725	33½	8.7703	54½	14.2681
2	.5236	13	3.4037	34	8.9012	55	14.399
2¼	.589	13½	3.5343	34½	9.0321	55½	14.5299
2½	.6545	14	3.6652	35	9.163	56	14.6608
2¾	.7199	14½	3.7961	35½	9.2939	56½	14.7917
3	.7854	15	3.927	36	9.4248	57	14.9226
3¼	.8508	15½	4.0579	36½	9.5557	57½	15.0536
3½	.9163	16	4.1888	37	9.6866	58	15.1844
3¾	.9817	16½	4.3197	37½	9.8175	58½	15.3153
4	1.0472	17	4.4506	38	9.9484	59	15.4462
4¼	1.1126	17½	4.5815	38½	10.0793	59½	15.5771
4½	1.1781	18	4.7124	39	10.2102	60	15.708
4¾	1.2435	18½	4.8433	39½	10.3411	60½	15.8389
5	1.309	19	4.9742	40	10.472	61	15.9698
5¼	1.3744	19½	5.1051	40½	10.6029	61½	16.1007
5½	1.4399	20	5.236	41	10.7338	62	16.2316
5¾	1.5053	20½	5.3669	41½	10.8647	62½	16.3625
6	1.5708	21	5.4978	42	10.9956	63	16.4934
6¼	1.6362	21½	5.6287	42½	11.1265	63½	16.6243
6½	1.7017	22	5.7596	43	11.2574	64	16.7552
6¾	1.7671	22½	5.8905	43½	11.3883	64½	16.8861
7	1.8326	23	6.0214	44	11.5192	65	17.017
7¼	1.8980	23½	6.1523	44½	11.6501	65½	17.1479
7½	1.9335	24	6.2832	45	11.781	66	17.2788
7¾	2.0289	24½	6.4141	45½	11.9119	66½	17.4097
8	2.0944	25	6.545	46	12.0428	67	17.5406
8¼	2.0598	25½	6.6759	46½	12.1735	67½	17.6715
8½	2.2253	26	6.8034	47	12.3045	68	17.8024
8¾	2.2907	26½	6.9377	47½	12.4355	68½	17.9333
9	2.3562	27	7.0686	48	12.5664	69	18.0642
9¼	2.4216	27½	7.1995	48½	12.6973	69½	18.1951
9½	2.4872	28	7.3384	49	12.8282	70	18.326
9¾	2.5525	28½	7.4614	49½	12.9591	70½	18.4569
10	2.618	29	7.5913	50	13.09	71	18.5868
10¼	2.6834	29½	7.7231	50½	13.2209	71½	18.7187
10½	2.7489	30	7.8554	51	13.3518	72	18.8496
10¾	2.8143	30½	7.9849	51½	13.4827	78	20.3370
11	2.8798	31	8.1158	52	13.6136	84	21.9912
11¼	2.9452	31½	8.2467	52½	13.7445	96	25.1328

APPROXIMATE WEIGHT OF ROUND BRACES WITH FLAT ENDS.

Length of Braces, inches	Diameter of Braces, inches	SIZE OF ENDS.		Weight, lbs.
		Width, inches	Thickness, in.	
14	1	2 1/4	1/2	7
16	1	2 1/4	1/2	7 1/4
18	1	2 1/4	1/2	7 1/2
20	1	2 1/4	1/2	8
22	1	2 1/4	1/2	8 1/2
24	1	2 1/4	1/2	9
26	1	2 1/4	1/2	9 1/2
28	1	2 1/4	1/2	10
30	1	2 1/4	1/2	10 1/2
32	1	2 1/4	1/2	11
34	1	2 1/4	1/2	11 1/2
36	1	2 1/4	1/2	12
38	1	2 1/4	1/2	12 1/2
40	1	2 1/4	1/2	13
42	1	2 1/4	1/2	13 1/2
44	1	2 1/4	1/2	14
46	1	2 1/4	1/2	14 1/2
48	1	2 1/4	1/2	15
50	1	2 1/4	1/2	15 1/2
52	1	2 1/4	1/2	16
54	1	2 1/4	1/2	16 1/2
56	1	2 1/4	1/2	17
58	1	2 1/4	1/2	17 1/2
60	1	2 1/4	1/2	18
14	1 1/8	2 1/4	5/8	7 1/2
16	1 1/8	2 1/4	5/8	8
18	1 1/8	2 1/4	5/8	8 1/2
20	1 1/8	2 1/4	5/8	9
22	1 1/8	2 1/4	5/8	10
24	1 1/8	2 1/4	5/8	11
26	1 1/8	2 1/4	5/8	12
28	1 1/8	2 1/4	5/8	13
30	1 1/8	2 1/4	5/8	14
32	1 1/8	2 1/4	5/8	15
34	1 1/8	2 1/4	5/8	16
36	1 1/8	2 1/4	5/8	17
38	1 1/8	2 1/4	5/8	17 1/2
40	1 1/8	2 1/4	5/8	18
42	1 1/8	2 1/4	5/8	18 1/2
44	1 1/8	2 1/4	5/8	19
46	1 1/8	2 1/4	5/8	19 1/2
48	1 1/8	2 1/4	5/8	20
50	1 1/8	2 1/4	5/8	21
52	1 1/8	2 1/4	5/8	22
54	1 1/8	2 1/4	5/8	23
56	1 1/8	2 1/4	5/8	24
58	1 1/8	2 1/4	5/8	25
60	1 1/8	2 1/4	5/8	26

NUMBER MODERN FORMED BRACES COMMONLY USED IN STANDARD TUBULAR BOILERS.

Length of Brace.	DIAMETER OF SHELL.							
	36	42	44	54	60	66	72	84
30	6	6	8	10	10	10	12	16
42	2	4
48	4	6	6	8	8	10
60	4
72	4	4	6

Under the diameter of each shell will be found the number of each length of brace generally used. The thickness of brace varies with thickness of shell.

METALS.

WEIGHT OF SUPERFICIAL FOOT.

Thick-ness.	W Iron.	C Iron.	Steel.	Copper.	Brass.	Lead.	Zinc.
Inch.	Lbs.	Lbs.	Lbs.	Lbs.	Lbs.	Lbs.	Lbs.
$\frac{1}{16}$	2.52	2.34	2.55	2.89	2.73	3.71	2.34
$\frac{1}{8}$	5.05	4.69	5.10	5.78	5.47	7.42	4.69
$\frac{3}{16}$	7.58	7.03	7.66	8.67	8.20	11.13	7.03
$\frac{1}{4}$	10.10	9.38	10.21	11.56	10.94	14.83	9.38
$\frac{5}{16}$	12.63	11.72	12.76	14.45	13.67	18.54	11.72
$\frac{3}{8}$	15.16	14.06	15.31	17.34	16.41	22.25	14.06
$\frac{7}{16}$	17.68	16.41	17.87	20.23	19.14	25.96	16.41
$\frac{1}{2}$	20.21	18.75	20.42	23.13	21.88	29.67	18.75
$\frac{5}{8}$	25.27	23.44	25.52	28.91	27.34	37.08	23.44
$\frac{3}{4}$	30.31	28.13	30.63	34.69	32.81	44.50	28.13
$\frac{7}{8}$	35.37	32.81	35.73	40.47	38.28	51.92	32.81
1	40.42	37.50	40.83	46.25	43.75	59.33	37.50

BIRMINGHAM GAUGE.				U. S. STANDARD GAUGE.			
No. of Gauge.	Thick-ness, Inches.	Weight.		No. of Gauge.	THICKNESS, IN.		Weight, Iron.
		Iron.	Steel.		Frac-tions.	Deci-mals.	
0000	.454	18.22	18.46	0000000	$\frac{1}{9}$.5	20.
000	.425	17.05	17.28	0000000	$\frac{15}{32}$.468	18.75
00	.38	15.25	15.45	000000	$\frac{7}{16}$.437	17.50
0	.34	13.64	13.82	0000	$\frac{13}{32}$.406	16.25
1	.3	12.04	12.20	000	$\frac{3}{8}$.375	15.
2	.284	11.40	11.55	00	$\frac{11}{32}$.343	13.75
3	.259	10.39	10.53	0	$\frac{5}{16}$.312	12.50
4	.238	9.55	9.68	1	$\frac{9}{32}$.281	11.25
5	.22	8.83	8.95	2	$\frac{17}{64}$.265	10.625
6	.203	8.15	8.25	3	$\frac{1}{4}$.25	10.
7	.18	7.22	7.32	4	$\frac{15}{64}$.234	9.375
8	.165	6.62	6.71	5	$\frac{7}{32}$.218	8.75
9	.148	5.94	6.02	6	$\frac{13}{64}$.203	8.125
10	.134	5.38	5.45	7	$\frac{3}{16}$.187	7.5
11	.12	4.82	4.88	8	$\frac{11}{64}$.171	6.875
12	.109	4.37	4.43	9	$\frac{5}{32}$.156	6.25
13	.095	3.81	3.86	10	$\frac{9}{64}$.140	5.625
14	.083	3.33	3.37	11	$\frac{1}{8}$.125	5.
15	.072	2.89	2.93	12	$\frac{7}{64}$.109	4.375
16	.065	2.61	2.64	13	$\frac{3}{32}$.093	3.75
17	.058	2.33	2.36	14	$\frac{5}{64}$.078	3.125
18	.049	1.97	1.99	15	$\frac{1}{2}$.070	2.8125
19	.042	1.69	1.71	16	$\frac{1}{8}$.062	2.5
20	.035	1.40	1.42	17	$\frac{1}{16}$.056	2.25
21	.032	1.28	1.30	18	$\frac{3}{160}$.05	2.
22	.028	1.12	1.14	19	$\frac{2}{20}$.043	1.75
23	.025	1.00	1.02	20	$\frac{1}{40}$.037	1.50
24	.022	.883	.895	21	$\frac{3}{80}$.034	1.375
25	.02	.803	.813	22	$\frac{1}{320}$.031	1.25
26	.018	.722	.732	23	$\frac{1}{32}$.028	1.125
27	.016	.642	.651	24	$\frac{3}{90}$.025	1.
28	.014	.562	.569	25	$\frac{4}{40}$.021	.875
				26	$\frac{7}{320}$.018	.75
				27	$\frac{1}{140}$.017	.6875
				28	$\frac{11}{640}$.015	.625

The U. S. Standard is the one in common use.

TO CONVERT WEIGHT OF METALS MULTIPLY BY FOLLOWING CONSTANTS:

Wrought iron into cast iron.	×	.928
“ “ “ steel.	×	1.014
“ “ “ zinc.	×	.918
“ “ “ brass.	×	1.082
“ “ “ copper.	×	1.144
“ “ “ lead.	×	1.468
Square iron into round.	×	.7854

WEIGHTS AND MEASUREMENTS OF STEEL "I" BEAMS.

Depth. Inches.	Min. Weight. lbs. per foot.	Inner Weights.	Max. Weight. lbs. per foot.	Min. Flange. inches.	Min. Web. inches.	Min. Area. square inches.
4	7.5	Vary by 1 lb.	10.5	2.66	.19	2.2
5	9.75	Vary by 2½ lbs.	14.75	3.00	.21	2.9
6	12.25	Vary by 2½ lbs.	17.25	3.33	.23	3.6
7	15.0	Vary by 2½ lbs.	20.0	3.66	.25	4.4
8	17.75	Vary by 2½ lbs.	25.25	4.00	.27	5.2
9	21.0	25 lbs. then vary by 5 lbs.	35.0	4.33	.29	6.3
10	25.0	Vary by 5 lbs.	40.0	4.66	.31	7.4
12	31.5	35 lbs. then vary by 5 lbs.	45.0	5.00	.35	9.3
12	40.0	Vary by 5 lbs.	55.0	5.25	.41	11.85
15	42.0	45 lbs. then vary by 5 lbs.	60.0	5.50	.46	12.5
15	60.0	Vary by 5 lbs.	80.0	6.00	.59	17.68

WEIGHTS AND MEASUREMENTS OF STEEL CHANNELS.

Depth. Inches.	Min. Weight. lbs. per foot.	Inner Weights.	Max. Weight. lbs. per foot.	Min. Flange. inches.	Min. Web. inches.	Min. Area. square inches.
4	5.25	Vary by 1 lb.	7.25	1.58	.18	1.6
5	6.5	Vary by 2½ lbs.	11.5	1.75	.19	2.0
6	8.0	Vary by 2½ lbs.	15.5	1.92	.20	2.4
7	9.75	Vary by 2½ lbs.	19.75	2.09	.21	2.9
8	11.25	Vary by 2½ lbs.	21.25	2.26	.22	3.4
9	13.25	15 lbs. then vary by 5 lbs.	25.0	2.43	.23	3.9
10	15.0	Vary by 5 lbs.	35.0	2.60	.24	4.5
12	20.5	25 lbs. then vary by 5 lbs.	40.0	2.94	.28	6.0
15	33.0	33 lbs. then vary by 5 lbs.	55.0	3.40	.40	9.9

PIPE AND PIPING.

Rule to find pressure allowed on a main steam pipe or header when thickness of pipe and diameter is known: From thickness of plate subtract the constant .1250, then multiply by one-sixth of tensile strength of plate and divide this product by diameter; the sum will be pressure allowed.

LEGEND:

T = Thickness of plate = .4850
 C = Constant = .1250
 T. S = Tensile strength = 60000
 D = Diameter = 24"

FORMULA:

$$\frac{(T - .1250) \times (1/6 \text{th of TS})}{D} = \text{pressure}$$

EXAMPLE:

$$\begin{array}{r}
 .4850 = \text{thickness of plate} \\
 .1250 = \text{constant} \\
 \hline
 .3600 \\
 10000 = 1/6 \text{ of tensile strength} \\
 \hline
 \text{diameter } 24'' \left. \begin{array}{l} 3600 \\ 24 \end{array} \right) \begin{array}{l} 3600 \\ 0000 \end{array} \left(\begin{array}{l} 150 \text{ lbs. pressure allowed} \\ 24 \end{array} \right. \\
 \hline
 120 \\
 120 \\
 \hline
 \end{array}$$

Rule to find thickness of material for a main, steel or iron, steam pipe or cylinder lap welded: Multiply pressure by diameter and divide by one-sixth of the tensile strength, and add .125

LEGEND:

P = pressure = 150 lbs.
 D = diameter = 24''
 T. S. = tensile strength = 60,000

FORMULA:

$$\frac{P \times D}{1/6 \text{ of T. S.}} + .125 = \text{thickness}$$

EXAMPLE:

$$\begin{array}{r}
 150 = \text{lbs. pressure} \\
 24'' = \text{diameter} \\
 \hline
 600 \\
 300 \\
 \hline
 1/6 \text{ of tensile strength} = 10,000 \left. \begin{array}{l} 3600 \text{ } 00 \\ 3000 \text{ } 0 \end{array} \right) \begin{array}{l} .36 \\ .125 \text{ added} \end{array} \\
 \hline
 600 \text{ } 00 \\
 600 \text{ } 00 \\
 \hline
 .485 = \text{thickness or } 31/64 \\
 \text{approximately}
 \end{array}$$

Rule to find thickness of plate for a 5'' copper pipe: Multiply pressure by inside diameter of pipe and divide by constant 8000; add to quotient the constant .0625.

LEGEND:

P = pressure = 175
 ID = inside diameter of pipe = .5
 C = constant = 8000

FORMULA:

$$\frac{P \times ID}{C} + .0625 = \text{thickness of plate}$$

EXAMPLE:

$$\begin{array}{r}
 175 = \text{pressure} \\
 .5'' = \text{inside diameter of pipe} \\
 \hline
 8000 \left. \begin{array}{l} 87.50000 \\ 80 \text{ } 00 \end{array} \right) \begin{array}{l} .109 \\ .0625 = \text{constant} \end{array} \\
 \hline
 75 \text{ } 00 \\
 72 \text{ } 00 \\
 \hline
 3 \text{ } 00 \\
 .1715 = \frac{11}{64} \text{ approximately}
 \end{array}$$

RADIATION OF DIFFERENT SIZES OF WROUGHT-IRON PIPE.

The following table gives the actual lengths of different sizes of pipe sufficient to make ten square feet of radiation:

1	inch	Pipe,	28	lineal	feet	=	10	square	feet	radiation.
1 $\frac{1}{4}$	"	"	24	"	"	=	10	"	"	"
1 $\frac{1}{2}$	"	"	20	"	"	=	10	"	"	"
2	"	"	16	"	"	=	10	"	"	"
2 $\frac{1}{2}$	"	"	13	"	"	=	10	"	"	"
3	"	"	11	"	"	=	10	"	"	"

TABLE OF EXPANSION OF WROUGHT-IRON PIPE.

Temperature of the Air when the Pipe is fitted.	Length of Pipe when fitted.	LENGTH OF PIPE WHEN HEATED TO					
		160 Degrees.		180 Degrees.		200 Degrees.	
Degrees Fahr.	Feet.	Feet.	Inches.	Feet	Inches	Feet	Inches
0	100	100	1.28	100	1.44	100	1.60
32	100	100	1.02	100	1.18	100	1.34
64	100	100	.77	100	.93	100	1.09

STANDARD FLANGES. SIZES: THREADED OR PLAIN.

Size Pipe, Inches.		Diameter Flange.		Thickness of Flanges.		Equivalent to Cast Iron.	
1-	Inch	6-	Inch	3/8-Inch		1 1/2-Inch	
1 1/4	"	6	"	3/8 "		1 1/2 "	
1 1/2	"	6	"	3/8 "		1 1/2 "	
2	"	8	"	1/2 "		2 "	
2 1/2	"	9	"	1/2 "		2 "	
3	"	9	"	1/2 "		2 "	
3 1/2	"	10	"	1/2 "		2 "	
4	"	10	"	1/2 "		2 "	
4 1/2	"	10 1/2	"	1/2 "		2 "	
5	"	11 1/2	"	1/2 "		2 "	
6	"	12 1/2	"	1/2 "		2 "	
7	"	13 1/2	"	1/2 "		2 "	
8	"	15 1/2	"	5/8 "		2 1/4 "	
9	"	16 1/2	"	5/8 "		2 1/4 "	
10	"	17 1/2	"	5/8 "		2 1/4 "	
12	"	21	"	5/8 "		2 1/4 "	

WROUGHT IRON WELDED STEAM, GAS AND WATER PIPE. TABLE OF STANDARD DIMENSIONS

Nominal Internal. Inches.	DIAMETER.		Thickness, Inches.	CIRCUMFERENCE.		Internal Area. Sq. Inches.	Length of Pipe per square foot of External Surface, Feet.	Square feet of Surface per foot in Length.	Nominal Weight per foot. Lbs.	Number of Threads per inch of Screw.	Inside Diameter, Inches.
	Actual External. Inches.	Actual Internal. Inches.		External. Inches.	Internal. Inches.						
1/8	405	.27	.068	1.272	.848	.0573	9.44	.106	.241	27	1/8
1/4	.54	.364	.088	1.696	1.144	.1041	7.075	.141	.42	18	1/4
3/8	.675	.494	.091	2.121	1.552	.1917	5.657	.177	.559	18	3/8
1/2	.84	.623	.109	2.639	1.957	.3048	4.547	.220	.837	14	1/2
3/4	.105	.824	.113	3.229	2.589	.5333	3.637	.275	1.115	14	3/4
1	1.315	1.048	.134	4.131	3.292	.8626	2.904	.344	1.668	11 1/2	1
1 1/4	1.66	1.38	.14	5.215	4.335	1.496	2.301	.434	2.244	11 1/2	1 1/4
1 1/2	1.9	1.611	.145	5.969	5.061	2.038	2.01	.497	2.678	11 1/2	1 1/2
2	2.375	2.067	.154	7.461	6.494	3.356	1.608	.621	3.609	8	2
2 1/2	2.875	2.468	.204	9.032	7.753	4.784	1.328	.753	5.739	8	2 1/2
3	3.5	3.067	.217	10.996	9.636	7.388	1.091	.916	7.536	8	3
3 1/2	4	3.548	.226	12.566	11.146	9.887	.955	1.047	9.001	8	3 1/2
4	4.5	4.026	.237	14.137	12.648	12.73	.849	1.178	10.665	8	4
4 1/2	5	4.508	.246	15.708	14.162	15.961	.764	1.309	12.34	8	4 1/2
5	5.563	5.045	.259	17.477	15.849	19.99	.687	1.456	14.502	8	5
6	6.625	6.065	.28	20.813	19.054	28.888	.577	1.734	18.762	8	6
7	7.625	7.023	.301	23.955	22.063	38.738	.501	1.996	23.271	8	7
8	8.625	7.982	.322	27.096	25.076	50.04	.433	2.256	28.177	8	8
9	9.625	8.937	.344	30.238	28.076	62.73	.397	2.520	33.701	8	9
10	10.75	10.019	.366	33.772	31.477	78.839	.355	2.814	40.065	8	10
11	11.75	11.	.375	36.914	34.558	95.033	.325	3.076	45.028	8	11
12	12.75	12.	.375	40.055	37.7	113.098	.299	3.338	48.985	8	12

TABLE GIVING DIAMETER AND AREA AT THE BOTTOM OF THE THREAD OF STAY-BOLTS AND STAYS OF USEFUL SIZES FOR CALCULATING THEIR STRENGTH, ETC.

Diam. of Stay Bolt	Thread per inch	Diam. at bottom of thread U. S. Standard	Area in sq. inches at bottom of thread U. S. Standard	Diam. at bottom of thread V thread	Area in sq. inches at bottom of thread V thread
$\frac{5}{8}$	12	.51675	.2097	.48067	.1815
$\frac{11}{16}$	12	.57925	.2635	.54317	.2317
$\frac{3}{4}$	12	.64175	.3235	.60567	.2881
$\frac{13}{16}$	12	.70425	.3895	.66817	.3506
$\frac{7}{8}$	12	.76675	.4617	.73067	.4193
$\frac{15}{16}$	12	.82925	.5409	.79317	.4941
1	12	.89175	.6246	.85567	.5750
$1\frac{1}{16}$	12	.95425	.7152	.91817	.6621
$1\frac{1}{8}$	12	1.01675	.8119	.98067	.7553
$1\frac{3}{16}$	12	1.07925	.9148	1.04317	.8547
$1\frac{1}{4}$	12	1.14175	1.0238	1.10567	.9601
$1\frac{5}{16}$	12	1.20425	1.1390	1.16817	1.0718
$1\frac{3}{8}$	12	1.26675	1.2603	1.23067	1.1895
$1\frac{1}{2}$	12	1.39175	1.5213	1.35567	1.4434
$1\frac{1}{2}$	6	1.28350	1.2939	1.21134	1.1525
$1\frac{5}{8}$	$5\frac{1}{2}$	1.38882	1.5149	1.31010	1.3480
$1\frac{3}{4}$	5	1.49020	1.7441	1.40350	1.5471
$1\frac{7}{8}$	5	1.61520	2.0490	1.52850	1.8349
2	$4\frac{1}{2}$	1.71134	2.3001	1.61512	2.0487
$2\frac{1}{8}$	$4\frac{1}{2}$	1.83634	2.6485	1.74012	2.3782
$2\frac{1}{4}$	$4\frac{1}{2}$	1.96134	3.0213	1.86512	2.7321
$2\frac{3}{8}$	4	2.05025	3.3014	1.94200	2.9620
$2\frac{1}{2}$	4	2.17525	3.7163	2.06700	3.3556
$2\frac{5}{8}$	4	2.30025	4.1557	2.19200	3.7738
$2\frac{3}{4}$	4	2.42525	4.6196	2.31100	4.1946
$2\frac{7}{8}$	$3\frac{1}{2}$	2.50386	4.9239	2.38015	4.4494
3	$3\frac{1}{2}$	2.62886	5.4278	2.50515	4.9290

TAP DRILLS.

THIS TABLE SHOWS THE DIFFERENT SIZES OF DRILL THAT SHOULD BE USED WHEN FULL THREAD IS TO BE TAPPED.

FOR MACHINE AND HAND TAP.

Diameter of Tap	No. of Threads to Inch	Size Drill for V Thread	Size Drill for U. S. Standard Thread	Size Drill for Whitworth Thread
$\frac{9}{32}$	16 18 20	$\frac{5}{32}$ $\frac{7}{32}$ $\frac{11}{32}$	$\frac{3}{16}$	$\frac{3}{16}$
$\frac{1}{8}$	16 18 20	$\frac{7}{16}$ $\frac{11}{16}$ $\frac{15}{16}$	$\frac{1}{4}$	$\frac{15}{64}$
$\frac{1}{8}$	16 18 ..	$\frac{7}{16}$ $\frac{11}{16}$ $\frac{15}{16}$	$\frac{1}{4}$	$\frac{15}{64}$
$\frac{1}{8}$	16 18 ..	$\frac{7}{16}$ $\frac{11}{16}$ $\frac{15}{16}$	$\frac{1}{4}$	$\frac{15}{64}$
$\frac{1}{8}$	14 16 18	$\frac{1}{4}$ $\frac{3}{8}$ $\frac{1}{2}$	$\frac{3}{8}$	$\frac{3}{8}$
$\frac{1}{8}$	14 16 18	$\frac{1}{4}$ $\frac{3}{8}$ $\frac{1}{2}$	$\frac{3}{8}$	$\frac{3}{8}$
$\frac{1}{8}$	14 16 ..	$\frac{1}{4}$ $\frac{3}{8}$ $\frac{1}{2}$	$\frac{3}{8}$	$\frac{3}{8}$
$\frac{1}{8}$	14 16 ..	$\frac{1}{4}$ $\frac{3}{8}$ $\frac{1}{2}$	$\frac{3}{8}$	$\frac{3}{8}$
$\frac{1}{8}$	12 13 14	$\frac{1}{8}$ $\frac{1}{4}$ $\frac{3}{8}$	$\frac{1}{8}$	$\frac{3}{8}$
$\frac{1}{8}$	12 13 14	$\frac{1}{8}$ $\frac{1}{4}$ $\frac{3}{8}$	$\frac{1}{8}$	$\frac{3}{8}$
$\frac{1}{8}$	12 14 ..	$\frac{1}{8}$ $\frac{1}{4}$ $\frac{3}{8}$	$\frac{7}{16}$	$\frac{7}{16}$
$\frac{1}{8}$	12 14 ..	$\frac{1}{8}$ $\frac{1}{4}$ $\frac{3}{8}$	$\frac{7}{16}$	$\frac{7}{16}$
$\frac{1}{8}$	10 11 12	$\frac{1}{2}$ $\frac{1}{2}$ $\frac{1}{2}$	$\frac{1}{2}$	$\frac{1}{2}$
$\frac{1}{8}$	10 11 12	$\frac{1}{2}$ $\frac{1}{2}$ $\frac{1}{2}$	$\frac{1}{2}$	$\frac{1}{2}$
$\frac{1}{8}$	10 11 12	$\frac{1}{2}$ $\frac{1}{2}$ $\frac{1}{2}$	$\frac{5}{8}$	$\frac{5}{8}$
$\frac{1}{8}$	10 11 12	$\frac{1}{2}$ $\frac{1}{2}$ $\frac{1}{2}$	$\frac{5}{8}$	$\frac{5}{8}$
$\frac{1}{8}$	9 10 ..	$\frac{1}{2}$ $\frac{1}{2}$ $\frac{1}{2}$	$\frac{3}{4}$	$\frac{3}{4}$
$\frac{1}{8}$	9 10 ..	$\frac{1}{2}$ $\frac{1}{2}$ $\frac{1}{2}$	$\frac{3}{4}$	$\frac{3}{4}$
1.	8 ..	$\frac{1}{2}$ $\frac{1}{2}$ $\frac{1}{2}$	$\frac{3}{4}$	$\frac{3}{4}$
$1\frac{1}{32}$	8 ..	$\frac{1}{2}$ $\frac{1}{2}$ $\frac{1}{2}$	$\frac{3}{4}$	$\frac{3}{4}$
$1\frac{1}{8}$	7 8 ..	$\frac{1}{2}$ $\frac{1}{2}$ $\frac{1}{2}$	$\frac{1}{2}$	$\frac{1}{2}$
$1\frac{1}{8}$	7 8 ..	$\frac{1}{2}$ $\frac{1}{2}$ $\frac{1}{2}$	$\frac{1}{2}$	$\frac{1}{2}$
$1\frac{1}{4}$	7 ..	$1\frac{1}{32}$..	$1\frac{1}{8}$	$1\frac{1}{8}$
$1\frac{1}{4}$	7 ..	$1\frac{1}{32}$..	$1\frac{1}{8}$	$1\frac{1}{8}$
$1\frac{1}{4}$	6 ..	$1\frac{1}{8}$..	$1\frac{1}{8}$	$1\frac{1}{8}$
$1\frac{1}{4}$	6 ..	$1\frac{1}{8}$..	$1\frac{1}{8}$	$1\frac{1}{8}$
$1\frac{1}{2}$	6 ..	$1\frac{1}{4}$..	$1\frac{3}{8}$	$1\frac{3}{8}$
$1\frac{1}{2}$	6 ..	$1\frac{1}{4}$..	$1\frac{3}{8}$	$1\frac{3}{8}$
$1\frac{5}{8}$	5 $5\frac{1}{2}$	$1\frac{3}{8}$ $1\frac{1}{2}$	$1\frac{3}{8}$	$1\frac{3}{8}$
$1\frac{5}{8}$	5 $5\frac{1}{2}$	$1\frac{3}{8}$ $1\frac{1}{2}$	$1\frac{3}{8}$	$1\frac{3}{8}$
$1\frac{3}{4}$	5 ..	$1\frac{1}{2}$..	$1\frac{1}{2}$	$1\frac{1}{2}$
$1\frac{3}{4}$	5 ..	$1\frac{1}{2}$..	$1\frac{1}{2}$	$1\frac{1}{2}$
$1\frac{7}{8}$	$4\frac{1}{2}$ 5	$1\frac{1}{2}$ $1\frac{1}{2}$	$1\frac{3}{8}$	$1\frac{3}{8}$
$1\frac{7}{8}$	$4\frac{1}{2}$ 5	$1\frac{1}{2}$ $1\frac{1}{2}$	$1\frac{3}{8}$	$1\frac{3}{8}$
2.	$4\frac{1}{2}$..	$1\frac{1}{2}$..	$1\frac{3}{8}$	$1\frac{3}{8}$



PIPE TAPS.

Size Pipe	No. of Threads to the Inch	Diameter of Drill	Size Pipe	No. of Threads to the Inch	Diameter of Drill
$\frac{1}{8}$	27	$\frac{21}{16}$	3.....	8	$3\frac{5}{16}$
$\frac{1}{4}$	18	$\frac{21}{16}$	$3\frac{1}{2}$	8	$3\frac{11}{16}$
$\frac{3}{8}$	18	$\frac{21}{16}$	4.....	8	$4\frac{5}{16}$
$\frac{1}{2}$	14	$\frac{21}{16}$	$4\frac{1}{2}$	8	$4\frac{7}{8}$
$\frac{3}{4}$	14	$\frac{21}{16}$	5.....	8	$5\frac{3}{8}$
1.....	$11\frac{1}{2}$	$1\frac{7}{16}$	6.....	8	$6\frac{7}{16}$
$1\frac{1}{4}$	$11\frac{1}{2}$	$1\frac{13}{16}$	7.....	8	$7\frac{7}{16}$
$1\frac{1}{2}$	$11\frac{1}{2}$	$1\frac{13}{16}$	8.....	8	$8\frac{1}{2}$
2.....	$11\frac{1}{2}$	$2\frac{1}{16}$	9.....	8	$9\frac{1}{2}$
$2\frac{1}{2}$	8	$2\frac{11}{16}$	10.....	8	$10\frac{1}{2}$

WEIGHTS OF ROUND AND SQUARE STEEL. PER LINEAL FOOT.

Size, inches.	Round, Weight, lbs.	Square, Weight, lbs.	Size, inches.	Round, Weight, lbs.	Square, Weight, lbs.
$\frac{3}{16}$.094	.120	$2\frac{1}{8}$	12.06	15.36
$\frac{1}{4}$.167	.213	$2\frac{1}{4}$	13.52	17.22
$\frac{5}{16}$.261	.332	$2\frac{3}{8}$	15.07	19.19
$\frac{3}{8}$.375	.478	$2\frac{1}{2}$	16.70	21.26
$\frac{7}{16}$.511	.651	$2\frac{5}{8}$	18.41	23.44
$\frac{1}{2}$.668	.851	$2\frac{3}{4}$	20.21	25.73
$\frac{9}{16}$.845	1.076	3	24.05	30.62
$\frac{5}{8}$	1.044	1.329	$3\frac{1}{4}$	28.23	35.94
$\frac{3}{4}$	1.503	1.914	$3\frac{1}{2}$	32.74	41.68
$\frac{7}{8}$	2.046	2.605	$3\frac{3}{4}$	37.57	47.84
1	2.672	3.402	4	42.77	54.45
$1\frac{1}{8}$	3.382	4.306	$4\frac{1}{2}$	54.83	69.81
$1\frac{1}{4}$	4.175	5.316	5	66.82	85.08
$1\frac{3}{8}$	5.052	6.432	$5\frac{1}{2}$	80.85	102.94
$1\frac{1}{2}$	6.012	7.655	6	96.22	122.51
$1\frac{5}{8}$	7.056	8.984	$6\frac{1}{2}$	112.92	143.78
$1\frac{3}{4}$	8.183	10.419	7	131.97	166.75
$1\frac{7}{8}$	9.394	11.961	$7\frac{1}{2}$	150.34	191.42
2	10.69	13.61	8	171.04	217.78

WEIGHTS OF FLAT STEEL. PER LINEAL FOOT.

Width, Inches.	THICKNESS, INCHES.											
	$\frac{1}{16}$	$\frac{1}{8}$	$\frac{3}{16}$	$\frac{1}{4}$	$\frac{5}{16}$	$\frac{3}{8}$	$\frac{7}{16}$	$\frac{1}{2}$	$\frac{5}{8}$	$\frac{3}{4}$	$\frac{7}{8}$	1
1	.21	.43	.638	.850	1.06	1.28	1.49	1.70	2.12	2.55	2.98
1 $\frac{1}{8}$.24	.48	.720	.955	1.20	1.43	1.68	1.92	2.39	2.87	3.35	3.88
1 $\frac{1}{4}$.27	.53	.797	1.06	1.33	1.59	1.86	2.12	2.65	3.19	3.72	4.21
1 $\frac{3}{8}$.30	.59	.875	1.17	1.46	1.76	2.05	2.34	2.92	3.51	4.09	4.68
1 $\frac{1}{2}$.32	.64	.957	1.28	1.59	1.92	2.23	2.55	3.19	3.83	4.47	5.10
1 $\frac{5}{8}$.35	.69	1.04	1.38	1.73	2.08	2.42	2.77	3.46	4.15	4.84	5.53
1 $\frac{3}{4}$.38	.75	1.11	1.49	1.86	2.23	2.60	2.98	3.72	4.47	5.20	5.95
2	.43	.85	1.28	1.70	2.12	2.55	2.98	3.40	4.25	5.10	5.95	6.80
2 $\frac{1}{4}$.48	.96	1.44	1.91	2.39	2.87	3.35	3.83	4.78	5.75	6.69	7.65
2 $\frac{1}{2}$.53	1.06	1.59	2.12	2.65	3.19	3.72	4.25	5.31	6.38	7.44	8.50
2 $\frac{3}{4}$.59	1.17	1.75	2.34	2.92	3.51	4.09	4.67	5.84	7.02	8.18	9.35
3	.64	1.28	1.91	2.55	3.19	3.83	4.46	5.10	6.38	7.65	8.93	10.20
3 $\frac{1}{4}$.69	1.38	2.07	2.76	3.45	4.15	4.83	5.53	6.91	8.29	9.67	11.05
3 $\frac{1}{2}$.75	1.49	2.23	2.98	3.72	4.47	5.20	5.95	7.44	8.93	10.41	11.90
3 $\frac{3}{4}$.80	1.60	2.39	3.19	3.99	4.78	5.58	6.38	7.97	9.57	11.16	12.75
4	.85	1.70	2.55	3.40	4.25	5.10	5.95	6.80	8.50	10.20	11.90	13.60
4 $\frac{1}{2}$.96	1.92	2.87	3.83	4.78	5.74	6.70	7.65	9.57	11.48	13.39	15.30
5	1.07	2.13	3.19	4.25	5.31	6.38	7.44	8.50	10.63	12.75	14.87	17.00
5 $\frac{1}{2}$	1.17	2.34	3.51	4.67	5.84	7.02	8.18	9.35	11.69	14.03	16.36	18.70
6	1.28	2.55	3.83	5.10	6.38	7.65	8.93	10.20	12.75	15.30	17.85	20.40
7	1.49	2.98	4.46	5.95	7.44	8.93	10.41	11.90	14.87	17.85	20.83	23.80
8	1.70	3.40	5.10	6.80	8.50	10.20	11.90	13.60	17.00	20.40	23.80	27.20

RULES FOR OBTAINING APPROXIMATE WEIGHT OF WROUGHT IRON.

FOR ROUND BARS.

RULE: Multiply the square of the diameter in inches by the length in feet, and that product by 2.6. The product will be the weight in pounds, nearly.

FOR SQUARE AND FLAT WROUGHT BARS.

RULE: Multiply the area of the end of the bar in inches by the length in feet, and that 3.32. The product will be the weight in pounds, nearly.

WROUGHT IRON, ASSUMED WEIGHT.

- A cubic foot = 480 lbs.
- A square foot, 1 inch thick..... = 40 lbs.
- A bar 1 inch square, 1 foot long..... = 3 1-3 lbs
- A bar 1 inch square, 1 yard long..... = 10 lbs.

RULE FOR FINDING THE SECTIONAL AREA OF A BAR OF WROUGHT IRON, WHEN WEIGHT PER FOOT IS GIVEN.

Multiply by 3 and divide by 10.

RULE FOR FINDING THE WEIGHT PER FOOT, WHEN AREA IS GIVEN.

Divide by 3 and multiply by 10.

NOTES ON CONSTRUCTION.

The necessity for vigilance and supervision of boiler designing and construction is made apparent in England by the stringent laws and by enforced rules and practices governing the same in way of additional factors for safety. They result in promoting good work and care in the operating and management of steam boilers.

Additional factors for safety are added to the established one of 5 due to deterioration by usage, age or fuel.

The English Board of Trade has established and tabulated a table of percentage of increase of factor of safety and cites reasons for such additional proportions.

All boilers must be designed and constructed according to their specifications, viz.: Holes to be drilled when shell plates have been rolled; straps or cover plates not less than $\frac{5}{8}$ of plates they cover; in butt joints rivet sections must be 75 per cent over rivets in single shear and circumferential seams at least one-half the percentage of longitudinal seam.

The increased factor of safety is insisted on when conditions are as follows:

TABLE.

PERCENTAGE OF INCREASE		
A.	= .1	To be added when all holes are fair and good in the long seam, but drilled out of place after bending.
B.	= .2	When all holes are fair and good in longitudinal seams, but drilled before bending.

PERCENTAGE OF INCREASE		
C.	= .2	When all holes are fair and good in longitudinal seams, but punched after bending.
D.	= .3	When all holes are fair and good in longitudinal seam but punched before bending.
E.	= .7	When all holes are not fair and good in longitudinal seam (and increased according to values).
F.	= .8	When holes are all fair and good in the circumferential seams, but drilled out of place after bending.
G.	= .1	When all holes are fair and good in the circumferential seams, but drilled before bending.
H.	= .1	When holes are fair and good in the circumferential seams, but punched after bending.
I.	= .15	If the holes are all fair and good in the circumferential seams, but punched before bending.
J.	= .15	If the holes are not fair and good in the circumferential seams (and increased according to values).
K.	= .2	If the double butt straps are not fitted to the longitudinal seams and said seams are lap and double riveted.
L.	= .07	If double butt straps are not fitted to the longitudinal seams and said seams are lap and triple riveted.
M.	= .3	If only single butt straps are fitted to the longitudinal seams and said seams are double riveted.
N.	= .15	If only single butt straps are fitted to the longitudinal seams and said seams are triple riveted.
O.	= .1	When any description of joint in the longitudinal seam is single riveted.
P.	= .2	If all holes are punched small and reamed afterwards or drilled out in place.
Q.	= .4	If the longitudinal seams are fitted with single butt straps and are single riveted.
R.	= .4	When material or workmanship is according to inspector doubtful or not the best (then the factor is increased accordingly).
S.	= .1	If the circumferential seams are lap joints and double riveted.
T.	= .2	If the circumferential seams are lap joints and single riveted.
U.	= .25	When the circumferential seams are lap and the plates are not entirely under or over covers, and 1.65 to be added if the boiler is not open to inspection during the whole period of its construction.

The benefits derived from these additional factors of safety will be the means of bringing the science of boiler designing and work of construction up to a high standard.

In designing seams reason must govern when calculations are made, for if too great a pitch is used the plate cannot be drawn together without springing of plate or heads of rivets coming off, and so prevent making a tight caulking edge.

Each joint will be taken up separately as the strength of a joint is less than that of the solid plate due to cutting away for rivet holes and the single riveted lap joint is the weakest designed.

Tests have been made on various designed joints, and as it would be impossible to test all joints constructed, calculations from practice, factors and co-efficients must be relied on and followed up; these have proved satisfactory when construction has been carefully complied with according to designs.

The aim in boiler construction is to have the percentage of strength in rivet and plate as near equal as possible.

The maximum strength of a boiler is calculated from its weakest point, and the subject of seams in various forms and design will be taken up later; also boiler diameter, material thickness of same; rivets, their diameter; shearing strength, if single or double; pitch of rivets, number of rivets in joints; butt straps and factors, such as constants, taken into consideration when calculating the strength of a seam and varying according to conditions; methods of construction and design of joint or difference in material.

The necessity for care in designing and constructing to resist great forces is clearly shown by the following calculation: A common size boiler $60'' \times 16'$ has approximately 32,145 square inches of bursting area and at a pressure of 100 pounds it has a total of 1,607 tons of energy or bursting pressure; with the higher pressures now used, this hazard increases.

The English Board of Trade, a recognized authority on steam boilers, says that the rivet percentage of seam should be in excess of the plate and when computing the rivet section when steel plates and rivets are used the rivet section must be divided by $28/23$. If iron rivets are used with steel plates then the rivet section must be $5/8$ times greater than plate section and be divided by $13/8$.

When describing strains, the action of shearing rivets means to shear across its diameter. The tearing strain refers to the action of tearing apart of plate. The crushing strain is the action to crush or rupture the plate between rivet holes and edge of plate.

In calculations for rivet strength the diameter of the rivet hole will be taken and not the diameter of the rivet, for the rivet must fill the rivet hole.

The reader will observe in following calculations that decimals will be omitted when of minor value.

LEGEND.

SYMBOLS USED IN FORMULAS

P	=	pressure
p	=	pitch of rivets
P _m	=	maximum pitch
N	=	number of rivets
P _d	=	diagonal pitch of rivets
D	=	diameter of boiler
d	=	diameter of rivet hole
T	=	Thickness of plate
%	=	percentage
V	=	distance between rows
E	=	distance center of rivets to edge of plate (lap)
TS	=	tensile strength of plate
AR	=	area of rivet hole
F	=	factor of safety

A coefficient is a prescribed amount to make up for any defects reducing strength of plate due to punching, riveting, caulking, &c.

A factor of safety is the difference between the safe working and bursting pressures.

It is well to explain here that calculations of joints are based on the principle that sections of the same do not vary, except according to the joints designed; the boiler, figuratively speaking, is composed of rings, each one having the same amount of plate width and pitch of rivets and the weakest part of this supposed ring is the base of the maximum strength. In the process of computing calculations this will appear clear to the student.

The rules for calculating strength of joints vary in formulas and results, but as stated in previous pages the rules the writer has used in connection with designing, testing and inspecting have been based on experiments and found in practice to have a factor of safety of reasonable margin.

While in computing joints the aim is to get the plate and rivet strength as near equal; favoring the rivet; it must be remembered that a variance in pitch will vary efficiencies as will also the diameter of a rivet, these being of standard sizes and varying in sixteenths; some of the rules will show an excess of rivet strength or even plate, and will appeal to the reader that a smaller diameter of rivet or greater pitch, or a lower or higher tensile strength, would affect the factors in securing the best possible efficiencies.

In the following rules in connection with boiler as outlined there are calculations to make from material and ratios for efficiencies. The strength of rivets has been computed from exhaustive tests and as the subject of rivet shearing will be a factor in calculating seams of efficiency it may be well to make some explanations. The necessary force to shear a rivet in single shear is 38,000 lbs. to square inch of cross section of rivet. The strain necessary to shear a rivet in double shear is 85 per cent more than in single shear.

EXAMPLE:

Rule to find strength of rivet in single shear: Multiply area of rivet hole by shearing resistance of rivet.

FORMULA:

$$A \times S = \text{strength of rivet in single shear}$$


EXAMPLE:

$$\begin{aligned} .5185 &= \text{area of rivet hole} \\ 38000 &= \text{shearing resistance} \end{aligned}$$


$$\begin{array}{r} 41480000 \\ 15555 \end{array}$$

$$19703.0000$$

19,703 = strength of one rivet in single shear



SINGLE SHEAR



DOUBLE SHEAR

$$\begin{array}{r} 38000 = \text{lbs. single shear} \\ .85 = \% \text{ more for double} \\ \text{shear} \\ \hline 190000 \\ 304000 \end{array}$$

$$32300.00 \text{ lbs.} = 85\% \text{ of } 38000 \text{ lbs.}$$

adding the value to the above

$$\begin{array}{r} 38000 = \text{single shearing strength} \\ 32300 = 85\% \text{ added} \end{array}$$

$$70300 = \text{shearing strength of a rivet in double shear}$$

CHAPTER IV.

BRACES AND REINFORCING.

While there are boilers being made today that have strength in designed circular forms, the many in use and those being constructed have surfaces requiring reinforcements, some having an excess over other types and the high pressures now in demand require the best methods and improved design of brace.

This is a subject of as much importance as the designing of a joint and requires careful selection, proportioning and attaching braces to counteract strains that may be due to resisting bursting pressures, and those of contraction, expansion and collapsing.

Various designed braces and stays have been in use and are as varied in stability, some having minimum amount of strength, due to their structural weakness; again while some have the desired form and strength, location or principle of attaching same has depreciated their value as a reinforcement.

The subject of bracing is broad and could be treated inexhaustively, this owing to the many necessities and forms where each must necessarily be worked out separately. It is the intention to take up the most general methods, such as stay bolts, formed braces, stay tubes, crown bars, and angle irons.

Factors that are taken into consideration are

Structural,
Design,
Tensile strength,
Location, and
Principle of attaching.

In using rivets for braces it is customary to have the combined area equal to $1\frac{1}{4}$ times the brace area.

STAY BOLTS.

The use of stay bolts or stud stays for bracing is not at best a very satisfactory method of reinforcement, this owing to position

and conditions, especially in fire box boilers where strains are caused by a bending force through the expansion of fire sheet, a pulling strain by the collapsing and bursting pressures and by that of vibration.

Care is necessary in selecting the best material; the U. S. Government requires the same tests to be made in accordance with those of plate used in connection with boilers coming under the supervision of the Federal Government. In physical and chemical tests results must show according to prescribed rules. Constant vibration is a menace to safety and braces are subject to and effected more by it than the strains from the pressures and more than the shell tubes or rivets are by it.

The best material for this strain is that made from piling material over that which is made from the bloom, this being due to its lamina structure.

Requirements to look for in brace materials are:

Tensile strength,
Elongation,
Reduction of area,
Elasticity.

Vigilance, careful and frequent tests and inspections of the stay bolts are necessary, for the force of expansion, contraction, tension, bending and vibration are severe. In the work of inserting and finishing this part of boiler construction defects often develop, this by stripping of threads when entering inner plate, again by hammering over ends; when this does occur the value of the brace is gone.

The design of the brace (stay bolt) is weak in the first place for the threads act in a measure as an initial fracture, especially so when one portion of thread is cut a little deeper than the balance. The hollow type of stay bolt has commendable features, viz.: The available admission of air to the (rich in heat units) volatile gases from fuel in furnace (these gases having a heat value of 62,000 heat units per pound, while the carbon or coke has only 14,500), the heating of the air before coming in contact and mixing with same, thus producing economical results, from minimum heat absorbed by air from water; another feature that commends itself is instant notice of any failure.

Rule to find safe working pressure on flat surfaces when thickness of plate and pitch of stay bolts are known:

Multiply the constant given for the specified thickness by the thickness of plate squared in sixteenths and divide by the greatest pitch squared.

FORMULA:

$$\frac{C \times T^2}{P^2} = \text{safe working pressure}$$

What is the safe working pressure on a curved surface less than a true circle? Plate 7/16 thick and stay bolts 5" × 6" centers.

EXAMPLE:

$$\frac{7}{16} = \frac{7}{16} = \text{thickness}$$

$$\frac{49}{16} = \text{thickness squared}$$

$$\frac{112}{49} = \text{constant as provided for thickness squared}$$

$$\begin{array}{r} \text{pitch} = 6'' \quad \frac{1008}{6} \quad \frac{448}{6} \\ \text{pitch squared} = 36 \quad \frac{5488}{36} \quad (152 \text{ lbs. safe working pressure}) \\ \frac{188}{180} \\ \frac{88}{72} \\ \frac{16}{16} \end{array}$$

Note constants for specific conditions as used in following examples:

For a plate three-fourths of an inch thick, stayed 9-inch by 10-inch centers:

$$\text{Working pressure} = \frac{120 \times 144}{100} = 172 \text{ pounds.}$$

For a plate nine-sixteenths of an inch thick, screw stays with nuts, stays pitched 9-inch by 10-inch centers:

$$\text{Working pressure} = \frac{135 \times 81}{100} = 109 \text{ pounds.}$$

For a plate three-fourths of an inch thick, supported by stays with double nuts, without washers or doubling plates, 10-inch by 12-inch centers:

$$\text{Working pressure} = \frac{170 \times 144}{144} = 170 \text{ pounds.}$$

For plate one-half inch thick, with washers three-eighths of an inch thick, stayed 10-inch by 12-inch centers:

$$\text{Working pressure} = \frac{160 \times 101.60}{144} = 112 \text{ pounds.}$$

For plate five-eighths of an inch thick, with doubling plate seven-sixteenths of an inch thick, stayed by 14-inch by 14-inch centers:

$$\text{Working pressure} = \frac{200 \times 149.81}{196} = 152 \text{ pounds.}$$

For plate five-eighths of an inch thick, with tees or angle bars one-half of an inch thick, stayed by 14-inch by 14-inch centers:

$$\text{Working pressure} = \frac{200 \times 167.96}{196} = 171 \text{ pounds.}$$

Plates heated for working must be annealed afterwards.

The diameter of a screw stay shall be taken at the bottom of the thread, provided it is the least diameter of the stay.

Flat heads not exceeding 20 inches in diameter may be used unsupported at pressure allowed by following rule:

Multiplying constant by thickness of head in sixteenths squared, and dividing by half of area to be supported, gives the pressure allowed.

FORMULA:

$$\frac{C \times T^2}{\frac{1}{2} \text{ of } A} = P$$

Where P = steam pressure allowable in pounds.

T = thickness of material = $\frac{3}{4}$ = $\frac{1}{8}$.

A = area of head in inches = 314".

C = 112 for plates $\frac{1}{8}$ of an inch and under.

C = 120 for plates over $\frac{1}{8}$ of an inch.

Provided, The flanges are made to an inside radius of at least $1\frac{1}{2}$ inches.

EXAMPLE:

Required the working pressure of a flat head 20 inches in diameter and $\frac{3}{4}$ of an inch thick.

$$\begin{array}{r}
 120 = \text{constant as provided for} \\
 144 = \text{head in sixteenths squared} \\
 \hline
 480 \\
 480 \\
 120 \\
 \hline
 \text{one-half area of head} = 157 \quad 17280 \text{ (110 pounds safe working pressure)} \\
 157 \\
 \hline
 158 \\
 157 \\
 \hline
 10
 \end{array}$$

FLAT SURFACES.

The maximum stress allowable on flat plates supported by stays shall be determined by the following rule:

All stayed surfaces formed to a curve the radius of which is over 21 inches, excepting surfaces otherwise provided for, shall be deemed flat surfaces.

CONSTANTS.

- C = 112 for screw stays with riveted heads, plates seven-sixteenths of an inch thick and under.
- C = 120 for screw stays with riveted heads, plates above seven-sixteenths of an inch thick.
- C = 120 for screw stays with nuts, plates seven-sixteenths of an inch thick and under.
- C = 125 for screw stays with nuts, plates above seven-sixteenths of an inch thick and under nine-sixteenths of an inch.
- C = 135 for screw stays with nuts, plates nine-sixteenths of an inch thick and above.
- C = 170 for stays with double nuts having one nut on the inside and one nut on the outside of plate, without washers or doubling plates.
- C = 160 for stays fitted with washers or doubling strips which have a thickness of at least .5 of the thickness of the plate and a diameter of at least .5 of the greatest pitch of the stay, riveted to the outside of the plates, and stays having one nut inside of the plate, and one nut outside of the washer or doubling strip. For T take 72 per cent of the combined thickness of the plate and washer or plate or doubling strip.
- C = 200 for stays fitted with doubling strips which have a thickness equal to at least .5 of the thickness of the plate reinforced, and covering the full area braced (up to the curvature of the flange, if any), riveted to either the inside or outside of the plate, and stays having one nut outside and one inside of the plates. Washers or doubling plates to be substantially riveted. For T take 72 per cent of the combined thickness of the two plates.

C=200 for stays with plates stiffened with tees or angle-bars having a thickness of at least two-thirds the thickness of plate and depth of webs at least one-fourth of the greatest pitch of the stays, and substantially riveted on the inside of the plates, and stays having one nut inside bearing on washers fitted to the edges of the webs, that are at right angles to the plate. For T take 72 per cent of the combined thickness of web and plate.

No flat plates or surfaces shall be unsupported at a greater distance than 18 inches.

Multiply the constant 120 by the thickness squared in sixteenths and divide product by the pitch of stay squared:

FORMULA:

$$\frac{C \times T^2}{P^2} = \text{working pressure}$$

LEGEND:

T = thickness of plate = $\frac{7}{16}$ = 7
 P = pitch = 10''
 C = constant = 120

EXAMPLE:

120 = constant
 49 = plate squared in 16ths

1080
 480

pitch squared = 100) 5880 (58.8 lbs. pressure allowed or 59 lbs. nearly
 500

880
 800

80

Rules adopted by authorities that have proven satisfactory from tests and usage and adopted by the U. S. Government and reputable boiler manufacturers are given in this chapter, and in connection material and workmanship is considered to be the best, fitted accurately and properly secured.

Exhaustive tests have been made by the highest authorities, governments, scientific and mechanical and results have shown that there are some differences; sufficient reasons in the fact show that the majority are near enough to establish formulas that have liberal margins of safety.

Judgment must be governed by conditions and construction when out of the ordinary and special consideration given, always

allowing a reasonable factor of safety for an unusual form or position.

For all stays the least sectional area shall be taken in calculating the stress allowable.

All screw stay bolts shall be drilled at the ends with a one-eighth inch hole to at least a depth of one-half inch beyond the inside surface of the sheet. Stays through laps or butt straps may be drilled with larger hole to a depth so that the inner end of said larger hole shall not be nearer than the thickness of the boiler plates from the inner surface of the boiler.

Such screw stay bolts, with or without sockets, may be used in the construction of marine boilers where fresh water is used for generating steam: *Provided, however,* that screw stay bolts of a greater length than 24 inches will not be allowed in any instance, unless the ends of said bolts are fitted with nuts. Water used from a surface condenser shall be deemed fresh water.

Holes for screwed stays must be tapped fair and true and full thread.

The ends of stays which are upset to include the depth of thread shall be thoroughly annealed after being upset.

The sectional area of pins to resist double shear and bending, accurately fitted and secured in crow feet, sling, and similar stays, shall be at least equal to required sectional area of the brace. Breadth across each side and depth to crown of eye shall be not less than .35 to .55 of diameter of pin. In order to compensate for inaccurate distribution the forks should be proportioned to support two-thirds of the load, thickness of forks to be not less than .66 to .75 of the diameter of pins.

The combined sectional area of rivets used in securing tee irons and crow feet to shell, said rivets being in tension, shall be not less than the required sectional area of brace. To insure a well-proportioned rivet point, the total length of shank shall closely approximate the grip plus 1.5 times the diameter of the shank. All rivet holes shall be drilled. Distance from center of rivet hole to edge of tee irons, crow feet, and similar fastenings shall be so proportioned that the net sectional areas through sides at rivet holes shall equal the required rivet section. Rivet holes shall be slightly countersunk in order to form a fillet at point and head.

CONSTANTS PROVIDED FOR THE VARYING REQUIREMENTS.

- C = 9,000 for tested steel stays exceeding $2\frac{1}{2}$ inches in diameter.
 C = 8,000 for tested steel stays $1\frac{1}{4}$ inches and not exceeding $2\frac{1}{2}$ inches in diameter, when such stays are not forged or welded. The ends, however, may be upset to a sufficient diameter to allow for the depth of the thread. The diameter shall be taken at the bottom of the thread, provided it is the least diameter of the stay. All such stays after being upset shall be thoroughly annealed.
 C = 8,000 for a tested Huston or similar type of brace, the cross-sectional area of which exceeds 5 square inches.
 C = 7,000 for such tested braces when the cross-sectional area is not less than 1.227 and not more than 5 square inches, provided such braces are prepared at one heat from a solid piece of plate without welds.
 C = 6,000 for all stays not otherwise provided for.

Rule to find sectional area of a brace to support a given area when pressure is known: Multiply area to be supported by pressure per square inch and divide by constant as provided for size and material of brace.

FORMULA:

$$\frac{A \times P}{C} = \text{sectional area of brace}$$

LEGEND:

- A = area to be supported = 36 square inches
 P = pressure = 150 lbs.
 C = constant = brace steel having $1\frac{1}{4}$ diameter = 8000

EXAMPLE:

36" = sectional area to be supported
 150 = lbs. pressure

1800
 36

constant for $1\frac{1}{4}$ steel brace = 8000) 54000000 (.6750 = $\frac{43}{64}$ or $\frac{11}{16}$ cross-sectional area nearly

48000
 60000
 56000

40000
 40000

0

Rule to find strain on a stay bolt: Multiply the area supported by the stay, by the pressure.

FORMULA:

$$A \times P = \text{strain on stay}$$

LEGEND:

A = area = $6'' \times 6'' = 36$ square inches
 P = pressure = 150 lbs.

EXAMPLE:

$$\begin{array}{r} 36 \text{ square inches} = \text{area} \\ 150 = \text{lbs. pressure} \\ \hline 1800 \\ 36 \\ \hline 5400 = \text{lbs. strain on bolt} \end{array}$$

Rule to find greatest area one stay bolt may support: Multiply area of stay bolt by constant and divide by working pressure.

FORMULA:

$$\frac{A \times C}{P} = \text{limit of area to be supported by one bolt}$$

LEGEND:

C = constant = 6000 lbs. allowed per cross-sectional area
 A = area of stay bolt = $\frac{1}{8}$ = .69029
 P = pressure = 150 lbs.

EXAMPLE:

$$\begin{array}{r} .69029 = \text{area of } \frac{1}{8} \text{ bolt} \\ 6000 = \text{constant} \\ \hline \text{pressure} = 150 \quad 41417.4000 \quad (27.6'' = \text{limit of area to be supported by one bolt}) \\ 300 \\ \hline 1141 \\ 1050 \\ \hline 917 \\ 900 \\ \hline 17 \end{array}$$

Rule to find number of stay bolts to support a given area when pressure is given:

Multiply area to be supported by pressure and divide sum by constants as provided for. Constants for the different size bolts to be used are as follows:

	for $\frac{7}{8}''$ diameter use constant	4000,
	" $1\frac{1}{8}''$ " " " "	6000,
	" $2\frac{1}{2}''$ " " " "	8000,

if for over that diameter and up to being pounds pressure per square inch of cross-sectional area.

THE BOILER.

FORMULA:

$$\frac{A \times P}{C} = \text{number of stay bolts}$$

The following example is where bolts are $\frac{7}{8}$ " in diameter:

LEGEND:

A = area to be supported = 800 square inches

P = pressure = 100 lbs.

C = constant = 4000

EXAMPLE:

800 = area to be supported
100 = lbs. pressure

$$\begin{array}{r} \text{constant} = 4000 \overline{) 80000} \text{ (20 stay bolts required)} \\ \underline{8000} \\ 0 \end{array}$$

The following example is where bolts are $1\frac{1}{8}$ " diameter:

LEGEND:

A = area to be supported = 500

P = pressure = 120 lbs.

C = constant = 6000

EXAMPLE:

500 = area to be supported
120 = lbs. pressure

$$\begin{array}{r} \overline{10000} \\ \underline{500} \\ \text{constant} = 6000 \overline{) 60000} \text{ (10 stay bolts required)} \\ \underline{6000} \\ 0 \end{array}$$

Rule to find centers for stay bolts when pressure, area to be supported and constant provided for stay bolt are known: Multiply area of stay bolt by constant and divide by pressure.

FORMULA:

$$\frac{A \times C}{P} = \text{centers of stay bolts}$$

LEGEND:

A = area to be supported = .3750

C = constant = 4000

P = pressure = 150 lbs.

EXAMPLE :

.3750 = area of stay bolt
4000 = constant

$$\text{pressure} = 150 \left(\frac{1500.0000}{150} \right) (10'' = \text{centers of stay bolts})$$

Rule to find area of stay bolt. Multiply centers of stay bolt by pressure and divide by constant 4,000; the quotient is area of stay bolt required.

FORMULA :

$$\frac{CB \times P}{C} = \text{area of stay bolt}$$

LEGEND :

P = pressure = 150 lbs.
C = constant = 4000.
CB = center of stay bolt = 10''

EXAMPLE :

10'' = center of stay bolt
150 = pressure

$$\begin{array}{r} 500 \\ 10 \\ \hline \text{constant} = 4000 \left(\frac{1500.0000}{1200} \right) (.3750 = \text{area of stay bolt}) \\ 300 \ 00 \\ 280 \ 00 \\ \hline 20 \ 000 \\ 20 \ 000 \\ \hline 0 \end{array}$$

English Board of Trade rule to find safe working pressure when steel stay bolts are used and are screwed into plates and fitted with nuts :

Multiply constant 80 (plus 25% for steel) by thickness of plate in sixteenths plus one sixteenth squared; divide by pitch of rivet squared minus 6; product is safe working pressure.

FORMULA :

$$\frac{C + \% \times (T + \frac{1}{16})^2}{P^2 - 6} = \text{safe working pressure}$$

LEGEND:

- T = thickness of plate = $\frac{7}{16}$
- P = pitch = 7
- C = constant = 80
- % = 25% added for steel

EXAMPLE:

	80 = constant	
	20 = 25% added for steel	
pitch = 7	100	
7	64 = $\frac{7}{16} + \frac{1}{16}$ or $\frac{8}{16}$, squared	
pitch squared = 49	400	
minus	6 600	
	43) 6400 (148 = lbs. pressure for steel bolts	
	43	
	210	7 = $\frac{7}{16}$ = thickness of plate
	172	1 = $\frac{1}{16}$ added
	380	8 = $\frac{8}{16}$
	344	8
	36	64 = $\frac{8}{16}$ squared

Rule to find pitch of stay bolts:

Multiply constant 112 by the square of the thickness of plate in sixteenths of an inch; divide this product by steam pressure and extract the square root of quotient.

FORMULA:

$$\sqrt{\frac{C \times T^2}{P}} = \text{pitch of stay}$$

LEGEND:

- C = constant = 112
- T = thickness of plate = $\frac{7}{16}$
- P = pressure = 150

EXAMPLE:

	112 = constant	
	49 = the square of $\frac{7}{16}$	
	1008	
	448	
	150) 5488 (36	
	450	square root of 36 is 6" pitch
	988	
	900	6) 36(6" = square root = pitch of bolts
	88	36
	88	—

TABLE OF STAY BOLTS, PLATE, PITCH AND PRESSURE.

Pressure in pounds.	Centers of Stay Bolts.		
	$\frac{3}{8}$ " Plate	$\frac{7}{16}$ " Plate.	$\frac{1}{2}$ " Plate.
20	11 $\frac{1}{4}$ " pitch	13" pitch	15" pitch
40	8	9 $\frac{1}{4}$ " "	10 $\frac{5}{8}$ " "
60	6 $\frac{1}{2}$ " "	7 $\frac{5}{8}$ " "	8 $\frac{1}{4}$ " "
80	5 $\frac{5}{8}$ " "	6 $\frac{1}{2}$ " "	7 $\frac{1}{2}$ " "
100	5	5 $\frac{1}{4}$ " "	6 $\frac{1}{4}$ " "
120	4 $\frac{1}{2}$ " "	5 $\frac{1}{4}$ " "	6 $\frac{1}{8}$ " "
140	4 $\frac{1}{4}$ " "	4 $\frac{7}{8}$ " "	5 $\frac{5}{8}$ " "
150	4 $\frac{1}{8}$ " "	4 $\frac{1}{4}$ " "	5 $\frac{1}{2}$ " "
160	4	4 $\frac{5}{8}$ " "	5 $\frac{1}{4}$ " "
Diam. of stay bolt	$\frac{7}{8}$ "	1"	1 $\frac{1}{4}$ "

CROW FOOT OR FORMED BRACES.

As stated in preceding pages the many and varied surfaces to be braced requiring specific methods and application of bracing, the H. T. boiler, having the minimum amount of flat surface and conditions favorable to apply the selection for suitable type of brace, is confined to the one with minimum structural weakness, taking the Huston, McGregor, or of equal stability.

In calculating the necessary reinforcement by bracing—the area of surface to be stayed, and working pressure is considered; while the thickness of head is a factor in its strength, the necessity for braces in lieu of increasing the thickness of head to self supporting, is without comment.

In all types of stays the least sectional area must be taken in calculating the stress allowable and the combined sectional area of rivets used in securing crow feet, angle irons and such form of braces, necessitating rivets, must not be less than the required sectional area of brace; all rivet holes to be drilled, and the distance from center of hole to edge of palm or brace surface shall be so proportionate that the net sectional areas through sides at rivet holes shall equal the rivet section; rivet holes in plate to be slightly countersunk.

Taking a flat surface in head above water line, say 800 square inches, to proportionate a proper thickness of head for that *unstayed*

portion it would be necessary to have the thickness of head by rule as follows:

Multiply area by pressure and again by constant; divide product by tensile strength multiplied by 10; the quotient will be the thickness for unstayed portion.

LEGEND:	FORMULA:
<p>A = area = 800 square inches P = pressure = 100 C = constant = 7000 lbs. per square inch TS = tensile strength = 60000</p>	$\frac{A \times P \times C}{TS \times 10} = \text{thickness for unstayed portion}$

EXAMPLE:

800 = area	80000	
100 = pressure	7000 = constant	
tensile strength = 60000	10	
multiplied by	600000	560000000 (933 = $\frac{11}{8}$ inch nearly in thickness
	5400000	
	2000000	
	1800000	
	2000000	
	1800000	
	200000	

This would not be desirable for reasons of cost, labor attached to working it and conductivity of heat, therefore heads must be of less thickness and bracing resorted to.

To find the area of an unstayed segment is the first thing necessary and that is a simple rule as used in boiler construction, as calculations for such measures are always favored.

Rule to find minimum area of stay or brace to support a given area: Divide load on stay by allowable strain per square inch of sectional area as provided; the quotient is minimum area of stay.

FORMULA:

$$\frac{L}{S} = \text{area of brace}$$

LEGEND:

L = load on stay = 6750 lbs.

S = strain per square inch of sectional area = 6000 lbs.

EXAMPLE:

strain allowed per sq. in. = 6000) 6750.000 (1.125 or $1\frac{1}{8}$ " diameter
6000

$$\begin{array}{r} \hline 750\ 0 \\ 600\ 0 \\ \hline 150\ 00 \\ 120\ 00 \\ \hline 300\ 00 \\ 300\ 00 \\ \hline \hline \end{array}$$

Rule to find area of stay beyond maximum of curved surface unsupported when thickness of plate and pressure are known: Multiply constant 112 by thickness of plate in sixteenths of an inch and divide product by the pressure in pounds per square inch; the quotient is area of stay required.

LEGEND:

C = constant = 112
T = thickness of plate = $\frac{7}{16}$
P = pressure = 150 lbs.

FORMULA:

$$\frac{C \times T}{P} = \text{area of stay}$$

EXAMPLE:

112 = constant
.7 = thickness in 16ths

pressure = 150) 78.4000 (.5226 = area or $\frac{13}{8}$ approximately
75 0

$$\begin{array}{r} \hline 3\ 40 \\ 3\ 00 \\ \hline 400 \\ 300 \\ \hline 1000 \\ 900 \\ \hline 100 \end{array}$$

To determine the areas of diagonal stays: Multiply the area of a direct stay required to support the surface by the slant or diagonal length of the stay; divide this product by the length of a line drawn at right angles to surface supported to center of palm of diagonal stay. The quotient will be the required area of the diagonal stay.

FORMULA:

$$\frac{A \times L}{1} = \text{sectional area of diagonal stay}$$

THE BOILER.

LEGEND:

- A = sectional area of direct stay = .7854
- L = length of diagonal stay = 60"
- l = length of line drawn at right angles to boiler head or surface supported to center of palm of diagonal stay = 48"

EXAMPLE:

.7854 = area of 1" direct stay
 60 = length of stay

length of line drawn at right angles to boiler = 48") 47.1240 (.9817 = sectional area of a diagonal brace = 1 1/8" nearly

3	92
3	84
84	
	48
360	
	336
24	

When diagonal braces are applied the angle should not exceed over 30 degrees.

Rule to find the load on a stay: Multiply area to be supported by pressure and divide by sectional area of stay bolt.

LEGEND:

- A = area to be supported = 50"
- P = pressure = 160 lbs.
- SB = area of stay bolt = .69029

FORMULA:

$$\frac{A \times P}{SB} = \text{strain on sectional area of stay}$$

EXAMPLE:

50" = area to be supported
 160 = pressure

3000
50
8000
69029
1097
69029
406
345
61
55
6
6
22919

area of stay bolt = .69029) 8000.00000 (11589 lbs. = strain on sectional area of stay

HEADS.

All heads employed in the construction of cylindrical externally fired boilers, for steamers navigating the Red River of the North and rivers that flow into the Gulf of Mexico, shall have a thickness of material as follows:

For boilers having a diameter—

Over 32 inches and not over 36 inches, not less than $\frac{1}{2}$ inch.

Over 36 inches and not over 40 inches, not less than $\frac{5}{16}$ inch.

Over 40 inches and not over 48 inches, not less than $\frac{3}{8}$ inch.

Over 48 inches, not less than $\frac{3}{4}$ inch.

Where flat heads do not exceed 20 inches in diameter they may be used without being stayed, and the steam pressure allowable shall be determined by the following formula:

$$P = \frac{C \times T^2}{A}$$

Where P = steam pressure allowable in pounds.

T = thickness of material in sixteenths of an inch.

A = one-half the area of head in inches.

C = 112 for plates $\frac{7}{16}$ of an inch and under.

C = 120 for plates over $\frac{7}{16}$ of an inch.

Provided, The flanges are made to an inside radius of at least $1\frac{1}{2}$ inches.

EXAMPLE.

Required the working pressure of a flat head 20 inches in diameter and $\frac{3}{4}$ of an inch thick. Substituting values, we have

$$P = \frac{120 \times 144}{157} = 110 \text{ pounds}$$

The heads of steam and mud drums of such boilers shall have a thickness of material of not less than half an inch; pressure to be determined by formula for flatheads.

CONVEXED HEAD.

Rule to find pressure allowed on a convexed head: Multiply the thickness of the plate by one-sixth of the tensile strength and divide by one-half of radius to which head is bumped; result gives pressure allowed per square inch.

Add 20 per cent to pressure when the head is double riveted to the shell and the holes are fairly drilled.

LEGEND:	FORMULA:
TS = tensile strength = 60000	$\frac{T \times (1/6 \text{ of TS})}{\frac{1}{2} \text{ of R}} = \text{lbs. pressure allowed}$
T = thickness of plate = $\frac{5}{8}$ = .625	
R = radius of bump = 60"	

EXAMPLE:

.625 = thickness of plate	10000 = 1/6 of TS
<hr style="width: 50%; margin: 0 auto;"/>	
half of radius = 30)	6250.000 (208 lbs. = pressure allowed on single riveted circumferential seam
	60
	<hr style="width: 50%; margin: 0 auto;"/>
	250
	240
	<hr style="width: 50%; margin: 0 auto;"/>
	10
	208 lbs. = pressure allowed on single riveted
	41.6 = 20% added for double riveted
	<hr style="width: 50%; margin: 0 auto;"/>
	249.6 lbs. pressure allowed double riveted

Rule to find bursting pressure on flat head: Multiply thickness of plate by ten times the tensile strength and divide by area of head in inches; the sum is bursting pressure.

LEGEND:	FORMULA:
T = thickness of plate = $\frac{5}{8}$ = .5625	$\frac{T \times (10 \times \text{TS})}{A \times C} = \text{bursting pressure}$
TS = tensile strength = 60000	
A = area of head = 934.822 inches	
D = diameter of head = 34 $\frac{1}{2}$ "	

EXAMPLE:

.5625 = thickness of plate	600000 = ten times tensile strength
<hr style="width: 50%; margin: 0 auto;"/>	
area of head = 934822)	337500.0000 (361 lbs. bursting pressure
	280446 6
	<hr style="width: 50%; margin: 0 auto;"/>
	57053 40
	56089 32
	<hr style="width: 50%; margin: 0 auto;"/>
	964 080
	934 822
	<hr style="width: 50%; margin: 0 auto;"/>
	29 258

Divide bursting pressure by 5 and this will give working pressure

CONCAVED HEAD.

Rule to find pressure allowed on a concave head: Multiply the pressure per square inch allowed on a bumped head attached convexly by the constant .6, and the product will give the pressure per square inch allowed on concaved head.

FORMULA:

$$P \times C = \text{pressure on concaved head}$$

LEGEND:

P = pressure allowed on a bumped head = 208 lbs.
C = constant = .6

EXAMPLE:

208 = pressure allowed on a bumped head
.6 = constant

—————
124.8 = lbs. pressure on a concaved head

NOTE ON DISHED HEADS.

Dished or bumped heads have strength due to form and thickness depending on diameter.

Bumped heads may contain a manhole opening flanged inwardly, when such flange is turned to a depth of three times the thickness of the material in the head.

DEPTHS OF DISH AND FLANGE HEADS.

Diam. Heads.	Diam. after Dishing and Flanging.	Depth of Dish.	Depth of Flange.
34	30	3	2
40	36	3	2
46	42	4	2
52½	48	5	2
58½	54	6	2
65	60	6	2
71	66	7	2
77	71½	7	2
78	72	8	2
87	80	8	2½
91	84	9	2½
97	90	10	2½
102	96	12	2½

CAST IRON HEADS.

Rule to find thickness of an unstayed boiler head so it will equal in strength the shell: Multiply square root of radius by the thickness of the shell plate in inches; the product is the required thickness of head.

LEGEND:

T = thickness of plate $\frac{3}{8}$ " = .375
 IR = inside radius = 19.9809

FORMULA:

$(\sqrt{IR}) \times T = \text{thickness of head}$


EXAMPLE:

4.47 = square root of radius
 .375 = thickness of shell

$$\begin{array}{r} 2235 \\ 3129 \\ \hline 1341 \end{array}$$

1.67625 = thickness of head required = $1\frac{11}{16}$ " approx.

A rule to find area of a segment of a circle as outlined by A, B and C.



Divide the diameter of circle by height of the segment, subtract 608 from quotient and extract the square root of the remainder; this result multiplied by four times the square of the height of the segment and divided by three, will give the area.

FORMULA:

$$\left\{ \frac{\sqrt{D}}{H} - .608 \right\} \times \left\{ \frac{4 \times H^2}{3} \right\} = \text{area of segment}$$

LEGEND:

H = height of segment 22''
 D = diam. of boiler 72''
 C = constant = .608

EXAMPLE:

(diameter)			
height 22''	72.0000	(3.2727	
66			
60			
44			
160		3.2727	
154		.608 constant	
154			
60		1) 2.66470000	(1.6323 sq. root
44		1	
160	26	1 66	1.6323
154	1	56	645
6	323	1047	8 1615
22'' height of segment	3262	7800	65 292
22		6524	979 38
44	32643	127600	1052.8335
44		97929	or 1053'' = area of
484 height squared		29671	segment.
4 four times			
3) 1936 = 4 times square of height			
645.33			

Rule to find number of braces to support a segment as just described: Multiply area of segment by pressure in pounds per square inch and divide by number of pounds pressure form or type of brace sectional area is allowed. To illustrate: A modern formed brace by 8,000 when sectional area exceeds 5 square inches; 7,000 when sectional area is less than 5 square inches, and 6,000 for all stays not otherwise provided for.

FORMULA:

$$\frac{A \times \text{Pressure}}{\text{Brace supporting value}} = \text{number of braces required}$$

THE BOILER.

EXAMPLE:

$$\begin{array}{r}
 1053 = \text{area of segment required} \\
 160 = \text{lbs. pressure} \\
 \hline
 63180 \\
 1053 \\
 \hline
 \text{modern brace} = 8000 \quad 168480 \text{ (21 + or 22 braces)} \\
 16000 \\
 \hline
 8480 \\
 8000 \\
 \hline
 480
 \end{array}$$

The table given below is an extract from Trautwine's Engineers' Pocket Book, and will be found of great value in arriving at an accurate solution.

The first column marked height, is the height of the segment in parts of the diameter of the boiler. The first number .001 refers to a segment whose height is 1/1000 of the diameter of the boiler, the second number refers to 2/1000 of the diameter of the boiler, and the third 3/1000 of the diameter of the boiler and so on until it reaches a complete semi-circle or half-diameter of the boiler.

CUBICAL CONTENTS.

Suppose now we desire to find the cubical contents by the table of the steam space in a boiler 48 inches in diameter by 14 feet long. The water line say is 4" above the top row of tubes and the height of the segment is 12 inches.

The area of circles or similar parts of circles of different sizes are directly proportional to the square of their diameter. Hence, it will only be necessary to find what part of the diameter, 12 inches (the height of the steam space), is. This is done by dividing 12 by 48 = .250. Find this quotient in the column of heights in the table, take the corresponding area and multiply it by the square of the diameter. Then 4×4 equals 16 and $12 \div 48$ equals .250. By the table we find that the area of a segment whose height is .250 is seen to be .153546. This multiplied by 16 gives 2.4567 square feet of the cross sectional area of the steam space. This area multiplied by 14, which is the length of the boiler in feet, or 2.4567×14 equals 34.39, which is the volume of steam space in cubic feet.

The same result in cubic feet can be obtained by the first method, which I do not think can be simplified any further.

BRACES AND REINFORCING.

91

AREAS OF CIRCULAR ARCS.

By This Table May be Obtained the Area of Segments of Circles.

Height	Area	Height	Area	Height	Area	Height	Area
.001	.000 042	.040	.010 538	.079	.028 894	.118	.052 090
.002	.000 119	.041	.010 932	.080	.029 435	.119	.052 737
.003	.000 219	.042	.011 331	.081	.029 979	.120	.053 385
.004	.000 337	.043	.011 734	.082	.030 526	.121	.054 037
.005	.000 471	.044	.012 142	.083	.031 077	.122	.054 690
.006	.000 619	.045	.012 555	.084	.031 630	.123	.055 346
.007	.000 779	.046	.012 971	.085	.032 186	.124	.056 004
.008	.000 952	.047	.013 393	.086	.032 746	.125	.056 664
.009	.001 135	.048	.013 818	.087	.033 308	.126	.057 327
.010	.001 329	.049	.014 248	.088	.033 873	.127	.057 991
.011	.001 533	.050	.014 681	.089	.034 441	.128	.058 658
.012	.001 746	.051	.015 119	.090	.035 012	.129	.059 328
.013	.001 969	.052	.015 561	.091	.035 586	.130	.059 999
.014	.002 199	.053	.016 008	.092	.036 162	.131	.060 673
.015	.002 438	.054	.016 458	.093	.036 742	.132	.061 349
.016	.002 685	.055	.016 912	.094	.037 324	.133	.062 027
.017	.002 940	.056	.017 369	.095	.037 909	.134	.062 707
.018	.003 202	.057	.017 831	.096	.038 497	.135	.063 389
.019	.003 472	.058	.018 297	.097	.039 087	.136	.064 074
.020	.003 749	.059	.018 766	.098	.039 681	.137	.064 761
.021	.004 032	.060	.019 239	.099	.040 277	.138	.065 449
.022	.004 322	.061	.019 716	.100	.040 875	.139	.066 140
.023	.004 619	.062	.020 197	.101	.041 477	.140	.066 833
.024	.004 922	.063	.020 681	.102	.042 081	.141	.067 528
.025	.005 231	.064	.021 168	.103	.042 687	.142	.068 225
.026	.005 546	.065	.021 660	.104	.043 296	.143	.068 924
.027	.005 867	.066	.022 155	.105	.043 908	.144	.069 626
.028	.006 194	.067	.022 653	.106	.044 523	.145	.070 329
.029	.006 527	.068	.023 155	.107	.045 140	.146	.071 034
.030	.006 866	.069	.023 660	.108	.045 759	.147	.071 741
.031	.007 209	.070	.024 168	.109	.046 381	.148	.072 450
.032	.007 559	.071	.024 680	.110	.047 006	.149	.073 162
.033	.007 913	.072	.025 196	.111	.047 633	.150	.073 875
.034	.008 273	.073	.025 714	.112	.048 262	.151	.074 590
.035	.008 638	.074	.026 236	.113	.048 894	.152	.075 307
.036	.009 008	.075	.026 761	.114	.049 529	.153	.076 026
.037	.009 383	.076	.027 290	.115	.050 165	.154	.076 747
.038	.009 764	.077	.027 821	.116	.050 805	.155	.077 470
.039	.010 148	.078	.028 356	.117	.051 446	.156	.078 194

Height	Area		Height	Area		Height	Area		Height	Area	
.157	.078	921	.199	.111	025	.241	.145	800	.281	.180	918
.158	.079	650	.200	.111	824	.242	.146	656	.282	.181	818
.159	.080	380	.201	.112	625	.243	.147	513	.283	.182	718
.160	.081	112	.202	.113	427	.244	.148	371	.284	.183	619
.161	.081	847	.203	.114	231	.245	.149	231	.285	.184	522
.162	.082	582	.204	.115	036	.246	.150	091	.286	.185	425
.163	.083	320	.205	.115	842	.247	.150	953	.287	.186	329
.164	.084	090	.206	.116	651	.248	.151	816	.288	.187	235
.165	.084	801	.207	.117	460	.249	.152	681	.289	.188	141
.166	.085	545	.208	.118	271	.250	.153	546	.290	.189	048
.167	.086	200	.209	.119	084291	.189	956
.168	.087	037	.210	.119	898292	.190	865
.169	.087	785	.211	.120	713	.251	.154	413	.293	.191	774
.170	.088	536	.212	.121	530	.252	.155	281	.294	.192	685
.171	.089	288	.213	.122	348	.253	.156	149	.295	.193	597
.172	.090	042	.214	.123	167	.254	.157	019	.296	.194	509
.173	.090	797	.215	.123	988	.255	.157	891	.297	.195	423
.174	.091	555	.216	.124	811	.256	.158	763	.298	.196	337
.175	.092	314	.217	.125	634	.257	.159	636	.299	.197	252
.176	.093	074	.218	.126	459	.258	.160	511	.300	.198	168
.177	.093	837	.219	.127	286	.259	.161	386	.301	.199	085
.178	.094	601	.220	.128	114	.260	.162	263	.302	.200	003
.179	.095	367	.221	.128	943	.261	.163	141	.303	.200	922
.180	.096	135	.222	.129	773	.262	.164	020	.304	.201	841
.181	.096	904	.223	.130	605	.263	.164	900	.305	.202	762
.182	.097	675	.224	.131	438	.264	.165	781	.306	.203	683
.183	.098	447	.225	.132	273	.265	.166	663	.307	.204	605
.184	.099	221	.226	.133	109	.266	.167	546	.308	.205	528
.185	.099	997	.227	.133	946	.267	.168	431	.309	.206	452
.186	.100	774	.228	.134	784	.268	.169	316	.310	.207	376
.187	.101	553	.229	.135	624	.269	.170	202	.311	.208	302
.188	.102	334	.230	.136	465	.270	.171	090	.312	.209	228
.189	.103	116	.231	.137	307	.271	.171	978	.313	.210	155
.190	.103	900	.232	.138	151	.272	.172	868	.314	.211	083
.191	.104	686	.233	.138	996	.273	.173	758	.315	.212	011
.192	.105	472	.234	.139	842	.274	.174	650	.316	.212	941
.193	.106	261	.235	.140	689	.275	.175	542	.317	.213	871
.194	.107	051	.236	.141	538	.276	.176	436	.318	.214	802
.195	.107	843	.237	.142	388	.277	.177	330	.319	.215	734
.196	.108	636	.238	.143	239	.278	.178	226	.320	.216	666
.197	.109	431	.239	.144	091	.279	.179	122	.321	.217	600
.198	.110	227	.240	.144	945	.280	.180	020	.322	.218	534

Height	Area	Height	Area	Height	Area	Height	Area
.323	219 469	.368	262 249	.413	306 140	.458	350 749
.324	220 404	.369	263 214	.414	307 125	.459	351 745
.325	221 341	.370	264 179	.415	308 110	.460	352 742
.326	222 278	.371	265 145	.416	309 096	.461	353 739
.327	223 216	.372	266 111	.417	310 082	.462	354 736
.328	224 154	.373	267 078	.418	311 068	.463	355 733
.329	225 094	.374	268 046	.419	312 055	.464	356 730
.330	226 034	.375	269 014	.420	313 042	.465	357 728
.331	226 974	.376	269 982	.421	314 029	.466	358 725
.332	227 916	.377	270 951	.422	315 017	.467	359 723
.333	228 858	.378	271 921	.423	316 005	.468	360 721
.334	229 801	.379	272 891	.424	316 993	.469	361 719
.335	230 745	.380	273 861	.425	317 981	.470	362 717
.336	231 689	.381	274 832	.426	318 970	.471	363 715
.337	232 634	.382	275 804	.427	319 959	.472	364 714
.338	233 580	.383	276 776	.428	320 949	.473	365 712
.339	234 526	.384	277 748	.429	321 938	.474	366 711
.340	235 473	.385	278 721	.430	322 928	.475	367 710
.341	236 421	.386	279 695	.431	323 919	.476	368 708
.342	237 369	.387	280 669	.432	324 909	.477	369 707
.343	238 319	.388	281 643	.433	325 900	.478	370 706
.344	239 268	.389	282 618	.434	326 891	.479	371 705
.345	240 219	.390	283 593	.435	327 883	.480	372 704
.346	241 170	.391	284 569	.436	328 874	.481	373 704
.347	242 122	.392	285 545	.437	329 866	.482	374 703
.348	243 074	.393	286 521	.438	330 858	.483	375 702
.349	244 027	.394	287 499	.439	331 851	.484	376 702
.350	244 980	.395	288 476	.440	332 843	.485	377 701
.351	245 935	.396	289 454	.441	333 836	.486	378 701
.352	246 890	.397	290 432	.442	334 829	.487	379 701
.353	247 845	.398	291 411	.443	335 823	.488	380 700
.354	248 801	.399	292 390	.444	336 816	.489	381 700
.355	249 758	.400	293 370	.445	337 810	.490	382 700
.356	250 715	.401	294 350	.446	338 804	.491	383 700
.357	251 673	.402	295 330	.447	339 799	.492	384 699
.358	252 632	.403	296 311	.448	340 793	.493	385 699
.359	253 591	.404	297 292	.449	341 788	.494	386 699
.360	254 551	.405	298 274	.450	342 783	.495	387 699
.361	255 511	.406	299 256	.451	343 778	.496	388 699
.362	256 472	.407	300 238	.452	344 773	.497	389 699
.363	257 433	.408	301 221	.453	345 768	.498	390 699
.364	258 395	.409	302 204	.454	346 764	.499	391 699
.365	259 358	.410	303 187	.455	347 760	.500	392 699
.366	260 321	.411	304 171	.456	348 756
.367	261 285	.412	305 156	.457	349 752

Rule to find pressure allowed on a brace for given size: Multiply area of brace by pressure allowed per square inch cross sectional area.

LEGEND:
 A = area of brace 3'' x 1/2'' = 1.5'' area
 S = strain allowed = 6000 lbs.
 that size brace

FORMULA:
 $A \times S = \text{pressure allowed}$

EXAMPLE:

$$\begin{array}{r} 3'' \\ .5 \\ \hline 1.5 = \text{area} \\ 6000 \text{ lbs. allowed per square inch} \\ \hline 90000 \text{ lbs. allowed on brace of that size} \end{array}$$

THROUGH BRACE RODS.

Through brace rods are often used when conditions are favorable, space ample for cleaning and inspection.

These rods are usually 1/4 to 2 1/2 inches diameter and washer or plates riveted to heads to increase holding or breaking surface; thickness of heads are governed by pressure, also by the size and number of rods. Same rule is used that governs the palm or formed brace.

Rule to find working pressure allowed on a through brace rod. Multiply area of rod by strain allowed according to corresponding diameter and divide by area supported by rod.

LEGEND:
 AR = 2'' rod = 3.1416 = area of rod
 A = 16x14 surface = 224'' area
 S = strain allowed on that size
 brace = 8000

FORMULA:
 $\frac{AR \times S}{A} = \text{working pressure}$

EXAMPLE:

$$\begin{array}{r} 3.1416 = \text{area of 2'' rod} \\ 8000 \text{ lbs. allowed on sectional area} \\ \hline \text{surface area} = 224 \quad 25132.8000 \text{ (112 lbs. working pressure)} \\ 224 \\ \hline 273 \\ 224 \\ \hline 492 \\ 448 \\ \hline 44 \end{array}$$

CURVED SURFACES.

To find safe working pressure on curved surface when stiffened by angle, single or double, or tee bars; for single, the angle iron should have a thickness of at least eight-tenths that of plate and a depth of at least one-half pitch;—where stiffened with double angle or tee irons, to have at least two-thirds that of thickness of plate and a depth of at least one-fourth of pitch; angles or tee bars being substantially riveted to the plate supported.

Where rounded tops of combustion chambers are stiffened with single or double angle-iron stiffeners, or tee bars, such angles or tee bars, shall be of thickness and depth of leaf not less than specified for rounded bottoms of combustion chambers. Said angles or tee bars shall be supported on thimbles and riveted through with rivets not less than one inch in diameter and spaced not to exceed six inches between centers.

Rule to find working pressure allowed on rounded surfaces supported by angle irons or tee bars: Multiply constant by thickness squared in sixteenths and divide by the pitch multiplied by the diameter of curve.

FORMULA:

$$\frac{C \times T^2}{P \times D} = \text{working pressure}$$

LEGEND:

T = thickness of plate in sixteenths of an inch = $\frac{1}{16} = 81$
 P = pitch of angle or tee stiffeners in inches = 7 inches
 D = diameter of curve to which plate is bent, in inches = 51 inches
 C = constant = 900

EXAMPLE:

900 = constant		51" = diameter
81 = thickness squared in 16ths		7" = pitch
900		357
7200		
72900	357)72900(204 lbs. = working pressure	
	714	
	1500	
	1428	
	72	

TUBE PLATE

Rule to find the working pressure of a tube sheet supporting a crown sheet braced by crown bars: Subtract inside diameter of tubes in inches from the least horizontal distance between tube centers in inches; multiply the remainder by thickness of tube plate and then by constant 27,000; divide product by extreme width of combustion chamber multiplied by least horizontal distance between tube centers.

FORMULA:

$$\frac{(D-d)T \times C}{W \times D} = \text{working pressure}$$

LEGEND:

- D = least horizontal distance between tube centers in inches = $4\frac{1}{8}$ inches
- d = inside diameter of tubes in inches = 2.782 inches
- T = thickness of tube plate in inches = $\frac{1}{16}$ inches = .6875
- W = extreme width of combustion chamber in inches = $34\frac{1}{4}$ inches
- C = 27,000.

EXAMPLE:

<p>4.125 = least horizontal distance 2.782 = inside diameter</p> <hr style="width: 10%; margin-left: 0;"/> <p>1.343 .6875 = thickness of tube plate</p> <hr style="width: 10%; margin-left: 0;"/> <p>6715 9401</p> <p>10744 8058</p> <hr style="width: 10%; margin-left: 0;"/> <p>.9233125 27000 = constant</p> <hr style="width: 10%; margin-left: 0;"/> <p>646 31875000 1846 6250</p> <hr style="width: 10%; margin-left: 0;"/> <p>24929. 4375000</p>	<p>34.25 = extreme width 4.125 = least horizontal distance</p> <hr style="width: 10%; margin-left: 0;"/> <p>17125 6850 3425</p> <hr style="width: 10%; margin-left: 0;"/> <p>13700</p> <hr style="width: 10%; margin-left: 0;"/> <p>141. 28125</p>
<p>141)24929 (176 lbs. = working pressure</p> <hr style="width: 10%; margin-left: 0;"/> <p>141</p> <hr style="width: 10%; margin-left: 0;"/> <p>1082</p> <hr style="width: 10%; margin-left: 0;"/> <p>987</p> <hr style="width: 10%; margin-left: 0;"/> <p>959</p> <hr style="width: 10%; margin-left: 0;"/> <p>846</p> <hr style="width: 10%; margin-left: 0;"/> <p>113</p>	

Rule to find thickness of plate for a tube sheet: Multiply pressure by width of fire box and by pitch of tubes (distance between centers) and divide this sum by pitch of tubes minus one inside diameter of one tube multiplied by constant.

FORMULA:

$$\frac{P \times W \times p}{(p-d) \times C} = \text{thickness of plate}$$

LEGEND:

p = pitch of tube = $4\frac{1}{8}$
 d = inside diam. of tube = 2.782
 P = pressure = 176 lbs.
 C = constant = 27000
 W = width of combustion chamber = $34\frac{1}{4}$ inches

EXAMPLE:

	176 = pressure lbs. per square inch
	34.25 = width of fire box
	<hr style="width: 50px; margin-left: auto; margin-right: 0;"/>
	880
	352
	704
	<hr style="width: 50px; margin-left: auto; margin-right: 0;"/>
	528
	<hr style="width: 50px; margin-left: auto; margin-right: 0;"/>
pitch of tubes = 4.125	6028.00
inside diam. = 2.782	4.125 = pitch of tubes
	<hr style="width: 50px; margin-left: auto; margin-right: 0;"/>
constant = 1.343	3014000
27000	1205600
	<hr style="width: 50px; margin-left: auto; margin-right: 0;"/>
9401000	602800
2686	2411200
	<hr style="width: 50px; margin-left: auto; margin-right: 0;"/>
36261000	24865.5000 (.6857 or $\frac{11}{16}$ nearly
	<hr style="width: 50px; margin-left: auto; margin-right: 0;"/>
	217566
	<hr style="width: 50px; margin-left: auto; margin-right: 0;"/>
	310890
	290088
	<hr style="width: 50px; margin-left: auto; margin-right: 0;"/>
	208020
	181305
	<hr style="width: 50px; margin-left: auto; margin-right: 0;"/>
	267150
	253827
	<hr style="width: 50px; margin-left: auto; margin-right: 0;"/>
	13323

U. S. RULES.

The compressive stress on tube plates, as determined by the following formula, must not exceed 13,500 pounds per square inch, when pressure on tops of combustion chamber is supported by vertical plates of such chamber.


$$\frac{P \times D \times W}{2 \times (D-d) \times T} = \text{compressive stress}$$

- P = working pressure in pounds = 176 lbs.
- D = least horizontal distance between tube centers in inches = 4.1250''
- d = inside diameter of tube in inches = 2.782.
- W = extreme width of combustion chamber in inches = 34 1/4
- T = thickness of tube sheet in inches = 11/16 = .6875.

EXAMPLE:

<p>176 = pressure</p> <p>4.1250 = distance tubes horizontally</p> <hr style="width: 100px; margin-left: 0;"/> <p style="margin-left: 20px;">8800</p> <p style="margin-left: 20px;">352</p> <p style="margin-left: 20px;">176</p> <p style="margin-left: 20px;">704</p> <hr style="width: 100px; margin-left: 0;"/> <p>726.0000</p> <p>34.25 = width of combustion chamber</p> <hr style="width: 100px; margin-left: 0;"/> <p style="margin-left: 20px;">36300000</p> <p style="margin-left: 20px;">14520000</p> <p style="margin-left: 20px;">29040000</p> <p style="margin-left: 20px;">21780000</p> <hr style="width: 100px; margin-left: 0;"/> <p>1.84662500) 24865.50000000 (13465 = compressive strain</p> <p style="margin-left: 20px;">18466 2500</p> <hr style="width: 100px; margin-left: 0;"/> <p style="margin-left: 20px;">6399 25000</p> <p style="margin-left: 20px;">5539 87500</p> <hr style="width: 100px; margin-left: 0;"/> <p style="margin-left: 20px;">859 375000</p> <p style="margin-left: 20px;">738 650000</p> <hr style="width: 100px; margin-left: 0;"/> <p style="margin-left: 20px;">120 7250000</p> <p style="margin-left: 20px;">110 7975000</p> <hr style="width: 100px; margin-left: 0;"/> <p style="margin-left: 20px;">9 92750000</p> <p style="margin-left: 20px;">9 23312500</p> <hr style="width: 100px; margin-left: 0;"/> <p style="margin-left: 20px;">69437500</p>	<p>4.1250 = dis. bet. tubes</p> <p>2.782 = inside diam. tube</p> <hr style="width: 100px; margin-left: 0;"/> <p>1.3430</p> <p>2 = twice</p> <hr style="width: 100px; margin-left: 0;"/> <p>2.6860</p> <p>.6875 = 11/16 = thickness of tube sheet</p> <hr style="width: 100px; margin-left: 0;"/> <p>134300</p> <p>188020</p> <p>214880</p> <p>161160</p> <hr style="width: 100px; margin-left: 0;"/> <p>1.84662500</p>
---	--

Sling stays may be used in lieu of girders in all cases, provided, however, that when such sling stays are used, girders or screw stays of the same sectional area must be used for securing the bottom of combustion chamber to the boiler shell.



Rule to find thickness of steel girder: From length of girder subtract pitch of bolts and multiply by centers of girders and by length of same and this sum by pressure; divide this product by depth of girder squared multiplied by constant and then multiplied by the square root of number of supporting bolts.

FORMULA:

$$\frac{(L-P) \times G \times L \times P}{d^2 \times C \times \sqrt{N}} = \text{thickness of girder required.}$$

LEGEND:

L = length of girder = 32''
 P = pitch of bolts = 9''
 G = girder centers = 8½''
 d = depth of girder = 5.18''
 C = constant = 6000
 N = number of bolts = 9

EXAMPLE:

	32.000'' = length of girder
	9.000'' = pitch of bolts
	<hr style="width: 100%;"/>
	23.000''
	8.5'' = girder centers
	<hr style="width: 100%;"/>
	115000
	184000
	<hr style="width: 100%;"/>
depth of girders = 5.18	195.5000
5.18	32'' = length of girder
<hr style="width: 100%;"/>	<hr style="width: 100%;"/>
4144	3910000
518	5865000
<hr style="width: 100%;"/>	<hr style="width: 100%;"/>
2590	6256.0000
<hr style="width: 100%;"/>	<hr style="width: 100%;"/>
26.8324	160 = pressure
constant = 6000	<hr style="width: 100%;"/>
<hr style="width: 100%;"/>	<hr style="width: 100%;"/>
160994.4000	3753600000
sq. rt. of bolts = 3	62560000
<hr style="width: 100%;"/>	<hr style="width: 100%;"/>
48298320000	1000960000 (2.0 = thickness of girder)
<hr style="width: 100%;"/>	965966
<hr style="width: 100%;"/>	<hr style="width: 100%;"/>
<hr style="width: 100%;"/>	349940

In connection with rules covering girder calculations there are constants used and varying according to plate thickness and design of bolt, such as screwed stayed bolts with and without lock nuts, sockets, with riveted heads, number of bolts and water used, as follows:

Use constant 5400 for roof stays, wrought iron.

Use constant 6000 for roof stays, steel.

A constant used by Joshua Rose for computing girder or crown bar supporting bolts 9000 (this for steel).

Rule to find area of supporting bolts (steel) for a girder stay or crown bar. Multiply pressure by area to be supported and divide this product by constant 9000, this will give the pounds strain allowed per square inch of sectional area for a mild steel bolt.

FORMULA:

$$\frac{A \times P}{C} = \text{area supporting bolt required}$$

LEGEND:

A = area to be supported = 8' × 8' = 64 square inches

P = pressure = 170 lbs.

C = constant = 9000

EXAMPLE:

64 = square inches to be supported

170 = pressure

4480
64

constant = 9000) 10880.0000 (1.2088 = area = 1½ approximately

1880 0
1800 0
800 00
720 00
80 000
72 000
8 000

Rule to find safe working pressure on a girder supporting a crown sheet of a back smoke box connection, when not subjected to heat in excess of ordinary steam pressures and assuming the combustion chamber ends are fitted to the edge of tube plate and the back of plate of the combustion box, four supporting bolts being used. Multiply constant by depth of girder squared in inches and multiply this sum by thickness of girder in inches; divide product by width of combustion chamber in inches minus pitch of supporting bolts multiplied by distance between girders from center to center in inches and again by length of girder in feet.

$$\frac{\text{FORMULA:} \\ C \times d^2 \times T}{(W - P) \times D \times L} = \text{pressure}$$

LEGEND:

W = width of combustion box in inches = 36''
 P = pitch of supporting bolts in inches = $7\frac{1}{2} = 7.5$
 D = distance between girder centers in inches = $7\frac{3}{4} = 7.75$
 L = length of girder in feet = 3 feet = 3
 d = depth of girder in inches = $7\frac{1}{2} = 7.5$
 T = thickness of girder in inches = 2'' = 2
 C = constant = 550—when girder is fitted with one supporting bolt
 825— " " " " " two or three supporting bolts
 935— " " " " " four supporting bolts

EXAMPLE:

width = 36''	
pitch = 7.5	
28.5	56.25 = depth squared
distance = 7.75	935 = constant
1 425	281 25
19 95	1687 5
199 5	50625
220.875	52593.75
length = 3	2 = thickness
662.825	105187.50
662)105187. (158 or 159 lbs. nearly	
662	
3898	
3310	
5887	
5296	
591	

Rule to find depth of steel girder for top of a combustion chamber: Multiply pressure by centers of girder and by length of girder bolts and multiply this sum by length of girder bolts minus pitch of same; divide this product by constant multiplied by thickness of girder and again by square root of number of bolts. The square root of quotient is depth of girder.

FORMULA:

$$\sqrt{\frac{P \times G \times L \times (L-p)}{C \times T \times \sqrt{N}}} = \text{depth of girder}$$

LEGEND:

- P = pressure = 160 lbs.
- G = girder centers = 8½.
- L = length of girder = 32''
- C = constant 6000 for steel
- C = constant 54000 for iron
- T = thickness of girder = 2''
- p = pitch of bolts = 9''
- N = number of bolts = 9
- d = depth of girder = 9''

EXAMPLE:

160 = pressure
8.5 = girder centers

800
1280
1360.0
32 = length of girder

27200
40800

constant = 6000 43520.0
thickness of girder = 2'' 23 = length of girder minus pitch of bolts

square root of 12000 1305600
no. of bolts = 3 870400

36000)1000960.0000 (27.8044
72000

280960 5)27.8044 (5.272 = 5 2/7 nearly =
252000)25 depth of girder

289600 102) 280
288000) 204

160000 1047) 7644
144000) 7329

160000 10542) 31500
144000) 21084

16000) 10416

ENGLISH BOARD OF TRADE RULES GOVERNING GIRDERS.

LEGEND:

- P = pressure.
 W = width of combustion chamber
 p = pitch of bolts
 D = distance between girder centers
 L = length of girder
 d = depth of girder
 T = thickness of girder
 C = constant for number of bolts
 Constants vary according to the iron or steel used, the lower constant for iron.
 Constant = 6000 = when only one supporting bolt
 " 9000 to 9900 = when two or three supporting bolts
 " 10200 to 11220 = when four to five supporting bolts
 For five bolts use same constant as for four
 For six or seven bolts use constant 10500 for iron
 " " " " " " 11550 " steel

FORMULAS:

$$\frac{C \times d^2 \times T}{(W - \text{pitch}) \times D \times L} = \text{working pressure}$$

$$\frac{P \times (W - \text{pitch}) \times D \times L}{C \times d^2} = \text{thickness of girder}$$

$$\frac{P \times (W - \text{pitch}) \times D \times L}{C \times T} = \text{depth of girder}$$

REINFORCEMENT FOR HOLES CUT IN BOILER SHELL.

All holes exceeding 6 inches in diameter cut in either the flat heads or circumferential shell of steel boilers shall be reinforced with wrought or cast steel rings to compensate for the material removed. In lieu of such a reinforce ring, holes in flat heads may, if preferred, be reinforced by flanging the metal about the hole inward to a depth of not less than three-quarters of an inch measured from the inner surface. Reinforce rings on flat heads must be efficiently riveted to the head, and must have a sectional area not less than .8 the section of metal removed, the latter being measured across the shorter axis of the opening.

Reinforce rings on the circumferential shell must be efficiently riveted to the shell, and must have a sectional area not less than .7 the section of metal removed, the latter being measured across the hole in a direction parallel to the length of the boiler.

Reinforce rings should be of thickness not less than that of plate to which attached.

Rule to find width of ring to reinforce an opening in a boiler shell such as a man-hole, when one ring is used: Multiply diameter of opening longitudinally by the thickness of plate and divide the product by twice the thickness of reinforcement ring; add the diameter of rivet hole to quotient. This will be for single riveting and when double riveted add twice the diameter of rivet hole.

FORMULA:

$$\frac{O \times T}{2 \times N} + 1R = \text{width of ring for single riveted}$$

LEGEND:

R = rivet diameter hole = .9375
 O = diameter of opening = 11"
 T = thickness of shell = $\frac{1}{2}$ " = .5000
 N = thickness of ring = $\frac{5}{8}$ " = .6250

EXAMPLE:

thickness of ring = .6250	11" = diameter of opening	
2	.5000 = thickness of shell plate	
<hr/>		
twice thickness of ring = 1.2500) 5.50000 (4.4	
	5 0000	.9375 = diam. of rivet hole
	<hr/>	
	50000	5.3375 = $5\frac{11}{32}$ " nearly
	50000	
	<hr/>	

When two rings are used the thickness of each must be at least that of shell and have same tensile strength as that of shell plate; a *single* ring not less than $1\frac{1}{4}$ the thickness of shell.

Rule to find number of rivets to be used in a reinforcement ring for reinforcing an opening such as a man-hole in boiler shell: Multiply the net section of the ring by four times the tensile strength of the material and divide this product by the product of the shearing strength of rivet multiplied by its area.

FORMULA:

$$\frac{NS \times (4 \times TS)}{SS \times A} = \text{number of rivets required}$$

LEGEND:

NS = net section = 1.5625
 SS = shearing strength = 38000
 TS = tensile strength = 60000
 A = area of rivet = .6013

EXAMPLE:

$ \begin{array}{r} 38000 = \text{shearing strength} \\ .6013 = \text{area of rivet} \\ \hline 114000 \\ 38000 \\ \hline 228000 \\ \hline 22849. \cancel{4000} \end{array} $	$ \begin{array}{r} 60000 = \text{tensile strength} \\ 4 \text{ times} \\ \hline 240000 \\ 1.5625 = \text{net section} \\ 240000 = 4 \text{ times tensile strength} \\ \hline 625000000 \\ 31250 \\ \hline 22849) \cancel{375000.0000} \text{ (16 rivets } \frac{7}{8}'' \text{ diameter required)} \\ \hline 146510 \\ 137094 \\ \hline 9416 \end{array} $
---	---

For a double riveted ring multiply net section of one ring by eight times the tensile strength of material and divide product by the sum obtained by multiplying 1.85 times the shearing strength of rivet's sectional area and the area of rivet.

CHAPTER V.

AMENDMENTS OF STEAMBOAT INSPECTION RULES AND REGULATIONS.

Lap welded boiler flues over 4 inches up to and including 30 inches in diameter shall be made of wrought iron or mild steel made by any process.

A test piece, 2 inches in length, cut from a tube, must stand being flattened by hammering until the sides are brought parallel with the curve on the inside at the ends not greater than three times the thickness of the metal without showing cracks or flaws, with bend at one side in the weld.

Each tube shall be subjected to an internal hydrostatic pressure of 500 pounds per square inch without showing signs of weakness or defects.

All steel tubes shall have ends properly annealed by the manufacturer before shipment. Tubes must stand drilling, riveting, and calking, and work necessary to install them into the tube head without showing any signs of weakness or defects.

No tube increased in thickness by welding one tube inside of another shall be allowed for use.

SEAMLESS STEEL BOILER TUBES.

MATERIAL.

The steel shall be made by the open-hearth process.

SURFACE INSPECTION.

The pipe must be free, inside and outside, from all surface defects that would materially weaken it or form starting points of corrosion. The defects to be especially avoided are snakes, checks, slivers, laps, pits, etc. Pipe must be smooth and straight.

The following tests shall be made before shipment by the manufacturer:

(a) A test piece, 2 inches in length, cut from a tube, must stand being flattened by hammering until the sides are brought parallel with the curve on the inside at the ends not greater than three times the thickness of the metal without showing cracks or flaws.

(b) Pulling tests must be made from every 50 pieces furnished, or fraction thereof, and must show the following results:

Tensile strength, not less than 48,000 pounds per square inch.

Elongation in 8-inch specimen, not less than 12 per cent.

The results of the pulling tests must be forwarded by the manufacturer to the purchaser of steam pipe, who will forward same to local inspector.

Any pipe used for mud or steam drums must have the ends of same properly annealed before the holes are drilled or the heads are riveted in: *Provided*, That this paragraph shall apply only to drums not exceeding 15 inches in diameter for use on pipe and coil boilers.

When pipe is used for steam lines where flanges are riveted on and calked, the ends of the pipe shall be properly annealed before drilling or riveting the flanges on.

When pipes are expanded into flanges by proper and approved machinery, and flared out at the ends to an angle not exceeding 20° (said angle to be taken in the direction of the length of the pipe) and having a depth of flare equal to *at least* one and one-half times the thickness of the material in said pipe, such pipes may be used for all steam and exhaust pipes when tested to two and one-half times the working pressure and found perfect in every respect.

If the pipe is used for steam lines where the pipe is peened in and flanged over, the ends of the pipe should be properly annealed before the peening or flanging is done.

The use of a square-nosed tool is recommended for cutting tubes and pipe.

Provided, That this entire section shall apply only to tubes and pipes used or to be used in boilers built after June 30, 1905, and to all other pipes referred to in this section subject to pressure installed for use on steam vessels after that date.

TABLES AND EXAMPLES.

Flues and furnaces safe working pressures.

The following table shows diameters, thickness of plate and safe working pressure on flues in sections of 3 feet, maximum length allowed 5 feet, also sections of 30" in length, maximum 40".

TABLE OF STEAM PRESSURE PER SQUARE INCH ALLOWABLE ON RIVETED AND LAP-WELDED FLUES MADE IN SECTIONS AND USED IN BOILERS WHOSE CONSTRUCTION IS COMMENCED AFTER JUNE 30, 1905.

Greatest length of sections allowable, 5 feet.		Greatest length of sections allowable, 3 feet.														
Thickness of material.		Least thickness of material allowable.														
		Diameter of flues.														
18 in.	20 in.	21 in.	21 in.	22 in.	22 in.	23 in.	24 in.	25 in.	26 in.	27 in.	28 in.	29 in.	30 in.	31 in.	32 in.	33 in.
Over 7, not over 8 inches	Over 8, not over 9 inches	Over 9, not over 10 inches	Over 10, not over 11 inches	Over 11, not over 12 inches	Over 12, not over 13 inches	Over 13, not over 14 inches	Over 14, not over 15 inches	Over 15, not over 16 inches	Over 16, not over 17 inches	Over 17, not over 18 inches	Over 18, not over 19 inches	Over 19, not over 20 inches	Over 20, not over 21 inches	Over 21, not over 22 inches	Over 22, not over 23 inches	Over 23, not over 24 inches
Lbs. pres-sure.	Lbs. pres-sure.	Lbs. pres-sure.	Lbs. pres-sure.	Lbs. pres-sure.	Lbs. pres-sure.	Lbs. pres-sure.	Lbs. pres-sure.	Lbs. pres-sure.	Lbs. pres-sure.	Lbs. pres-sure.	Lbs. pres-sure.	Lbs. pres-sure.	Lbs. pres-sure.	Lbs. pres-sure.	Lbs. pres-sure.	Lbs. pres-sure.
205	200	186	168	146	141	137	133	130	127	124	122	120	118	116	114	114
228	210	195	176	160	147	142	138	135	131	128	126	124	121	120	120	120
240	220	204	184	167	153	148	144	140	137	133	130	128	125	125	125	125
255	240	222	200	181	166	160	154	150	146	142	138	136	132	129	128	128
268	251	231	208	189	173	168	162	158	154	149	146	143	138	136	135	135
288	268	246	221	203	186	180	172	166	160	154	149	147	144	141	140	140
300	284	264	238	218	200	192	184	178	171	165	159	155	151	148	148	148
320	300	276	252	230	211	203	194	188	181	175	169	164	160	157	156	156
335	315	288	264	240	220	211	202	195	188	181	174	168	164	161	160	160
350	330	300	276	250	228	218	208	200	193	186	179	174	168	164	164	164
365	345	312	288	260	236	225	214	206	198	190	183	177	171	166	165	165
380	360	324	300	270	246	234	222	213	204	196	188	181	174	168	167	167
395	375	336	312	280	254	241	228	218	208	200	192	184	177	170	169	169
410	390	348	324	290	264	250	236	225	215	206	198	190	182	174	173	173
425	405	360	336	300	274	259	244	232	221	212	203	195	186	178	177	177
440	420	372	348	310	280	264	248	236	224	214	205	196	187	178	177	177
455	435	384	360	320	286	268	251	238	226	216	206	197	188	179	178	178
470	450	396	372	330	292	272	254	241	228	218	208	199	190	181	180	180
485	465	408	384	340	298	276	257	244	231	220	210	201	192	183	182	182
500	480	420	396	350	304	278	259	245	232	221	211	202	193	184	183	183
515	495	432	408	360	310	280	260	246	233	222	212	203	194	185	184	184
530	510	444	420	370	316	282	261	247	234	223	213	204	195	186	185	185
545	525	456	432	380	322	284	262	248	235	224	214	205	196	187	186	186
560	540	468	444	390	328	286	263	249	236	225	215	206	197	188	187	187
575	555	480	456	400	334	288	264	250	237	226	216	207	198	189	188	188
590	570	492	468	410	340	290	265	251	238	227	217	208	199	190	189	189
605	585	504	480	420	346	292	266	252	239	228	218	209	200	191	190	190
620	600	516	492	430	352	294	267	253	240	229	219	210	201	192	191	191
635	615	528	504	440	358	296	268	254	241	230	220	211	202	193	192	192
650	630	540	516	450	364	298	269	255	242	231	221	212	203	194	193	193
665	645	552	528	460	370	300	270	256	243	232	222	213	204	195	194	194
680	660	564	540	470	376	302	271	257	244	233	223	214	205	196	195	195
695	675	576	552	480	382	304	272	258	245	234	224	215	206	197	196	196
710	690	588	564	490	388	306	273	259	246	235	225	216	207	198	197	197
725	705	600	576	500	394	308	274	260	247	236	226	217	208	199	198	198
740	720	612	588	510	400	310	275	261	248	237	227	218	209	200	199	199
755	735	624	600	520	406	312	276	262	249	238	228	219	210	201	200	200
770	750	636	612	530	412	314	277	263	250	239	229	220	211	202	201	201
785	765	648	624	540	418	316	278	264	251	240	230	221	212	203	202	202
800	780	660	636	550	424	318	279	265	252	241	231	222	213	204	203	203
815	795	672	648	560	430	320	280	266	253	242	232	223	214	205	204	204
830	810	684	660	570	436	322	281	267	254	243	233	224	215	206	205	205
845	825	696	672	580	442	324	282	268	255	244	234	225	216	207	206	206
860	840	708	684	590	448	326	283	269	256	245	235	226	217	208	207	207
875	855	720	696	600	454	328	284	270	257	246	236	227	218	209	208	208
890	870	732	708	610	460	330	285	271	258	247	237	228	219	210	209	209
905	885	744	720	620	466	332	286	272	259	248	238	229	220	211	210	210
920	900	756	732	630	472	334	287	273	260	249	239	230	221	212	211	211
935	915	768	744	640	478	336	288	274	261	250	240	231	222	213	212	212
950	930	780	756	650	484	338	289	275	262	251	241	232	223	214	213	213
965	945	792	768	660	490	340	290	276	263	252	242	233	224	215	214	214
980	960	804	780	670	496	342	291	277	264	253	243	234	225	216	215	215
995	975	816	792	680	502	344	292	278	265	254	244	235	226	217	216	216
1010	990	828	804	690	508	346	293	279	266	255	245	236	227	218	217	217
1025	1005	840	816	700	514	348	294	280	267	256	246	237	228	219	218	218
1040	1020	852	828	710	520	350	295	281	268	257	247	238	229	220	219	219
1055	1035	864	840	720	526	352	296	282	269	258	248	239	230	221	220	220
1070	1050	876	852	730	532	354	297	283	270	259	249	240	231	222	221	221
1085	1065	888	864	740	538	356	298	284	271	260	250	241	232	223	222	222
1100	1080	900	876	750	544	358	299	285	272	261	251	242	233	224	223	223
1115	1095	912	888	760	550	360	300	286	273	262	252	243	234	225	224	224
1130	1110	924	900	770	556	362	301	287	274	263	253	244	235	226	225	225
1145	1125	936	912	780	562	364	302	288	275	264	254	245	236	227	226	226
1160	1140	948	924	790	568	366	303	289	276	265	255	246	237	228	227	227
1175	1155	960	936	800	574	368	304	290	277	266	256	247	238	229	228	228
1190	1170	972	948	810	580	370	305	291	278	267	257	248	239	230	229	229
1205	1185	984	960	820	586	372	306	292	279	268	258	249	240	231	230	230
1220	1200	996	972	830	592	374	307	293	280	269	259	250	241	232	231	231
1235	1215	1008	984	840	598	376	308	294	281	270	260	251	242	233	232	232
1250	1230	1020	996	850	604	378	309	295	282	271	261	252	243	234	233	233
1265	1245	1032	1008	860	610	380	310	296	283	272	262	253	244	235	234	234
1280																

Thickness of material.	Greatest length of sections allowable, 30 inches.																
	Least thickness of material allowable.																
	34 inch.	35 inch.	36 inch.	37 inch.	38 inch.	39 inch.	40 inch.	41 inch.	42 inch.	43 inch.	44 inch.	45 inch.	46 inch.	47 inch.	48 inch.	49 inch.	50 inch.
	Over 23, not 24, inches	Over 24, not 25, inches	Over 25, not 26, inches	Over 26, not 27, inches	Over 27, not 28, inches	Over 28, not 29, inches	Over 29, not 30, inches	Over 30, not 31, inches	Over 31, not 32, inches	Over 32, not 33, inches	Over 33, not 34, inches	Over 34, not 35, inches	Over 35, not 36, inches	Over 36, not 37, inches	Over 37, not 38, inches	Over 38, not 39, inches	Over 39, not 40, inches
	over 113	over 112	over 111	over 110	over 109	over 108	over 107	over 106	over 105	over 104	over 103	over 102	over 101	over 100	over 100	over 100	over 100
	Lbs. pres-sure.	Lbs. pres-sure.	Lbs. pres-sure.	Lbs. pres-sure.	Lbs. pres-sure.	Lbs. pres-sure.	Lbs. pres-sure.	Lbs. pres-sure.	Lbs. pres-sure.	Lbs. pres-sure.	Lbs. pres-sure.	Lbs. pres-sure.	Lbs. pres-sure.	Lbs. pres-sure.	Lbs. pres-sure.	Lbs. pres-sure.	Lbs. pres-sure.
34-inch.	113	112	111	110	109	108	107	106	105	104	103	102	101	100	100	100	100
35-inch.	116	115	114	113	112	111	110	109	108	107	106	105	104	103	102	101	100
36-inch.	120	118	116	114	112	110	108	106	104	102	100	98	96	94	92	90	88
37-inch.	126	124	121	118	114	110	107	104	101	98	95	92	89	86	83	80	77
38-inch.	133	128	123	118	113	108	103	98	93	88	83	78	73	68	63	58	53
39-inch.	136	131	126	121	117	113	109	105	101	97	93	89	85	81	77	73	69
40-inch.	136	131	126	121	117	113	109	105	101	97	93	89	85	81	77	73	69
41-inch.	140	134	129	124	119	114	110	106	102	98	94	90	86	82	78	74	70
42-inch.	143	137	132	127	122	118	114	110	106	102	98	94	90	86	82	78	74
43-inch.	144	138	133	128	123	118	113	108	103	98	93	88	83	78	73	68	63
44-inch.	144	138	133	128	123	118	113	108	103	98	93	88	83	78	73	68	63
45-inch.	144	138	133	128	123	118	113	108	103	98	93	88	83	78	73	68	63
46-inch.	144	138	133	128	123	118	113	108	103	98	93	88	83	78	73	68	63
47-inch.	144	138	133	128	123	118	113	108	103	98	93	88	83	78	73	68	63
48-inch.	144	138	133	128	123	118	113	108	103	98	93	88	83	78	73	68	63
49-inch.	144	138	133	128	123	118	113	108	103	98	93	88	83	78	73	68	63
50-inch.	144	138	133	128	123	118	113	108	103	98	93	88	83	78	73	68	63
51-inch.	144	138	133	128	123	118	113	108	103	98	93	88	83	78	73	68	63
52-inch.	144	138	133	128	123	118	113	108	103	98	93	88	83	78	73	68	63
53-inch.	144	138	133	128	123	118	113	108	103	98	93	88	83	78	73	68	63
54-inch.	144	138	133	128	123	118	113	108	103	98	93	88	83	78	73	68	63
55-inch.	144	138	133	128	123	118	113	108	103	98	93	88	83	78	73	68	63
56-inch.	144	138	133	128	123	118	113	108	103	98	93	88	83	78	73	68	63
57-inch.	144	138	133	128	123	118	113	108	103	98	93	88	83	78	73	68	63
58-inch.	144	138	133	128	123	118	113	108	103	98	93	88	83	78	73	68	63
59-inch.	144	138	133	128	123	118	113	108	103	98	93	88	83	78	73	68	63
60-inch.	144	138	133	128	123	118	113	108	103	98	93	88	83	78	73	68	63

Diameter of flues.

FLUES.

The preceding table includes all such riveted and lap-welded flues, exceeding 6 inches in diameter and not exceeding 40 inches in diameter, not otherwise provided for by law.

For any such flue requiring more pressure than is given in table, the same will be determined by proportion of thickness to any given pressure in table to thickness for pressure required, as per example:

A flue not over 19 inches in diameter and 3 feet long requires a thickness of .39 of an inch for 176 pounds pressure; what thickness would be required for 250 pounds pressure?

FORMULA:

$$\frac{\text{Pressure required} \times T}{P} = \text{thickness of plate required}$$

LEGEND:

P = pressure = 176 lbs.

T = thickness of plate = .39 or $\frac{3}{8}$ nearly

EXAMPLE:

250 = increased pressure required
.39 = thickness of plate

2250
750

first pressure = 176) 97.5000 (.5539 = $\frac{9}{16}$ nearly = thickness of plate required

88 0

9 50
8 80

700
528

1720
1580

136

Or, if .39 inch thickness gives a pressure of 176 pounds, what will .554 inch thickness give?

FORMULA:

$$\frac{\text{Thickness of plate required} \times P}{T} = \text{pressure}$$

THE BOILER.

EXAMPLE:

.554 = thickness of plate
176 = first pressure

3324
3878
554

original thickness of plate = .39)97.504 (250 = lbs. pressure
78

195
195
0

And all such flues shall be made in sections, according to their respective diameters, not to exceed the lengths prescribed in the table, and such sections shall be properly fitted one into the other and substantially riveted, and the thickness of material required for any such flue of a given diameter shall in no case be less than the least thickness prescribed in the table for any such given diameter; and all such flues may be allowed the prescribed working steam pressure if, in the opinion of the inspectors, it is deemed safe to make such allowance. Inspectors are therefore required, from actual measurement of each flue, to make such reduction from the prescribed working steam pressure for any material deviation in the uniformity of the thickness of material, or for any material deviation in the form of the flue from that of a true circle, as in their judgment the safety of navigation may require.

FURNACES.

The tensile strength of steel used in constructing furnaces shall not exceed 67,000, and be not less than 58,000 pounds. The minimum elongation in 8 inches shall be 20 per cent.

All corrugated furnaces having plain parts at the ends not exceeding 9 inches in length (except flues especially provided for), when new, and made to practically true circles, shall be allowed a steam pressure in accordance with the following formula:

$$\frac{C \times T}{D} = \text{pressure}$$

Rule to find collapsing pressure of a spirally corrugated furnace, corrugations 1½" deep: Multiply square of thickness of flue in thirty-seconds of an inch by the constant 1200 and divide by external diameter of flue in inches multiplied by square root of length in inches.

LEGEND:
 L = length = 81"
 D = diameter = 40"
 T = thickness = 5/8 = 20/32
 C = constant = 1200

FORMULA:

$$\frac{T^2 \times 1200}{D \times \sqrt{L}} = \text{collapsing pressure}$$

9) 81" (9 = sq. root
 81 of length

40" diameter
 9 square root of length

360

EXAMPLE:
 20 = thickness in 32nds of an inch
 20
 ———
 400 = thickness squared
 1200 = constant

80000
 400

360) 480000 (1333 lbs. collapsing pressure
 360

1200
 1080

1200
 1080

1200
 1080

120

MORISON CORRUGATED TYPE.

[In calculating the mean diameter of the Morison furnace, the least inside diameter plus 2 inches may be taken as the mean diameter, thus—

(Mean diameter = least inside diameter + 2 inches.)

Rule to find safe working pressure on a Morison corrugated furnace: Multiply constant 15,600 by thickness of plate and divide by diameter.

T = thickness in inches, not less than five-sixteenths of an inch.
 C = 15600, a constant, determined from an actual destructive test under the supervision of the Board of Supervising Inspectors, when corrugations are not more than 8 inches from center to center, and the radius of the outer corrugations is not more than one-half of the suspension curve.

THE BOILER.

FORMULA:

$$\frac{C \times T}{D} = \text{working pressure}$$

LEGEND:

D = diameter = 42''

T = thickness of plate = $\frac{1}{2} = .5$

C = constant = 15600

EXAMPLE:

15600 = constant

.5 = thickness of plate

$$\begin{array}{r} \text{diameter} = 42'' \quad 7800.0 \text{ (185 lbs. working pressure)} \\ \underline{42} \\ 360 \\ \underline{336} \\ 240 \\ \underline{210} \\ 30 \end{array}$$

COLLAPSING.

Rules for determining the collapsing pressures on furnace flues are given by eminent authorities, and these after many tests and experiments. These rules vary in method of computing and in the results; however, there is a reasonable margin for safety in the maximum results.

Hutton's rule for finding collapsing pressure:

Multiply the constant 806,300 by thickness of plate squared in inches and divide product by length of furnace in feet multiplied by diameter in inches.

FORMULA:

$$\frac{C \times T^2}{L \times D} = \text{collapsing pressure}$$

LEGEND:

C = constant = 806300

T = thickness of plate = $\frac{3}{8} = .3750$

D = diameter = 38''

L = length of furnace = 14 feet

EXAMPLE:

$$\begin{array}{r}
 806300 = \text{constant} \\
 .14062500 = \text{thickness squared} \\
 \hline
 \text{length} = 14 \quad 403150000 \\
 \text{diameter} = 38 \quad 1612600 \\
 \hline
 \quad 4837800 \\
 152 \quad 3225200 \\
 38 \quad 806300 \\
 \hline
 532) 113385.98750000 \text{ (213 lbs. = collapsing pressure)} \\
 \underline{1064} \\
 \quad 698 \\
 \quad \underline{532} \\
 \quad \quad 1665 \\
 \quad \quad \underline{1596} \\
 \quad \quad \quad 69
 \end{array}$$

Nystrom's rule for finding collapsing pressure:

FORMULA:

C = constant = 200000
Other data same

$$\frac{T^2 \times C}{D \times \sqrt{L}} = \text{collapsing pressure}$$

EXAMPLE:

$$\begin{array}{r}
 .14062500 = \text{thickness squared} \\
 200000 = \text{constant} \\
 \hline
 142.12) 28125.00000000 \text{ (197 lbs. = collapsing pressure)} \\
 \underline{14212} \\
 \quad 139130 \\
 \quad \underline{127908} \\
 \quad \quad 1152 \\
 \quad \quad \underline{112220} \\
 \quad \quad \quad 99484 \\
 \quad \quad \quad \underline{12736}
 \end{array}$$

Rule by Michael Longridge for finding collapsing pressure:
Multiply constant 174,000 by thickness of plate squared in inches;
divide product by diameter multiplied by the square root of length.

FORMULA:

$$\frac{T^2 \times C}{D \times \sqrt{L}} = \text{collapsing pressure}$$

C = constant = 174000
other data same

THE BOILER.

EXAMPLE:

$$\begin{aligned} \text{length} &= 38 & .14062500 &= \text{thickness squared} \\ \text{sq. rt. of diam.} &= 3.74 & 174000 &= \text{constant} \end{aligned}$$

$$\begin{array}{r} 1\ 52 \\ 26\ 6 \\ 114 \\ \hline \end{array} \quad \begin{array}{r} 5625000000 \\ 98437500 \\ 14062500 \\ \hline \end{array}$$

$$142.12) 24468.750000 \text{ (172 lbs. = collapsing pressure)}$$

14212

102567

99484

30835

28424

2411

LEEDS SUSPENSION BULB FURNACE.

Rule to find safe working pressure on a Leeds suspension bulb furnace: Multiply constant 17,300 by thickness of plate and divide by diameter.

T = thickness in inches, not less than five-sixteenths of an inch.
C = a constant, 17300, determined from an actual destructive test under the supervision of the Board, when corrugations are not more than 8 inches from center to center, and not less than $2\frac{1}{4}$ inches deep.

FORMULA:

$$\frac{C \times T}{D} = \text{working pressure}$$

LEGEND:

C = constant = 17300
T = thickness = $\frac{3}{8}$ = .375
D = diameter = 36"

EXAMPLE:

17300 = constant
.375 = thickness of plate

86500

121100

51900

$$\text{diameter } 36'') 6487.500 \text{ (180 lbs. working pressure)}$$

36

288

288

07

FOX TYPE.

Rule to find safe working pressure on the above type of furnace:
Multiply constant 14,000 by thickness of plate and divide by diameter.

T = thickness in inches, not less than five-sixteenths.
C = 14000, a constant, when corrugations are not more than 8 inches from center to center and not less than 1½ inches deep.

FORMULA:

$$\frac{C \times T}{D} = \text{safe working pressure}$$

LEGEND:

D = diameter = 40"
T = thickness of plate = ½" = .5
C = constant = 14000

EXAMPLE:

$$\begin{array}{r} 14000 = \text{constant} \\ .5 = \text{thickness of plate} \\ \hline \text{Diameter} = 40'' \quad 7000.0 \text{ (175 lbs. working pressure)} \\ \hline 40 \\ \hline 300 \\ \hline 280 \\ \hline 200 \\ \hline 200 \\ \hline \end{array}$$

PURVES TYPE.

FORMULA:

$$\frac{C \times T}{D} = \text{pressure}$$

T = thickness in inches not less than seven-sixteenths.
D = least outside diameter in inches.
C = 14000, a constant, when rib projections are not more than 9 inches from center to center and not less than 1¾ inches deep.

BROWN TYPE.

$$\frac{C \times T}{D} = \text{pressure}$$

T = thickness in inches, not less than five-sixteenths.
D = least outside diameter in inches.
C = 14000, a constant (ascertained by an actual destructive test under the supervision of the Board of Supervising Inspectors), when corrugations are not more than 9 inches from center to center and not less than 1½ inches deep.

The thickness of corrugated and ribbed furnaces shall be ascertained by actual measurement. The manufacturer shall have said furnace drilled for a one-fourth inch pipe tap and fitted with a screw plug that can be removed by the inspector when taking this measurement. For the Brown and Purves furnaces the holes shall be in the center of the second flat; for the Morison, Fox, and other similar types in the center of the top corrugation, at least as far in as the fourth corrugation from the end of the furnace.

TYPE HAVING SECTIONS 18 INCHES LONG.

$$\frac{C \times T}{D} = \text{pressure}$$

T = thickness in inches, not less than seven-sixteenths.

D = mean diameter in inches.

C = 100000, a constant, when corrugated by sections not more than 18 inches from center to center and not less than $2\frac{1}{2}$ inches deep, measuring from the least inside to the greatest outside diameter of the corrugations, and having the ends fitted one into the other and substantially riveted together, provided that the plain parts at the ends do not exceed 12 inches in length.

CONES.

Rule to find collapsing pressure on a truncated cone up to 42 inches in length: Multiply twice thickness of plate by the tensile strength and by the hypotenuse length of cone; divide this sum by the square inches in a trapezoid of equal dimensions of truncated cone.

FORMULA:

$$\frac{2 \times T \times TS \times \text{Hypotenuse}}{\text{Area of trapezoid}} = \text{bursting pressure}$$

LEGEND:

T = thickness of plate = $\frac{3}{8}$ = .375

TS = tensile strength = 60000

Hypotenuse = 40"

Area of trapezoid = 1200

EXAMPLE:

.7500 = twice thickness of $\frac{3}{8}$ " plate
 60000 = tensile strength

45000 .0000
 40" = length of hypotenuse of cone

area of a trapezoid = 1200) 1800000 .0000 (1500 lbs. bursting pressure
 1200

6000
 6000

CONE TOPS.

Flues used in vertical boilers as upper combustion chambers formed in the shape of a cone, when new and made to practically true circles, shall be allowed a steam pressure according to the following formula:

$$\frac{C \times T}{D} = \text{pressure}$$

- T = thickness of flue in inches, not less than five-sixteenths.
- D = outside diameter in inches, at the center of the length of the flue, not to exceed 42 inches.
- C = 10153, a constant, when the length of the flue does not exceed 42 inches, measuring from center of rivet holes in top of head to the center of rivet holes in the tube head.

When the flue exceeds 42 inches in diameter at the center, it shall be deemed flat surface and must be stayed accordingly.

Rule to find safe working pressure on a truncated cone as in a submerged tube upright boiler, length limited to 40": Multiply constant 8000 by thickness of plate, minimum limit $\frac{5}{16}$, and divide by diameter (small and large diameter added together and divided by 2).

LEGEND:

- C = constant = 8000
- T = thickness of plate = $\frac{7}{16}$ = .4375
- D = diameter, small = 30"
 " large = 40"

FORMULA:

$$\frac{C \times T}{D} = \text{working pressure}$$

EXAMPLE:

8000 = constant
 .4375 = $\frac{7}{16}$ plate

35) 3500.0000 (100 lbs. pressure
 35
 00

large diam. 40"
 small diam. 30"
 2) 70
 35'

ADAMSON TYPE.

When plain horizontal flues are made in sections not less than 18 inches in length, and not less than five-sixteenths of an inch thick, and flanged to a depth of not less than three times the diameter of rivet hole plus the radius at furnace wall (inside diameter of furnace), the thickness of the flanges shall be as near the thickness of the body of the plate as practicable.

The radii of the flanges on the fire side shall be not less than three times the thickness of plate.

The distance from the edge of the rivet hole to the edge of the flange shall be not less than the diameter of the rivet hole, and the diameter of the rivets before driven shall be at least one-fourth inch larger than the thickness of the plate.

The depth of the ring between the flanges shall be not less than three times the diameter of the rivet holes, and the ring shall be substantially riveted to the flanges. The fire edge of the ring shall terminate at or about the point of tangency to the curve of the flange, and the thickness of the ring shall be not less than one-half inch.

PLAIN CIRCULAR FURNACES OR FLUES, AND ADAMSON FURNACES MADE
IN SECTIONS NOT LESS THAN 18 INCHES IN LENGTH.

Rule to find safe working pressure of an Adamson furnace: Multiply length of section by thickness of plate in sixteenths; from this product subtract the length of furnace multiplied by constant 1.03; multiply result by constant 51.5 divided by the diameter.

FORMULA:

$$[S \times T - (L \times 1.03)] \times \frac{51.5}{D} = \text{pressure}$$

LEGEND:

- S = length of section = $18\frac{3}{4}$
 D = outside diameter of furnace in inches = 44''
 L = length of furnace in inches = 48''
 T = thickness of plate in sixteenths of an inch = $\frac{1}{2} = \frac{8}{16}$
 C = constant = 51.5
 C = constant = 1.03

EXAMPLE :

diameter = 44) 51.5 (1.17 41 <hr style="width: 100%;"/> 7 5 4 4 <hr style="width: 100%;"/> 3 10 3 08 <hr style="width: 100%;"/> 2	18.75 = length of section 8 = thickness of plate in 16ths <hr style="width: 100%;"/> 150.00 49.44 <hr style="width: 100%;"/> 100.56 1.17 <hr style="width: 100%;"/> 7 0392 10 056 100 56 <hr style="width: 100%;"/> 117.6552 = safe working pressure	48 = length of furnace 1.03 = constant <hr style="width: 100%;"/> 1 44 48 <hr style="width: 100%;"/> 49.44
---	---	--

VERTICAL TYPE.

Cylindrical flues used as furnaces in vertical boilers, when new, and made to practically true circles, shall be allowed a steam pressure by the following formula :

$$\frac{C \times T}{D} = \text{pressure}$$

- T = thickness of flue in inches, not less than one-fourth.
- D = outside diameter of flue in inches, not to exceed 42 inches.
- C = 10,577, a constant, when the length of the flue does not exceed 42 inches, measuring from the center of the rivet holes in the head to the center of the rivet holes in the leg.

When the flue exceeds 42 inches in diameter, it is deemed to be flat surface and must be stayed accordingly.

STEAM CHIMNEY FLUES.

The Morison, Fox, Purves, or Brown types of corrugated furnaces may be used as flues for steam chimneys or superheaters and shall be allowed a steam pressure by their respective formulas, and other flues, as described below, when new and made to practically true circles and shall be allowed a steam pressure by the following formula :

$$\frac{C \times T}{D} = \text{pressure}$$

T = thickness of material in inches.

D = outside diameter of flue in inches.

C = 12000 for flues under 30 inches in diameter, plates at least five-sixteenths of an inch thick, supported by angle rings at least $2\frac{1}{2}$ by $2\frac{1}{2}$ inches.

C = 12000 for flues 30 inches and under 45 inches in diameter, plates at least three-eighths of an inch thick, supported by angle rings at least $2\frac{1}{2}$ by $2\frac{1}{2}$ inches.

C = 12000 for flues 45 inches and under 55 inches in diameter, plates at least seven-sixteenths of an inch thick, supported by angle rings at least 3 by 3 inches.

C = 12000 for flues 55 inches and under 65 inches in diameter, plates at least one-half inch thick, supported by angle rings at least 3 by 3 inches.

C = 12000 for flues 65 inches and under 75 inches in diameter, plates at least nine-sixteenths of an inch thick, supported by angle rings at least $3\frac{1}{2}$ by $3\frac{1}{2}$ inches.

C = 12000 for flues 75 inches and under 85 inches in diameter, plates at least five-eighths of an inch thick, supported by angle rings at least $3\frac{1}{2}$ by $3\frac{1}{2}$ inches.

C = 12000 for flues 85 inches in diameter, plates at least eleven-sixteenths of an inch thick, supported by angle rings at least 4 by 4 inches.

For flues over 85 inches in diameter, add one-sixteenth of an inch to eleven-sixteenths of an inch for every 10 inches increase in the diameter of the flue.

The distance, center to center, between angle rings, or center of angle rings to center of rivets in the heads, shall in no case exceed $2\frac{1}{2}$ feet.

The angle rings shall be accurately fitted and substantially riveted to the flue and connected to the outer shell by braces, which braces shall not exceed 20 inches from center to center on the flue.

ADAMSON RINGS.

Adamson rings may be substituted for the angle rings, but each ring shall not be at a greater distance than $2\frac{1}{2}$ feet from center to center of rings, which rings shall not be required to be braced to the outer shell.

Rule to find the working pressure of an Adamson flue used in a steam chimney: Multiply constant by thickness of plate in inches and divide by diameter.

LEGEND:

T = thickness of plate = $\frac{1}{2}$ = .5
 D = diameter = 45"
 C = constant = 12000

FORMULA:

$\frac{C \times T}{D}$ = working pressure

Rule to get compressive strain on a furnace flue from a collapsing pressure: Multiply diameter of flue by pressure and divide product by twice the thickness of flue plate.

FORMULA:

$$\frac{D \times P}{2 \times T} = \text{compressive strain}$$

LEGEND:

D = diameter = 30"

P = collapsing pressure = 845

T = thickness of flue plate = $13/32 = .40625$

EXAMPLE:

30" = diameter

845 lbs. = collapsing pressure

$$\begin{array}{r} \text{thickness} = .40625 \quad \begin{array}{r} 150 \\ 120 \\ \hline 2 \quad 240 \end{array} \\ \text{twice thickness} = .81250 \quad \begin{array}{r} 25350.0000 \quad (3120 \text{ lbs. compressive strain}) \\ \hline 243750 \\ \hline 97500 \\ 81250 \\ \hline 162500 \\ 162500 \\ \hline \end{array} \end{array}$$

PLAIN FLUES.

Rule to find the working pressure of a plain flue used in a steam chimney: Multiply constant by thickness in inches and divide by diameter.

FORMULA:

$$\frac{C \times T}{D} = \text{pressure}$$

LEGEND:

L = length of chimney = 8 ft.

T = thickness of material in inches = $\frac{11}{16}$.

D = outside diameter of flue in inches = 46".

C = 8000 for flues under 32 inches in diameter, plates at least five-eighths of an inch thick, and not exceeding 8 feet in length.

C = 8000 for flues over 32 inches and under 46 inches in diameter, plates at least eleven-sixteenths of an inch thick, and not exceeding 8 feet in length.

SOCKET BOLTS.

For all boilers carrying a steam pressure of 60 pounds and under per square inch the flue may be braced with socket bolts in lieu of angle rings, such bolts to have heads and the ends to be threaded for nuts, with plate washers not over 12 inches between centers (or equivalent) on the inside of the flue; bolts to be at least 1 inch in diameter at bottom of thread.

For all boilers carrying a steam pressure of over 60 pounds and not over 120 pounds per square inch the flue may be braced with socket bolts in lieu of angle rings, such bolts to have heads and the ends to be threaded for nuts, with plate washers not over 10 inches between centers (or equivalent) on the inside of flue; bolts to be at least $1\frac{1}{8}$ inches in diameter at bottom of thread.

Plain flues, Adamson flues, and flues supported by angle bars, when used as furnaces, shall in no case be allowed a greater working pressure than found by the above formulas.

LIMITED FORMULA:

$$\frac{C \times T}{D} = \text{pressure}$$

LEGEND:

- C = constant = 9900
- T = thickness of plate = $\frac{1}{2}$ = .5
- D = diameter = 40"

EXAMPLE:

$$\begin{array}{r} 9900 = \text{constant} \\ .5 = \text{thickness of plate} \\ \hline \text{diameter} = 40'' \quad 49500 \text{ (} 123\frac{3}{4} \text{ lbs. pressure)} \\ \hline 40 \\ \hline 95 \\ 80 \\ \hline 150 \\ 120 \\ \hline 30 \end{array}$$

Hutton's rule to find collapsing pressure on a furnace flue lap riveted or flange connected: Multiply thickness of plate squared 32nds by constant 660 and divide by diameter multiplied by square root of length.

LEGEND:

T = thickness = $\frac{3}{8}$ = .375
 C = constant = 660
 D = diameter = 36''
 L = length = 64''

FORMULA:

$$\frac{T^2 \times C}{D \times \sqrt{L}} = \text{collapsing pressure}$$

EXAMPLE:


$$\begin{array}{r} .144 = \text{thickness squared in 32nds} \\ 660 = \text{constant} \\ \hline \text{diameter} = 36 \quad 8640 \\ \text{sq. root of length} = 8 \quad 864 \\ \hline 288 \quad 95040 \quad (330 \text{ lbs.} = \text{collapsing pressure}) \\ 864 \\ \hline 864 \\ 864 \\ \hline 0 \end{array}$$

TABLE OF COLLAPSING PRESSURES OF FURNACES BY W. S. HUTTON.

Diameter in inches	Length in inches	Thickness in 32nd	Collapsing pressures, lbs. per square inch
33.5	360	11	113
42	420	12	100
42	300	12	119
54	36	8	120
38	86	16	436
36	24	8	218
36	24	12	490
36	48	12	350
43	23	17	842

CHAPTER VI.

SINGLE RIVETED LAP JOINT.



Causes for failure at joint:

First—Shearing of one rivet.

Second—Tearing of plate between rivets.

Third—Crushing of rivet or plate.

In calculating seams it will be necessary to have some data, and to follow this out we will assume it to be as follows:

LEGEND:

TS = tensile strength = 60000
 CS = resistance to crushing = 95000
 SS = resistance to shearing of rivet = 38000
 D = diameter of boiler = 48"
 d = diameter of rivet hole = $13/16 = .8125$
 A = area of rivet hole = .5185
 T = thickness of plate = $5/16 = .3125$
 P = pitch = $1\frac{7}{8} = 1.8750$
 F = factor of safety = 5

First:—resistance to shear one rivet

FORMULA:

$A \times SS =$ resistance to shearing of one rivet.

EXAMPLE:

.5185 = area of rivet

38000 = shearing strength of rivet,
 single shear

4148000
 15555

19703.0000

19,703 lbs. shearing strength of one rivet.

Second:—tearing the plate between rivets.

Rule to find strength of net section of plate: From pitch of rivet, subtract diameter of rivet hole and multiply this sum by thickness of plate. Multiply this product by the tensile strength of plate.

FORMULA:

$$(P-d) \times T \times TS = \text{strength of net section of plate.}$$

EXAMPLE:

1.8750 = pitch
 .8125 = diameter of rivet

1.0625
 .3125 = thickness of plate

53125
 21250
 10625
 31875

.33203125
 60000 = tensile strength

19921.87500000

19,921 = strength of net section of plate.

Third:—resistance to crushing of rivet or plate.

FORMULA:

$$P \times T \times TS = \text{strength of solid plate.}$$

EXAMPLE:

1.8750 = pitch of rivets
 .3125 = thickness of plate

93750
 37500
 18750
 56250

.58593750
 60000 = tensile strength

35156.25000000

35,156 lbs. strength solid plate

The net section of rivets is the weakest part of joint. To find the efficiency of joint, multiply the weakest section by constant 100 and divide by the strength of solid plate.

EXAMPLE:

19,703 = shearing resistance of one rivet
35,156 = strength of solid plate

$$\begin{array}{r} 35,156 \text{) } 19,703.00 \text{ (} .56 = 56\% \text{ efficiency of joint} \\ \underline{17\ 579\ 0} \\ 2\ 125\ 00 \\ \underline{2\ 109\ 36} \end{array}$$

Rule to find safe working pressure from these calculations: Multiply the tensile strength of plate by the efficiency of joint and this sum by twice the thickness of plate; divide this product by diameter of boiler multiplied by factor of safety.

FORMULA:

$$\frac{TS \times \% \times (2 \times T)}{D \times F} = \text{safe working pressure}$$

EXAMPLE:

$$\begin{array}{r} 60000 = \text{tensile strength} \\ .56 = \% \text{ efficiency} \\ \hline 3600\ 00 \\ 30000\ 0 \\ \hline 33600.00 \\ .6250 = \text{twice thickness of plate} \\ \hline 16800000 \\ \text{diam. of boiler} = 48' \quad 6720000 \\ \text{factor of safety} = 5 \quad 20160000 \\ \hline 240 \text{) } 21000.000000 \text{ (87.5 lbs. = working pressure} \\ \underline{1920} \\ 1800 \\ \underline{1680} \\ 1200 \\ \underline{1200} \end{array}$$

Rule to find thickness of plate: Multiply pressure by factor 6 and multiply again by radius or one-half diameter of boiler and divide product by tensile strength of plate; the quotient will be thickness of plate.

LEGEND:

F = factor = 6
 R = radius = 30" or one-half diameter.
 TS = tensile strength = 60000
 P = pressure = 125 lbs.

FORMULA:

$$\frac{P \times F \times R}{TS} = \text{thickness of plate}$$

EXAMPLE:

125	= lbs. pressure
6	= factor
—	
750	
30	= radius
—	
tensile strength = 60000	22500000 (3750 = $\frac{3}{8}$ plate
	180000
—	
450000	
420000	
—	
300000	
300000	
—	

Rule to find pitch of rivets for single, double and triple riveted lap joints when the shearing strength of rivets is near equal to strength of net section of plate: Multiply area of rivet hole by the shearing resistance of rivets and by number of rows of rivets; divide product by thickness of plate multiplied by tensile strength; add to quotient the diameter of rivet hole.

FORMULA:

$$\frac{A \times SS \times N}{T \times TS} + DH = \text{pitch single riveted joint}$$

LEGEND:

A = area of rivet = $15/16 = .6903$
 SS = shearing strength of rivet = 38000
 N = number of rows of rivets = 1
 T = thickness of plate = .4375
 TS = tensile strength = 60000
 DH = diameter of rivet hole = .9375

EXAMPLE:

	.6903 = area of rivet
	38000 = shearing strength
plate thickness = .4375	55224000
tensile strength = 60000	20709
	26231.4000 (.9992
	23625 0 .9375 = diameter of rivet hole
	2606 40 1.9367 = 1 15/16 = pitch
	2362 50
	243 900
	236 250
	7 6500
	5 2500
	2 4000

Custom through using iron rivets has established a rule to make the rivet hole 1-16 larger than the rivet, but owing to a better rivet material and use of steel rivets, experience has proved that less than 1-16 larger is better.

Rule to find diameter of a rivet for a single riveted lap joint — steel rivets and plate: Add to plate thickness 7-16 of an inch.

FORMULA:

T plus $\frac{7}{16}$ = diameter of rivet for single riveted lap joint

LEGEND:

T = thickness of plate = $\frac{3}{8}$ = .3750

EXAMPLE:

.3750 = thickness of plate

.4375 = $\frac{7}{16}$

.8125 = $\frac{13}{16}$ rivet (this sectional area after rivet has been driven)

The Board of Supervising Inspectors of Steam Vessels, in their rules and regulations governing the construction of steam boilers for marine purposes, prescribe the following rules for single and double riveted lap joints:

- d = T + $\frac{3}{8}$ inch for iron plates and iron rivets, single riveted lap joints.
- d = T + $\frac{5}{16}$ inch for iron plates and iron rivets, double riveted lap joints.
- d = T + $\frac{7}{16}$ inch for steel plates and steel rivets, single riveted lap joints.
- d = T + $\frac{3}{8}$ inch for steel plates and steel rivets, double riveted lap joints.

It has been generally considered good practice to have rivet section percentage of strength higher, this for the benefits of caul-

ing and increasing rivet strength and to make up for depreciation due to heating and driving rivet; but one authority on boiler construction says to have plate higher in efficiency to provide for plate deteriorating due to pitting and corrosion; however, in designing seams these conditions can be provided for when computing boiler joints.

Rule to find center of rivet to edge of plate (lap): Multiply diameter of rivet hole by 1.5 (one and a half) constant.

FORMULA:

$$d \times C = \text{lap}$$

LEGEND:

d = diameter of rivet hole = $\frac{3}{4} = .750$
 C = constant = 1.5

FORMULA:

.750 = rivet diameter
 1.5 = constant

$$\begin{array}{r} 3750 \\ 750 \\ \hline \end{array}$$

$$\underline{1.1250} = 1\frac{1}{8}'' \text{ lap}$$

Rule to find percentage of rivet in a single riveted lap joint, steel plate and steel rivets: Multiply area of rivet by number of rows in one pitch and by the constant 100; divide this product by pitch of rivet multiplied by thickness of plate in inches.

LEGEND:

P = pitch of rivets = $1\frac{1}{8} = 1.9375$
 A = area of rivet $\frac{3}{4}$ hole = .44179
 C = constant = 100
 T = thickness of plate = $\frac{3}{8} = .375$
 N = number of rows of rivets = 1
 D = diameter of rivet hole = $\frac{3}{4} = .750$

FORMULA:

$$\frac{A \times N \times C}{P \times T} = \text{rivet percentage}$$

EXAMPLE:

pitch of rivet = 1.9375
 thickness of plate = .375 .44179 = area of rivet
 1 = no. of rows

$$\begin{array}{r} 96875 \\ 135625 \quad .44179 \\ 58125 \quad 100 = \text{constant} \\ \hline \end{array}$$

$$.7265625)44.1790000 (.60 = 60\% \text{ rivet percentage}$$

$$\underline{43 \ 593750}$$

$$5852500$$

Rule to find percentage of plate in single riveted joint, steel plate and steel rivets, when pitch and diameter of rivet are given: From pitch of rivet subtract sum of diameter of hole, multiply by constant 100 and divide by pitch.

FORMULA:

$$\frac{P-d \times C}{P} = \text{percentage of plate}$$

EXAMPLE:

1.9375 = pitch
.750 = rivet hole diameter

$$\frac{1.1875}{100} = \text{constant}$$

$$\text{pitch} = 1.9375 \times 118.7500 \text{ (61\% = percentage of plate)}$$

$$\begin{array}{r} 116 \ 250 \\ \hline 2 \ 5000 \\ 1 \ 9375 \\ \hline 5625 \end{array}$$

LLOYDS RULES.

Rule to find working pressure: Multiply constant by thickness of plate and by per cent of joint efficiency; divide this product by diameter of boiler.

CONSTANTS USED.

	Thick- ness	Thick- ness	Thick- ness	Thick- ness
For iron plate punched, lap joint	$\frac{1}{2}$	$\frac{1}{2}$ to $\frac{3}{4}$	$\frac{3}{4}$ & over	
“ “ “ drilled “ “	155	165	170	
“ “ “ punched double strap	170	180	190	
“ “ “ drilled “ “	170	180	190	
	180	190	200	
	Thick- ness	Thick- ness	Thick- ness	Thick- ness
For Steel Plate.	$\frac{3}{8}$ & under	$\frac{3}{8}$ to $\frac{1}{2}$	$\frac{1}{2}$ to $\frac{3}{4}$	$\frac{3}{4}$ & over
Lap joints punched }	200	215	230	240
“ “ drilled }	215	230	250	260
“ “ double strap punched }				
“ “ double strap drilled }				

LEGEND:

T = thickness of plate
D = diameter
% = joint efficiency

FORMULAS:

$$\frac{C \times T \times \%}{D} = \text{working pressure}$$

$$\frac{P \times D}{C \times \%} = \text{thickness of plate}$$

MANCHESTER STEAM USERS ASSOCIATION FORMULAS:

$$\frac{T \times 2 \times \% \times TS}{D \times 5 \times 100} = \text{working pressure}$$

$$\frac{D \times P \times 5 \times 100}{T \times \% \times 2} = \text{thickness of plate}$$

APPENDIX.

The following formulas are taken from those of the British Board of Trade and are given for the determination of the pitch, distance between rows of rivets, diagonal pitch, maximum pitch and distance from centers of rivets to edge of lap of single and double riveted lap joints, for both iron and steel boilers:

- Let p = greatest pitch of rivets in inches.
 n = number of rivets in one pitch.
 pd = diagonal pitch in inches.
 d = diameter of rivets in inches.
 T = thickness of plate in inches.
 V = distance between rows of rivets in inches.
 E = distance from edge of plate to center of rivet in inches.

TO DETERMINE THE PITCH.

Iron plates and rivets:

$$\frac{d^2 \times .7854 \times n}{T} + d = \text{pitch}$$

Example, first, for single-riveted joint: Given, thickness of plate (T) = $\frac{1}{2}$ inch, diameter of rivet (d) = $\frac{7}{8}$ inch. In this case n = 1. Required the pitch.

$$\frac{(\frac{7}{8})^2 \times .7854 \times 1}{\frac{1}{2}} + \frac{7}{8} = 2.077 \text{ inches} = \text{pitch}$$

Example for double-riveted joint: Given, $t = \frac{1}{2}$ inch and $d = \frac{13}{16}$ inch. In this case $n = 2$.

$$\frac{(\frac{13}{16})^2 \times .7854 \times 2}{\frac{1}{2}} + \frac{13}{16} = 2.886 \text{ inches} = \text{pitch}$$

For *steel* plates and steel rivets:

$$\frac{23 \times d^2 \times .7854 \times n}{28 \times T} + d. = \text{pitch}$$

Example for single-riveted joint: Given, thickness of plate = $\frac{1}{2}$ inch, diameter of rivet = $\frac{15}{16}$ inch. In this case $n = 1$.

$$\frac{23 \times (\frac{15}{16})^2 \times .7854 \times 1}{28 \times \frac{1}{2}} + \frac{15}{16} = 2.071 \text{ inches} = \text{pitch}$$

Example for double-riveted joint: Given, thickness of plate = $\frac{1}{2}$ inch, diameter of rivet = $\frac{7}{8}$ inch. $n = 2$.

$$\frac{23 \times (\frac{7}{8})^2 \times .7854 \times 2}{28 \times \frac{1}{2}} + \frac{7}{8} = 2.85 \text{ inches} = \text{pitch}$$

FOR DISTANCE FROM CENTER OF RIVET TO EDGE OF LAP.

$$\frac{3 \times d}{2} = E \text{ or lap}$$

Example: Given, diameter of rivet (d) = $\frac{7}{8}$ inch; required the distance from center of rivet to edge of plate.

$$\frac{3 \times \frac{7}{8}}{2} = 1.312 \text{ inches} = E, \text{ for single or double riveted lap joint.}$$

FOR DISTANCE BETWEEN ROWS OF RIVETS.

The distance between lines of centers of rows of rivets for double, chain-riveted joints (V) should not be less than twice the diameter of rivet, but it is more desirable that V should not be less than $4d+1$.

Example under latter formula: Given, diameter of rivet = $\frac{7}{8}$ inch;

$$\frac{(4 \times \frac{7}{8}) + 1}{2} = 2.25 \text{ inches} = V$$

For ordinary, double, zigzag riveted joints:

$$\frac{\sqrt{(11p + 4d)(p + 4d)}}{10} = V$$

Example: Given, pitch = 2.85 inches, and diameter of rivet = $\frac{7}{8}$ inch:

$$\frac{\sqrt{(11 \times 2.85 + 4 \times \frac{7}{8}) \times (2.85 + 4 \times \frac{7}{8})}}{10} = 1.487 \text{ inches} = V$$

DIAGONAL PITCH.

For double, zigzag riveted lap joint. Iron and steel:

$$\frac{6p + 4d}{10} = pd$$

Example: Given, pitch = 2.85 inches, and $d = \frac{7}{8}$ inch;

$$\frac{(6 \times 2.85) + (4 \times \frac{7}{8})}{10} = 2.06 \text{ inches} = pd$$

MAXIMUM PITCHES FOR RIVETED LAP JOINTS.

For single-riveted lap joints:

$$\text{Maximum pitch} = (1.31 \times T) + 1\frac{5}{8}$$

For double-riveted lap joints:

$$\text{Maximum pitch} = (2.62 \times T) + 1\frac{5}{8}$$

Example: Given, a thickness of plate = $\frac{1}{2}$ inch, required the maximum pitch allowable.

For single-riveted lap joint:

$$\text{Maximum pitch} = (1.31 \times \frac{1}{2}) + 1\frac{5}{8} = 2.28 \text{ inches}$$

For double-riveted lap joint:

$$\text{Maximum pitch} = (2.62 \times \frac{1}{2}) + 1\frac{5}{8} = 2.935 \text{ inches}$$

To determine the pitch of rivets from the above formulas, use the diameter and area of the rivet holes. The diameter of the rivets as given in the following tables is the diameter of the driven rivet.

Any riveted joint will be allowed when it is constructed so as to give an equal percentage of strength to that obtained by the use of the formula given.


Following are single and double-riveted lap joints tables, taken from the handbook of Thomas W. Traill, entitled Boilers, Marine and Land; Their Construction and Strength, may be taken for use in single and double riveted joints as approximating the formulas of the British Board of Trade for such joints.

STEEL PLATES AND STEEL RIVETS.

SINGLE-RIVETED LAP JOINTS.

THICKNESS OF PLATE IN INCHES	DIAMETER OF RIVET IN INCHES	PITCH IN INCHES	LAP IN INCHES	EFFICIENCY
$\frac{1}{4}$	$\frac{1}{2}$	$1\frac{1}{4}$	1	50
$\frac{1}{4}$	$\frac{5}{8}$	$1\frac{5}{8}$	$1\frac{1}{8}$	57
$\frac{1}{4}$	$\frac{3}{4}$	$1\frac{7}{8}$	$1\frac{3}{8}$	60
$\frac{5}{16}$	$\frac{5}{8}$	$1\frac{3}{8}$	$1\frac{1}{8}$	50
$\frac{5}{16}$	$\frac{3}{4}$	$1\frac{5}{8}$	$1\frac{5}{8}$	54
$\frac{5}{16}$	$\frac{3}{4}$	$1\frac{7}{8}$	$1\frac{1}{4}$	56
$\frac{3}{8}$	$\frac{3}{4}$	$1\frac{1}{8}$	$1\frac{1}{4}$	52
$\frac{3}{8}$	$\frac{7}{8}$	$1\frac{7}{8}$	$1\frac{5}{8}$	53
$\frac{3}{8}$	$\frac{7}{8}$	$2\frac{1}{8}$	$1\frac{7}{8}$	55
$\frac{7}{16}$	$\frac{3}{4}$	$1\frac{9}{8}$	$1\frac{1}{4}$	47
$\frac{7}{16}$	$\frac{7}{8}$	$1\frac{11}{8}$	$1\frac{5}{8}$	51
$\frac{7}{16}$	$\frac{7}{8}$	$2\frac{1}{8}$	$1\frac{1}{2}$	53
$\frac{1}{2}$	$\frac{7}{8}$	$1\frac{13}{8}$	$1\frac{7}{8}$	48
$\frac{1}{2}$	$\frac{11}{8}$	2	$1\frac{1}{2}$	50
$\frac{1}{2}$	1	2	$1\frac{5}{8}$	51
$\frac{9}{16}$	$\frac{15}{16}$	$1\frac{7}{8}$	$1\frac{1}{2}$	46
$\frac{9}{16}$	1	$2\frac{1}{8}$	$1\frac{3}{8}$	48

COMPUTING STRENGTH OF A DOUBLE RIVETED LAP JOINT.



Causes for failure at joint.

- 1st. Resistance to shearing two rivets.
- 2nd. Resistance to tearing of plate between two rivets.
- 3rd. Resistance to crushing in front of two rivets.

Assuming a given boiler of dimensions and data as follows :

LEGEND:

- D = diameter of boiler = 54"
 T = thickness of plate = $\frac{3}{8}$ = .3750
 P = pitch of rivets = $3\frac{1}{8}$ = 3.0625
 TS = tensile strength = 55000
 CS = crushing strength of rivets = 95000
 SS = shearing strength of rivets = 38000
 A = area of rivet hole = $\frac{1}{8}$ = .69029 or .69
 d = diameter of rivet hole = $\frac{1}{8}$ = .9375

First. Resistance to shearing two rivets.

Rule to find shearing strength of rivets in single shear: Multiply area of rivet hole by number of rivets in single shear and this sum by shearing resistance of rivet.

FORMULA:

$A \times 2 \times SS = \text{strength of two rivets in single shear}$

EXAMPLE:

.69 = area of rivet hole
2 = number of rows

$\frac{1}{8}$
 38000 = shearing strength of rivet in
 single shear

1104000
 414

52440.00

52,440 = strength of two rivets in single shear



Second. Resistance to tearing of plate between two rivets.

Rule to find strength in net section of plate: From pitch of rivet subtract diameter of rivet; multiply this sum by thickness of plate multiplied by tensile strength.

FORMULA:

$$(P-d) \times T \times TS = \text{strength in net section of plate}$$

EXAMPLE:

3.0625 = pitch
 .9375 = diameter of rivet hole

2.1250
 20625 = thickness \times tensile strength
106250
 42500
 127500
42500

.3750 = thickness of plate
 55000 = tensile strength

18750000
 18750

20625.00000

43828.1250

43,828 = strength of net section of plate

Third. Resistance to crushing of plate in front of two rivets.

FORMULA:

$$d \times 2 \times T \times CS = \text{resistance to crushing in front of two rivets}$$

EXAMPLE:

.9375 = diameter of rivet hole
 2 = two times

1.8750

.375 = thickness of plate

93750
 131250
 56250

.7031250

95000 = crushing strength

35156250000
 63281250

66796.87500000

66,796 = resistance to crushing in front of two rivets

Rule to find strength of solid plate: Multiply pitch of rivets by the thickness of plate and this sum by tensile strength.

FORMULA:

$$P \times T \times TS = \text{strength of solid plate}$$

THE BOILER.

EXAMPLE:

3.0625 = 3 $\frac{1}{8}$ pitch
 .375 = thickness of plate

153125
 214375
 91875

1.1484375
 55000 = tensile strength

5742 1875000
 57421 875

63164. ~~003250000~~
 63,164 = strength of solid plate

Rule to find efficiency from weakest section of joint: Multiply sum of weakest section by 100 and divide by sum of strength of solid plate.

FORMULA:

$$\frac{43,828 \times 100}{63,163} = \text{efficiency of joint}$$

EXAMPLE:

43,828 = strength of net section of plate
 100 = constant

strength of solid plate = 63,164 $\frac{4382800}{378984}$ (69 per cent efficiency of joint)

592960
 568476
 24484

Rule to find safe working pressure from these calculations: Multiply tensile strength of plate by joint's efficiency and multiply this sum by twice the thickness of plate and divide this product by the diameter of boiler in inches multiplied by factor of safety.

FORMULA:

$$\frac{TS \times \% \times (2 \times T)}{D \times F} = \text{working pressure}$$

EXAMPLE:

55000 = tensile strength
 .69 = efficiency of joint

495000
 330000

37950. ~~000~~
 750 = twice thickness of plate

diam of boiler = 54" 1897500
 factor of safety = 5 265650

270) 28462. ~~5000~~ (105 lbs. working pressure
 270

1462
 1350

112

When finding diameter of rivet holes for lap and butt joints, the following constants are used:

C=2.25 for lap joints double riveted up to and including 1/2" plate.

C=1.9 for triple riveted lap joint up to 1/2" plate.

C=1.8 for butt joints triple and quadruple riveted.

Rule to find diameter of rivet hole: The square root of product of thickness of plate in inches multiplied by constant used in connection with joint form and plate will give diameter of rivet hole.

LEGEND:

T = thickness of plate = 1/16 = .4375
 C = constant = 2.25

FORMULA:

$\sqrt{T \times C}$ = diameter of rivet hole

EXAMPLE:

.4375 = thickness of plate
 2.25 = constant

21875
 8750
 8750

9) .984375 (.9921 = 1" nearly or hole for 1 1/8
 81 rivet

189) 1743
 1701

1982) 4275
 3964

19841) 31100
 19841
 11259

Rule to find diameter of shell: Multiply tensile strength by thickness of plate in inches and by per cent of joint; divide this product by pressure multiplied by the factor.

FORMULA:

$$\frac{TS \times T \times \% \text{ of joint}}{P \times F} \times 2 = \text{diameter of shell}$$

LEGEND:

P = pressure = 130
 T = thickness of plate = $\frac{1}{2}$ = .5
 F = factor = 6
 % = percentage of joint = 80
 TS = tensile strength = 60000

EXAMPLE:

	60000	tensile strength
	.5	= thickness of plate

pressure = 130	30000.0	
constant = 6	80	= joint efficiency

	780)24000.00	(30 = radius
	2340	2

	600	60" diameter

Rule to find tensile strength of plate for boiler: Multiply given pressure per square inch by tensile strength; multiply this by one-half diameter of boiler; divide by the given thickness of material in inches, and the quotient will give the required tensile strength per square inch in pounds.

FORMULA:

$$\frac{(P \times TS) \times (\frac{1}{2} \text{ of } D)}{T} = \text{tensile strength}$$

LEGEND:

TS = tensile strength = 60000
 P = pressure = 125 lbs.
 D = diameter of boiler = 60"
 T = thickness of plate = .3750

EXAMPLE:

	125	= pressure
	60000	= tensile strength

	7500000	
	30	= $\frac{1}{2}$ the diameter

thickness of plate = .3750	225000000	(60000 lbs. = tensile strength
	22500	

	00000	

Rule to find thickness of shell plate when percentage of joint is known: Multiply diameter of shell by pressure and again by factor of safety and multiply this sum by 100; divide product by tensile strength multiplied by efficiency of seam multiplied by 2.

LEGEND:

D = diameter = 60''
 P = pressure = 150
 F = factor of safety = 5
 % = percentage of seam strength = 80
 TS = tensile strength = 60000
 C = constant = 100

FORMULA:

$$\frac{D \times P \times F \times 100}{TS \times \% \times 2} = \text{thickness of shell plate}$$

EXAMPLE:

	60'' = diameter of shell
	150 = pressure

	3000
	60

tensile strength =	60000
percentage =	80

	480000
two times =	2

	960000

	45000
	100 = constant

	450000

	3840000

	660000 00
	576000 00

	84000 000
	76800 000

	7200 0000
	6720 0000

	480 0000

(. 4687 = 15/32'' = thickness required)

Rule to find diameter of steel rivet for steel plate double riveted lap joint: Add $\frac{3}{8}$ of an inch to plate thickness.

FORMULA:

$$\frac{3}{8} \text{ plus } T = \text{diameter of rivet}$$

T = thickness of plate = $\frac{7}{16} = .4375$

EXAMPLE:

.4375 = plate
.375 = $\frac{3}{8}$

.8125 = $\frac{13}{16}$ rivet diameter

Rule to find pitch of rivet in a double riveted lap joint — steel plate, steel rivets: Multiply square of diameter of rivet hole by constant 23, this sum by .7854; then multiply this product by the number of rows of rivets; divide by diameter of rivet multiplied by constant 28, and add diameter of rivet hole to quotient. Result gives pitch of rivet.

FORMULA:

$$\frac{d^2 \times 23 \times .7854 \times N}{d \times 28} + d = \text{pitch}$$

d = diameter of rivet hole = $\frac{3}{4}$ = .9375
 N = number of rows = 2

EXAMPLE:

	.9375 = diameter rivet hole
	.9375
	<u>46875</u>
	65625
	28125
	<u>84375</u>
	.87890625 = diameter of rivet hole [squared
	23 = constant]
	<u>263671875</u>
	175781250
	<u>20.21484375</u>
	.7854
	<u>808592</u>
	1010740
diam. of rivet hole = .9375	1617184
constant = 28	<u>1415036</u>
	75000 1587670392
	<u>19750</u> 2 rows of rivets
26.2500	3175340784 (1.2096
	<u>262500</u> .9375 = diameter of rivet hole
	550340 2.1471 = $2\frac{9}{64}$ nearly = pitch
	<u>525000</u>
	2534078
	<u>2362500</u>
	1715784
	<u>1575000</u>
	140784

Rule to find distance between rows of chain double riveted joint:
To four times the diameter of one rivet hole add one and divide by two.

FORMULA:

$$\frac{4d \text{ plus } 1}{2} = \text{distance between rows chain riveted joint}$$

LEGEND:

$$d = \text{diameter of rivet hole} = \frac{7}{8} = .8750$$

EXAMPLE:

$$\begin{array}{r} .8750 = \text{diameter of rivet hole} \\ \underline{\quad\quad\quad} \\ 4 \\ \hline 3.5000 \\ 1.0000 \text{ added} \\ \hline 2) 4.5000 \\ \underline{\quad\quad\quad} \\ 2.2500 = 2\frac{1}{4}'' \text{ distance between rows} \end{array}$$

Rule to find diagonal pitch of rivet: To four times the diameter of rivet hole add six times the pitch on straight line and divide by 10.

FORMULA:

$$\frac{4d + 6P}{10} = \text{diagonal pitch}$$

LEGEND:

$$d = \text{diameter of rivet hole} = \frac{7}{8} = .8750$$

$$p = \text{pitch} = 3\frac{3}{8} = 3.3750$$

EXAMPLE:

$$\begin{array}{r} 3.3750 = \text{pitch} \\ \underline{\quad\quad\quad} \\ 6 \text{ times} \\ \hline 20.2500 \end{array} \qquad \begin{array}{r} .8750 = \text{diameter of rivet hole} \\ \underline{\quad\quad\quad} \\ 4 \text{ times} \\ \hline 3.5000 = 4 \text{ times diameter} \\ 20.2500 = 6 \text{ times pitch} \\ \hline 10) 23.7500 (2.3750 = 2\frac{3}{8} \text{ diagonal pitch of} \\ \underline{\quad\quad\quad} \\ 20 \qquad\qquad\qquad \text{rivets} \\ \hline 37 \\ 30 \\ \hline 75 \\ 70 \\ \hline 50 \\ 50 \\ \hline 0 \end{array}$$

Rule to find spacings center of rivet to edge of plate. Multiply diameter of rivet by 3 and divide by 2.

FORMULA:

$$\frac{3 \times d}{2} = \text{distance from center of rivet to edge of plate}$$

d = diam. of rivet $\frac{7}{8} = .8750$

EXAMPLE:

$$\begin{array}{r} .8750 \\ \underline{\quad 3} \\ 2)2.6250 \end{array}$$

1.3125 = $1\frac{5}{16}$ inch distance

Rule to find pitch of rivet to give best percentage of strength in a double zig zag riveted joint: Multiply twice the rivet sectional area by the shearing strength of rivet and divide by thickness of plate multiplied by its tensile strength; add to product one diameter of rivet.

FORMULA:

$$\frac{(2 \times A) \times SS}{T \times TS} \text{ plus 1 diam. of rivet} = \text{pitch}$$

LEGEND:

- A = rivet area = $\frac{1}{8}$ = .5185
- SS = shearing strength one rivet = 38000
- T = plate thickness = $\frac{3}{8}$ = .3750
- TS = tensile strength of plate = 60000
- d = diameter of rivet = $\frac{7}{8}$ = .8125

EXAMPLE:

$$\begin{array}{r} .5185 = \text{sectional area of rivet} \\ \underline{\quad 2} \end{array}$$

1.0370 = twice sectional area of rivet
38000 = shearing strength of one rivet

$$\begin{array}{r} \frac{3}{8} \text{ plate} = .3750 \quad 82960000 \\ \text{tensile strength} = \quad 60000 \quad 31110 \end{array}$$

$$\begin{array}{r} 22500.0000 \quad 39406.0000 \quad (1.7513 \\ \underline{\quad 22500} \quad \underline{\quad .8125} = \text{diam. of one rivet} \end{array}$$

$$\begin{array}{r} 169060 \\ \underline{157500} \end{array} \quad 2.5638 = 2\frac{9}{16} \text{ inch pitch}$$

$$\begin{array}{r} 115600 \\ \underline{112500} \end{array}$$

$$\begin{array}{r} 31000 \\ \underline{22500} \end{array}$$

$$\begin{array}{r} 85000 \\ \underline{67500} \end{array}$$

$$\underline{17500}$$

Rule to find plate percentage in a double riveted lap joint:
From pitch of rivet subtract diameter of rivet and multiply by constant 100; divide this product by pitch of rivet.

<p>LEGEND: P = pitch = $3\frac{1}{8} = 3.125$ d = diameter of rivet hole = $\frac{7}{8} = .8750$ C = constant = 100</p>	<p>FORMULA: $\frac{(P-d) \times 100}{P} = \text{percentage of plate}$</p>
---	--

EXAMPLE:
 3.1250 = pitch of rivet
 .8750 = diameter of rivet hole

2.2500
 100 = constant

3.1250)225.0000 (72 = percentage of plate
 218750

 62500
 62500

Rule to find percentage of rivet in a double riveted lap joint:
Multiply area of rivet by the number of rows of rivet in one pitch; multiply this product by 100 and by the constant 23; divide this product by pitch multiplied by thickness of plate and constant 28.

<p>LEGEND: T = thickness of plate = $\frac{7}{16} = .4375$ P = pitch = $3\frac{1}{8} = 3.125$ A = area of rivet hole = $\frac{7}{8} = .6013$ d = diameter of rivet = $\frac{7}{8} = .8750$ N = number of rows = 2</p>	<p>FORMULA: $\frac{A \times N \times 100 \times 23}{P \times T \times 28} = \text{per cent. of rivet section}$</p>
---	---

pitch = 3.125
 thickness of plate = .4375

15625
 21875
 9375
 1 2500

 1.3671875
 constant = 28

 10 9375000
 27 343750

 38.2812500

EXAMPLE:
 .6013 = area of rivet hole
 2 rows

1.2026
 100 = constant

120.2600
 23 = constant

3607800
 2405200

 38.281)2765.9800 (72.2 = % of rivet strength
 2679 67

 86 310
 76 562

 9 7480
 7 6562

 2 0918

Rule to find bursting pressure of boiler: Multiply tensile strength by twice the thickness of plate and divide by the internal diameter of boiler.

FORMULA:

$$\frac{TS \times (2 \times T)}{D} = \text{bursting pressure}$$

LEGEND:

TS = tensile strength = 60000
 T = thickness of plate = $\frac{3}{8}$ = .375
 D = internal diameter = 60''

EXAMPLE:

thickness of plate = .375	60000 = tensile strength
2	.750 = twice thickness of plate
twice thickness = .750	3000000
	420000
internal diameter = 60''	45000 (750 lbs. per square inch bursting pressure)
	420
	300
	300
	0

The bursting pressure divided by the factor of safety will give the safe working pressure. The factor of safety of 5 has been generally accepted by eminent engineers and boilermakers.

$$\frac{\text{factor} = 5) 750 \text{ per sq. inch bursting pressure}}{5} = 150 \text{ lbs. working pressure}$$

Rule to find working pressure on boilers from a lowest percentage of joint: Multiply tensile strength of material by the lowest percentage of joint, then by twice the thickness of plate and divide by diameter multiplied by factor of safety.

FORMULA:

$$\frac{TS \times \% \times (2 \times T)}{D \times F} = \text{working pressure}$$

LEGEND:

TS = tensile strength = 60000
 % = lowest percentage of joint = 80
 T = thickness of plate = $\frac{1}{2}$ = .500
 D = internal diameter = 71.1250 (outside = 72'')

LAP JOINTS.


EXAMPLE :

$$\begin{array}{r}
 \text{Internal} \\
 \text{diameter of boiler} = 71.1250 \\
 \text{factor of safety} = 6 \\
 \hline
 4800000 \\
 1.0000 = \text{twice thickness of plate} \\
 \hline
 426.7500 \times 4800000.0000 \text{ (112 lbs. working pressure)} \\
 4267500 \\
 \hline
 5325000 \\
 4267500 \\
 \hline
 10575000 \\
 8535000 \\
 \hline
 2040000
 \end{array}$$

Rule to find safe working pressure according to the U. S. Government rule is as follows: Multiply one sixth of the lowest tensile strength found stamped on any plate by the thickness of same, expressed in inches or decimal parts of same, and divide by the radius or half of diameter expressed in inches. The result will give pressure allowed for a single riveted boiler; when double riveted add 20 per cent. This rule is based on the rivet and plate section being equal and holes drilled.

Thickness of plate	Diameter of rivet	Pitch in inches	Lap in inches	Distance between rows	Efficiency
1/4	1/2	1 13/16	1	1 3/4	69
1/4	5/8	2 5/8	1 1/8	1 7/8	72
1/4	1 1/16	2 7/8	1 3/16	1 15/16	74
5/16	3/8	2 3/16	1 1/8	1 5/8	68
5/16	1/2	2 1/2	1 5/16	1 3/4	70
5/16	3/4	2 7/8	1 1/4	1 15/16	72
3/8	3/4	2 9/16	1 1/4	1 7/8	68
3/8	1 1/8	2 7/8	1 1/16	2	69
3/8	7/8	3 1/4	1 1/16	2 3/16	71
7/16	3/4	2 5/16	1 1/4	1 7/8	65
7/16	7/8	2 11/16	1 1/16	2 1/16	67
7/16	1 1/8	3 5/16	1 1/2	2 3/16	70
1/2	7/8	2 11/16	1 1/16	2	65
1/2	1 1/8	3	1 1/2	2 1/8	66
1/2	1	3 5/16	1 5/8	2 1/4	68
9/16	1 1/16	2 3/4	1 1/2	2	63
9/16	1	3	1 5/8	2 1/8	65

COMPUTING STRENGTH OF TRIPLE RIVETED LAP JOINTS.



Causes for failure at joint.

- 1st. Resistance to shearing three rivets.
- 2nd. Resistance to tearing between three rivets.
- 3rd. Resistance to crushing in front of three rivets.

Assuming a boiler of dimensions and data as follows:

LEGEND:

- T = thickness of plate = $\frac{3}{8}$ = .375
 TS = tensile strength = 55000
 d = diameter of rivet = $\frac{13}{16}$ = .8125
 A = area of rivet hole = $\frac{13}{16}$ = .5185
 P = pitch of rivet = $3\frac{1}{4}$ = 3.2500
 SR = shearing resistance of rivets = 38000
 CS = crushing strength of rivet and plate = 95000
 D = diameter of boiler = 60"
 F = factor of safety = 5

First. Resistance to shearing of three rivets.

Rule to find strength of rivets in single shear: Multiply area of rivet hole by number of rivets, and multiply this sum by the shearing resistance of rivet material.

FORMULA:

$$A \times \text{No. of rivets} \times \text{SR} = \text{strength of rivets in single shear}$$

EXAMPLE:

$$\begin{aligned} .5185 &= \text{area of rivet hole} \\ 3 &= \text{number of rivets} \end{aligned}$$

$$\begin{array}{r} 1.5555 \\ \underline{38000} \text{ = shearing resistance of rivets} \\ 124440000 \\ \underline{46665} \\ 59109.0000 \end{array}$$

59,109 lbs. = strength of three rivets in single shear

Second. Resistance to tearing of plate between three rivets.

Rule to find strength of net section of plate: From pitch of rivets subtract diameter of rivet hole and multiply by thickness of plate and multiply this sum by the tensile strength of plate.

FORMULA:

$$(P-d) \times T \times TS = \text{strength of net section of plate}$$

EXAMPLE:

$$\begin{array}{l} 3.2500 = \text{pitch of rivet} \\ .8125 = \text{diameter of rivet hole} \end{array}$$

$$\begin{array}{l} 2.4375 \\ .375 = \text{thickness of plate} \end{array}$$

$$\begin{array}{r} 121875 \\ 170625 \\ 73125 \end{array}$$

$$\begin{array}{r} .9140625 \\ 55000 = \text{tensile strength} \end{array}$$

$$\begin{array}{r} 45703125000 \\ 45703125 \end{array}$$

$$\begin{array}{r} 50273.4375000 \\ 50,273 = \text{strength of net section of plate} \end{array}$$

Third: Resistance to crushing in front of plate in front of three rivets.

FORMULA:

$$d \times 3 \times T \times CS = \text{resistance to crushing in front of three rivets}$$

EXAMPLE:

$$\begin{array}{l} .8125 = \text{diameter of rivet} \\ 3 = \text{three rivets} \end{array}$$

$$\begin{array}{l} 2.4375 \\ .375 = \text{thickness of plate} \end{array}$$

$$\begin{array}{r} 121875 \\ 170625 \\ 73125 \end{array}$$

$$\begin{array}{r} .9140625 \\ 95000 = \text{crushing strength of rivet} \\ \text{and plate} \end{array}$$

$$\begin{array}{r} 45703125000 \\ 82265625 \end{array}$$

$$\begin{array}{r} 86835.9375000 \\ 86,835 \text{ lbs.} = \text{resistance to crushing of material} \end{array}$$

Rule to find strength of solid plate: Multiply pitch of rivets by thickness of plate and this sum by tensile strength of material.

FORMULA:

$$P \times T \times TS = \text{strength of solid plate}$$

EXAMPLE:

$$\begin{aligned} 3.2500 &= \text{pitch} \\ .375 &= \text{thickness of solid plate} \end{aligned}$$

$$\begin{array}{r} 162500 \\ 227500 \\ \hline 97500 \end{array}$$

$$\begin{array}{r} 1.2187500 \\ 55000 = \text{tensile strength} \end{array}$$

$$\begin{array}{r} 60937500000 \\ 60937500000 \\ \hline \end{array}$$

$$\begin{array}{r} 67031.2500000 \\ 67,031 \text{ lbs.} = \text{strength of solid plate} \end{array}$$

Rule to find efficiency of this joint: Divide net section of plate by strength of solid plate.

EXAMPLE:

$$\begin{aligned} 50,273 &= \text{net section of plate} \\ 67,031 &= \text{strength of solid plate} \end{aligned}$$

$$67031)50273.000 (.749 = \text{efficiency}$$

$$\begin{array}{r} 469217 \\ \hline \end{array}$$

$$\begin{array}{r} 335130 \\ 268124 \\ \hline \end{array}$$

$$\begin{array}{r} 670060 \\ 603279 \\ \hline \end{array}$$

$$66781$$

Rule to find safe working pressure from these calculations: Multiply tensile strength of plate by efficiency of joint and multiply this sum by twice thickness of plate; divide this product by diameter of boiler in inches multiplied by factor of safety.

EXAMPLE:

55000 = tensile strength of plate
 .749 = percentage of joint

495 000
 2200 00
 38500 0

41195.0000
 .7500 = twice thickness of plate

diam. of boiler = 60'' 2059 7500
 factor of safety = 5 28836 5


300)30896.2500 (102.9 lbs. working pressure
 300

896
 600
 2962
 2700
 262

Thickness of plate	Diameter of rivet	Pitch in inches	Lap in inches	Distance between rows	Efficiency
1/4	1/2	2 1/2	1	1 7/8	76
1/4	5/8	3 1/2	1 1/8	2 1/16	80
1/4	11/16	4	1 3/16	2 1/8	81
5/16	5/8	2 15/16	1 1/8	2	76
5/16	11/16	3 1/8	1 3/16	2 1/6	76
5/16	3/4	4	1 1/4	2 3/16	79
3/8	3/4	3 3/8	1 1/4	2 3/8	76
3/8	13/16	3 7/8	1 5/8	2 1/4	77
3/8	7/8	4 1/16	1 7/16	2 1/2	79
7/16	3/4	3	1 1/4	2	73
7/16	7/8	3 11/16	1 7/16	2 1/2	76
7/16	15/16	4 3/8	1 1/2	2 3/8	77
1/2	7/8	3 1/2	1 7/16	2 1/4	73
1/2	13/16	4	1 1/2	2 5/8	74
1/2	1	4 7/16	1 5/8	2 11/16	76
9/16	13/16	3 5/8	1 1/2	2 3/16	72
9/16	1	4 1/16	1 5/8	2 1/2	73

CHAPTER VII.

BUTT JOINT DOUBLE STRAPPED AND DOUBLE RIVETED.



Where butt straps are used in the construction of marine boilers, the straps for single butt strapping shall in no case be less than the thickness of the shell plates; and where double butt straps are used, the thickness of each shall in no case be less than five-eighths ($\frac{5}{8}$) the thickness of the shell plates.

A rule to find thickness of butt straps is as follows: Multiply the thickness of shell plate by factor 5 and this sum by the wide pitch of rivets in inches minus diameter of one rivet; divide this product by the wide pitch minus two times diameter of rivet multiplied by constant 8.

FORMULA:

$$\frac{T \times F \times (WP - d)}{WP - (2 \times d) \times C} = \text{thickness of each butt strap}$$

LEGEND:

T = thickness of plate = $\frac{7}{16} = .4375$
 d = diameter of rivet = $\frac{7}{8} = .8750$
 WP = wide pitch = $6\frac{3}{4} = 6.7500$
 F = factor = 5
 C = constant = 8

EXAMPLE:

	.4375 = thickness of plate	
	5 = factor	
	<hr/>	
	2.1875 = 5 times thickness	
	5.8750	6.7500 = wide pitch
wide pitch =		<hr/>
twice rivet diam. =	1093750	.8750 = rivet diameter
	<hr/>	
	153125	<hr/>
	5.0000	5.8750
constant =	8	
	<hr/>	
	175000	
	<hr/>	
	109375	
	<hr/>	
	40.0000	12.85150000 (.3212 = thickness of butt strap
	<hr/>	= $\frac{11}{12}$ approximately
	12 0	
	<hr/>	
	85	
	<hr/>	
	80	
	<hr/>	
	51	
	<hr/>	
	40	
	<hr/>	
	115	
	<hr/>	
	80	
	<hr/>	
	35	

When joints have one strap, butt or lap, the rivets are in single shear only. In triple riveted joints, double strap, the two inner rows are in double shear and the outer in single shear.

Rule to find strength of a solid strip of plate or resistance to a tensile strength: Multiply width of strip by thickness of plate and this product by the tensile strength of material.

FORMULA:

$$W \times T \times TS = \text{strength of solid plate}$$

LEGEND:

- W = width of strip = 6.3750
- T = thickness of plate = .4375
- TS = tensile strength = 60000

EXAMPLE:

	6.3750 = width of strip
	.4375 = thickness of plate
	<hr/>
	318750
	<hr/>
	446250
	<hr/>
	191250
2	<hr/>
	55000
	<hr/>
	2.78906250
	<hr/>
	60000 = tensile strength
	<hr/>
	167343.75000000

167,343 lbs. = strength of solid plate

BUTT JOINT, DOUBLE STRAP AND DOUBLE RIVETED.

Possible causes for failure.

- First. Resistance to tearing of plate at outer row of rivets.
- Second. Resistance to shearing of two rivets in double shear and one in single shear.
- Third. Resistance to tearing of plate at inner row of rivets and shearing one of the outer row single shear.
- Fourth. Resistance to crushing in front of three rivets.
- Fifth. Crushing in front of two rivets and shearing one rivet.

LEGEND:

- T = thickness of plate = $\frac{7}{16} = .4375$
- dh = diameter of rivet hole = $\frac{13}{16} = .8125$
- D = diameter of boiler = 60"
- p = pitch of rivets = $4\frac{3}{8} = 4.3750$
- TS = tensile strength = 60000
- A = area of rivet hole = $\frac{13}{16} = .5185$
- SS = shearing strength of rivet, single shear = 38000
- DS = " " " " double " = 70300
- N = number of rows of rivets = 2
- CS = crushing strength of material = 95000
- F = factor of safety = 5

- First. Resistance to tearing at outer row of rivets.

FORMULA:

$$(p - dh) \times T \times TS = \text{net section of plate}$$

EXAMPLE:

$$4.3750 = \text{pitch of rivet}$$

$$.8125 = \text{diameter of rivet hole}$$

$$\begin{array}{r} 3.5625 \\ .4375 = \text{thickness of plate} \end{array}$$

$$\begin{array}{r} 178125 \\ 249375 \\ 106875 \\ 142500 \end{array}$$

$$1.55859375 \quad 60000 = \text{tensile strength}$$

$$93515.82500000$$

93,515 lbs. = strength of net section of plate.

- Second. The resistance to shearing two rivets in double shear and one in single shear.

FORMULA:

$$A \times N \times DS + (A \times SS) = \text{total shearing strength of rivets}$$

EXAMPLE:

	. 5185 = area of rivet hole	
	2 = number of rows of rivets	
	<hr style="width: 50px; margin-left: auto; margin-right: 0;"/>	
	1. 0370	
	70300 = shearing strength	
	<hr style="width: 50px; margin-left: auto; margin-right: 0;"/>	double shear
area of rivet = . 5185	3111000	
single shearing strength = 38000	<hr style="width: 50px; margin-left: auto; margin-right: 0;"/>	72590
	4148 0000	72901. 10000
	<hr style="width: 50px; margin-left: auto; margin-right: 0;"/>	19703. = area multiplied by SS
	15555	
	<hr style="width: 50px; margin-left: auto; margin-right: 0;"/>	
	19703. 00000	92604 lbs. = total shearing strength of rivets

Third. The resistance to tearing at inner row of rivets and shearing of one rivet.

FORMULA:

$$(p - 2dh) \times T \times TS + (A \times SS) = \text{resistance to tearing at inner row}$$

EXAMPLE:

	4. 3750 = pitch of rivets	
	1. 6250 = two diameters of rivet hole	
	<hr style="width: 50px; margin-left: auto; margin-right: 0;"/>	
	2. 7500	
	. 4375 = thickness of plate	
	<hr style="width: 50px; margin-left: auto; margin-right: 0;"/>	
	137500	
	192500	
	82500	
	<hr style="width: 50px; margin-left: auto; margin-right: 0;"/>	
	1 10000	
	<hr style="width: 50px; margin-left: auto; margin-right: 0;"/>	
	1. 20312500	
	<hr style="width: 50px; margin-left: auto; margin-right: 0;"/>	60000 = tensile strength
	72187. 500000000	
	<hr style="width: 50px; margin-left: auto; margin-right: 0;"/>	19703 = area multiplied by SS
	<hr style="width: 50px; margin-left: auto; margin-right: 0;"/>	
	91890 lbs. = resistance to tearing at inner row of rivets	

Fourth. The resistance to crushing in front of three rivets.

FORMULA:

$$dh \times 3 \times T \times CS = \text{resistance to crushing}$$

THE BOILER.

EXAMPLE:

.8125 = diameter of rivet
3 = three rivets

2.4375
.4375 = thickness of plate

121875
170625
73125
97500

1.06640625
95000 = crushing strength

5332 03125000
95976 5625

101308 ~~.59375000~~ lbs. = resistance to crushing strength
in front of three rivets

Fifth. The resistance to crush in front of two rivets and shearing of one rivet

FORMULA:

$2 \times T \times CS + (A \times SS)$ = resistance to crushing plate and shearing one rivet

EXAMPLE:

.4375 = thickness of plate
2 = two rivets

.8750 = twice thickness of plate
95000 = crushing strength

43750000
78750

83125 ~~.0000~~
19703 = area multiplied by SS

102828 lbs. = resistance to crushing plate and
shearing one rivet

Strength of solid plate.

FORMULA:

$p \times T \times TS$ = strength of solid plate

EXAMPLE:

4.3750 = pitch
.4375 = thickness of plate

218750
306250
131250
1 75000

1.91406250
60000 = tensile strength

114843 ~~.750000000~~ lbs. = strength of solid plate

To find efficiency of joint from these computations: Divide weakest section of plate by strength of solid plate.

EXAMPLE:

Weakest section of plate = 91890

Strength of solid plate = 114843

$$\frac{114843 \times 91890.00}{91874 \ 4} (.80 = \text{efficiency of joint})$$

15 60

Rule to find safe working pressure from joint efficiency: Multiply tensile strength of plate by joint efficiency and multiply that product by twice the thickness of plate; divide by diameter of boiler multiplied by factor of safety.

FORMULA:

$$\frac{TS \times \% \times (2 \times T)}{D \times F} = \text{safe working pressure}$$

EXAMPLE:

60000 = tensile strength

.80 = efficiency of joint

$$\frac{48000.00}{.8750}$$

240000

diameter of boiler = 60'' 3360000

factor = 5 3840000

$$\frac{300) 42000.0000}{300} (140 \text{ lbs.} = \text{working pressure})$$


$$\frac{1200}{1200}$$

0

DOUBLE RIVETED BUTT JOINTS.

Thickness of Plate.	Diameter of Rivets.	Pitch of Rivets in Inches.	Width of Outside Butt Strap.	Width of Inside Butt Strap.	Thickness of Covering Straps.	Vertical or Transverse Pitch.	Edge of Butt Strap to Center of Rivets.	Pitch of Rivets. Girth Seam.	Edge of Plate to Center of Rivets. Girth Seam.	Strength of Joint. Per Cent.
$\frac{1}{8}$ in	$\frac{1}{4}$ in	$2\frac{1}{4} \times 4\frac{1}{2}$	$4\frac{1}{2}$ in	9 in	$\frac{1}{4}$ in	$2\frac{1}{4}$ in	$1\frac{1}{8}$ in	$2\frac{1}{8}$ in	$1\frac{1}{8}$ in	83
" "	$\frac{3}{4}$ "	$2\frac{3}{8} \times 4\frac{3}{4}$	$4\frac{7}{8}$ "	$9\frac{7}{8}$ "	$\frac{5}{16}$ "	$2\frac{7}{8}$ "	$1\frac{1}{4}$ "	$2\frac{1}{8}$ "	$1\frac{3}{8}$ "	82.9
" "	$\frac{1}{2}$ "	$2\frac{1}{2} \times 4\frac{1}{2}$	$5\frac{1}{4}$ "	$10\frac{1}{2}$ "	$\frac{3}{8}$ "	$2\frac{5}{8}$ "	$1\frac{1}{2}$ "	$2\frac{1}{4}$ "	$1\frac{3}{4}$ "	82
" "	$\frac{7}{8}$ "	$2\frac{1}{2} \times 5\frac{1}{8}$	$5\frac{3}{8}$ "	$11\frac{1}{4}$ "	$\frac{7}{16}$ "	$2\frac{1}{2}$ "	" "	$2\frac{1}{4}$ "	$1\frac{3}{4}$ "	80

BUTT JOINT DOUBLE STRAPPED TRIPLE RIVETED.



Rule to find diagonal pitch of rivets for a butt joint double strap and triple riveted:

To the horizontal pitch multiplied by 6 add diameter of rivet multiplied by 4 and divide result by 10.

FORMULA:

$$\frac{(Hp \times C6) + (d \times C4)}{10} = \text{diagonal pitch}$$

LEGEND:

Hp = horizontal pitch = 3.3750
 d = diameter of rivet = .8750

EXAMPLE:

<p>horizontal pitch = 3.3750</p> $\begin{array}{r} 3.3750 \\ \times 6 \\ \hline 20.2500 \\ 3.5000 \\ \hline 23.7500 \end{array}$	<p>diameter of rivet = .8750</p> $\begin{array}{r} .8750 \\ \times 4 \\ \hline 3.5000 \end{array}$
<p>10) 23.7500 (2.3750 = diagonal pitch</p> $\begin{array}{r} 23.7500 \\ \underline{20} \\ 37 \\ \underline{30} \\ 75 \\ \underline{70} \\ 50 \\ \underline{50} \\ 0 \end{array}$	

Rule to find distance between inner rows of rivets in a butt joint, double or triple riveted chain or zig zag form. Multiply 11 times the pitch plus 8 times the rivet diameter by the pitch, plus 8 times the rivet diameter; extract square root of this product and divide the sum by 10.

FORMULA:

$$\frac{\sqrt{(11 \times p + 8 \times d) \times (p + 8 \times d)}}{10} = \text{distance between rows of rivets}$$

LEGEND:

p = narrow pitch = $3\frac{3}{8} = 3.375$
 d = diameter of rivet = .875

EXAMPLE:

3.375 = narrow pitch
 11 = 11 times

```

    37.125
    7.000
    -----
    44.125
    10.375
    -----
    220625
     3 08875
    13 2375
    441 25
    -----
    
```

```

    .875 = rivet diam.
     8
    -----
    7.000 = 8 times rivet diam.

    3.375 = narrow pitch
    7.000 = 8 times diam. rivet
    -----
    10.375
    
```

2) 458.796875 (21.419
 4

41) 58
 41

424) 1779
 1696

4281) 8368
 4281

42829) 408775
 385461

23314

10) 21.419
 2.1419 = $2\frac{1}{8}$ approximate distance

Rule to find pitch of rivets in a butt joint double strap and triple riveted inner row: Multiply thickness of plate by 3.5 and add $1\frac{5}{8}$ of an inch to product.

LEGEND:

T = thickness of plate = $\frac{7}{16} = .4375$
 p = pitch $3.5 = 3.5000$
 $1\frac{5}{8} = 1.6250$

FORMULA:

$$T \times 3.5 + 1\frac{5}{8} = \text{pitch}$$

THE BOILER.

EXAMPLE:

$$\begin{array}{r}
 .4375 = \text{thickness of plate} \\
 \underline{3.5} \\
 21875 \\
 \underline{13125} \\
 1.53125 \\
 1.6250 = 1\frac{5}{8} \\
 \underline{\hspace{1.5em}} \\
 3.15625 = 3\frac{5}{32} \text{ pitch}
 \end{array}$$

Rule to find plate percentage at wide pitch: From wide pitch subtract diameter of rivet and divide this product by wide pitch of rivet.

FORMULA:

$$\frac{\text{WP} - d}{\text{WP}} = \text{plate percentage}$$

LEGEND:

$$\begin{array}{l}
 \text{WP} = \text{wide pitch} = 6.7500 \\
 d = \text{rivet diameter} = 1\frac{1}{8} = .9375
 \end{array}$$

EXAMPLE:

$$\begin{array}{r}
 6.7500 = \text{pitch of rivet} \\
 .9375 = \text{diameter of rivet} \\
 \underline{\hspace{1.5em}} \\
 \text{wide pitch} = 6.7500) 5.812500 (.86 = \text{plate percentage at wide pitch} \\
 \underline{5 \quad 40000} \\
 412500 \\
 \underline{405000} \\
 7500
 \end{array}$$

Rule to find percentage of plate at narrow pitch: From narrow pitch subtract rivet diameter and divide this product by narrow pitch.

FORMULA:

$$\frac{\text{NP} - d}{\text{NP}} = \text{plate percentage}$$

LEGEND:

$$\begin{array}{l}
 \text{NP} = \text{narrow pitch} = 3.5000 \\
 d = \text{rivet diameter} = 1\frac{1}{8} = .9375
 \end{array}$$

EXAMPLE:

$$\begin{array}{r}
 3.5000 = \text{narrow pitch} \\
 .9375 = \text{rivet diameter} \\
 \hline
 \text{narrow pitch} = 3.5000 \times 2.562500 \quad (.73 = \text{plate percentage at narrow pitch}) \\
 \hline
 2.45000 \\
 \hline
 112500 \\
 105000 \\
 \hline
 7500
 \end{array}$$

Rule to find safe working pressure on a boiler butt joint double strap, triple riveted: Multiply tensile strength of material by the lowest percentage of joint and this sum by twice the thickness of plate; divide by diameter of boiler multiplied by factor of safety.

FORMULA:

$$\frac{\text{TS} \times \% \times (T \times 2)}{D \times F} = \text{safe working pressure}$$

LEGEND:

- TS = tensile strength = 60000
- % = lowest percentage of joint = 73%
- T = thickness of plate = $\frac{1}{8}$ = .4375
- D = diameter of boiler = 72"
- F = factor of safety = 5

EXAMPLE:

$$\begin{array}{r}
 60000 = \text{tensile strength} \\
 .73 = \text{lowest percentage of joint} \\
 \hline
 180000 \\
 420000 \\
 \hline
 43800.00 \\
 .8750 = \text{twice thickness of plate} \\
 \hline
 219000000 \\
 \text{boiler diam.} = 72 \quad 30660000 \\
 \text{factor} = 5 \quad 35040000 \\
 \hline
 360) 38325.000000 \quad (106 \text{ lbs. working pressure} \\
 \underline{360} \\
 2325 \\
 \underline{2160} \\
 165
 \end{array}$$

TRIPLE RIVETED BUTT JOINTS.

Plate thickness.	Diameter of rivet.	Thickness of strap.	Width of outer strap.	Width of inner strap.	Pitch of inner row of rivets.	Pitch of outer row of rivets.	Distance between middle and outer row of rivets.	Distance between inner and middle row.	Distance inner row to edge of butt.	Efficiency.
1/4	1/2	1/4	6 1/2	11 3/8	2 1/4	4 1/2	2 3/8	1 1/2	1 5/8	87
3/8	5/8	1/4	6 3/4	12 3/8	2 3/8	4 3/8	2 3/8	1 1/2	1 3/4	86
1/2	7/8	1/4	9 1/4	14	3 1/8	6 1/4	2 3/8	2 1/8	2 1/2	88
5/8	1	1/4	9 1/4	14	3 1/8	6 1/4	2 3/8	2 1/8	2 1/2	88
3/4	1 1/8	3/8	9 3/4	14 1/4	3 1/4	6 1/2	2 1/2	2 3/8	2 1/8	87
7/8	1 1/4	3/8	9 3/4	14 1/4	3 1/4	6 1/2	2 1/2	2 3/8	2 1/8	87
1	1 1/2	3/8	10 1/8	15 5/8	3 3/8	6 3/4	2 3/4	2 1/4	2 1/8	86
1 1/8	1 3/4	3/8	10 3/8	16	3 1/2	7	2 1/2	2 3/8	2 1/8	86
1 1/4	1 7/8	7/8	11	16 1/4	3 3/4	7 1/2	3	2 3/8	3	86
1 1/2	2	7/8	11 5/8	18	3 7/8	7 3/4	3 3/8	2 5/8	3 3/16	85
1 3/4	2 1/8	1	11 5/8	18	3 7/8	7 3/4	3 3/8	2 5/8	3 3/16	85
2	2 1/4	1 1/2	11 5/8	18	3 7/8	7 3/4	3 3/8	2 5/8	3 3/16	84

COMPUTING STRENGTH OF A BUTT JOINT DOUBLE STRAP AND TRIPLE RIVETED.

There are five causes for failure at a butt joint double strap and triple riveted, as follows:

- First. By tearing at outer row of rivets.
- Second. By shearing of four rivets in double shear and one in single shear.
- Third. By the tearing at middle row of rivets and the shearing of one rivet.
- Fourth. By the crushing in front of four rivets and shearing of one rivet.
- Fifth. By the crushing in front of five rivets, four through strap, the fifth through inner covering of plate only.

LEGEND:

- D = diameter of boiler = 72"
- ID = internal diameter of boiler = 71.1250
- F = factor = 5
- TS = tensile strength = 60000
- P = pressure
- Pt = pitch inner row = 3 3/8 = 3.375
- Po = pitch outer row = 6 3/4 = 6.750
- SS = shearing strength of rivets = 38000
- CS = crushing resistance = 95000
- T = thickness of plate = 7/8 = .4375
- d = diameter of rivet = 7/8 = .8750
- DH = diameter of rivet hole = 1 1/8 = .9375
- A = area of rivet = .6903
- CP = cover plate or thickness of strap = .3750

First. The failure by tearing at the outer row of rivets, the resistance is found by the following rule: From pitch of rivet subtract the diameter of rivet and multiply by thickness of plate and then multiply by tensile strength of material.

FORMULA:

$$(P_o - DH) \times T \times TS = \text{net section of plate}$$

EXAMPLE:

6.7500 = wide pitch
 .9375 = diameter of rivet hole

5.8125
 .4375 = thickness of plate

290625
406875
174375
2 32500
2.54296875
60000 = tensile strength of plate
152578.12500000 lbs. = net section of plate

Second. Shearing of four rivets in double shear and one in single shear.

FORMULA:

$$A \times N \times DS + 1d \text{ of SS} = \text{strength of rivets}$$

N = number of rivets = 4
 for double shear

EXAMPLE:

.6903 = area of $\frac{11}{16}$ rivet
 4 = number of rivets. double shear

2.7612
70300 = strength of rivets double shear
8283600
193284
194112.3000
26231. = single shearing strength one rivet
220343. lbs. = strength of rivets

area of rivet = .6903
single shearing re- = 38000
sistance
55224000
20709
26231.4000

Third. Tearing at middle row of rivets and shearing of one rivet, the resistance is:

FORMULA:

$$(P_o - 2DH) \times T \times TS \text{ plus } (A \times SS) = \text{resistance to tearing of plate at middle row and shearing one rivet}$$

THE BOILER.

EXAMPLE :

6.7500 = wide pitch
 1.8750 = 2 diameters of rivet hole

4.8750
 .4375 = thickness of plate

243750
 341250
 146250
 1 95000

2.13281250
 60000 = tensile strength

127968.75000000
 26231. = shearing strength one rivet single
 shear
 154199. lbs. = resistance to tearing at middle row
 and shearing one rivet

Fourth. Crushing in front of four rivets and shearing of one rivet.

FORMULA :

$(4DH \times T \times CS) \text{ plus } (A \times SS)$ = resistance to crushing in front of four rivets
 and shearing one rivet

EXAMPLE :

3.7500 = four diameters of rivet hole
 .4375 = thickness of plate

187500
 262500
 112500
 1 50000

1.64062500
 95000 = crushing strength of rivet
 material

820312500000
 14765625

155859.37500000
 26231 = shearing strength one rivet single
 shear

182090. lbs. = resistance to crushing in front of
 four rivets and shearing of one

Fifth. Crushing in front of five rivets, four through straps, the fifth through
 inner cover plate only, the resistance is:

FORMULA :

$(4DH \times T \times CS) \text{ plus } (DH \times CP \times CS)$ = resistance to crushing of plate in
 front of five rivets

EXAMPLE:

diameter of rivet hole = .9375	3.7500 = four diameters of rivet hole
strap thickness = .3750	.4375 = thickness of plate
<u>468750</u>	<u>187500</u>
65625	262500
28125	112500
<u>35156250</u>	<u>150000</u>
crushing strength of rivet = 95000	1.64062500
<u>175781250000</u>	<u>95000 = crushing strength of rivet</u>
316406250	820312500000
<u>33398. 437500000</u>	<u>1476562500</u>
	155859. 375000000
	<u>33398</u>
	189257 lbs. = crushing strain of plate in front of five rivets

Rule to find strength of strip of plate at wide pitch.

FORMULA:

$$P_o \times T \times TS = \text{strength of plate at wide pitch}$$

EXAMPLE:

6.7500 = wide pitch	
.4375 = thickness of plate	
<u>337500</u>	
472500	
202500	
2 70000	
<u>2.95312500</u>	
	60000 = tensile strength
<u>177187. 500000000</u>	lbs. = strength of strip of plate at wide pitch

Rule to find efficiency of joint from these calculations.

LEGEND:

152578 = strength of net section of plate
 177187 = strength of solid plate

EXAMPLE:

177187) 152578.00	(.86 = efficiency of joint
<u>141749 6</u>	
10828 40	
<u>10631 22</u>	
197 18	

THE BOILER.

Rule to find safe working pressure from efficiency of joint: Multiply tensile strength of plate by percentage of joint; multiply this sum by twice thickness of plate and divide product by diameter multiplied by factor of safety. The quotient will be the safe working pressure of boiler.

FORMULA:

$$\frac{TS \times \% \times (2 \times T)}{ID \times F} = \text{safe working pressure}$$

EXAMPLE:

60000 = tensile strength of plate
 .86 = percentage of joint

3600 00
 48000 0

51600.00
 .8750 = twice thickness of plate

internal diam. of boiler = 71.1250 258 000000
 factor of safety = 5 41280 000

355.6250)45150.000000 (126.95 = safe working pressure
 3556250

9587500
 7112500


24750000
 21337500

34125000
 32006250

21187500
 17781250

3406250

QUADRUPLE-RIVETED BUTT JOINT.



Computing strength of a quadruple-riveted butt joint.

Causes for possible failure in a butt joint double strap and quadruple riveted:

- First. Tearing of plate through the line of rivets at outer row.
- Second. Tearing of plate through line of rivets at second outer row and shearing of outer row of rivets.
- Third. Failure of plate through second row of narrow pitch and shearing of the two outer rows of rivets
- Fourth. By shearing of all rivets.

LEGEND:

- TS = tensile strength = 60000
- SS = shearing strength of rivets material = 38000
- CS = crushing strain of material = 95000
- T = thickness of plate = $\frac{7}{8}$ = .4375
- D = diameter of boiler = 72"
- d = diameter of rivets = $\frac{13}{8}$ = .8125
- DH = diameter of rivet hole = $\frac{7}{8}$ = .8750
- A = area of rivets = $\frac{7}{8}$ = .6013
- PN = narrow pitch = $4\frac{1}{8}$ = 4.0625
- PW = wide pitch = $8\frac{1}{8}$ = 8.125
- Po = outside pitch = $16\frac{1}{4}$ " = 16.2500 or width of strap
- N = number of rivets

In connection with this problem it is assumed that the straps or cover plates are three fourths ($\frac{3}{4}$) the thickness of shell plates. Calculations will be made according to points of possible failures.

- First. Tearing of plate through the line of rivets at outer row.

FORMULA:

Po—d = section of plate to resist tearing

THE BOILER.

EXAMPLE:

16.2500 = outside pitch
 .8750 = diameter of $\frac{7}{8}$ rivet hole

15.3750 = section of plate to resist tearing
 less diameter of rivet

To calculate the efficiency of a joint it will be necessary to find out strength of solid plate in strip calculated.

16.2500 = pitch outside row
 .4375 = thickness of plate

812500
 1137500
 487500
 650000

7.10937500
 60000 = tensile strength

426562.50000000 lbs. = strength of solid plate
 at point of calculation.

Second. Tearing of plate at line of rivets next to outer row.

FORMULA:

$(P_o - 2DH) \times T \times TS + SS$ of 1d = resistance to tearing of plate at line of 2d
 outer row

EXAMPLE:

16.2500 = outer pitch or width of strip
 1.7500 = two diameters of rivet hole

14.5000
 .4375 = thickness of plate

725000
 1015000
 435000
 580000

6.34375000
 60000 = tensile strength of plate

380625.00000000
 380625 = lbs. resistance to tearing of plate at second outer row
 22849 = strength of the one rivet in outer row

403474 = lbs. resistance at that part of joint

Third. Failure of plate through second row of rivets in narrow pitch and shearing of the two outer rows of rivets.

FORMULA:

$(P_o - 4DH) \times T \times TS + SS$ of 3d = lbs. resistance in width of strip

EXAMPLE :

$ \begin{array}{r} .6013 = \text{area of one rivet} \\ 38000 = \text{shearing strength} \\ \text{of rivet} \\ \hline 48104000 \\ 18039 \\ \hline 22849.4000 \\ 3 = \text{three rivets} \\ \hline 68548.2000 \end{array} $	$ \begin{array}{r} 16.2500 = \text{width of strip of plate outer row} \\ 3.5000 = \text{diameter of four rivet hole} \\ \hline 12.7500 \\ .4375 = \text{thickness of plate} \\ \hline 637500 \\ 892500 \\ 382500 \\ 510000 \\ \hline 5.57812500 \\ 60000 = \text{tensile strength} \\ \hline 334687.50000000 \\ 68548 = \text{shearing strength of three rivets in} \\ \text{outer rows} \\ 403235 = \text{lbs. resistance through net section} \\ \text{of plate} \end{array} $
---	--

Fourth. Point of possible failure by shearing of all rivets. There being three rivets in single shear and eight in double shear.

FORMULA :

$A \times SS \times N = \text{single shear} + N \text{ in double shear} = \text{shearing strength of rivets in joint}$

EXAMPLE :

$ \begin{array}{r} .6013 = \text{area of } \frac{7}{8} \text{ rivet} \\ 38000 = \text{shearing strength in single} \\ \text{shear} \\ \hline 48104000 \\ 18038 \\ \hline 22849.4000 \\ 3 = \text{number of rivets in single shear} \\ \hline 68548.2000 = \text{shearing strength of 3 rivets in} \\ \text{single shear} \\ .6013 = \text{area of } \frac{7}{8} \text{ rivet} \\ 70300 = \text{shearing strength in double shear} \\ \hline 1803900 \\ 420910 \\ \hline 42271.3900 \\ 8 = \text{number of rivets} \\ \hline 338171.1200 \end{array} $	$ \begin{array}{r} 334687.50000000 \\ 68548 = \text{shearing strength of three rivets in} \\ \text{outer rows} \\ 403235 = \text{lbs. resistance through net section} \\ \text{of plate} \end{array} $
--	--

Add this latter product to the sum of three rivets in single shear, which gives the total shearing strength of rivets in joint.

$ \begin{array}{r} 68548 = \text{shearing strength of 3 rivets in single shear} \\ 338171 = \text{shearing strength of 8 rivets in double shear} \\ \hline 406719 \text{ lbs.} = \text{total shearing strength of rivets in joint} \end{array} $	
---	--

THE BOILER.

To get the efficiency of joint at this point: Divide resistance of net section of plate by strength of solid plate.

EXAMPLE:

403235 = resistance through net section of plate
 426562 = strength of solid plate

$$\begin{array}{r}
 426562)403235.000 (.945 = \text{per cent. of efficiency} \\
 \underline{3839058} \\
 1932920 \\
 \underline{1706248} \\
 2266720 \\
 \underline{2132810} \\
 133910
 \end{array}$$

Rule to find safe working pressure for boiler from these calculations: Multiply tensile strength by lowest percentage and by twice thickness of plate; divide this product by diameter multiplied by factor of safety.

FORMULA:

$$\frac{TS \times \% \times 2T}{D \times F} = \text{safe working pressure}$$

EXAMPLE:

$$\begin{array}{r}
 60000 = \text{tensile strength} \\
 .945 = \text{lowest percentage of joint} \\
 \underline{56700.000} \\
 300000 \\
 \underline{240000} \\
 540000 \\
 56700.000 \\
 .8750 = \text{twice thickness of plate} \\
 \underline{283500000} \\
 \text{diam. of boiler} = 72'' \quad 396900000 \\
 \text{factor of safety} = 5 \quad \underline{453600000} \\
 360)49612.5000000 (137.8 = \text{lbs. safe working pressure} \\
 \underline{360} \\
 1361 \\
 \underline{1080} \\
 2812 \\
 \underline{2520} \\
 2925 \\
 \underline{2880} \\
 45
 \end{array}$$

Butt straps or cover plates of a quadruple riveted joint.

Possible causes for failure of butt straps.

- First. Both straps breaking across the inner row of rivets.
- Second. The plate and inner strap breaking through line of next to inner row of rivets.
- Third. The inner strap breaking through the inner row of rivets and shearing rivets.
- Fourth. The outer strap breaking through the inside row of rivets and shearing of rivets.

LEGEND:

- DH = diameter of rivet hole = $\frac{7}{8} = .8750$
- TS = tensile strength = 60000
- Po = outer pitch = 16.2500
- T = thickness of strap = .3750

First possible cause. Both straps breaking across the inner row of rivets.

FORMULA.

$$(Po - 4DH) \times T \times N \times TS = \text{tensile strength of two straps}$$

EXAMPLE:

$$\begin{array}{r}
 16.2500 = \text{outer pitch} \\
 3.5000 = \text{four rivet hole diameters} \\
 \hline
 12.7500 \\
 .3750 = \text{thickness of strap} \\
 \hline
 6375000 \\
 892500 \\
 3 \ 82500 \\
 \hline
 4.78125000 = \text{square inches of material at} \\
 \qquad \qquad \qquad 2 \ \text{straps (point of possible fracture)} \\
 \hline
 9.56250000 = \text{total number of square inches} \\
 60000 = \text{tensile strength} \\
 \hline
 573750.00000000 \ \text{lbs.} = \text{tensile strength of the two straps}
 \end{array}$$

Showing strength of straps section stronger than plate section.

Second. Point of possible failure—the resistance to fracture at this point is greater than first possible cause.

Third. Possible cause for failure by breaking of strap through line of rivet holes at inner row.

FORMULA:

$$(Po - 4DH) \times T \times TS + (N \times SS) = \text{total resistance to tear plate and shear rivets.}$$

THE BOILER.

EXAMPLE:

16.2500 = outer pitch
 3.5000 = four rivet hole diameters

12.7500
 .3750 = thickness of plate

6375000
 892500
 3 82500

4.78125000
 60000 = tensile strength

286875. ~~00000000~~
 182792 = rivet strength

469667 lbs. = resistance to tear plate and shear rivets

22849 = shearing resistance single shear of $\frac{7}{8}$ rivets
 8 = number of rivets

182792

Fourth. Point of possible failure—same as third point.

These calculations show the straps resistance to strain exceeds the shell plate.

TABLE OF PRESSURE ALLOWABLE ON BOILERS MADE SINCE FEBRUARY 28, 1872.

Diam-eter of boiler.	Thick-ness of plates.	45,000 tensile strength, 1-6, 7,500.		50,000 tensile strength, 1-6, 8,333.3.		55,000 tensile strength, 1-6, 9,166.6.		60,000 tensile strength, 1-6, 10,000.		65,000 tensile strength, 1-6, 10,833.3.		70,000 tensile strength, 1-6, 11,666.6.		Diam-eter of boiler.
		Pres-sure.	20 per cent ad-ditional.	Pres-sure.	20 per cent ad-ditional.	Pres-sure.	20 per cent ad-ditional.	Pres-sure.	20 per cent ad-ditional.	Pres-sure.	20 per cent ad-ditional.	Pres-sure.	20 per cent ad-ditional.	
36 inches	.1875	78.12	83.74	86.8	104.16	95.48	114.57	104.16	124.99	112.84	135.4	121.52	145.82	36 inches
	.21	87.5	93.75	97.21	116.65	106.94	128.33	116.96	139.99	126.36	151.65	136.11	163.33	
	.23	95.83	102.08	106.47	127.76	115.72	140.54	127.76	153.32	138.41	166.09	149.07	178.38	
	.25	104.16	110.42	115.74	138.88	127.31	152.77	138.88	166.65	150.46	180.55	162.03	194.43	
	.26	108.33	114.99	120.37	144.44	132.4	158.88	144.44	173.32	156.48	189.77	168.51	202.21	
	.29	120.83	126.99	134.25	161.11	147.68	177.21	161.11	193.33	176.53	209.43	187.96	225.55	
	.3125	130.2	138.24	144.67	173.6	159.14	190.96	173.6	208.32	188.07	225.68	202.5	243.04	
	.33	137.5	145.58	152.77	183.32	168.05	201.66	183.32	219.99	198.61	235.33	213.88	256.65	
	.35	145.83	153.87	162.03	194.43	178.23	213.87	194.43	233.32	210.64	252.76	226.84	272.20	
	.375	156.25	164.08	173.61	208.33	190.97	229.16	208.33	249.99	225.69	270.83	243.05	291.66	
38 inches	.1875	74.01	88.81	82.23	98.67	90.46	108.54	98.68	118.41	106.4	128.28	115.13	138.16	38 inches
	.21	82.89	99.46	92.1	110.52	101.31	121.57	110.52	132.62	119.73	143.67	128.93	154.71	
	.23	90.78	108.93	100.87	121.04	110.96	133.15	121.05	145.26	131.13	157.35	141.22	169.46	
	.25	98.68	118.41	109.64	131.56	120.61	144.73	131.57	157.88	142.54	171.04	153.5	184.20	
	.26	102.63	123.15	114.03	136.83	125.43	150.51	136.84	164.2	148.24	177.88	159.64	191.56	
	.29	114.47	137.36	127.19	152.62	139.91	167.89	152.63	183.15	165.35	198.42	178.06	213.67	
	.3125	123.35	148.02	137.06	164.46	150.76	180.91	164.47	197.36	178.17	213.8	191.88	230.25	
	.33	130.26	156.31	144.73	173.67	159.2	191.04	173.68	208.41	188.15	225.78	202.62	243.14	
	.35	138.15	165.78	153.5	184.21	168.85	202.62	184.21	221.05	199.56	239.47	214.91	257.89	
	.375	148	177.60	164.73	197.67	180.91	217.09	197.67	236.83	213.81	256.57	230.26	276.31	
40 inches	.1875	70.31	84.37	78.12	93.74	85.93	103.11	93.75	112.5	101.56	121.87	109.37	131.24	40 inches
	.21	78.75	94.50	87.49	104.98	96.24	115.48	104.98	126	113.74	136.48	122.49	146.98	
	.23	86.25	103.5	95.83	114.99	105.41	126.49	114.99	138	124.58	149.49	134.16	160.99	
	.25	93.75	112.5	104.16	124.99	114.58	137.49	124.99	150	135.41	162.49	145.83	174.99	
	.26	97.5	117.5	108.33	129.99	119.16	142.99	130	150	140.83	168.99	151.66	181.99	
	.29	108.75	130.5	120.83	144.99	132.90	159.49	143	174	157.08	188.99	169.16	202.99	
	.3125	117.18	140.61	130.2	156.24	143.22	171.86	156.25	187.45	169.27	203.12	182.29	218.74	
	.33	123.75	148.5	137.49	164.98	151.24	181.48	165	198	178.74	214.48	192.49	230.98	
	.35	131.25	157.5	145.83	174.99	160.41	192.49	175	210	189.58	227.49	204.16	244.99	
	.375	140.62	168.74	156.24	187.48	171.87	206.24	187.5	225	209.12	243.74	218.74	262.48	
42 inches	.1875	66.96	80.35	74.40	89.28	81.84	98.20	89.28	107.13	96.72	116.06	104.16	124.99	42 inches
	.21	75	90	83.32	99.99	91.66	109.99	99.52	120	108.33	139.99	116.66	139.99	
	.23	82.14	98.56	91.23	109.51	100.39	120.46	109.52	131.42	118.65	142.38	127.77	153.32	
	.25	89.28	107.13	99.2	119.04	109.12	136.94	119.04	142.86	124.96	154.75	138.88	166.65	
	.26	92.85	111.42	103.17	123.8	113.49	139.18	123.8	148.56	134.12	160.94	144.44	173.32	

THE STEAM BOILER.

TABLE OF PRESSURE ALLOWABLE ON BOILERS MADE SINCE FEBRUARY 28, 1872.

Diam-eter of boiler.	Thick-ness of plates.	45,000 tensile strength, 1-6, 7,500.		50,000 tensile strength, 1-6, 8,333.3.		55,000 tensile strength, 1-6, 9,166.6.		60,000 tensile strength, 1-6, 10,000.		65,000 tensile strength, 1-6, 10,833.3.		70,000 tensile strength, 1-6, 11,666.6.		Diam-eter of boiler.	
		Pres-sure.	20 per cent ad-ditional.	Pres-sure.	20 per cent ad-ditional.	Pres-sure.	20 per cent ad-ditional.	Pres-sure.	20 per cent ad-ditional.	Pres-sure.	20 per cent ad-ditional.	Pres-sure.	20 per cent ad-ditional.		
44 inches	.29	103.57	124.28	115.07	138.08	126.57	151.85	138.09	165.7	149.6	179.52	161.11	193.33	44 inches	
	.3125	111.6	133.02	124	148.74	136.4	163.68	148.74	178.56	157.3	193.44	173.61	208.23		
	.33	117.85	141.42	130.94	157.9	144.04	172.84	158.56	170.23	170.23	204.27	183.33	219.00		
	.35	125	150	138.88	168.65	152.77	182.32	166.66	190.55	180.55	216.66	194.44	233.32		
	.375	133.92	160.7	148.8	178.56	163.68	196.40	178.57	214.28	193.45	232.14	208.33	249.99		
	.1875	63.92	76.7	71.02	85.22	78.12	93.74	85.22	102.26	92.32	110.78	99.42	119.32		
	.21	71.59	85.6	79.54	95.44	87.48	104.98	95.44	114.54	103.34	124.08	111.36	133.63		
	.23	78.4	94.08	87.12	103.44	95.33	114.99	103.44	116.31	103.45	135.9	121.96	146.35		
	.25	85.22	102.26	94.66	113.97	104.16	124.99	113.97	126.35	113.75	147.72	132.56	159.07		
	.26	88.63	108.35	98.48	118.37	108.33	129.99	118.38	130.81	128.02	155.62	137.87	165.44		
	.2925	98.86	118.63	108.34	131.80	120.83	149.99	129.81	148.97	142.76	171.33	153.76	184.53		
	.33	109.53	137.83	128.36	142.08	130.2	156.24	142.04	158.11	153.88	184.65	165.71	198.85		
.35	119.31	148.17	137.57	158.98	137.89	174.98	158.98	180.9	172.34	206.8	181.6	209.98			
.375	127.81	153.37	142.04	170.44	156.24	187.48	170.45	204.94	184.63	221.58	198.86	236.63			
46 inches	.1875	61.14	73.36	67.93	81.51	74.72	89.66	81.51	97.81	88.31	105.97	95.1	114.12	46 inches	
	.21	68.47	82.16	76.08	91.29	83.69	100.42	91.3	109.86	98.01	118.69	106.52	127.82		
	.23	75	90.82	83.33	100	91.66	109.59	100	120	108.23	129.39	116.66	137.62		
	.25	81.52	97.82	90.57	108.68	99.63	119.55	108.69	130.42	117.73	141.3	130.9	150.99		
	.26	84.78	101.73	94.2	113.04	103.62	124.34	113.44	135.94	122.46	146.85	131.88	158.35		
	.2925	94.56	113.47	103.77	126.06	115.57	138.08	126.09	151.3	136.69	163.92	151.1	170.52		
	.3125	101.9	122.78	113.21	135.86	124.54	149.44	135.86	163.03	147.19	186.52	160.31	190.81		
	.33	107.6	129.12	119.56	143.47	131.52	157.82	143.47	172.16	155.43	186.52	167.39	200.66		
	.35	114.13	136.95	126.8	152.8	139.49	167.38	152.8	182.1	164.83	197.82	177.53	213.92		
	.375	122.18	146.73	135.86	163.03	149.45	179.34	163.04	193.64	177.53	211.94	190.21	228.25		
	.1875	58.59	70.30	65.1	78.12	71.61	85.93	78.12	93.74	84.63	101.55	91.13	109.35		48 inches
	.21	65.62	78.74	72.91	87.49	80.24	95.24	87.49	104.88	94.79	113.54	102.08	122.49		
.23	71.87	86.74	79.85	95.82	87.84	105.4	95.83	114.89	103.81	124.57	111.8	132.16			
.25	78.12	93.74	86.8	104.16	95.48	114.57	104.16	124.89	112.84	135.4	121.52	149.82			
.26	81.25	97.50	90.27	108.32	99.3	119.16	108.33	129.89	117.36	140.83	126.38	151.63			
.2925	90.66	108.74	100.69	120.82	110.76	132.91	120.83	144.89	130.9	157.08	140.97	169.16			
.3125	97.65	117.18	108.5	130.2	119.35	143.22	130.21	156.23	141.05	169.26	151.9	182.28			
.33	103.12	123.74	114.58	137.49	126.04	151.24	137.5	165	148.95	178.74	160.41	192.45			
.35	109.37	131.24	121.52	145.83	133.67	160.4	145.83	170.13	158.57	189.57	170.13	204.15			
.375	117.18	140.61	130.2	156.24	143.22	171.86	156.23	187.50	169.27	203.12	182.29	218.74			

THE BOILER.

TABLE OF PRESSURE ALLOWABLE ON BOILERS MADE SINCE FEBRUARY 28, 1872.

Diam-eter of boiler.	Thick-ness of plates.	45,000 tensile strength, 1-6, 7,500.		50,000 tensile strength, 1-6, 8,333.3.		55,000 tensile strength, 1-6, 9,166.6.		60,000 tensile strength, 1-6, 10,000.		65,000 tensile strength, 1-6, 10,833.3.		70,000 tensile strength, 1-6, 11,666.6.		Diam-eter of boiler.
		Pres-sure.	20 per cent ad-ditional.	Pres-sure.	20 per cent ad-ditional.	Pres-sure.	20 per cent ad-ditional.	Pres-sure.	20 per cent ad-ditional.	Pres-sure.	20 per cent ad-ditional.	Pres-sure.	20 per cent ad-ditional.	
54 inches	.1875	52.08	62.49	57.87	69.44	63.65	76.38	69.77	82.44	75.23	90.27	81.01	97.21	54 inches
	.21	58.33	69.99	64.81	77.77	71.29	85.54	77.77	93.32	84.25	101.1	90.74	108.88	
	.23	63.88	76.65	70.98	85.17	78.08	93.69	85.18	102.21	92.28	110.73	99.38	119.25	
	.25	69.44	83.32	77.16	92.59	84.87	101.84	92.59	111.10	100.3	120.36	108.02	129.62	
	.26	72.22	86.66	80.24	96.28	88.27	105.92	96.29	115.54	104.31	125.17	112.44	134.8	
	.29	80.55	96.66	89.5	107.40	98.45	115.14	107.41	128.88	116.35	139.62	125.3	150.36	
	.3125	86.8	104.16	96.44	115.73	106.09	127.30	115.55	138.66	125.38	150.45	135.03	162.03	
	.33	91.66	109.99	101.84	122.22	112.03	134.43	122.42	146.66	132.4	158.88	142.59	171.10	
	.35	97.22	116.66	108.02	129.62	118.82	142.58	129.62	155.54	140.43	168.51	151.23	181.47	
	.375	104.16	124.99	115.74	138.88	127.31	152.77	138.88	166.65	150.46	180.55	162.03	194.43	
60 inches	.1875	46.87	56.24	52.08	62.49	57.29	68.74	62.5	75	67.7	81.24	72.91	87.49	60 inches
	.21	52.5	63	58.33	69.99	64.16	76.99	69.99	84	75.83	90.99	81.66	97.99	
	.23	57.5	69	63.88	76.65	70.27	84.32	76.66	91.99	83.05	99.66	89.44	107.32	
	.25	62.5	75	69.44	83.32	76.38	91.65	83.33	99.99	90.27	108.32	97.22	116.66	
	.26	65	78	72.22	86.66	79.44	95.32	86.66	103.99	93.88	112.65	101.11	121.33	
	.29	72.5	87	80.55	96.66	88.61	106.33	96.66	115.99	104.72	125.66	112.77	135.32	
	.3125	78.12	93.74	86.8	104.16	95.48	114.57	104.18	124.99	112.95	135.64	121.52	145.82	
	.33	82.5	99	91.66	109.99	100.83	120.99	109.99	132	119.16	142.99	128.33	153.99	
	.35	87.5	105	97.22	116.66	106.94	128.32	116.66	139.99	126.38	151.65	136.11	163.33	
	.375	93.75	112.5	104.16	124.99	114.58	137.49	125	150	135.41	162.49	145.83	174.99	
66 inches	.1875	42.61	51.13	47.34	56.8	52.07	62.49	56.81	68.17	61.55	73.86	66.28	79.53	66 inches
	.21	47.72	57.26	53	63.63	58.33	69.99	63.63	76.35	68.93	82.71	74.24	89.08	
	.23	52.27	62.72	58	69.69	63.88	76.65	69.69	83.62	75.07	90.6	81.31	97.57	
	.25	56.81	68.17	63.13	75.75	69.44	83.32	75.75	90.90	82.02	98.48	88.38	106.06	
	.26	59.09	70.9	65.65	78.78	72.22	86.66	78.78	94.53	85.35	102.42	91.91	110.29	
	.29	65.90	79.08	73.23	87.87	80.55	96.66	87.87	105.44	95.2	114.24	102.52	123.02	
	.3125	71	85.2	78.91	94.69	86.89	104.16	94.69	123.09	102.58	123.09	110.47	132.56	
	.33	75	90.2	83.33	99.99	91.66	109.99	99.99	120.27	108.33	127.99	116.66	139.99	
	.35	79.56	95.47	88.38	106.05	97.22	116.66	106.05	127.27	114.89	137.86	123.73	148.47	
	.375	85.22	102.26	94.69	113.62	104.16	124.99	113.62	136.34	123.1	147.72	132.57	159.08	
72 inches	.1875	39.06	46.87	43.4	52.08	47.74	57.28	52.08	62.49	56.42	67.70	60.76	72.91	72 inches
	.21	43.75	52.5	48.6	58.33	53.32	64.16	58.33	69.99	63.19	75.82	68.05	81.66	
	.23	47.91	57.49	53.24	63.88	58.56	70.27	63.88	76.65	69.21	83.05	74.53	89.43	
	.25	52.08	62.49	57.87	69.44	63.65	76.38	69.44	83.32	75.22	90.26	81.01	97.21	
	.26	54.16	64.99	60.18	72.21	66.2	79.44	66.2	86.06	78.24	93.88	84.25	101.10	



THE STEAM BOILER.

TABLE OF PRESSURE ALLOWABLE ON BOILERS MADE SINCE FEBRUARY 28, 1872.

Diam-eter of boiler.	Thick-ness of plates.	45,000 tensile strength, 1-6, 7,500.		50,000 tensile strength, 1-6, 8,333.3.		55,000 tensile strength, 1-6, 9,166.6.		60,000 tensile strength, 1-6, 10,000.		65,000 tensile strength, 1-6, 10,833.3.		70,000 tensile strength, 1-6, 11,666.6.		Diam-eter of boiler.	
		Pres-sure.	20 per cent ad-ditional.	Pres-sure.	20 per cent ad-ditional.	Pres-sure.	20 per cent ad-ditional.	Pres-sure.	20 per cent ad-ditional.	Pres-sure.	20 per cent ad-ditional.	Pres-sure.	20 per cent ad-ditional.		
78 inches	.29	60.41	72.49	67.12	80.54	73.84	88.60	80.55	96.66	87.26	104.71	93.98	112.77	78 inches	
	.3125	65.10	78.12	72.33	86.8	79.57	95.48	86.8	104.16	94.03	112.83	101.27	121.32		
	.33	69.75	82.5	76.38	91.65	84.02	100.82	91.66	109.99	99.3	119.16	106.94	128.32		
	.35	72.91	87.49	81.01	97.21	89.11	106.93	97.22	116.66	105.32	126.38	113.42	136.1		
	.375	78.12	93.74	86.8	104.16	95.48	114.57	104.16	124.99	112.84	135.43	121.52	151.82		
	.1875	36.05	43.21	40.06	48.07	44.07	52.87	48.07	57.68	52.08	62.49	56.08	67.29		
	.21	40.38	48.45	44.87	53.84	49.35	59.22	53.84	64.00	58.33	69.99	62.82	75.38		
	.23	44.23	53.07	49.14	58.96	54.05	64.86	58.96	70.76	63.88	76.65	68.80	82.56		
	.25	48.07	57.68	53.41	64.09	58.76	70.3	64.4	76.92	69.44	83.32	74.78	89.73		
	.26	50.7	60.91	55.55	66.66	66.11	73.33	66.66	79.99	72.22	86.66	77.77	93.32		
	.29	55.76	66.91	61.96	74.35	68.16	81.79	74.35	89.22	80.55	96.66	86.75	104.1		
	.3125	60.09	72.1	66.77	80.12	73.45	88.14	80.12	96.14	86.8	104.16	93.48	112.17		
.33	63.46	76.13	70.51	84.61	77.56	93.07	84.61	101.53	91.66	109.99	98.71	118.45			
.35	67.3	80.76	74.78	89.73	82.26	98.71	89.74	107.68	97.22	116.66	104.70	125.64			
.375	72.11	86.53	80.12	96.14	88.14	105.76	96.15	115.38	104.16	124.99	112.17	134.6			
84 inches	.21	33.48	40.17	37.2	44.68	40.92	49.1	44.94	53.56	48.36	58.03	52.08	62.49	84 inches	
	.23	37.5	45	41.66	49.99	45.83	54.99	50.60	60	54.16	64.99	58.33	69.99		
	.25	41.02	49.22	45.63	54.75	50.19	60.22	54.75	65.71	59.32	71.18	63.88	76.66		
	.26	44.64	53.56	49.6	59.52	54.56	65.47	59.52	71.42	64.48	77.37	69.44	83.32		
	.29	51.78	62.13	57.53	69.03	63.29	75.94	69.04	82.84	74.8	89.76	80.55	96.66		
	.3125	55.8	66.96	62	74.4	68.2	81.84	74.4	89.28	80.6	96.72	86.8	104.16		
	.33	58.92	70.7	65.47	78.56	72.02	86.42	78.57	94.28	85.11	102.13	91.66	109.99		
	.35	62.5	75	69.44	83.32	76.38	91.65	83.32	99.99	90.27	108.32	97.22	116.66		
	.375	66.96	80.35	74.4	89.28	81.84	98.2	89.28	107.13	96.72	116.06	104.16	124.99		
	.1875	31.25	37.5	34.72	41.66	38.19	45.82	41.66	49.99	45.13	54.15	48.68	58.33		90 inches
	.21	35	42	38.88	46.65	42.77	51.32	46.65	55.99	50.55	60.66	54.44	65.32		
	.23	38.33	45.99	42.59	51.10	46.85	56.22	51.10	61.33	55.37	66.44	59.62	71.54		
.25	41.66	49.99	46.29	55.54	50.92	61.1	55.54	66.66	60.18	72.21	64.81	77.77			
.26	43.33	51.99	48.14	57.76	52.96	63.55	57.77	69.32	62.59	75.1	67.4	80.88			
.29	48.33	57.99	53.7	64.44	59.07	70.8	64.44	77.32	69.81	83.77	75.18	90.21			
.3125	52.08	62.49	57.86	69.43	63.65	76.38	69.44	83.32	75.23	90.27	81.01	97.21			
.33	55	66	61.11	73.33	67.22	80.66	73.33	87.99	79.44	95.32	85.55	102.66			
.35	58.33	69.99	64.81	77.77	71.29	85.54	77.77	93.32	84.25	101.1	90.72	108.88			
.375	62.5	75	69.44	83.32	76.38	91.65	83.33	99.99	90.27	108.32	97.22	116.66			

TABLE OF PRESSURE ALLOWABLE ON BOILERS MADE SINCE FEBRUARY 28, 1872.

Diam-eter of boiler.	Thick-ness of plates.	45,000 tensile strength, 1-6, 7,500.		50,000 tensile strength, 1-6, 8,333.3.		55,000 tensile strength, 1-6, 9,166.6.		60,000 tensile strength, 1-6, 10,000.		65,000 tensile strength, 1-6, 10,833.3.		70,000 tensile strength, 1-6, 11,666.6.		Diam-eter of boiler.
		Pres-sure.	20 per cent ad-ditional.	Pres-sure.	20 per cent ad-ditional.	Pres-sure.	20 per cent ad-ditional.	Pres-sure.	20 per cent ad-ditional.	Pres-sure.	20 per cent ad-ditional.	Pres-sure.	20 per cent ad-ditional.	
96 inches	.1875	29.29	35.14	39.06	42.96	35.8	42.96	39.06	46.87	42.31	50.77	45.57	54.08	96 inches
	.21	32.81	39.37	43.74	48.12	40.1	48.12	43.75	52.5	47.39	56.86	51.04	61.24	
	.23	35.93	43.11	47.91	52.7	43.92	52.7	47.91	57.49	51.9	62.28	55.9	67.08	
	.25	39.06	46.87	52.08	57.28	47.74	57.28	52.08	62.49	56.42	67.67	60.76	72.91	
	.26	40.62	48.74	54.16	59.58	49.65	59.58	54.16	64.99	58.78	70.53	63.19	75.82	
	.29	45.31	54.37	60.4	66.45	55.38	66.45	60.41	72.49	65.45	78.54	70.48	84.57	
	.3125	48.82	58.58	65.1	71.6	59.67	71.6	65.1	78.12	70.52	84.62	75.95	91.14	
	.33	51.56	61.87	68.74	75.62	63.02	75.62	68.75	82.5	74.47	89.36	80.2	96.24	
	.35	54.68	65.61	72.91	80.19	66.83	80.19	72.91	87.49	78.99	94.78	85.06	102.07	
	.375	58.58	70.29	78.12	85.93	71.61	85.93	78.12	93.74	84.63	101.55	91.14	109.6	

NOTE.—At the heads of the double columns will be found the tensile strength of the plates per square inch of section, also one-sixth of that amount. The pressure allowable on single-riveted boilers will be found in the first division of the double columns under the tensile strength and opposite the diameters and thickness; and, in the second divisions, the pressures allowable on boilers where all the rivet holes have been fairly drilled and no part of such holes has been punched, and the longitudinal laps of their cylindrical parts double riveted.

The pressure for any dimension of boiler not found in the above table must be ascertained in the manner prescribed.

The following rules and tables are from a commercial rating and only approximate.

STANDARD STEAM BOILER MEASUREMENTS.

HORIZONTAL TUBULAR.

Based on 12 square feet of heating surface to a horse power.

A Commercial Rating.

Dia.	Size.		Thick-ness.		Boiler with Hand Holes.			Boiler with Man Holes.				
	Length	Shell.	Heads.	Size of Dome.	Tubes No.	Heat. Surf. Dia. sq. ft.	Horse Power	Tubes No.	Heating. Surf. Dia. sq. ft.	Horse Power.		
30	6	¼	⅜	16x20	19	2½	106	9				
30	8	¼	⅜	16x20	19	2½	141	12				
					38	2½	256	21				
36	8	¼	⅜	18x20	28	3	226	19				
					25	3½	234	20				
					38	2½	311	26				
36	10	¼	⅜	18x20	28	3	283	24				
					25	3½	292	24				
42	10	¼	⅜	20x24	38	3	372	31				
					34	3½	385	32				
42	12	¼	⅜	20x24	38	3	446	37				
					34	3½	462	39				
42	14	¼	⅜	20x24	38	3	520	43				
					34	3½	539	45				
42	16	¼	⅜	20x24	38	3	595	43				
					34	3½	616	51				
44	12	¼	⅜	24x24	48	3	544	45				
					38	3½	510	43				
44	14	¼	⅜	24x24	48	3	635	53				
					38	3½	491	41				
48	12	⅕	⅞	24x24	58	3	647	54	50	3	572	48
					50	3½	651	54	34	3½	475	40
48	14	⅕	⅞	24x24	58	3	755	63	50	3	667	55
					50	3½	759	63	34	3½	547	46
48	16	⅕	⅞	24x24	58	3	862	72	50	3	762	64
					50	3½	867	72	34	3½	633	53
48	18	⅕	⅞	24x24	58	3	970	81	50	3	857	71
					50	3½	976	81	34	3½	712	59
					71	3	912	76	59	3	780	65
54	14	⅕	½	30x30	56	3½	851	71	48	3½	748	62
					43	4	763	64	40	4	719	60
					71	3	1042	87	59	3	891	74
54	16	⅕	½	30x30	56	3½	972	81	48	3½	855	71
					43	4	802	67	40	4	821	68

The above table is based on rule for ascertaining Heating Surface.

A commercial rating of boiler horse power is obtained by the following rule :

Add to two-thirds of boiler shell area, tube area and the area of one head (this will compensate for tubes holes in both) and

divide product by unit of H. P. according to type of boiler. (See table.)

FORMULA:

$$\frac{\frac{2}{3} SA + TA + AH}{HP \text{ unit}} = HP$$

LEGEND:

SA = shell area
 TA = tube area
 AH = area of head
 60" = boiler diameter
 16' = length
 46 4" tubes
 HP unit = 12 sq. ft.

EXAMPLE:

3.1416 = circumference of one inch
 60" = diameter of boiler

188.4960
 192" = length of boiler

3769920
 16964640
 1884960

diameter of head = 60"
 60
 3600
 area of one inch = .7854

3)36191.2320 = area of boiler shell

14400
 18000
 28800
 25200

12063.7440 = $\frac{1}{3}$
 2

area head = 2827.4400

24127.4880 = $\frac{2}{3}$ of boiler shell area
 2827.4400 = area of one head

26954.9280
 110986.4448 = tube area

inches per square ft. = 144) 137941.3728 (957.9 = square feet of heating surface

834
 720

3.1416 = circumference of 1 in.
 4" = tube diameter

1141
 1008

calculating 12 square ft. per HP = 12) 957.9 (79.8 = HP

12.5664
 192" = length of tube

1333
 1296

84
 117
 108

251328
 1130976
 125664

37

99
 96

2412.7488 = heating surface one tube
 46 tubes

3

144764928
 96509952

110986.4448 = tube area

Heating surface proper means any portion of the boiler where heat is applied to one side of the plate, and water on the other.

The heating surface of a round furnace and tubes is figured by their internal diameter, water tubes and external fired surfaces are measured by their outside diameter, this latter being the surface heated must necessarily be considered as effective heating surface.

The heating surface of boilers can readily be obtained from the following table: In the case of horizontal tubular bricked in boilers, two-thirds of the boiler shell, the whole of the tube surface, and the front and rear head deducting area of tubes and surface above water-line is figured as effective heating surface.

Diameter of boiler, inches	26	28	30	32	34	36	38	40	42	44	46	48
Two-thirds of the heating surface of shell per foot of length	4.54	4.89	5.24	5.59	5.93	6.29	6.63	6.98	7.33	7.68	8.03	8.38
Diameter of boiler, inches	50	52	54	56	58	60	62	64	66	68	70	72
Two-thirds of the heating surface of shell per foot of length	8.73	9.08	9.42	9.77	10.12	10.47	10.82	11.17	11.52	11.87	12.22	12.57

TYPES OF BOILERS AND ESTIMATED GRATE TO HEATING SURFACE PER HORSE POWER.

Types.	Square feet of Heating Surface per horse power.	Square feet of Heating Surface to one foot of grate.
Cylinder	6 to 10	12 to 15
Flue	8 to 12	20 to 25
Horizontal Tubular	12 to 14	25 to 35
Water Tube	11 to 12	35 to 40
Vertical	10 to 12	25 to 30
Internal Fired	12 to 15	50 to 100

RATIO GRATE SURFACE TO HORSE POWER.

Type of Boiler.	Ratio.
HT	4 to 6
WT	3
Loco	02 " 6
Marine	12

HEATING SURFACE RATIO TO GRATE SURFACE.

HT	40 to 50
WT	34 " 65
Loco	30 " 34
Marine	28 " 32

COAL AND GRATE.

The average consumption of coal for steam boilers is 12 pounds per hour for each square foot of grate surface.

Western coals, having a large amount of sulphur, require more space in furnace and more air.

Rule to find area of grate for a given boiler :

Divide pounds of water to be evaporated per hour by number of pounds of water evaporated multiplied by number of pounds of coal burned per hour per square foot of grate.

FORMULA :

$$\frac{\text{number of lbs. of water evaporated per hour}}{\text{water in lbs. evap.} \times \text{per lbs. of coal per hour}} = \text{area of grate}$$

LEGEND :

2400 = lbs. of water to be evaporated
 12 = lbs. of coal per square foot of grate
 9 = lbs. of water

EXAMPLE :

108)2400 (22 square feet of grate required
 216

240
 216

24 12 lbs. of coal per sq. ft. of grate
 9 lbs. of water per lbs. of coal

108 lbs. of water evaporated per sq. foot of grate

TABLE FOR PRESSED STEEL BOILER LUGS.

Iron rivets have a shearing strength of 38000 lbs.
 Steel " " " " " " 45000 "

See tables for boiler weights and rivet strength.




Diameter of boiler, inches.	Height of base of lug above center of boiler.	Width of lug.	Length of lug projection.	Height of lug on boiler.	Thick-ness.	Weight, lbs.
30	1	7	7	7	$\frac{3}{16}$	6
36	2	7	7	7	$\frac{1}{4}$	8
42	$2\frac{7}{8}$	8	8	8	$\frac{1}{4}$	10½
48	$3\frac{1}{8}$	8	8	8	$\frac{1}{8}$	14
54	$3\frac{1}{2}$	10	10	10	$\frac{1}{8}$	20½
60	$4\frac{1}{2}$	10	10	10	$\frac{3}{8}$	23
66	$4\frac{1}{2}$	12	12	12	$\frac{3}{8}$	35
72	5	12	12	12	$\frac{1}{2}$	40
78	6	12	12	12	$\frac{1}{2}$	45
84	7	12	12	12	$\frac{9}{16}$	50

WEIGHT OF HORIZONTAL TUBULAR BOILERS FOR 125 LBS. STEAM PRESSURE
COMPLETE WITH FITTINGS FULL OF WATER.

Diameter of boiler, inches	36	36	42	42	44	48	50	54	54	60	60
Length in feet . .	8	10	10	12	12	12	13	13	15	14	15
Weight full of water	6,100	7,600	9,500	10,600	11,600	13,400	14,300	15,400	17,900	20,900	24,900
Diameter of boiler, inches.	60	66	66	72	72	78	78	84	84	90	90
Length in feet	16	16	16	16	18	18	20	18	20	18	20
Weight full of water	27,300	30,400	35,100	40,100	44,100	48,100	56,100	55,100	67,100	65,100	75,100

DIRECTIONS FOR SETTING BOILERS.

Make the excavation to a depth suitable to ground that boiler is to rest upon not less than 24 inches. Build foundation walls at least 12" wider than walls to floor level, fronts to rest upon two courses of brick above the floor level. Set boiler in place and block it up three or four inches higher than it is to remain, the back side of front to set back four inches from front edge of brick work. Carry up the side and end walls to the proper height for the resting place of brackets (if boiler has brackets place rollers between plates and lugs) leaving space so that walls will not be pushed out of place by expansion of boiler. (Some engineers prefer an air space in setting side and end walls, as a nonconductor of heat.) The walls should be tied together by headers and run every eighteen inches. The headers from outside walls should touch those of inner wall and not be tied together. Fire brick in the furnace should be laid with a course of headers every six courses so that the wall can easily be taken out and repaired at any time when necessary. The rear connection or back arch should be lined with fire brick, the ends of arch resting on side walls and the arch of such radius to permit of easy access to tubes at rear head. A space of one inch should be left between rear end of boiler and inside of arch so that the expansion of boiler will not affect brick work and should be so arranged that it can be removed without injury to walls. It is preferable when covering a boiler to do so with magnesia, as it is light, a non-conductor and will give evidence of any leakage at a local point by discoloration or becoming soft, not like the brick covered boiler that may have leakage many feet from point of steam issuing. If brick is to be used a two inch space should be left between boiler and brick work.



THE STEAM BOILER.

MEASUREMENTS FOR SETTINGS RETURN TUBULAR BOILERS FULL FLUSH FRONTS.
SEE PLAN AND ELEVATION.

Horse Power.	Diameter of Boiler.	Length of Boiler.	Front-Smoke Box.	Top of Bridge Wall to bottom of Boiler.	Back Head to Back Wall.	Top of Grates to bottom of Boiler.	Top of Grates to Floor Line.	Top of Filling to bottom of Boiler.	Width of Furnace.	Width of Walls over all.	Length of Foundation Walls.		Length of Furnace.	Width of Furnace.	Thickness of Front Brick Work.	Thickness of Bridge Wall.	Thickness of Back Wall.	Thickness of Side Walls.	Height of Walls from Floor Line.
											Ft.	In.							
15	36	8	12	10	16	26	20	20	36	7-4	12-7	36	36	13	18	20	18	7-0	
20	36	10	12	10	16	26	20	20	36	7-4	14-7	42	42	13	18	20	18	7-0	
25	42	10	12	12	20	26	22	22	42	7-10	14-7	42	42	13	20	20	20	7-7	
30	42	12	12	12	20	26	22	22	42	7-10	16-7	48	42	13	20	20	20	7-7	
35	44	12	12	12	20	26	22	22	44	8-0	16-7	48	44	13	20	20	20	7-7	
40	48	12	12	12	22	26	24	22	48	8-0	16-7	48	44	13	20	20	20	7-10	
45	50	13	14	14	22	26	24	22	50	8-6	17-7	48	48	15 1/2	24	24	24	8-0	
50	54	13	16	15	24	28	25	24	54	8-10	17-7	54	50	15 1/2	24	24	24	8-6	
60	54	15	16	15	24	28	25	24	54	8-10	17-7	60	54	15 1/2	24	24	24	8-6	
75	60	15	18	15	28	30	26	24	60	10-0	19-7	60	60	15 1/2	28	26	30	8-11	
80	60	16	18	16	28	30	26	24	60	10-0	20-7	66	60	15 1/2	28	26	30	8-11	
100	66	16	18	16	28	34	26	24	66	10-6	20-7	72	66	16	28	26	30	9-8	
125	72	18	20	18	30	34	26	24	72	11-0	20-7	72	72	16	28	26	30	10-1	
150	72	18	20	18	30	34	26	24	72	11-0	22-7	78	72	16	30	26	30	10-1	
175	78	18	20	18	30	34	26	24	78	11-6	22-7	78	78	16	30	26	30	10-6	

MATERIALS FOR BRICKWORK OF REGULAR TUBULAR BOILERS.
SINGLE SETTING.

Boilers.	Common Brick.	Fire Brick.	Sand, bushels	Cement, barrels.	Fire Clay, lbs.	Lime, barrels.
30 inches x 8 feet	5200	320	42	5	192	2
30 " x 10 "	5800	320	46	5½	192	2¼
36 " x 8 "	6200	480	50	6	288	2½
36 " x 9 "	6600	480	53	6½	288	2¾
36 " x 10 "	7000	480	56	7	288	3
36 " x 12 "	7800	480	62	8	288	3¼
42 " x 10 "	10000	720	80	10	432	4
42 " x 12 "	10800	720	86	11	432	4¼
42 " x 14 "	11600	720	92	11¾	432	4½
42 " x 16 "	12400	720	99	12½	432	5
48 " x 10 "	12500	980	100	12½	590	5¼
48 " x 12 "	13200	980	108	13½	590	5½
48 " x 14 "	14200	980	116	14½	590	5¾
48 " x 16 "	15200	980	124	15½	590	6
54 " x 12 "	13800	1150	108	13¾	690	5½
54 " x 14 "	14900	1150	117	15	690	6
54 " x 16 "	16000	1150	126	16	690	6¼
60 " x 10 "	13500	1280	108	13½	768	5½
60 " x 12 "	14800	1280	118	14¾	768	6
60 " x 14 "	16100	1280	128	16	768	6½
60 " x 16 "	17400	1280	140	17½	768	7
60 " x 18 "	18700	1280	148	18¾	768	7½
66 " x 16 "	19700	1400	157	19¾	840	8
72 " x 16 "	20800	1550	166	20¾	930	8½

TWO BOILERS IN A BATTERY.

30 inches x 8 feet	8900	640	70	9	384	3½
30 " x 10 "	9600	640	76	9½	384	4
36 " x 8 "	10500	960	84	10½	576	4¼
36 " x 9 "	11100	960	88	11	576	4½
36 " x 10 "	11800	960	95	12	576	4¾
36 " x 12 "	13000	960	104	13	576	5¼
42 " x 10 "	17500	1440	140	17½	864	7
42 " x 12 "	18600	1440	148	18½	864	7½
42 " x 14 "	19900	1440	159	20	864	8
42 " x 16 "	21200	1440	168	21	864	8½
48 " x 10 "	21400	1960	170	21½	1180	8¾
48 " x 12 "	22300	1960	178	22⅓	1180	9
48 " x 14 "	23900	1960	190	24	1180	9½
48 " x 16 "	25100	1960	200	25	1180	10
54 " x 12 "	23300	2300	186	23⅓	1380	9⅓
54 " x 14 "	24800	2300	198	25	1380	10
54 " x 16 "	26300	2300	210	26⅓	1380	10½
60 " x 10 "	22600	2560	180	22½	1536	9
60 " x 12 "	24800	2560	198	25	1536	10
60 " x 14 "	26800	2560	214	27	1536	10¾
60 " x 16 "	28900	2560	230	29	1536	11½
60 " x 18 "	31000	2560	248	31	1536	12½
66 " x 16 "	33100	2800	264	33	1680	13¼
72 " x 16 "	34000	3100	272	34	1860	13¾

In connection with boiler setting the following information will be useful:

One barrel of lime will lay 800 brick.

Two barrels of lime will lay one perch rubble stone.

To every barrel of lime estimate about $\frac{5}{8}$ yards of good sand for brick work.

One and one quarter barrels of cement and three quarters yard of sand will lay 100 feet of rubble stone.

Rule to find number of brick required: Multiply the number of cubic feet by 22.5.

The cubic feet is found by multiplying length by height, then by thickness.

Bricks are usually made $8'' \times 4'' \times 2''$ requiring 27 bricks to make a cubic foot without mortar, the latter is estimated to fill one sixth of space.

CHIMNEYS AND STACKS.

The use for chimneys is necessary in many plants and maintained at great expense of heat units varying as high as 30 per cent of fuel. The necessity arises from following causes, viz.: cost of installing modern methods and the necessity for a chimney to carry off obnoxious gases.

The main object is to obtain air supply for combustion of fuel. Areas for chimneys are calculated from grate area, coal burned in a certain time and usually a ratio of 8 to 1.

The temperatures of gases escaping up a chimney will depend on the material and distance from boilers—the higher the temperature the greater the velocity.

The weight of air necessary for fuels varies, hence the necessity for computing for the maximum amount.

The volume of air is proportional to its temperature; 24 pounds of air at the mean of the atmosphere temperature is 300 cubic feet and at a temperature of 550 degrees F is twice as great.

Rule to find the volume of one pound of air under atmospheric pressure for a given temperature: Divide the absolute temperature

of air by the constant 40; the result gives the volume in cubic feet nearly.

LEGEND:	EXAMPLE:
Temp. of atmosphere 80	40)80 (2 = volume of one pound in cubic feet
Constant 40	80
	—

The intensity of draft is independent of the area of the flue but is proportional to the difference in weight of two columns of air of equal base, one internal and one external. The difference in temperatures between the volume escaping from the inside and the atmosphere increases the draft as the difference between the temperature increases.

The atmospheric pressure or draft is estimated by the height of an equivalent column of water.

CONSIDERATIONS GOVERNING THE HEIGHT OF A CHIMNEY.

It must be high enough to give the required intensity of draft at an economical flue temperature, and to be well above the surrounding objects; increased capacity is much more cheaply gained by increasing the area, it being cheaper to build nearer the ground, and the capacity increases with the square of the diameter and only as the square root of the height. If of brick the height should not exceed ten or eleven times the base, on account of stability.

Rule to find the difference in pressure to be expected between the inside and outside of a chimney for a given height and temperature: Divide 39 by the absolute (actual temperature Fahrenheit plus 461) temperature of the outside air; again, divide 40 by the absolute average temperature of the gases in the stack; subtract the latter from the former quotient, multiply the remainder by the height of the chimney in feet, and divide by 5.2; the final quotient will be the draft in inches in water.

The following table will give the draft power in inches of water for chimneys of specific height basing the temperature as follows:
Escaping gases 552 degrees F.

Atmospheric temperature 62 degrees F.

Height of Chimney in Feet.	Draft Power in Inches of Water.	Theoretical velocity in feet per second.	
		Cold Air Entering.	Hot Gases Escaping.
10	.073	17.8	35.6
20	.146	25.3	50.6
30	.219	31.0	62.0
40	.292	35.7	71.4
50	.365	40.0	80.0
60	.438	43.8	87.6
70	.511	47.3	94.6
80	.585	50.6	101.2
90	.657	53.7	107.4
100	.730	56.5	113.0
120	.876	62.0	124.0
150	1.095	69.3	138.6
175	1.277	74.8	149.6
200	1.460	80.0	160.0

Draft required depends largely on quality and nature of fuel and rate of combustion; it is least for wood and free burning fuels and greatest for fine coal; for slack coal draft equivalent to $1\frac{1}{4}$ inches of water is necessary.

In designing height of chimney it is the aim to provide for an excess of demands and regulate by dampers to amount required.

Increasing height will increase the flow of escaping gases.

AREA OF CHIMNEY WHEN HORSE POWER IS GIVEN.

Three horse power per square foot of grate surface.

Rule.— Divide the horse power by 3.33 times the square root of the height. The quotient will be the required effective area in square feet. To the diameter or length of side required to give this area add two inches to compensate for friction.

HORSE POWER OF A GIVEN CHIMNEY.

Rule.— From the area in square feet subtract .6 of the square root of that area and multiply the remainder by the square root of the height and by 3.33.

Or:

Multiply the area in square inches by the square root of the height in feet and divide by 40. The quotient will be the horse power.

Formula, $H. P. = 3.33(A - 0.6 \sqrt{A}) \sqrt{H}$. (Assuming 1 H. P. = 5 lbs. of coal burned per hour.)
 SIZE OF CHIMNEYS FOR STEAM BOILERS—KENT.

Diam. inches	Area A. sq. ft.	Effective Area $E = A - 0.6 \sqrt{A}$ sq. ft.	Height of Chimney														Equivalent Square Chimney Side of Square $\sqrt{E + 4}$ inches
			Commercial Horse-power of Boiler														
			50	60	70	80	90	100	110	125	150	175	200	225	250	300	
			ft.	ft.	ft.	ft.	ft.	ft.	ft.	ft.	ft.	ft.	ft.	ft.	ft.	ft.	
18	1.77	.97	23	25	27	29											16
21	2.41	1.47	35	38	41	44											19
24	3.14	2.08	49	54	58	62	66										22
27	3.98	2.78	65	72	78	83	88										24
30	4.91	3.58	84	92	100	107	113	119									27
33	5.94	4.48	115	125	133	141	149	156									30
36	7.07	5.47	141	152	163	173	182	191	204								32
39	8.30	6.57	183	196	208	219	229	245	268								35
42	9.62	7.76		216	231	245	258	271	289	316	342						38
48	12.57	10.44			311	330	348	365	389	426	460	492					43
54	15.90	13.51				427	449	472	503	551	595	636	675				48
60	19.64	16.98					536	565	593	632	692	748	800	848	894		54
66	23.76	20.83						694	728	776	849	918	981	1040	1097	1201	59
72	28.27	25.08						835	876	934	1023	1105	1181	1253	1320	1447	64
78	33.18	29.73							1038	1107	1212	1310	1400	1485	1565	1715	70
84	38.48	34.76							1214	1294	1418	1531	1637	1736	1830	2005	75
90	44.18	40.19								1496	1639	1770	1893	2008	2116	2318	80
96	50.27	46.01								1712	1876	2027	2167	2298	2423	2654	86
102	56.75	52.23								1944	2130	2300	2459	2609	2750	3012	91
108	63.62	58.83								2090	2399	2592	2771	2939	3098	3393	96
114	70.88	65.83									2685	2900	3100	3288	3466	3797	101
120	78.54	73.22									2986	3226	3448	3657	3855	4223	107
132	95.03	89.18									3637	3929	4200	4455	4696	5144	117
144	113.10	106.72									4352	4701	5026	5331	5618	6155	128

For pounds of coal burned per hour for any given size of chimney, multiply the figures in the table by 5.

Following is a table by Professor Trowbridge:

Height in feet.	Pounds of Coal burned per hour per square foot of section of chimney.	Pounds of Coal burned per hour per square foot, the ratio of grate to chimney being 8 to 1.
20	60	7.5
25	68	8.5
30	76	9.5
35	84	10.5
40	93	11.6
45	99	12.4
50	105	13.1
55	111	13.8
60	116	14.5
65	121	15.1
70	126	15.8
75	131	16.4
80	135	16.9
85	139	17.4
90	144	18.0
95	148	18.5
100	152	19.0
105	156	19.5
110	160	20.0

CHIMNEYS.

Area of chimney for given height and number of square feet of grate surface connected.

Rule.— Multiply the number of square feet of grate surface by 120, and divide by the square root of the height. The quotient will be the required cross section in square inches. See table.

AREA OF CHIMNEYS, IN SQUARE INCHES, WHEN CONNECTED TO GRATE SURFACES FROM TWENTY-FIVE TO ONE THOUSAND SQUARE FEET, AND FOR DIFFERENT HEIGHTS.

Square feet of Grate Surface.	60	65	70	75	80	85	90	95	100	105	110	115	120	125	130	135	140	145	150	155	160	Square feet of Grate Surface
25	387	372	358	346	335	325	318	307	300	292	288	25
50	774	744	717	699	676	650	632	615	600	582	572	50
75	1161	1116	1055	1026	1006	976	948	923	900	878	848	830	75
100	1549	1488	1424	1385	1341	1301	1264	1231	1200	1178	1144	1119	1099	1080	1062	1045	1029	1014	1000	987	975	100
125	1938	1860	1792	1735	1677	1624	1581	1540	1500	1463	1430	1398	1369	1342	1316	1291	1267	1244	1222	1201	1181	125
150	2322	2239	2151	2078	2012	1959	1907	1866	1800	1758	1716	1678	1643	1610	1578	1547	1517	1488	1460	1433	1407	150
175	2711	2624	2530	2447	2374	2312	2251	2194	2100	2049	2009	1972	1937	1904	1872	1841	1811	1782	1754	1727	1701	175
200	3098	2997	2898	2811	2748	2683	2620	2562	2400	2349	2298	2264	2231	2200	2169	2139	2109	2080	2052	2025	2000	200
225	3482	3349	3227	3117	3018	2928	2848	2776	2500	2452	2400	2371	2344	2318	2292	2266	2240	2214	2188	2163	2139	225
250	3873	3731	3585	3464	3358	3253	3169	3077	2700	2654	2600	2571	2546	2521	2495	2469	2443	2417	2391	2366	2342	250
275	4260	4094	3924	3816	3698	3578	3476	3385	2900	2856	2800	2771	2746	2721	2695	2669	2643	2617	2591	2566	2542	275
300	4647	4457	4261	4157	4028	3904	3793	3693	3000	2958	2900	2871	2846	2821	2795	2769	2743	2717	2691	2666	2642	300
325	5034	4827	4611	4503	4364	4230	4110	4003	3000	2958	2900	2871	2846	2821	2795	2769	2743	2717	2691	2666	2642	325
350	5422	5200	5010	4840	4695	4555	4437	4300	3500	3458	3400	3371	3346	3321	3295	3269	3243	3217	3191	3166	3142	350
375	5811	5578	5378	5242	5098	4958	4837	4700	4000	3958	3900	3871	3846	3821	3795	3769	3743	3717	3691	3666	3642	375
400	6200	5957	5737	5589	5442	5298	5169	5030	4500	4458	4400	4371	4346	4321	4295	4269	4243	4217	4191	4166	4142	400
425	6590	6327	6087	5920	5754	5590	5438	5285	5000	4958	4900	4871	4846	4821	4795	4769	4743	4717	4691	4666	4642	425
450	6980	6697	6437	6251	6067	5894	5723	5550	5000	4958	4900	4871	4846	4821	4795	4769	4743	4717	4691	4666	4642	450
475	7370	7067	6787	6581	6378	6186	6005	5825	5000	4958	4900	4871	4846	4821	4795	4769	4743	4717	4691	4666	4642	475
500	7760	7437	7137	6911	6678	6446	6225	6005	5000	4958	4900	4871	4846	4821	4795	4769	4743	4717	4691	4666	4642	500
525	8150	7807	7487	7241	6998	6746	6495	6245	5000	4958	4900	4871	4846	4821	4795	4769	4743	4717	4691	4666	4642	525
550	8540	8167	7827	7561	7298	7026	6755	6485	5000	4958	4900	4871	4846	4821	4795	4769	4743	4717	4691	4666	4642	550
575	8930	8537	8177	7891	7608	7316	7025	6735	5000	4958	4900	4871	4846	4821	4795	4769	4743	4717	4691	4666	4642	575
600	9320	8907	8527	8221	7918	7606	7295	7005	5000	4958	4900	4871	4846	4821	4795	4769	4743	4717	4691	4666	4642	600
625	9710	9277	8877	8551	8228	7906	7585	7285	5000	4958	4900	4871	4846	4821	4795	4769	4743	4717	4691	4666	4642	625
650	10100	9647	9227	8881	8538	8196	7855	7535	5000	4958	4900	4871	4846	4821	4795	4769	4743	4717	4691	4666	4642	650
675	10490	10017	9577	9211	8858	8506	8155	7825	5000	4958	4900	4871	4846	4821	4795	4769	4743	4717	4691	4666	4642	675
700	10880	10387	9927	9541	9168	8806	8445	8105	5000	4958	4900	4871	4846	4821	4795	4769	4743	4717	4691	4666	4642	700
725	11270	10757	10277	9871	9478	9096	8715	8355	5000	4958	4900	4871	4846	4821	4795	4769	4743	4717	4691	4666	4642	725
750	11660	11127	10627	10201	9798	9406	9015	8645	5000	4958	4900	4871	4846	4821	4795	4769	4743	4717	4691	4666	4642	750
775	12050	11497	10977	10531	10118	9726	9335	8965	5000	4958	4900	4871	4846	4821	4795	4769	4743	4717	4691	4666	4642	775
800	12440	11867	11327	10871	10448	10056	9665	9305	5000	4958	4900	4871	4846	4821	4795	4769	4743	4717	4691	4666	4642	800
825	12830	12237	11677	11211	10778	10376	9985	9625	5000	4958	4900	4871	4846	4821	4795	4769	4743	4717	4691	4666	4642	825
850	13220	12607	12027	11551	11108	10706	10315	9955	5000	4958	4900	4871	4846	4821	4795	4769	4743	4717	4691	4666	4642	850
875	13610	12977	12377	11891	11448	11046	10655	10295	5000	4958	4900	4871	4846	4821	4795	4769	4743	4717	4691	4666	4642	875
900	14000	13347	12727	12231	11788	11386	10995	10635	5000	4958	4900	4871	4846	4821	4795	4769	4743	4717	4691	4666	4642	900
925	14390	13717	13077	12571	12128	11726	11335	10975	5000	4958	4900	4871	4846	4821	4795	4769	4743	4717	4691	4666	4642	925
950	14780	14087	13427	12911	12468	12066	11675	11315	5000	4958	4900	4871	4846	4821	4795	4769	4743	4717	4691	4666	4642	950
975	15170	14457	13777	13251	12808	12406	12015	11655	5000	4958	4900	4871	4846	4821	4795	4769	4743	4717	4691	4666	4642	975
1000	15560	14827	14127	13591	13148	12746	12355	11995	5000	4958	4900	4871	4846	4821	4795	4769	4743	4717	4691	4666	4642	1000

THE STEAM BOILER.

PROPORTIONS OF SELF-SUPPORTING STEEL STACKS.

Horse Power of Stack.	Inside Diameter in Inches.	Height in Feet.	Draft Power in Hydraulic Inches	Tons of Coal Consumed per Hour.	Square Feet of Grate Area.	Diameter at Base.		Diameter at Top of Bell Portion.		Diameter at Top of Stack.		Cubic Yards of Masonry in Foundation.	Fire Brick in Lining.	Common Brick in Lining.	Weight of Stack without Brick Lining, in Tons.
						Feet.	Inches.	Feet.	Inches.	Feet.	Inches.				
100	30	70	0.41	0.25	30	7	6	4	6	3	4	20.6	4500	3500	7.1
115	30	90	0.53	0.28	34	7	6	4	6	3	4	29.5	5000	5000	10.0
130	30	110	0.65	0.32	38	7	6	4	6	3	4	40.0	7000	6500	13.0
125	33	70	0.41	0.31	36	7	7	4	7	3	4	25.0	5000	4500	8.8
140	33	90	0.53	0.35	42	7	7	4	7	3	4	34.5	6000	5500	11.0
160	33	110	0.65	0.40	46	7	7	4	7	3	4	46.0	7500	7000	14.1
150	36	70	0.41	0.37	44	7	7	4	7	3	4	29.6	5000	5000	9.6
175	36	90	0.53	0.44	52	7	7	4	7	3	4	40.0	7000	6000	11.6
200	36	110	0.65	0.50	58	7	7	4	7	3	4	52.5	8000	8000	15.0
250	42	90	0.53	0.62	74	9	8	4	8	4	4	32.1	7500	6000	12.3
275	42	110	0.65	0.68	80	9	8	4	8	4	4	46.0	9000	8000	16.2
300	42	130	0.76	0.75	92	10	9	5	9	4	4	63.3	10500	11000	20.2
350	48	90	0.53	0.87	104	9	9	5	9	4	4	40.0	8000	7000	13.6
375	48	110	0.65	0.93	118	9	9	5	9	4	4	56.0	10000	9000	18.1
400	48	130	0.76	1.00	118	11	9	6	9	4	4	75.7	12000	12000	21.8
430	54	90	0.53	1.07	126	9	9	6	9	4	4	52.6	9000	7500	15.3
470	54	110	0.65	1.17	138	10	9	6	9	4	4	71.9	11000	10000	20.1
510	54	130	0.76	1.27	150	11	9	6	9	4	4	84.7	13000	13000	24.0
580	60	100	0.59	1.45	170	10	6	6	6	4	4	67.3	11000	8000	18.5
675	60	125	0.73	1.62	190	12	6	7	7	4	4	97.0	14000	13000	24.7
700	60	150	0.87	1.75	206	13	6	7	7	4	4	122.0	17000	17000	31.9
800	66	100	0.59	1.75	206	11	6	6	6	4	4	80.0	12000	9000	20.8
800	66	125	0.73	2.00	234	12	6	6	6	4	4	105.0	15000	15000	26.3
900	66	150	0.87	2.25	264	13	6	6	6	4	4	135.0	18000	20000	34.4
950	72	125	0.65	2.31	280	13	6	6	6	4	4	90.0	16000	11000	27.2
1050	72	150	0.87	2.67	310	14	6	6	6	4	4	113.0	20000	19000	38.8
1150	72	175	1.03	2.87	326	15	6	6	6	4	4	155.0	23000	26000	42.3
1150	78	125	0.65	2.87	326	13	6	6	6	4	4	105.0	17000	18000	30.0
1250	78	150	0.87	3.12	368	14	6	6	6	4	4	141.0	21000	24000	38.9
1350	78	175	1.03	3.37	396	15	6	6	6	4	4	185.0	24000	29000	45.0
1400	84	130	0.76	3.50	412	14	4	4	4	4	4	116.0	19000	21000	33.8
1550	84	165	0.97	3.87	458	16	4	4	4	4	4	161.0	25000	28000	44.7
1700	84	200	1.18	4.25	500	16	4	4	4	4	4	217.0	30000	34000	54.3
1800	96	140	0.82	4.50	530	15	4	4	4	4	4	140.0	24000	25000	52.4
2100	96	180	1.06	5.25	620	17	4	4	4	4	4	200.0	30000	31000	52.9
2300	96	220	1.30	5.75	676	18	4	4	4	4	4	273.0	37000	42000	65.3
2400	108	150	0.87	6.00	706	16	6	6	6	4	4	175.0	28000	31000	49.9
2700	108	190	1.12	6.75	794	18	6	6	6	4	4	242.0	35000	37000	62.3
3000	108	240	1.41	7.50	882	20	6	6	6	4	4	325.0	45000	48000	89.0
3000	120	150	0.87	7.50	882	17	6	6	6	4	4	262.0	31000	35000	53.9
3500	120	200	1.18	8.75	1030	19	6	6	6	4	4	304.0	40000	47000	71.0
3900	120	250	1.48	9.75	1148	21	6	6	6	4	4	400.0	51000	60000	94.8
4200	132	200	1.18	10.50	1238	20	6	6	6	4	4	294.0	45000	50000	77.2
4700	132	250	1.48	11.75	1382	23	4	4	4	4	4	400.0	56000	62000	100.5
5200	132	300	1.67	13.00	1528	25	4	4	4	4	4	530.0	67000	75000	140.7

THE BOILER.

SMOKE STACKS.

APPROXIMATE WEIGHT IN POUNDS OF ONE FOOT OF STACK.

Diameter, inches.	THICKNESS OF MATERIAL.				
	No. 16.	No. 14.	No. 12.	No. 10.	No. 8.
	Weight.	Weight.	Weight.	Weight.	Weight.
10	8	10	13	16	19
12	9	12	14	19	23
14	11	14	16	22	27
16	12	16	20	25	31
18	14	18	23	28	35
20	15	19	25	31	38
22	17	21	28	34	42
24	18	23	30	36	45
26	19	24	32	40	48
28	21	26	35	43	52
30	22	28	37	46	56
32	23	30	39	48	58
34	24	31	41	50	60
36	26	32	43	52	63
38	27	34	44	54	66
40	29	36	47	57	70
42	31	38	49	60	74
44	33	41	54	66	81
48	35	45	59	72	89
54	38	48	64	82	97
60	42	53	71	90	108
66	45	59	77	98	117
72	51	65	86	110	131
78	58	74	98	120	150
84	62	80	105	130	160
96	72	92	130	148	180

SPECIFICATIONS OF VERTICAL TUBULAR BOILERS.
WITH FULL LENGTH TUBES.

	4	5	6	8	10	12	15	18	21	25	30	34	40	46	50
Horse power	24	31	37	42	48	57	67	77	88	98	108	138	168	198	228
Diameter of shell, inches	24	30	36	42	48	54	60	66	72	78	84	90	96	102	108
Height of shell, inches	50	60	72	84	96	108	120	132	144	156	168	180	192	204	216
Length of tubes, inches	32	40	48	56	64	72	80	88	96	104	112	120	128	136	144
Number of 2-inch tubes	31	37	42	48	54	60	67	74	81	88	95	102	110	117	124
Thickness of shell, inches	1/4	1/4	1/4	1/4	1/4	1/4	1/4	1/4	1/4	1/4	1/4	1/4	1/4	1/4	1/4
Thickness of heads, inches	1/4	1/4	1/4	1/4	1/4	1/4	1/4	1/4	1/4	1/4	1/4	1/4	1/4	1/4	1/4
Height of furnace, inches	18	20	22	24	26	28	30	32	34	36	38	40	42	44	46
Diameter of furnace, inches	18	20	22	24	26	28	30	32	34	36	38	40	42	44	46
Height of furnace, square feet	19	21	23	25	27	29	31	33	35	37	39	41	43	45	47
Heating surface, square feet	50	60	72	84	96	108	120	132	144	156	168	180	192	204	216
Size of lever safety-valve, inches	3/4	1	1 1/4	1 1/2	1 3/4	2	2 1/4	2 1/2	2 3/4	3	3 1/4	3 1/2	3 3/4	4	4 1/4
Size of blow-off, inches	3/4	1	1 1/4	1 1/2	1 3/4	2	2 1/4	2 1/2	2 3/4	3	3 1/4	3 1/2	3 3/4	4	4 1/4
Weight, complete, lbs.	1100	1200	1350	1630	1850	2000	3000	3350	4000	4350	4700	5700	6100	6500	7500
Diam. of stack required, inches	8	8	10	10	10	13	13	13	16	16	16	18	18	18	20

SPECIFICATIONS OF VERTICAL TUBULAR BOILERS.
WITH SUBMERGED TUBES.

	5	7	9	12	15	18	21	25	30	34	40	46	50
Horse power	24	30	36	42	48	54	60	66	72	78	84	90	96
Diameter of shell, inches	24	30	36	42	48	54	60	66	72	78	84	90	96
Height of shell, inches	72	84	96	108	120	132	144	156	168	180	192	204	216
Length of tubes, inches	30	27	39	39	51	51	63	63	75	75	87	87	99
Number of 2-inch tubes	31	45	45	59	91	91	115	115	139	139	163	163	187
Thickness of shell, inches	1/4	1/4	1/4	1/4	1/4	1/4	1/4	1/4	1/4	1/4	1/4	1/4	1/4
Thickness of heads, inches	1/4	1/4	1/4	1/4	1/4	1/4	1/4	1/4	1/4	1/4	1/4	1/4	1/4
Height of combustion chamber, inches	18	18	18	18	18	18	24	24	24	24	24	24	24
Height of furnace, inches	24	27	27	30	30	30	36	36	36	36	36	36	36
Diameter of furnace, inches	19	25	25	30	30	30	36	36	36	36	36	36	36
Height of furnace, square feet	21	27	27	33	33	33	40	40	40	40	40	40	40
Heating surface, square feet	52	71	71	94	123	154	184	208	255	300	335	405	500
Size of lever safety-valve, inches	1	1 1/4	1 1/4	1 1/2	1 1/2	1 1/2	2	2	2 1/2	2 1/2	2 1/2	3	3 1/2
Size of blow-off, inches	3/4	1	1 1/4	1 1/2	1 1/2	1 1/2	1 3/4	1 3/4	1 3/4	1 3/4	1 3/4	1 3/4	1 3/4
Weight complete, lbs.	1550	2050	2250	3150	3200	4000	4150	4450	5700	5900	6300	7500	7700
Diameter of stack required, inches	8	10	10	13	13	16	16	16	18	18	18	20	20

CAPACITIES OF BOILERS FOR LOW PRESSURE STEAM HEATING APPARATUS.

Boiler Surface, square feet.	Total Direct Radiation, square feet.	Direct Radiation per square foot of Boiler Surface.
40	168	4.20
50	218	4.36
60	272	4.53
80	384	4.80
100	504	5.04
120	626	5.21
140	752	5.37
152	830	5.46
172	962	5.60
194	1114	5.74
211	1232	5.84
252	1522	6.04
292	1816	6.21
295	1840	6.23
347	2240	6.45
399	2642	6.62
421	2820	6.69
482	3321	6.89
541	3818	7.05
580	4247	7.37
720	6210	8.46

The quantities of radiation in the above table are exclusive of all piping. One square foot of indirect requires the same boiler capacity as $1\frac{1}{2}$ square feet of direct radiation.

TO DETERMINE THE SIZE OF STEAM PIPE MAINS FOR VARYING
RADIATION.

For every 100 square feet of radiating surface, allow the area of a one-inch pipe (.7854 square inches).

LIST OF SIZES OF STEAM MAINS.

Radiation, square feet.	One Pipe Work, inches.	Two Pipe Work, inches.
40 to 50	1	$\frac{3}{4}$ x $\frac{3}{4}$
100 " 125	$1\frac{1}{4}$	1 x $\frac{3}{4}$
125 " 250	$1\frac{1}{2}$	$1\frac{1}{4}$ x 1
250 " 400	2	$1\frac{1}{2}$ x $1\frac{1}{4}$
400 " 650	$2\frac{1}{2}$	2 x $1\frac{1}{2}$
650 " 900	3	$2\frac{1}{2}$ x 2
900 " 1250	$3\frac{1}{2}$	3 x $2\frac{1}{2}$
1250 " 1600	4	$3\frac{1}{2}$ x 3
1600 " 2050	$4\frac{1}{2}$	4 x $3\frac{1}{2}$
2050 " 2500	5	$4\frac{1}{2}$ x 4
2500 " 3600	6	5 x $4\frac{1}{2}$
3600 " 5000	7	6 x 5
5000 " 6500	8	7 x 6
6500 " 8100	9	8 x 6
8100 " 10000	10	9 x 6

Under ordinary conditions, one square foot of direct radiation surface will heat approximately in :

Bath-room	40	cubic feet.
Living-room	50	" "
Living-room, exposures, ordinary amount of glass	60	" "
Halls	50 to 70	" "
Sleeping rooms	55	" "
School-rooms	60	" 80
Churches and auditoriums of large cubic contents and with high ceilings	65	" 100
Factories and work-shops	75	" 150

CAPACITIES OF BOILERS FOR HOT WATER HEATING APPARATUS.

Boiler Surface, square feet.	Total Direct Radiation, square feet.	Direct Radiation per square foot of boiler surface.
20	110	5.50
30	181	6.03
40	257	6.42
50	338	6.76
60	425	7.08
70	512	7.46
80	603	7.54
90	695	7.72
100	792	7.92
120	991	8.26
140	1198	8.56
159	1400	8.80
199	1842	9.25
225	2142	9.52
279	2788	9.99
323	3332	10.31
372	3976	10.68
453	5065	11.18
517	5938	11.48

The quantities of radiation in the above table are exclusive of all piping.

One square foot of indirect requires the same boiler capacity as 1½ square feet of direct radiation.

CHAPTER IX.

SAFETY VALVES.

A safety valve should have area sufficient for the escape of steam with rapidity to prevent the raising of steam to exceed 10 per cent of pressure allowed and calculations should be from a standard, the maximum water that could be evaporated per pounds of fuel.

Any spring-loaded safety valve constructed so as to give an increased lift by the operation of steam, after being raised from its seat, or any spring-loaded safety valve constructed in any other manner so as to give an effective area equal to that of the aforementioned spring-loaded safety valve, may be used in lieu of the common lever-weighted valve on all boilers on steam vessels, and each spring-loaded valve shall be supplied with a lever that will raise the valve from its seat a distance of not less than that equal to one-eighth of the diameter of the valve opening; but in no case shall any spring-loaded safety valve be used in lieu of the lever-weighted safety valve without first having been approved by the Board of Supervising Inspectors.

The valves shall be so arranged that each boiler shall have at least one separate safety valve, unless the arrangement is such as to preclude the possibility of shutting off the communication of any boiler with the safety valve or valves employed. This arrangement shall also apply to lock-up safety valves when they are employed.

The use of two safety valves may be allowed on any boiler, provided the combined area of such valves is equal to that required by rule for one such valve. Whenever the area of a safety valve, as found by the rule of this section will be greater than that cor-

responding to 6 inches in diameter, two or more safety valves, the combined area of which shall be equal at least to the area required, must be used.

EXAMPLES:

Boiler pressure = 75 pounds per square inch (gauge).

2 furnaces: Grate surface = 2 × 5 feet 6 inches long × 3 feet wide = 33 square feet.

Water evaporated per pound of coal = 8 pounds.

Coal burned per square foot grate surface per hour = $12\frac{1}{2}$ pounds.

Evaporation per square foot grate surface per hour = $8 \times 12\frac{1}{2} = 100$ lbs.

Hence $W = 100$ and gauge pressure = 75 pounds.

From table the corresponding value of a is .230 square inches.

Therefore area of safety valve = $33 \times .23 = 7.59$ square inches.

For which the diameter is $3\frac{1}{8}$ inches nearly.

Boiler pressure = 215 pounds.

6 furnaces: Grate surface = 6 × 5 feet 6 inches long × 3 feet 4 inches wide = 110 square feet.

Water evaporated per pound coal = 10 pounds.

Coal burned per square foot grate surface per hour = 30 pounds.

Evaporation per square foot grate surface per hour = $10 \times 30 = 300$ lbs.

Hence $W = 300$, gauge pressure = 215, and $a = .270$ (from table).

Therefore area of safety valve = $110 \times .270 = 29.7$ square inches, which is too large for one valve. Use two.

$$\frac{29.7}{2} = 14.85 \text{ square inches. Diameter} = 4\frac{3}{8} \text{ inches.}$$

Rule to determine the area of a safety valve for boiler using oil as fuel or for boilers designed for any evaporation per hour:

Divide the total number of pounds of water evaporated per hour by any number of pounds of water evaporated per square foot of grate surface per hour (W) taken from, and within the limits of, the table. This will give the equivalent number of square feet of grate surface for boiler for estimating the area of valve. Then apply the table as in previous examples.

The areas of all safety valves on boilers contracted for or the construction of which commenced on or after June 1, 1904, shall be determined in accordance with the following formula and table:

EXAMPLE.

Required the area of a safety valve for a boiler using oil as fuel, designed to evaporate 8,000 pounds of water per hour, at 175 pounds gauge pressure.

Make $W = 200$.

8,000

———— = 40, the equivalent grate surface, in square feet.

200

For gauge pressure = 175 pounds and $W = 200$ from table, $a = .218$ square inch. $.218 \times 40 = 8.72$ square inches, the total area of safety valve required for this boiler, for which the diameter is $3\frac{1}{8}$ square inches nearly.

From which formula the areas required per square foot of grate surface in the following table are found by assuming the different values of W and P .

The figures (a) in table multiplied by square feet of grate surface give the area of safety valve or valves required.

When these calculations result in an odd size of safety valve, use next larger standard size.

TABLE OF AREA OF SAFETY VALVES REQUIRED PER SQUARE FOOT OF GRATE SURFACE FOR DIFFERENT PRESSURES AND RATES OF EVAPORATION.
 These figures represent evaporation in pounds per square foot of grate surface per hour (W) = pounds water evaporated per pound coal X pounds coal burned per square foot grate surface per hour.

P, absolute pressure per square inch.	The figures below give a, the area in square inches required per square foot of grate surface at the above rate of evaporation.															
	100	120	140	160	180	200	220	240	260	280	300	320	340	360	380	
65	319	383	447	510	574	638	702	765	829	893	956					
70	296	355	414	474	533	592	652	711	769	828						
75	276	332	387	442	497	552	608	663	718	773	829					
80	259	311	363	415	466	518	570	622	674	726	778					
85	244	292	341	390	438	487	536	585	634	682	731					
90	230	276	322	368	414	460	506	552	598	644	690					
95	218	262	305	349	392	436	479	523	567	610	654					
100	208	249	290	332	373	414	456	497	538	580	622					
105	197	236	276	316	355	394	434	473	513	552	592					
110	188	226	264	301	339	377	414	452	489	527	565					
115	180	216	252	288	324	360	396	432	468	504	540					
120	172	207	241	276	311	345	379	414	448	483	517					
125	166	199	232	265	298	331	364	397	431	463	497					
130	160	192	223	255	287	319	351	383	415	447	479					
135	154	184	215	246	276	307	337	368	398	429	460					
140	148	177	207	237	266	296	325	355	385	414	444					
145	143	172	201	229	258	287	315	344	372	401	430					
150	138	166	194	222	249	277	304	332	360	387	415					
155	134	160	187	214	241	268	294	321	348	375	401					
160	130	156	181	207	233	259	285	311	337	363	389					
165	126	151	176	201	226	251	276	301	326	352	378					
170	122	146	171	195	219	244	268	292	317	341	366					
175	118	142	166	189	213	236	260	284	308	331	355					
180	115	138	161	184	207	229	254	277	300	323	346					
185	112	135	157	179	202	224	247	269	291	314	336					
190	109	131	153	175	196	218	240	262	284	306	328					
195	106	128	149	170	191	213	234	255	277	298	319					
200	104	124	145	166	187	207	228	249	270	290	310					
205	101	121	142	162	182	202	223	243	263	283	303					
210	99	119	138	158	178	198	217	237	257	277	297					
215	97	116	135	154	173	193	212	231	250	269	289					
220	95	114	132	151	170	189	208	226	245	264	283					
225	94	113	131	149	168	184	203	221	240	258	276					
230	92	110	129	147	166	180	200	216	235	253	270					
235	90	108	126	144	162	180	198	214	229	247	264					
240	88	106	124	141	159	176	194	212	225	242	259					
245	86	104	121	138	155	173	190	207	225	242	259					
250	85	102	119	135	152	170	186	203	220	237	254					
255	83	100	117	133	149	167	183	200	216	233	250					
260	81	98	114	130	146	163	179	195	211	228	244					
265	81	98	114	130	146	163	179	195	211	228	244					
270	81	98	114	130	146	163	179	195	211	228	244					
275	81	98	114	130	146	163	179	195	211	228	244					
280	81	98	114	130	146	163	179	195	211	228	244					
285	81	98	114	130	146	163	179	195	211	228	244					
290	81	98	114	130	146	163	179	195	211	228	244					
295	81	98	114	130	146	163	179	195	211	228	244					
300	81	98	114	130	146	163	179	195	211	228	244					
305	81	98	114	130	146	163	179	195	211	228	244					
310	81	98	114	130	146	163	179	195	211	228	244					
315	81	98	114	130	146	163	179	195	211	228	244					
320	81	98	114	130	146	163	179	195	211	228	244					
325	81	98	114	130	146	163	179	195	211	228	244					
330	81	98	114	130	146	163	179	195	211	228	244					
335	81	98	114	130	146	163	179	195	211	228	244					
340	81	98	114	130	146	163	179	195	211	228	244					
345	81	98	114	130	146	163	179	195	211	228	244					
350	81	98	114	130	146	163	179	195	211	228	244					
355	81	98	114	130	146	163	179	195	211	228	244					
360	81	98	114	130	146	163	179	195	211	228	244					
365	81	98	114	130	146	163	179	195	211	228	244					
370	81	98	114	130	146	163	179	195	211	228	244					
375	81	98	114	130	146	163	179	195	211	228	244					
380	81	98	114	130	146	163	179	195	211	228	244					
385	81	98	114	130	146	163	179	195	211	228	244					
390	81	98	114	130	146	163	179	195	211	228	244					
395	81	98	114	130	146	163	179	195	211	228	244					
400	81	98	114	130	146	163	179	195	211	228	244					

Continued on next page.

TABLE OF AREA OF SAFETY VALVES REQUIRED PER SQUARE FOOT OF GRATE SURFACE FOR DIFFERENT PRESSURES AND RATES OF EVAPORATION.

P, absolute pressure per square inch.	These figures represent evaporation in pounds per square foot of grate surface per hour (W) = pounds water evaporated per pound coal X pounds coal burned per square foot grate surface per hour.														
	100	120	140	160	180	200	220	240	260	280	300	320	340	360	380
260	.080	.096	.112	.128	.144	.160	.176	.192	.208	.224	.240	.255	.271	.287	.303
265	.078	.094	.110	.125	.141	.157	.172	.188	.203	.219	.235	.250	.266	.282	.298
270	.077	.092	.107	.123	.138	.153	.169	.184	.199	.215	.230	.245	.261	.276	.291
275	.075	.090	.105	.121	.136	.151	.166	.181	.196	.211	.226	.241	.256	.271	.286
280	.074	.089	.104	.118	.133	.148	.163	.178	.192	.207	.222	.237	.251	.266	.281
285	.073	.087	.102	.116	.131	.146	.160	.175	.189	.204	.218	.233	.247	.262	.276
290	.072	.086	.100	.114	.129	.143	.157	.172	.186	.200	.214	.228	.242	.257	.271
295	.070	.084	.098	.112	.127	.141	.154	.169	.182	.196	.210	.224	.238	.253	.267
300	.069	.083	.096	.110	.124	.138	.151	.166	.179	.193	.207	.221	.235	.249	.263
305	.068	.082	.095	.109	.122	.136	.149	.163	.177	.190	.204	.217	.231	.245	.258
310	.067	.080	.093	.107	.120	.134	.147	.160	.174	.187	.201	.214	.227	.241	.254
315	.066	.079	.092	.105	.118	.132	.145	.158	.171	.184	.197	.210	.223	.237	.250
300	The figures below give a, the area in square inches required per square foot of grate surface at the above rate of evaporation.														

The seats of all safety valves shall have an angle of inclination of 45 degrees to the center line of their axis.

Rule to find area of pop safety valve computed from grate surface, water evaporation and pressure: Multiply constant .2074 by water evaporated per pound of coal per hour and divide by working pressure; this gives area of safety valve per square foot of grate surface. Multiplying this result by total grate surface gives required area of safety valve for furnace grate area.

FORMULA:

$$\frac{.2074 \times W}{P} = \text{area of safety valve per square foot of grate area}$$

LEGEND:

- C = constant = .2074
- W = pounds of water evaporated per square foot of grate surface per hour = 8 pounds of water per pound of coal.
- P = absolute pressure plus 15 pounds atmospheric pressure = 90 pounds.
- G = grate surface = 30 feet.
- Coal burned per square foot of grate per hour = 12.5 pounds.

EXAMPLE:

lbs. of coal burned per square
foot of grate per hour = 12.5
water evaporated = 8

100.0

.2074 = constant
100 = lbs. of water evap. per hour

working pressure = 90) 20.7400 (.2304 = area of valve per 1
18 0 square foot of grate

2 74
2 70

400
360

.2304 = area of valve
30 = total square feet of grate surface

6.9120 = 3" diameter valve required

REQUIREMENTS IN CONSTRUCTION OF LEVER-SAFETY VALVES.

All the points of bearing on lever must be in the same plane.

The distance of the fulcrum must in no case be less than the diameter of the valve opening.

The length of the lever should not exceed the distance of the fulcrum multiplied by ten.

The width of the bearings of the fulcrum must not be less than three-fourths of 1 inch.

The length of the fulcrum link should not be less than 4 inches.

In all cases the weight must be adjusted on the lever to the pressure of steam allowed in each case by a correct steam gauge attached to the boiler. The weight must then be securely fastened in its position and the lever marked for the purpose of facilitating the replacing of the weight should it be necessary to remove the same, and in no case shall a line or any other device be attached to the lever or weight except in such manner as will enable the engineer to raise the valve from its seat.

When safety valve is blown off always note pressure on gauge; if there is a difference, seek the cause and adjust the gauge or valve until they are as intended.

The lever safety valve, while being very extensively used, is not perfect in action or operation, in not seating itself until pressure has been reduced considerable below point it is set at.

The following rules are used in determining values, viz.: pressure, length of lever and weight of ball.

Rule to find weight of ball when pressure, length of lever and area of valve is known: Multiply pressure in pounds by area of valve in inches and multiply this product by distance of valve center to fulcrum; subtract weight of lever from this product and divide sum by length of lever.

LEGEND:

Va = valve area = 12.5664 = 4" valve

L = length of lever = 30"

W = weight of lever = 20 lbs.

d = distance valve center to fulcrum = 4"

P = pressure = 100 lbs.

FORMULA:

$$\frac{P \times Va \times d - W}{L} = \text{weight required for ball}$$

EXAMPLE:

$$12.5664 = 4'' \text{ valve area}$$

$$100 = \text{pressure}$$

$$\begin{array}{r} 1256.6400 \\ \hline 4 = \text{distance valve center to fulcrum} \end{array}$$

$$\begin{array}{r} 5026.5600 \\ \hline 20. = \text{weight of lever} \end{array}$$

$$\text{length of lever} = 30'' \quad \begin{array}{r} 5006.5600 \\ \hline 30 \end{array} (166.8853 \text{ or } 167 \text{ lbs. nearly} = \text{weight of ball})$$

$$\begin{array}{r} 200 \\ 180 \\ \hline 206 \\ 180 \\ \hline 265 \\ 240 \\ \hline 256 \\ 240 \\ \hline 160 \\ 150 \\ \hline 100 \\ 90 \\ \hline 10 \end{array}$$

Rule to find length of lever when pressure and weight of ball and area of valve is given: Multiply area of valve by pressure in pounds and by distance of center of valve to fulcrum; to this product add weight of lever; divide by weight of ball.

FORMULA:

$$\frac{V_a \times P \times d + W}{W_t} = \text{length of lever}$$

EXAMPLE

Wt = weight of ball = 166.8853 lbs.

$$12.5664 = \text{valve area}$$

$$100 = \text{lbs. pressure}$$

$$\begin{array}{r} 1256.6400 \\ \hline 4'' = \text{valve center to fulcrum} \end{array}$$

$$\begin{array}{r} 5026.5600 \\ \hline 20. = \text{weight of lever} \end{array}$$

$$\text{weight of ball} = 166.8853 \quad \begin{array}{r} 5046.5600 \\ \hline 5006.559 \\ \hline 40.0010 \end{array} (30 = \text{length of lever})$$

Rule to find pressure a safety valve will blow off at when weight of ball, length of lever and distance of valve center to fulcrum are known: Multiply weight of ball by length of lever, add weight of lever to this and divide by valve area multiplied by distance of valve center to fulcrum; the quotient will be pressure in pounds.

$$\text{FORMULA:}$$

$$\frac{Wt \times L + W}{Va \times d} = \text{pressure}$$

EXAMPLE:

166.8853 = weight of ball
30" = length of lever

$$\begin{array}{r} \text{valve area} = 12.5664 \quad 5006.5590 \\ \text{distance} = \quad 4'' \quad 20. \quad = \text{weight of lever} \\ \hline 50.2656) 5026.55900 \quad (99.9 \text{ or } 100 \text{ pounds} \\ \quad 4523 \quad 904 \quad \quad \quad \text{pressure nearly} \\ \hline \quad \quad 502 \quad 6550 \\ \quad \quad 452 \quad 3904 \\ \hline \quad \quad 50 \quad 26460 \\ \quad \quad 45 \quad 23904 \\ \hline \quad \quad 5 \quad 02556 \end{array}$$

Extracts from U. S. Government rules and regulations, prescribed by the Board of Supervising Inspectors, as amended January, 1907:

"No engineer's license shall be issued hereafter or grade increased except upon written examination, which written examination shall be placed on file as records of the office of the inspectors issuing said license. When any person makes application for license it shall be the duty of local inspectors to give the applicant the required examination as soon as practicable."

CLASSIFICATION OF ENGINEERS.

CHIEF.

Chief engineer of ocean steamers.

Chief engineer of condensing lake, bay and sound steamers.

Chief engineer of noncondensing lake, bay and sound steamers.

Chief engineer of condensing river steamers.

Chief engineer of noncondensing river steamers.

Any person holding chief engineer's license shall be permitted to act as first assistant on any steamer of double the tonnage of same class named in said chief's license.

Engineers of all classifications may be allowed to pursue their profession upon all waters of the United States in the class for which they are licensed.

FIRST ASSISTANT.

First assistant engineer of ocean steamers.

First assistant engineer of condensing lake, bay and sound steamers.

First assistant engineer of noncondensing lake, bay and sound steamers.

First assistant engineer of condensing river steamers.

First assistant engineer of noncondensing river steamers.

Engineers of lake, bay and sound steamers, who have actually performed the duties of engineer for a period of three years, shall be entitled to examination for engineer of ocean steamers, applicant to be examined in the use of salt water, method employed in regulating the density of the water in boilers, the application of the hydrometer in determining the density of sea water and the principle of constructing the instrument; and shall be granted such grade as the inspectors having jurisdiction on the Great Lakes and seaboard may find him competent to fill.

Any assistant engineer of steamers of 1,500 gross tons and over, having had actual service in that position for one year, may, if the local inspectors, in their judgment, deem it advisable, have his license indorsed to act as chief engineer on lake, bay, sound, or river steamers of 750 gross tons or under.

Any person having had a first assistant engineer's license for two years and having had two years' experience as second assistant engineer, shall be eligible for examination for chief engineer's license.

SECOND ASSISTANT.

Second assistant engineer of ocean steamers.

Second assistant engineer of condensing lake, bay and sound steamers.

Second assistant engineer of noncondensing lake, bay and sound steamers.

Second assistant engineer of condensing river steamers.

Any person having had a second assistant engineer's license for two years and having had two years' experience as third assistant engineer, shall be eligible for examination for first assistant engineer's license.

THIRD ASSISTANT.

Third assistant engineer of ocean steamers.

Third assistant engineer of condensing lake, bay and sound steamers.

First, second, and third assistant engineers may act as such on any steamer of the grade of which they hold license, or as such assistant engineer on any steamer of a lower grade than those to which they hold a license.

Any person having a third assistant engineer's license for two years and having had two years' experience as oiler or water tender since receiving said license, shall be eligible for examination for second assistant engineer's license.

Inspectors may designate upon the certificate of any chief or assistant engineer the tonnage of the vessel on which he may act.

Any assistant engineer may act as engineer in charge on steamers of 100 tons and under. In all cases where an assistant engineer is permitted to act as engineer in charge, the inspectors shall so state on the face of his certificate of license without further examination.

It shall be the duty of an engineer when he assumes charge of the boilers and machinery of a steamer to forthwith thoroughly examine the same and if he finds any part thereof in bad condition, caused by neglect or inattention on the part of his predecessor, he shall immediately report the facts to the master, owner, or agent and to the local inspectors of the district, who shall thereupon investigate the matter and if the former engineer has been culpably derelict of his duty, they shall suspend or revoke his license.

Before making general repairs to a boiler of a steam vessel the engineer in charge of such steamer shall report, in writing, the nature of such repairs to the local inspector of the district wherein such repairs are to be made.

And it shall be the duty of all engineers when an accident occurs to the boilers or machinery in their charge tending to render

the further use of such boilers or machinery unsafe until repairs are made, or when, by reason of ordinary wear, such boilers or machinery have become so unsafe, to report the same to the local inspectors immediately upon the arrival of the vessel at the first port reached subsequent to the accident, or after the discovery of such unsafe condition by said engineer.

Whenever a steamer meets with an accident involving loss of life or damage to property, it shall be the duty of the licensed officers of any such steamer to report the same in writing and in person without delay to the nearest board: *Provided*, That when from distance it may be inconvenient to report in person it may be done in writing only and the report sworn to before any person authorized to administer oaths.

No person shall receive an original license as engineer or assistant engineer (except for special license on small pleasure steamers and ferryboats of 10 tons and under, sawmill boats, pile drivers, boats exclusively engaged as fishing boats and other similar small vessels) who has not served at least three years in the engineer's department of a steam vessel, a portion of which experience must have been obtained within the three years next preceding the application.

Provided, That any person who has served three years as apprentice to the machinist trade in a marine, stationary, or locomotive engine works, and any person who has served for a period of not less than three years as a locomotive or stationary engineer, and any person graduated as a mechanical engineer from a duly recognized school of technology, may be licensed to serve as an engineer of steam vessels after having had not less than one year's experience in the engine department of steam vessels, a portion of which experience must have been obtained within the three years preceding his application; which fact must be verified by the certificate, in writing, of the licensed engineer or master under whom the applicant has served, said certificate to be filed with the application of the candidate; and no person shall receive license as above, except for special license, who is not able to determine the weight necessary to be placed on the lever of a safety valve (the diameter of valve, length of lever, distance from center of valve to fulcrum, weight of lever and weight of valve and stem being known) to with-

stand any given pressure of steam in a boiler, or who is not able to figure and determine the strain brought on the braces of a boiler with a given pressure of steam, the position and distance apart of braces being known, such knowledge to be determined by an examination in writing, and the report of examination filed with the application in the office of the local inspectors, and no engineer or assistant engineer now holding a license shall have the grade of the same raised without possessing the above qualifications. No original license shall be granted any engineer or assistant engineer who can not read and write and does not understand the plain rules of arithmetic.

Any person may be licensed as engineer (on Form 2130 $\frac{7}{8}$) [New Form 880] on vessels propelled by gas, fluid, naphtha, or electric motors, of 15 gross tons or over, engaged in commerce, if in the judgment of the inspectors, after due examination in writing, he be found duly qualified to take charge of the machinery of vessels so propelled.

Any person holding a license as engineer of steam vessels, desiring to act as engineer of motor vessels, must appear before a board of local inspectors for examination as to his knowledge of the machinery of such motor vessels, and if found qualified shall be licensed as engineer of motor vessels. Form 878, special license to engineers, shall be issued only to engineers in charge of vessels of 10 tons and under. All other licenses to engineers shall be issued on Forms 876 and 877, according to grades specified in this section.

INSPECTING BOILERS.

The necessity of care in inspecting steam boilers is apparent when the amount of power stored up while the boiler is in commission is known—as an illustration: a common sized boiler 60" \times 16' has 38923 square inches, and carrying a pressure of 100 pounds, has 1946 tons of energy. With strains of expansion and contraction not equal all over but varying, and limits to the extreme—(i. e.) the temperature of fire in furnace to that of parts furthest from it, and furthermore when considering that 85% of the boiler is concealed—this by design or principle of installation—the

necessity of vigilance can be realized, especially when the causes of failure and defects are numerous, viz.:

Material,
Design,
Construction,
Appliances,
Fuel,
Feed Water,
Settings, and
Management and Care.

The hydrostatic test is a method not very satisfactory but often necessary when access to parts is impossible, or where a design of boiler has flat surface and notice of bulging or elongation must be noted before and after pressure; it is necessary when notes of bracing are to be taken and when there are any minor defects such as leaks at rivets or caulking so they can be remedied before more serious results follow. When a hydrostatic test is made of boilers that are accessible, braces and such joints that are weaker than the original plates' tensile strength, must be inspected carefully for any distortions or leaks due to riveting, welds or defective flanges—and hidden defects may give evidence of their presence.

INSPECTIONS.

There are internal and external inspections, both essential in determining the boiler's safety; for to determine the safe working pressures, an internal inspection is absolutely necessary.

The conditions for this latter examination are as follows: The boiler must be cool, water out (this is supposing the boiler has been in commission), ashes and soot removed, the mud only washed out of boiler (it is well to avoid excessive pump pressure when washing out until inspection is made), this so as not to destroy or wash off any evidence of leaks that might be at points inaccessible to view from the outside, but would be in evidence at a point inside, for deposits or precipitation in suspension would collect at point where leakage was, thus giving evidence of leaks that could not be seen from outside; this, of course, applies to boilers of size and design accessible. A thorough examination must be made of all parts of boiler accessible; sounding plates where possible over fire or in

furnace; and parts where not possible over fire or in furnace to see or sound, symptoms that would deceive the eye, can, at times, be detected by the sense of touch; flanges and junction of pipes at boilers must be examined, for threads are an initial fracture, and by the pipe or boiler expanding much undue strain results and often causes breaking off of pipe. The tubes at rear and front heads being thin, are often a source of annoyance; examine seams and rivets for leakage and cracks; see that openings to outlets are free from obstructions; sound braces; examine flanges, seams and rivets internally, the condition as to incrustation, corrosion, pitting, and when in doubt, give a hydrostatic test; this would reveal any weakness and leaks impossible to see, or defects developed by closing down the boiler, resulting in contraction. An inspection and sounding of braces should follow the hydrostatic test. Stay bolts must be sounded when type of boiler is braced by them.

The first thing, look at or for the water level, then the steam pressure; view the furnace, tube sheets, crown sheets and sides in internal fired boilers and bottom and furnace walls in external fired boilers, looking at back head from rear doors for leakage; (the doors at rear end were designed for access to back head and to view when the boilers were in commission) the blow-off, and as much of the bottom as possible; brick work; examine the blow off pipe; if it is hot outside of valve it is evidence of leakage at valve (this unless some drips or other steam outlets are connected into same blow-off pipe). A leaky blow-off valve is a source of danger, waste of fuel and energy; the danger lies in the fact that the precipitates will collect at a point where there is leakage and as the blow-off pipe part of it is exposed to heat one can realize there is danger by burning of blow-off pipe.

The outside of brick settings should be examined for fissures or cracks caused by expanding of boiler and excessive heat. These cracks admit cold air, quantity governed by size and draft. These are the cause of much loss of energy, certainly a waste of fuel, and at expense of life or boiler.

Examine the feed appliances; test the steam gauge; following this up by firing up of boiler to point of safe working pressure, then the setting of valve if necessary. When the steam gauge is taken off, blow out the pipe and be sure it is clear, for oftentimes these pipes

are neglected, and if there is a syphon or trap for condensation, this latter will generate corrosion and liable to stop up stop-cock, if not the pipe.

Management and care must be considered, as we have measured the safe working pressure by design, material and construction. The best of man's work would be trivial in the hands of an ignorant boiler attendant, and the only factor for safety in such cases would be to *keep the boilers cold*. Again, the inspector must bear in mind that those in power to hire attendants are oftentimes those whose knowledge of the requirements necessary, for men and duties is very limited.

Fuel should be considered by the inspector, for in these days of coal as fuel it must be remembered that the more sulphur in the fuel, the quicker crystallization will develop in the plates.

Quality of feed water, its temperature and point of admission should be looked after; for these are elements that will, in a measure, give evidence of what one expects.

POINTS TO CONSIDER WHEN INSPECTING BOILERS.

Evidence of excessive firing; piping of boilers for best effect to allow for expansion; avoid rigidity; pipe of sufficient strength for high pressures; deterioration from leakage; corrosion from sulphuric action—soot and moisture develops sulphuric acid. Remember that 75 per cent of the boiler is concealed either by the design or settings and much depends on viewing and examining the minimum portion; that a large amount of energy is stored up in the boiler when in commission; for instance, a boiler 60' \times 16' at 100 pounds pressure has approximately 1946 tons of energy stored in it. This suggests reasons for thought. There is lamination or blisters and bagging of plates to look for, or to be expected. See that water columns are properly connected and convenient to try at all times; that the safety valve is of sufficient size and operative; that blow-pipes are of proper size and protected; that the feed water appliances are ample and more than one to feed boiler; that the feed water enters at a suitable place; that the check and stop valves are connected and placed a reasonable distance from boiler; that the boiler (if externally fired) is properly set for heat distribution; that the grates are not too close to the boiler (bottom), for space is necessary for combustion and conductivity of heat. Do not for-

get that it is a human being who is in charge of the boiler and that it is human to err. This will impress the inspector that if the man in-charge knew as much as he does, the inspector's services would not be necessary. It also qualifies the old adage, "No man is the best judge of his own work or actions."

● THE SAFE WORKING PRESSURE.

Years ago the Lloyds of Europe adopted a rule to govern the safe working by pressure, viz.: One sixth of the tensile strength of plate, multiplied by thickness of the plate, and divided by the radius; and for years this rule was used universally. It was the supposition that the plate and rivet strength would be near equal and construction the best, 20 per cent was added for double riveted longitudinal seam. At that time low pressures were the rule, consequently security or safety was reasonably expected; but when other factors came to be considered, different types of engines that required higher pressures and fuel became a prime factor, along with space, the demand for higher pressure became apparent and something more than the old time design and construction of boilers had to be considered. The weakest point had to be strengthened, necessitating butt joints, drilled holes, modern flanging, braces and bracing, larger plates and less joints, abandonment of cast iron for man holes and openings. Boiler making tools and machinery had to keep pace, thus the advancement made in the craft necessitates some more definite rules to govern us in the allowing of a safe working pressure. The factor of six, as formerly used, was, no doubt, little enough when iron plates, short and narrow, were used; chipping done by hand, i. e., the grooving by same; punched holes; the drift pin and designing of seams. Thus it was absolutely necessary for a large factor of safety; but as stated, boiler construction to-day is modern and complies to the demand for high pressures. We are too advanced to use such a large safety factor as 6. It is true there are the extremes, but there are things that must be considered in this matter of safety factor, viz., design; tensile strength; thickness of plate; diameter of hole; diameter and pitch of rivet; shearing strength of rivet; diameter of boiler; bracing; lowest percentage of seam. It might be carried further to be more definite, by considering the boiler's use; if boiler would

be forced; if loads would vary; type of engine; if the boiler would be used for power or heating only.

It would not be consistent to lay down any specified rule to govern all cases. It may be that the boiler would deteriorate faster in one location than another. This, of course, would be a local consideration, but in these days of modern ideas, designs and construction, a factor of four would be ample to cover all differences in construction and material.

Prepare for inspection by having ashes and deposits removed from under boiler and ash pits, tubes cleaned and soot removed.

Allow boiler and setting time to cool off gradually, open gauges before letting water run out. Leave dampers open and furnace door closed.

Wash boiler out and have same as dry as possible.

Take steam gauges down for testing.

Steam gauges should be connected with a union between stop cock and gauge, so that the latter can be taken off syphon or pipe without disturbing threads that would alter position when connecting gauge again. It is advisable, when having gauges tested, to raise steam and note point of blowing off, and adjust safety valve if necessary.

If a hydrostatic test is to be made have pump and piping connected and the hydrostatic test applied to a pressure equal to the proportions of 150 pounds to 100 pounds working pressure.

The U. S. Government makes annual inspections and tests and all mandates are carried out to the letter.

Testing of plates, piping and material must fill all requirements, or condemnation or rejection follows. Boilers and appliances must be approved before installing and put into commission.

Some of the requirements are as follows:

CAST STEEL AND CAST IRON.

No cast steel or cast iron subject to pressure shall be allowed to be used in boilers or the pipes connected thereto, except as described as follows:

Cast iron or cast steel may be used in the construction of man-hole and hand-hole plates, valves and cocks, water columns, flanges, saddles, ells, tees, crosses or manifolds when such flanges, saddles,

ells, tees, crosses, valves and cocks, or manifolds are bolted or riveted directly to the boiler and the valves or cocks; also, casings of slip joints in pipes: *Provided, however,* that the material shall be of the best grade and of suitable thickness and uniform section for the pressure allowed on boilers.

FEED WATER.

The feed water shall not be admitted into any boiler at a temperature less than 100° F., and no marine boiler shall be used without having proper auxiliary appliances for supplying said boilers with water in addition to the usual mode employed.

NAME PLATES.

There shall be fastened to each boiler a plate containing the name of the manufacturer of the material, the place where manufactured, the tensile strength, the name of the builder of the boiler, when and where built.

FUSIBLE PLUGS.

Every boiler, other than boilers of the water-tube type, shall have at least one fusible plug as described below. Plugs shall be made of a bronze casing filled with good Banca tin from end to end. The manufacturers of fusible plugs shall stamp their name or initials thereon for identification and shall file with the local inspectors a certificate, duly sworn to, that such plugs are filled with Banca tin.

Fusible plugs, except as otherwise provided, shall have an external diameter of not less than three-fourths of an inch pipe tap, and the Banca tin shall be at least one-half of an inch in diameter at the smallest end and shall have a larger diameter at the center or at the opposite end of the plug.

Fusible plugs, when used in the tubes of upright boilers, shall have an external diameter of not less than three-eighths of an inch pipe tap, and the Banca tin shall be at least one-fourth of an inch in diameter at the smaller end and shall have a greater diameter at the opposite end of the plug: *Provided, however,* that all plugs used in boilers carrying a steam pressure exceeding 150 pounds to the square inch may be reduced at the smaller end of the Banca tin to five-sixteenths of an inch in diameter.

Externally heated cylindrical boilers, with flues, shall have one

plug inserted in one flue and also one plug inserted in shell of each boiler, immediately below the fire line and not less than 4 feet from the front end: *Provided, however,* that when such flues are not more than 6 inches in diameter a fusible plug of not less diameter than three-eighths-inch pipe tap may be used in such flues.

Other shell boilers, except especially provided for, shall have one plug inserted in the crown sheet of the back connection.

Vertical tubular boilers shall have one plug inserted in one of the tubes at least 2 inches below the lowest gauge cock, but in boilers having a cone top the plug shall be inserted in the upper tube sheet.

All plugs shall be inserted so that the small end of the Banca tin shall be exposed to the fire.

It shall be the duty of the inspector at each annual inspection to see that the plugs are in good condition.

GAUGE COCKS AND WATER GLASS.

All boilers shall be supplied with one reliable water gauge and three gauge cocks in each boiler: *Provided,* that when the gauge glass and gauge cocks are connected to the boilers by a water column there must be an additional gauge cock inserted in the head or shell of boiler. The lower gauge cock in boilers more than 48 inches in diameter shall not be less than 4 inches from the top of the flues or tubes. In boilers less than 48 inches in diameter the lower gauge cock shall not be less than $2\frac{1}{2}$ inches above the top of the flues or tubes. A gauge glass shall be considered a reliable water gauge, and a float such as used on western river steamers shall be considered on such boilers as a reliable water gauge.

In vertical boilers or boilers of the water-tube type the location of the lowest gauge cock shall be determined by the local inspectors.

Boilers known as flash boilers constructed of a continuous coil of pipe or series of coils of pipes under three-fourths inch in diameter, whose construction has been approved by the Board of Supervising Inspectors, shall not be required to be supplied with gauge cocks or low-water gauges.

DRILLING TO DETERMINE THICKNESS.

Any boiler ten years old or more shall, at the first annual inspection thereafter, be drilled at points near the water line and at bottom of shell of boiler, or such other points as the local inspectors may direct, to determine the thickness of such material at those points; and the steam pressures allowed shall be governed by such ascertained thickness and the general condition of the boiler.

HYDROSTATIC PRESSURE.

The hydrostatic pressure applied must be in the proportion of 150 pounds to the square inch to 100 pounds to the square inch of the steam pressure allowed and the inspector, after applying the hydrostatic test, must thoroughly examine every part of the boiler.

In applying the hydrostatic test to boilers with a steam chimney, the test gauge should be applied to the water line of such boilers.

All coil and pipe boilers hereafter made, when such boiler is completed and ready for inspection, must be subjected at the first inspection to a hydrostatic pressure double that of the steam pressure allowed in the certificate of inspection.

The use of malleable-iron or cast-steel manifolds, tees, return bends or elbows in the construction of pipe generators shall be allowed and the pressure of steam shall not be restricted to less than one-half the hydrostatic pressure applied to pipe generators unless a weakness should develop under such test as would render it unsafe in the judgment of the inspector making such inspection.

DRUMS AND HEADS.

All drums attached to coil, pipe, sectional or water-tube boilers not already in use or actually contracted for, to be built for use on a steam vessel and its building commenced at or before the date of the approval of this rule, shall be required to have the heads of wrought iron or steel or cast steel flanged and substantially riveted to the drums or secured by bolts and nuts of equal strength with rivets, in all cases where the diameters of such drums exceed 6 inches.

Drums and water cylinders constructed with a bumped head at each or either end, (any opening in the shell or heads to be

reinforced as required by the rules of the Board, the circumferential and horizontal seams to be welded and properly annealed after such welding is completed), when tested with a hydrostatic pressure at least double the amount of the steam pressure allowed may be used for marine purposes.

PIPES.

COPPER.

All copper pipe subject to pressure shall be flanged over or outward to a depth of not less than twice the thickness of the material in the pipe and such flanging shall be made to a radius not to exceed the thickness of the pipe. On boilers whose construction was commenced after June 30, 1905, no bend will be allowed in copper pipe of which the radius is less than one and one-half times the diameter of the pipe and such pipe must be so led and flanges so placed that they may be readily taken down if required. Such pipes must be protected by iron casings when run through coal bunkers and must be clear of the coal chutes.

The flanges of all copper steam pipes over 3 inches in diameter shall be made of brass or bronze composition, forged iron or steel, or open-hearth steel castings and shall be securely brazed or riveted to the pipe: *Provided, however*, that when such pipes are properly formed with a taper through the flange, such taper being fully reinforced, the riveting or brazing may be dispensed with: *And provided, also*, that when the pipe has been expanded by proper and capable machinery into grooved flanges and the pipe flared out at the ends to an angle of approximately 20°, said angle to be taken in the direction of the length of the pipe and having a depth of flare equal to at least one and one-half times the thickness of the material in the pipe, said riveting or brazing may be dispensed with. Where copper pipes are expanded into or riveted to flanges it will be necessary for the pipes with their flanges attached to withstand a hydrostatic pressure of two and one-half times the boiler pressure.

Flanges must be of sufficient thickness and must be fitted with such number of good and substantial bolts to make the joints at least equal in strength to all other parts of the pipe.

Any form of joint that will add to the safety or increase the

strength of flange and pipe connections over those provided for by this rule, will be allowed on any and all classes of steam pipe.

WATER TUBE AND COIL BOILERS.

Blue prints or drawings of coil boilers and of other boilers, with their specifications, submitted to the Board of Supervising Inspectors for approval under section 4429, Revised Statutes of the United States, must be in duplicate before action thereon will be taken by the Board, with a view of approving the same; one set to be filed with the records of the Board of Supervising Inspectors and the other with the records of the supervising inspector of the district where the manufacturer of the boiler is located.

Rule to find the working pressure allowable on cylindrical shells of water tube or coil boilers, when such shells have a row or rows of pipes or tubes inserted therein: From pitch of holes subtract diameter of pipe, then multiply by thickness of plate and one-sixth of tensile strength. Divide this product by pitch of holes multiplied by radius.

FORMULA:

$$\frac{p-d \times T \times 1/6 \text{ of TS}}{p \times R} = \text{pressure}$$

LEGEND:

p = pitch = 2''
 d = diameter of pipe = 1''
 T = thickness of plate = $\frac{1}{2}$ '' = .5
 TS = tensile strength = 60000
 R = radius = 10''

EXAMPLE:

$$\begin{array}{r}
 2 = \text{pitch} \\
 1 = \text{diameter of pipe} \\
 \hline
 1 \\
 .5 = \text{thickness of plate} \\
 \hline
 \text{pitch} = 2'' \quad .5 \\
 \text{radius} = 10'' \quad 10000 = \text{one-sixth of tensile strength of} \\
 \hline
 20) \quad 5000.0 \quad \text{(250 pounds pressure allowed)} \\
 \quad 40 \\
 \hline
 \quad 100 \\
 \quad 100 \\
 \hline
 \quad 0
 \end{array}$$

CHAPTER X.

FEED WATER HEATING AND PURIFICATION.

While boiler designing, construction and setting have received the thought and attention of many prominent specialists of this age, this for security against the high pressures necessary to meet the demands of modern engines and that factor, fuel, it is apparent even to the layman that the feed water for steam boilers must be a factor worthy of much consideration, for it means life of boiler and efficiency of same — this under varying conditions even to those who have free fuel and best of water. Various appliances and methods are employed to obtain the best possible results from feed water, for the latter is one of the primaries for disaster and expense in operation. Many well designed and well constructed boilers have been condemned on this account. Reputations that have been built on years of experience and study have been affected by local influences — bad feed water.

Instances can be cited where boilers designed and made by the most progressive boiler makers have been condemned and only material and construction given by the operators as a cause for failures or reduced condition. Feed water is the initial factor in the steam plant. To install the best designed and constructed boiler from the best of material and subject the same to bad feed water, failure of seams or plate are the results expected.

In some localities incrustation and deposits from water are unknown — this where matter which is soluble in land strata are absent — but these locations are very few to the major part of this country. Hence the necessity for an appliance — a vital adjunct to the steam plant — i. e., a feed water purifier.

Many and varied are the appliances now used for this purpose; it would seem that each one has its advocates and no doubt its niche, or suitable place. They all aim to obtain the best possible results, but many fail to accomplish the maximum effect.

A brief description of types mostly in use may be interesting or at least give some food for thought. Possibly future discussions may change views and show that present convictions are wrong. Such subjects are almost inexhaustible and when analyzed they can be made subjects of much merit and of great interest to those whose lives are devoted to steam engineering. For instance, analyzing the boiler, we find:

- Material.
- Design.
- Construction.
- Settings.
- Appliances.
- Management and care, and
- Feed water.

It is the latter which I will attempt to digest, not in material value order, or on personal judgment, but as they suggest themselves to the mind when reviewing this subject. A brief description of types in use are:

1. Auxiliary pipes.
2. Water backs.
3. Pipes in uptakes.
4. Closed heaters.
5. Boxes or receptacles in boilers.
6. Live steam heaters.
7. Open heaters.

There is no question but that any or all of these types have some merit in some particular place or under some conditions.

I will take them up in individual order and try to point out their degree of usefulness, or advantages, one over the other.

In order to obtain the best values, we must look for requirements, they must be known; then put them in valued order.

The heater and purifier must have some of these requirements. There is much variance with each type, no two alike, when units of measurement are taken. Quotations of prices are based on individual units of measurement and, like the different types of boilers, are rated on a given quantity of heating surface ranging from 6 to 15 square feet—this irrespective of plate thickness, grate surface, fuel or draft. It is the same with the heaters and so-called purifiers.

1. AUXILIARY PIPES.

These are connected to boiler, water and steam connections. They simply make additional heating surface and have very little merit otherwise. They are not to be recommended for either efficiency, safety or economy. They are short-lived, a menace to security, subject to incrustation and fracture due to expansion and contraction; impossible to clean, making, oftentimes, long and serious delays. It is like courting disaster to apply these to a boiler.

2. WATER BACKS.

These are usually placed back of boiler, top of setting, or in front of or at sides of furnace and shapes are either cylindrical or flat. They are supposed to act in a dual capacity—feed water heater and form an arch or a part of the furnace. It cannot be said that there is any fuel economy. They are a part of the boiler and absorb furnace heat. They have boiler pressure, and are no prevention against solids in suspension going into boiler. They often become incrustated, necessitating repairs, and when one considers the difference in temperature in such a short space, between parts exposed to fire and boiler room, expectations can be realized. The tempering of water by heat before going to boiler, as in case of injectors, is the only point of merit they have. The cylinder type may have some advantages—strength of form and being more accessible to clean. The flat type offers little in that respect. The latter are more costly, owing to the flange and the bracing by stay bolts. Again, either type has the disadvantage of adding weight on settings or walls. The latter are expensive items in keeping up the boiler plant.

3. PIPES IN UPTAKE.

This application for heating feed water has sometimes primary benefits in the way of economy, due to absorbing heat from escaping gases. But this is largely a guess and it is a question if they are often or long economical, for the heat escaping up the stack or uptake is a large factor, in fact very necessary and essential when natural draft is depended on, and supply limited; for to reduce this temperature means less oxygen to fuel.

In some places, and under some conditions, there may be some economy, but in the average plant, none. Incrustated pipes, solids in suspension forced into boilers, fractures, delays in removal or cleaning, can be expected. This type cannot be considered a profitable investment even in plants where induced draft is used, unless water is purified before going through same.

4. CLOSED HEATERS.

Water or steam tubes or pipes, return bends, corrugated or straight, coils, with and without setting chambers.

These appliances are made in varying forms, the aim being to obtain heat from exhaust steam in non-condensing plants, but it is futile to expect anything like purification of feed water from this type. No matter what design they are, their value is limited to that of heating to some extent, the feed water then at a low temperature. They have pressure in excess of the boiler, this owing to the necessity of lifting check valve or overcoming weight of water and pressure in boiler. The exhaust steam temperature must be conducted through plate pipes, coils or tubes, there being no chance for precipitation other than light solids, such as magnesia—this owing to lack of temperature imparted by exhaust and the existing pressure in heater, even with back pressure on engine, for to precipitate other solids the temperature must be increased with pressure obtained in heater. For instance, if pressure was 100 pounds, the temperature necessary would be 338 F., but at atmospheric pressure it would be 212 F. Then what chances could there be even with back pressure when the heat must be conducted through plate? Should light solids be precipitated these would be forced into boiler. Again, this type or class of heater is hard if not almost impossible to clean. Thus, should any solids be in suspension and collect, when the attempt is made to clean exhaust pipes must be disconnected and those of water or steam tube type are difficult for access.

Those with a so-called setting chamber have very little effect from settling, for these have a continuous circulation when feed water passes through. Hence settling is impossible when pumps would be stopped; then the only amount of settling would be equal to that which volume of water at that time would hold.

One argument used in its favor, as heard, is that "only one

pump is required." This apparently is enough to convince the layman that to select this type is wise. Some of these closed heaters may have individual merit. For instance, the return bend expands on one end — that is, it is free to do so. Then the corrugated tube has additional heating surface and prevents leaking at ends, expansion and contraction being taken up by the corrugations. But in this form of heater, condensation is usually lost with its purity and heat units. This heater is fast being relegated to one place in the power plant, and that place is the condensing one. Its position being between the engine, cylinder and injection water. Its value, besides giving some heat, is to prevent condensation of steam in cylinder by the injection water.

5. THE BOX OR RECEPTACLE THAT IS PLACED IN THE BOILER.

This idea of a feed water heater and purifier is not new. It is old and has been tried and found wanting. These may be obtained in any shape, or to be put or placed in any part of boiler, on top of tubes or under same. That does not prevent results from being the same. Though feeding impure water into a box having holes or slots, it is a fact the water must find its level, must flow to that point where steam globules are formed and then ascend into space to diffuse. Precipitation does not occur at the instant of contact with heat. Even if it did these receptacles are only settling pans and the perforations are limited — this to confine water inside as long as possible and to aid precipitation. Danger is courted, for should those openings become stopped up danger from low water is the result. If these boxes are open then the solids will find their way to all parts of boiler — this through circulation. These boxes obstruct steam passages, retard circulation and make internal inspections impossible. The price involved in these would be far better invested in something to prevent solids from going into boiler or in aiding to purify feed water before going into boilers, this being done now in modern plants.

6. THE LIVE STEAM HEATER AND PURIFIER.

The live steam purifier, like all other contrivances and appliances for bettering the condition of boilers and increasing efficiency and reducing the hazard and risk in steam boilers, has its advocates.

Much has been claimed for it. Like preceding types it no doubt has some features that might at least appear commendable. But, however, claims are one thing, effects, results and investments are others. The name is somewhat misleading. Its value ceases as an investment when cost and maintenance are experienced. While admitting that it would have one factor, that of precipitation of solids that were held in solution by boiler pressure temperature, this does not alone insure purity of water or establish it as a purifier, for two results are necessary for purification of feed water — viz.: precipitation and filtering.

The pans used are settling surfaces for some of the solids that will settle, but much goes into boiler through gravity circulation. The live steam heaters are selected for only one action — precipitation — and this at the expense of condensation, they being in a position at a considerable distance from water line to grate surface. Some argue that if only some of the solids are prevented from going into boiler, the value of the live steam heater must be considered with fuel saving and efficiency gained, this offsetting the condensation. But there are points of disadvantages. The added hazard, being subjected to the full boiler pressure, has additional energy stored in it. They are placed much higher than boiler water line, access to clean difficult, involve much expense for installation, special frame support and floor. When points of advantages are taken into consideration and weighed with the disadvantages, care should be taken when selection of a feed water purifier is to be made.

7. THE OPEN HEATER AND PURIFIER.

Feed water purification is a possibility and this is when open type of feed water heater and purifier is used, (this is only when care and reason are exercised in selection), and this can be done with minimum loss of furnace heat. It is practically the solution solved when the elements and requirements are adjusted and proportions are proper, viz., time and temperature.

Where a lack of temperature fails time must be increased. Additional body of water will represent time.

This appliance is open to the atmosphere. The feed water supply comes in contact with the exhaust steam or steam used for tem-

perature necessary for precipitation. It will produce a partial vacuum on engine when exhaust steam is used. Precipitation occurs at lowest possible temperature, 15 to 20 per cent of pure water being gained by condensation. There are some open heaters that are so constructed that precipitation is expected at instant of contact of steam and water. Others have so limited a supply of water that no time for action is allowed. In some cases a few strokes of the pump takes all the water out. Others, while they have a copious supply of water, the filtering material is such that it separates, thus leaving water with its solids in suspension free to go to pump, then to the boiler. Others, again, have no facilities for cleaning the filter, unless at expense of closing down or putting cold water into boilers. Most of these are simply receivers, heaters or condensers. They cannot be termed feed water purifiers.

A few suggestions on selection may be in order. Conditions must be observed. First, quality of water to be used; this will determine the filtering surface, but the main requirements are: high temperature, large body of water, large amount of filtering surface, easy to clean.

The two elements, time and temperature, are necessary.

Points to be considered in selecting slow filtering — filter accessible to clean when in use, filtering material and adjustment of same against derangement.

When filtering is operative, deposits will collect on filtering material, thus the necessity of some way to clean off same at any time.

There is the greatest of economy in heating feed water by exhaust steam, even when the latter is used for heating purposes. In this age we are resorting to chemistry as a positive aid in water purification.

FEED WATER HEATERS—KENT

Percentage of saving for each degree of increase in temperature of feed-water heated by waste steam

Initial Temperature of Feed	Pressure of Steam in Boiler, pounds per square inch above Atmosphere										
	0	20	40	60	80	100	120	140	160	180	200
32°	.0872	.0861	.0855	.0851	.0847	.0844	.0841	.0839	.0837	.0835	.0833
40	.0878	.0867	.0861	.0856	.0853	.0850	.0847	.0845	.0843	.0841	.0839
50	.0886	.0875	.0868	.0864	.0860	.0857	.0854	.0852	.0850	.0848	.0846
60	.0894	.0883	.0876	.0872	.0867	.0864	.0862	.0859	.0856	.0855	.0853
70	.0902	.0890	.0884	.0879	.0875	.0872	.0869	.0867	.0864	.0862	.0860
80	.0910	.0898	.0891	.0887	.0883	.0879	.0877	.0874	.0872	.0870	.0868
90	.0919	.0907	.0900	.0895	.0888	.0887	.0884	.0883	.0879	.0877	.0875
100	.0927	.0915	.0908	.0903	.0899	.0895	.0892	.0890	.0887	.0885	.0883
110	.0936	.0923	.0916	.0911	.0907	.0903	.0900	.0898	.0895	.0893	.0891
120	.0945	.0932	.0925	.0919	.0915	.0911	.0908	.0906	.0903	.0901	.0899
130	.0954	.0941	.0934	.0928	.0924	.0920	.0917	.0914	.0912	.0909	.0907
140	.0963	.0950	.0943	.0937	.0932	.0929	.0925	.0923	.0920	.0918	.0916
150	.0973	.0959	.0951	.0946	.0941	.0937	.0934	.0931	.0929	.0926	.0924
160	.0982	.0968	.0961	.0955	.0950	.0946	.0943	.0940	.0937	.0935	.0933
170	.0992	.0978	.0970	.0964	.0959	.0955	.0952	.0949	.0946	.0944	.0941
180	.1002	.0988	.0981	.0973	.0969	.0965	.0961	.0958	.0955	.0953	.0951
190	.1012	.0998	.0989	.0983	.0978	.0974	.0971	.0968	.0964	.0962	.0960
200	.1022	.1008	.0999	.0993	.0988	.0984	.0980	.0977	.0973	.0972	.0969
210	.1033	.1018	.1009	.1003	.0998	.0994	.0990	.0987	.0984	.0981	.0979
220		.1029	.1019	.1013	.1008	.1004	.1000	.0997	.0994	.0991	.0989
230		.1039	.1031	.1024	.1018	.1012	.1010	.1007	.1003	.1001	.0999
240		.1050	.1041	.1034	.1029	.1024	.1020	.1017	.1014	.1011	.1009
250		.1062	.1052	.1045	.1040	.1035	.1031	.1027	.1025	.1022	.1019

Given boiler pressure = 100 lbs. gauge; feed water temperature, original = 60°F. and final = 209°F.; to find the percentage of saving resulting from heating the feed water.

To solve by table look in column of steam pressures headed "100" and opposite to 60° in the first column read .0864, which multiplied by (209—60 = 149) the increase of temperature of feed-water, gives 12.9 per cent.

FORMULA:

$$FT - OT \times C = \text{percentage}$$

FT = final temperature = 209

OT = original temperature = 60

C = constant = .0864

EXAMPLE:

209 = final temperature

60 = original temperature

149 = difference of temperature

.0864 = column constant

$$\begin{array}{r} 596 \\ 894 \\ \hline 1192 \end{array}$$

12.8736 = 12 9/10 per cent. nearly

PUMPS AND TANKS.

The efficiency of a pump varies with the type, size, lift, elevation, temperature of water and friction. The steam pump is flexible as regards capacity, a few revolutions faster or slower will greatly increase or diminish the quantity delivered, the maximum efficiency depending on details as to size and connection and locating pump. Hot water cannot be lifted by suction, as its vapor destroys the necessary vacuum, hence the necessity to have the hot water flow to the pump. When long suction pipes are used it will be necessary to have a larger size than with shorter distances, this to allow for friction which might prevent adequate supply to pump. Use as few elbows and sharp bends and valves as possible; avoid traps or air pockets in pipe; suction pipes should be absolutely air tight. A vacuum chamber should be placed on the opposite side of the pump from where suction enters and a foot valve will be found advantageous and desirable, the latter if its location is such that it can be drained when necessary. The valve insures quick starting of pump by keeping suction pipe filled with water. A priming pipe will be convenient when chambers are to be filled to enable pump to start quickly. In starting a pump under pressure it oftentimes happens that the pump will not discharge the water while the pressure is

resting on the discharge valve, for the reason that the air in pump cylinders is not discharged, but only compressed by the motion of plungers, then it is necessary to expel air from pump and suction pipe. This can be done by placing a check valve in the discharge pipe near the pump and opening an air vent on the discharge between pump and check, or on a valve chamber on top.

A relief valve is desirable, to prevent damage which might occur by obstruction in discharge line, thus increasing pressure on pump in excess of that which pump was designed for.

Sometimes a pump when first started will deliver a good stream of water, which gradually diminishes in volume until it stops entirely. One reason for this is leak in suction pipes or stuffing box of pump, or, when suction primer is used, in the hand pump stuffing box. Another reason might be that the pump lowers the suction supply, thus increasing the lift until there is not sufficient speed for the elevation. If the pump works indifferently, delivering a stream obviously too small, it is generally because the pump was not properly primed and some air remains in the top part of pump shell. Unless primed by steam ejector the pet cock or plug found on top of pump shell should always be open while priming, and the pump must not be started until water flows out of same.

A pump with horizontal top discharge and short length of discharge pipe is sometimes difficult to start, especially if suction lift is high, owing to the fact that the water is thrown out of the pump shell before the water in suction pipe has got fairly started, thus allowing air to rush back into the pump. If the pump is to work under this condition it is better to use a pump with a vertical discharge and deliver through an elbow, or else lead the discharge pipe upward for a short distance so as to keep a slight pressure or head on the pump, and after priming as high as possible start quickly.

There is generally nothing gained by running above the proper speed required for a given elevation.

To find the theoretical horse power required to elevate water, multiply the gallons pumped per minute by the head in feet and by 8.33 (weight of one gallon of water) and divide product by 33,000. This will be only approximate.

LEGEND:

800 = gallons per minute
 20 = feet elevation
 8.33 = weight of one gallon of water

EXAMPLE:

800 gallons per minute
 20 = feet elevation

16000
 8.33 = weight of one gallon of water

48000
 48000
 128000

33000)133280.000 (4.038 H. P. required
 132000

1280 00
 990 00

290 000
 264 000

26 000

Ordinarily pumps will elevate water 50 to 60 feet, and if specially built in regard to strength, could elevate 100 feet, depending on speed.

THEORETICAL STEAM CONSUMPTION.

AT A PISTON TRAVEL OF 100 FEET PER MINUTE.

For use with this table, the effective piston travel is only that portion of the total travel during which the steam valve is open. Thus, if an engine is running 400 feet per minute, and cutting off at 1/2 stroke, its effective travel will be 200 feet, and its theoretical steam consumption will be 200 divided by 100 multiplied by the amount given in the table for its cylinder diameter and steam

pressure. The actual consumption exceeds the theoretical by 25 per cent to 50 per cent.

Diameter of Cylinder	Cubic Feet per Minute	INITIAL STEAM PRESSURE									
		60	70	80	90	100	110	120	130	140	150
		STEAM CONSUMPTION IN POUNDS PER HOUR									
8	34.9	365	410	455	500	540	585	630	670	720	760
9	44.3	465	507	575	630	690	740	800	855	920	964
10	54.5	570	640	710	780	845	915	985	1050	1125	1185
11	66	690	770	860	940	1020	1110	1190	1270	1360	1435
12	78.5	820	920	1020	1120	1220	1320	1420	1520	1620	1710
14	107	1120	1250	1390	1530	1660	1800	1940	2070	2210	2330
16	139.6	1460	1625	1810	2000	2160	2350	2530	2700	2880	3040
18	176.7	1850	2070	2290	2530	2750	2970	3200	3420	3650	3850
20	218.2	2290	2550	2840	3120	3380	3660	3950	4200	4500	4750
22	264	2760	3090	3430	3760	4100	4430	4780	5090	5440	5750
24	314	3290	3660	4070	4490	4860	5270	5680	6060	6480	6820
26	369	3870	4310	4800	5270	5720	6200	6680	7110	7600	8020
28	428	4490	5000	5560	6110	6650	7190	7750	8260	8820	9310
30	491	5160	5750	6390	7010	7610	8250	8880	9490	10120	10680

EXAMPLE: To determine the steam consumption of a 12 and 18 × 12 × 18 *Duplex* Compound Pump: Piston speed 85 feet per minute: Initial Steam pressure 100 pounds.

Since the pump is duplex and since live steam enters the high pressure cylinders only, the theoretical consumption would be double that of a single 12" cylinder; or at 100 feet piston speed, 1220 × 2 = 2440 pounds per hour.

Theoretical consumption at 85 feet piston speed, 2440 × .85 = 2074 pounds per hour.

The actual steam consumption exceeds the theoretical by 20 per cent to 50 per cent.

The mean pressure of the atmosphere is usually estimated at 14.7 pounds per square inch, so that with a perfect vacuum it will sustain a column of mercury 29.9 inches, or a column of water 33.9 feet high at sea level.

To determine the proportion between the steam and the pump cylinder, multiply the given area of the pump cylinder by the resistance on the pump in pounds per square inch, and divide the product by the available pressure of steam in pounds per square inch. The product equals the area of the steam cylinder. To this

must be added an extra area to overcome the friction, which is usually taken at 25 per cent.

The resistance of friction in the flow of water through pipes of uniform diameter is independent of the pressure and increase directly as the length and the square of the velocity of the flow, and inversely as the diameter of the pipe. With wooden pipes the friction is 1.75 times greater than in metallic. Doubling the diameter increases the capacity four times.

To determine the velocity in feet per minute necessary to discharge a given volume of water in a given time, multiply the number of cubic feet of water by 144 and divide the product by the area of the pipe in inches.

To determine the area of a required pipe, the volume and velocity of water being given, multiply the number of cubic feet of water by 144 and divide the product by the velocity in feet per minute.

To find the diameter of pump plungers to pump a given quantity of water at 100 feet piston speed per minute, divide the number of gallons by 4, then extract the square root, and the result will be the diameter in inches of the plungers.

To find the number of gallons delivered per minute by a single double-acting pump at 100 feet piston speed per minute, square the diameters of the plungers, then multiply by 4.

The area of the steam piston, multiplied by the steam pressure, gives the total amount of pressure that can be exerted. The area of the water piston, multiplied by the pressure of water per square inch, gives the resistance. A margin must be made between the power and resistance.

CAPACITY OF PUMPS AT 100 FEET PISTON SPEED.

A travel of 100 feet piston speed per minute is considered practical and is accepted as standard speed. Slow speed for boiler feeding is recommended. No set rule can be given to cover all conditions. In Fire Pumps, where the largest quantity of water is required, the speed may exceed 200 feet per minute.

THEORETICAL CAPACITY OF PUMPS AT 100 FEET SPEED OF
PISTON OR PLUNGER.

Diameter of Pump or Plunger in Inches	U. S. GALLONS PER			Diameter of Pump or Plunger in Inches	U. S. GALLONS PER		
	Minute	Hour	24 Hours		Minute	Hour	24 Hours
1	4.07	244.7	5875	14 1/4	828	49704	1192896
1 1/4	6.37	382.5	9180	14 1/2	858	51468	1235232
1 1/2	9.18	550.8	13219	14 3/4	887	53256	1278144
1 3/4	12.49	749	17992	15	918	55070	1321915
2	16.31	979	23500	15 1/4	949	56928	1366272
2 1/4	20.6	1239	28180	15 1/2	980	58800	1411200
2 1/2	25.5	1530	36720	15 3/4	1012	60720	1457280
2 3/4	30.8	1851	44424	16	1044	62668	1504046
3	36.7	2203	52878	16 1/4	1077	64638	1551312
3 1/4	43.1	2586	62064	16 1/2	1110	66642	1599408
3 1/2	49.9	2998	71971	16 3/4	1144	68676	1648224
3 3/4	57.3	3442	82619	17	1179	70752	1698048
4	65.2	3916	94002	17 1/4	1214	72840	1748160
4 1/4	73.7	4422	106128	17 1/2	1249	74964	1799136
4 1/2	82.6	4957	118971	17 3/4	1285	77124	1850976
4 3/4	92	5523	132552	18	1322	79314	1903550
5	102	6120	146880	18 1/4	1359	81528	1956672
5 1/4	112	6745	161934	18 1/2	1396	83778	2010672
5 1/2	123	7404	177696	18 3/4	1434	86060	2065449
5 3/4	134	8093	194248	19	1473	88368	2120832
6	146	8812	211511	19 1/4	1511	90660	2175840
6 1/4	159	9562	229500	19 1/2	1552	93120	2234880
6 1/2	172	10344	248256	19 3/4	1590	95400	2289600
6 3/4	185	11152	267660	20	1632	97920	2350080
7	200	11995	287884	20 1/4	1673	100380	2409120
7 1/4	214	12867	308808	20 1/2	1714	102840	2468160
7 1/2	229	13769	330478	20 3/4	1756	105396	2529504
7 3/4	245	14700	352300	21	1799	107952	2590848
8	261	15667	376011	21 1/4	1842	110538	2652912
8 1/4	277	16660	399852	21 1/2	1886	113154	2715696
8 1/2	294	17688	424512	21 3/4	1930	115800	2779200
8 3/4	312	18741	449978	22	1974	118482	2843568
9	330	19828	475887	22 1/4	2020	121194	2908656
9 1/4	349	20944	502668	22 1/2	2065	123924	2974176
9 1/2	368	22092	530208	22 3/4	2111	126696	3040704
9 3/4	388	23280	558720	23	2158	129492	3107808
10	408	24480	587518	23 1/4	2205	132324	3175776
10 1/4	428	25716	617184	23 1/2	2253	135186	3244464
10 1/2	449	26989	647789	23 3/4	2301	138078	3313872
10 3/4	471	28290	678960	24	2349	140958	3382992
11	493	29616	710784	24 1/4	2399	143952	3454848
11 1/4	516	30986	743677	24 1/2	2449	146958	3526992
11 1/2	539	32374	776993	24 3/4	2499	149952	3598848
11 3/4	564	33795	811080	25	2550	152994	3671856
12	587	35251	846046	25 1/2	2653	159179	3820300
12 1/4	612	36735	881640	26	2758	165484	3971630
12 1/2	637	38250	918000	26 1/2	2865	171908	4125800
12 3/4	663	39816	955584	27	2974	178457	4282967
13	689	41370	992880	27 1/2	3085	185130	4443125
13 1/4	716	42972	1031328	28	3199	191922	4606125
13 1/2	743	44610	1070640	28 1/2	3314	198838	4772118
13 3/4	771	46278	1110672	29	3431	205876	4941028
14	799	47980	1151536	30	3672	220320	5287675

For practical purposes, deduct 10 per cent, as no pump will deliver its theoretical capacity.

FRICION LOSS IN POUNDS PRESSURE.

For each 100 feet of length, in different size, clean iron pipes, discharging given quantities of water per minute.

Galls. per Minute.	SIZES OF PIPES—INSIDE DIAMETER.															
	$\frac{3}{4}$ in.	1 in.	1 $\frac{1}{4}$ in.	1 $\frac{1}{2}$ in.	2 in.	2 $\frac{1}{2}$ in.	3 in.	4 in.	6 in.	8 in.	10 in.	12 in.	14 in.	16 in.	18 in.	
5	3.3	0.84	0.31	0.12	
10	13.0	3.16	1.05	0.47	0.12	
15	28.7	6.98	2.38	0.97	
20	50.4	12.3	4.07	1.66	0.42	
25	78.0	19.0	6.40	2.62	0.21	1.10	
30	27.5	9.15	3.75	0.91	
35	37.0	12.4	5.05	
40	48.0	16.1	6.52	1.60	
45	20.2	8.15	
50	24.9	10.0	2.44	0.81	0.35	0.09	
75	56.1	22.4	5.32	1.80	0.74	
100	39.0	9.46	7.20	1.31	0.33	0.05	
125	14.9	4.89	1.99	
150	21.2	7.0	2.85	0.69	0.10	
175	28.1	9.46	3.85	
200	37.5	12.47	5.02	1.22	0.17	
250	19.66	7.76	1.89	0.26	0.07	0.03	0.01	
300	28.06	11.2	2.66	0.37	0.09	0.04	
350	15.2	3.65	0.50	0.12	0.05	0.02	
400	19.5	4.73	0.66	0.16	0.06	
450	25.0	6.01	0.81	0.20	0.07	0.03	
500	30.8	7.43	0.96	0.25	0.09	0.04	0.017	0.009	0.005	
750	2.21	0.53	0.18	0.08	
1000	3.88	0.94	0.32	0.13	0.062	0.036	0.020	
1250	1.46	0.49	0.20	
1500	2.09	0.70	0.29	0.135	0.071	0.040	
1750	0.95	0.38	
2000	1.23	0.49	0.234	0.123	0.071	
2250	0.63	
2500	0.77	0.362	0.188	0.107	
3000	1.11	0.515	0.267	0.150	
3500	0.697	0.365	0.204	
4000	0.910	0.472	0.263
4500	0.593	0.333
5000	0.730	0.408

HEIGHTS IN FEET TO WHICH PUMPS WILL ELEVATE WATER

Steam pressure, 50 pounds per square inch at the pump. No allowance made for friction in pipes, etc.

Diameter of Steam Cylinders	DIAMETER OF WATER CYLINDERS																	
	2 Inch	2½ Inch	3 Inch	3½ Inch	4 Inch	5 Inch	6 Inch	7 Inch	8 Inch	9 Inch	10 Inch	10½ Inch	12 Inch	14 Inch	16 Inch	18 Inch	20 Inch	
3½	230	147	102	75	58	37												
4	300	192	134	134	75	48	34											
5	469	300	209	153	117	75	52	38										
6	675	432	300	221	169	108	75	55	42	33	37							
7	920	588	408	300	230	147	102	75	57	45	48							
8	768	533	344	300	192	141	98	75	59	48	44						
9	972	675	496	380	243	169	124	95	75	61	44	42					
10	833	612	469	300	208	153	117	94	75	55	50	38				
12	881	675	432	300	220	169	133	108	68	50	55	42			
14	920	588	408	300	228	182	147	97	75	75	57	45		
16	768	564	392	300	300	236	192	174	141	98	75	59		
18	972	650	490	379	300	243	220	162	122	95	75		
20	833	600	469	370	300	272	208	150	117	92		
22	741	567	448	364	329	252	185	142	112		
24	882	675	533	432	392	300	220	169	133		
26	1034	788	626	508	460	356	258	197	156		
28	919	726	588	533	407	300	230	181		
30	1054	834	676	612	468	345	263	208		
32	948	798	697	533	391	300	237		
34	1070	868	786	603	442	339	268		
36	972	881	675	495	380	300		

The maximum limit of piston speed depends upon the head pumped against.

SIZES FOR BOILER FEED PUMPS.

Diameter of Steam Cylinder	Diam. of Water Cylinder	Stroke	Horse Power Boilers	Steam Pipe	Exhaust Pipe	Suction Pipe	Discharge Pipe
3½"	2¼"	4"	30 to 40	⅜"	½"	1"	¾"
4½"	2¾"	4	80 to 100	½"	¾"	2	1¼"
5½"	3½"	5	140 to 160	¾"	1¼"	2½"	1½"

When long suction is required use larger suction pipe. Ordinarily allowance for boiler feeding is to deliver 1 cubic foot or 7½ gallons of water per horse power.

THEORETICAL DISCHARGE OF CIRCULAR ORIFICES OR NOZZLES

Diameter in Inches (Ellis.)

NOTE. The actual discharge will be less than the theoretical one given below, ranging with the form of nozzle or tube through which the water flows. For a ring nozzle 64%, and for a good form of tapering smooth nozzle about 82%, can be assumed as the actual discharge.

Head.		Velocity of discharge in feet per second.	Number of United States Gallons of 231 Cubic Inches Discharge per Minute.													
Lbs.	Feet		1/16 Inch	1/8 Inch	3/16 Inch	1/4 Inch	3/8 Inch	1/2 Inch	5/8 Inch	3/4 Inch	7/8 Inch	1 Inch	1 1/4 Inch	1 1/2 Inch	2 Inch	2 1/2 Inch
10	23.1	38.58	0.37	1.48	3.30	5.90	13.2	23.6	36.8	53.2	72.2	94.4	148	212	378	590
15	34.7	47.25	0.45	1.81	4.02	7.23	16.2	28.7	45.0	65.1	88.4	116.	181	260	463	723
20	46.2	54.55	0.52	2.09	4.66	8.35	18.7	33.4	52.0	75.3	102.	134.	209	300	534	835
25	57.8	60.99	0.58	2.33	5.23	9.33	20.9	37.2	58.2	84.1	114.	149.	233	336	597	933
30	69.3	66.82	0.64	2.56	5.71	10.2	22.8	40.9	63.7	92.2	125.	164.	256	368	654	1022
35	80.9	72.16	0.69	2.76	6.16	11.0	24.7	44.2	68.8	99.6	135.	177.	276	397	707	1104
40	92.4	77.14	0.74	2.95	6.60	11.8	26.4	47.2	73.6	106.	144.	189.	295	425	755	1180
45	104.0	81.83	0.78	3.13	6.99	12.5	28.0	50.2	78.1	113.	153.	200.	313	450	801	1252
50	115.5	86.26	0.82	3.30	7.37	13.2	29.5	52.8	82.3	119.	161.	211.	330	475	845	1320
55	127.1	90.46	0.86	3.46	7.73	13.8	30.9	55.4	86.3	125.	169.	221.	346	498	886	1385
60	138.6	96.49	0.90	3.62	8.08	14.5	32.3	57.8	90.1	130.	177.	231.	362	520	925	1446
65	150.2	98.35	0.94	3.77	8.40	15.1	33.6	60.2	93.8	136.	184.	241.	377	542	963	1506
70	161.7	102.06	0.97	3.91	8.73	15.6	34.9	62.5	97.4	141.	191.	250.	391	562	999	1561
75	173.3	105.65	1.01	4.04	9.03	16.2	36.1	64.6	101.	146.	198.	259.	404	582	1034	1616
80	184.8	109.11	1.04	4.18	9.33	16.7	37.8	66.6	104.	150.	204.	267.	418	601	1068	1669
85	196.4	112.46	1.07	4.31	9.62	17.2	38.5	68.8	107.	155.	210.	275.	431	620	1101	1720
90	207.9	115.72	1.10	4.43	9.89	17.7	39.6	70.8	110.	160.	217.	283.	443	637	1133	1770
95	219.5	118.89	1.13	4.55	10.2	18.2	40.7	72.8	113.	164.	223.	291.	455	655	1164	1820
100	231.1	121.98	1.16	4.67	10.4	18.7	41.7	74.6	116.	168.	228.	299.	467	672	1194	1866
105	242.6	125.00	1.19	4.78	10.7	19.1	42.8	76.5	119.	172.	234.	306.	478	688	1224	1912
110	254.2	127.94	1.22	4.90	10.9	19.6	43.8	78.3	122.	177.	239.	313.	490	705	1253	1957
115	265.7	130.82	1.25	5.01	11.2	20.0	44.8	80.1	125.	181.	245.	320.	501	720	1281	2002
120	277.3	133.63	1.27	5.12	11.4	20.4	45.7	81.8	127.	184.	250.	327.	512	736	1308	2044
125	288.8	136.38	1.30	5.22	11.7	20.9	46.7	83.5	130.	188.	255.	334.	522	751	1335	2086
130	300.4	139.08	1.33	5.32	11.9	21.3	47.6	85.1	133.	192.	260.	341.	532	766	1362	2128

PRESSURE OF WATER

The pressure of water in pounds per square inch for every foot in height to 300 feet: and then by intervals to 1,000 feet head. By this table, from the pounds pressure per square inch, the feet head is readily obtained, and vice versa.

Feet Head	Pressure per Square Inch	Feet Head	Pressure per Square Inch	Feet Head	Pressure per Square Inch	Feet Head	Pressure per Square Inch	Feet Head	Pressure per Square Inch	Feet Head	Pressure per Square Inch
1	0.43	53	22.95	105	45.48	157	68.00	209	90.53	261	113.06
2	0.86	54	23.39	106	45.91	158	68.43	210	90.96	262	113.49
3	1.30	55	23.82	107	46.34	159	68.87	211	91.39	263	113.92
4	1.73	56	24.26	108	46.78	160	69.31	212	91.83	264	114.36
5	2.16	57	24.69	109	47.21	161	69.74	213	92.26	265	114.79
6	2.59	58	25.12	110	47.64	162	70.17	214	92.69	266	115.22
7	3.03	59	25.55	111	48.08	163	70.61	215	93.13	267	115.66
8	3.46	60	25.99	112	48.51	164	71.04	216	93.56	268	116.09
9	3.89	61	26.42	113	48.94	165	71.47	217	93.99	269	116.52
10	4.33	62	26.85	114	49.38	166	71.91	218	94.43	270	116.96
11	4.76	63	27.29	115	49.81	167	72.34	219	94.86	271	117.39
12	5.20	64	27.72	116	50.24	168	72.77	220	95.30	272	117.82
13	5.63	65	28.15	117	50.68	169	73.20	221	95.73	273	118.26
14	6.06	66	28.58	118	51.11	170	73.64	222	96.16	274	118.69
15	6.49	67	29.02	119	51.54	171	74.07	223	96.60	275	119.12
16	6.93	68	29.45	120	51.98	172	74.50	224	97.03	276	119.56
17	7.36	69	29.88	121	52.41	173	74.94	225	97.46	277	119.99
18	7.79	70	30.32	122	52.84	174	75.37	226	97.90	278	120.42
19	8.22	71	30.75	123	53.28	175	75.80	227	98.33	279	120.85
20	8.66	72	31.18	124	53.71	176	76.23	228	98.76	280	121.29
21	9.09	73	31.62	125	54.15	177	76.67	229	99.20	281	121.72
22	9.53	74	32.05	126	54.58	178	77.10	230	99.63	282	122.15
23	9.96	75	32.48	127	55.01	179	77.53	231	100.06	283	122.59
24	10.39	76	32.92	128	55.44	180	77.97	232	100.49	284	123.02
25	10.82	77	33.35	129	55.88	181	78.40	233	100.93	285	123.45
26	11.26	78	33.78	130	56.31	182	78.84	234	101.36	286	123.89

THE BOILER.

Feet Head	Pressure per Square Inch	Feet Head	Pressure per Square Inch	Feet Head	Pressure per Square Inch	Feet Head	Pressure per Square Inch	Feet Head	Pressure per Square Inch	Feet Head	Pressure per Square Inch	Feet Head	Pressure per Square Inch
27	11.69	79	34.21	131	56.74	183	79.27	235	101.79	287	124.32		
28	12.12	80	34.65	132	57.18	184	79.70	236	102.23	288	124.75		
29	12.55	81	35.08	133	57.61	185	80.14	237	102.60	289	125.18		
30	12.99	82	35.52	134	58.04	186	80.57	238	103.09	290	125.62		
31	13.42	83	35.95	135	58.48	187	81.00	239	103.53	291	126.05		
32	13.86	84	36.39	136	58.91	188	81.43	240	103.96	292	126.48		
33	14.29	85	36.82	137	59.34	189	81.87	241	104.39	293	126.92		
34	14.72	86	37.25	138	59.77	190	82.30	242	104.83	294	127.35		
35	15.16	87	37.68	139	60.21	191	82.73	243	105.26	295	127.78		
36	15.59	88	38.12	140	60.64	192	83.17	244	105.69	296	128.22		
37	16.02	89	38.55	141	61.07	193	83.60	245	106.13	297	128.65		
38	16.45	90	38.98	142	61.51	194	84.03	246	106.56	298	129.08		
39	16.89	91	39.42	143	61.94	195	84.47	247	106.99	299	129.51		
40	17.32	92	39.85	144	62.37	196	84.90	248	107.43	300	129.95		
41	17.75	93	40.28	145	62.81	197	85.33	249	107.86	320	138.62		
42	18.19	94	40.72	146	63.24	198	85.76	250	108.29	330	142.95		
43	18.62	95	41.15	147	63.67	199	86.20	251	108.73	350	151.61		
44	19.05	96	41.58	148	64.10	200	86.63	252	109.16	370	160.27		
45	19.49	97	42.01	149	64.54	201	87.07	253	109.59	390	168.94		
46	19.92	98	42.45	150	64.97	202	87.50	254	110.03	400	173.27		
47	20.35	99	42.88	151	65.40	203	87.93	255	110.46	500	216.58		
48	20.79	100	43.31	152	65.84	204	88.36	256	110.89	600	259.90		
49	21.22	101	43.75	153	66.27	205	88.80	257	111.32	700	303.22		
50	21.65	102	44.18	154	66.70	206	89.23	258	111.76	800	346.54		
51	22.09	103	44.61	155	67.14	207	89.66	259	112.19	900	389.86		
52	22.52	104	45.05	156	67.57	208	90.10	260	112.62	1000	433.18		

Rule to find pressure of water head: Multiply constant .434 by number of feet of head.

EXAMPLE:

.434 = constant
45 = feet head

2170
1736

19.530 = pressure or 19½ lbs. approximately

TANKS.

Rule to find capacity of round tank: Square diameter in inches and multiply sum by .7854, then by height in inches; divide this product by 231. This gives capacity in gallons.

FORMULA:

$$\frac{D^2 \times .7854 \times h}{231} = \text{capacity of round tank}$$

LEGEND:

D = diameter of tank = 60''
h = height of tank = 60''
231 cubic inches in one gallon

EXAMPLE:

60'' = diameter of tank
60

3600 = diameter squared
.7854

14400
18000
28800
25200

2827.4400
60 = height

231) 169646.4000 (734.4 gallons capacity
1617

794
693

1016
924

924
924

THE BOILER.

U. S. GALLONS IN ROUND TANKS.

For 1 Foot in Depth.

Dia. of Tanks.		No. U. S. Gals.	Cubic Ft. and Area in sq. ft.	Dia. of Tanks.		No. U. S. Gals.	Cubic Ft. and Area in sq. ft.	Dia. of Tanks.		No. U. S. Gals.	Cubic Ft. and Area in sq. ft.
ft.	in.			ft.	in.			ft.	in.		
1		5.87	.785	5	8	188.66	25.22	19		2120.90	283.53
1	1	6.89	.922	5	9	194.25	25.97	19	3	2177.10	291.04
1	2	8.	1.069	5	10	199.92	26.73	19	6	2234.	298.65
1	3	9.18	1.227	5	11	205.67	27.49	19	9	2291.70	306.25
1	4	10.44	1.396	6		211.51	28.27	20		2350.10	314.16
1	5	11.79	1.576	6	3	229.50	30.68	20	3	2409.20	322.06
1	6	13.22	1.767	6	6	248.23	33.18	20	6	2469.10	330.06
1	7	14.73	1.989	6	9	267.69	35.78	20	9	2529.60	338.16
1	8	16.32	2.182	7		287.88	38.48	21		2591.	346.36
1	9	17.99	2.405	7	3	308.81	41.28	21	3	2653.	354.66
1	10	17.95	2.460	7	6	330.48	44.18	21	6	2715.80	363.05
1	11	21.58	2.885	7	9	352.88	47.17	21	9	2779.30	371.54
2		23.50	3.142	8		376.01	50.27	22		2843.60	380.13
2	1	25.50	3.409	8	3	399.88	53.46	22	3	2908.60	388.82
2	2	27.58	3.687	8	6	424.48	56.75	22	6	2974.30	397.61
2	3	29.74	3.976	8	9	449.82	60.13	22	9	3040.80	406.49
2	4	31.99	4.276	9		475.89	63.62	23		3108.	415.48
2	5	34.31	4.587	9	3	502.70	67.20	23	3	3179.90	424.56
2	6	36.72	4.909	9	6	530.24	70.88	23	6	3244.60	433.74
2	7	39.21	5.241	9	9	558.51	74.66	23	9	3314.	443.01
2	8	41.78	5.585	10		587.52	78.54	24		3384.10	452.39
2	9	44.43	5.940	10	3	617.26	82.52	24	3	3455.	461.86
2	10	47.16	6.305	10	6	640.74	86.59	24	6	3526.60	471.44
2	11	49.98	6.681	10	9	678.95	90.76	24	9	3598.90	481.11
3		52.88.	7.069	11		710.90	95.03	25		3672.	490.87
3	1	55.86	7.467	11	3	743.58	99.40	25	3	3745.80	500.74
3	2	58.92	7.876	11	6	766.99	103.87	25	6	3820.30	510.71
3	3	62.06	8.296	11	9	811.14	108.43	25	9	3895.60	520.77
3	4	65.28	8.727	12		846.03	113.10	26		3971.60	530.93
3	5	68.58	9.168	12	3	881.65	117.86	26	3	4048.40	541.19
3	6	71.97	9.261	12	6	918.	122.72	26	6	4125.90	551.55
3	7	75.44	10.085	12	9	955.09	127.68	26	9	4204.10	562.
3	8	78.99	10.559	13		992.91	132.73	27		4283.	572.66
3	9	82.62	11.045	13	3	1031.50	137.89	27	3	4362.70	583.21
3	10	86.33	11.541	13	6	1070.80	143.14	27	6	4443.10	593.96
3	11	90.13	12.048	13	9	1110.80	148.49	27	9	4524.30	604.81
4		94.	12.566	14		1151.50	153.94	28		4606.20	615.75
4	1	97.96	13.095	14	3	1193.0	159.48	28	3	4688.80	626.80
4	2	102.	13.635	14	6	1235.30	165.13	28	6	4772.10	637.94
4	3	106.12	14.186	14	9	1278.20	170.87	28	9	4856.20	649.18
4	4	110.32	14.748	15		1321.90	176.71	29		4941.	660.52
4	5	114.61	15.321	15	3	1366.40	182.65	29	3	5026.60	671.96
4	6	118.97	15.90	15	6	1411.50	188.69	29	6	5112.90	683.49
4	7	123.42	16.50	15	9	1457.40	194.83	29	9	5199.90	695.13
4	8	127.95	17.10	16		1504.10	201.06	30		5287.70	706.86
4	9	132.56	17.72	16	3	1551.40	207.39	30	3	5376.20	718.69
4	10	137.25	18.35	16	6	1599.50	213.82	30	6	5465.40	730.62
4	11	142.02	18.99	16	9	1648.40	220.35	30	9	5555.40	742.64
5		146.88	19.63	17		1697.90	226.98	31		5646.10	754.77
5	1	151.82	20.29	17	3	1748.20	233.71	31	3	5737.50	766.99
5	2	156.83	20.97	17	6	1799.30	240.53	31	6	5829.70	779.31
5	3	161.93	21.65	17	9	1851.10	247.45	31	9	5922.60	791.73
5	4	167.12	22.34	18		1903.60	254.47	32		6016.20	804.25
5	5	172.38	23.04	18	3	1956.80	261.59	32	3	6110.60	816.86
5	6	177.72	23.76	18	6	2010.80	268.80	32	6	6205.70	829.58
5	7	183.15	24.48	18	9	2065.50	276.12	32	9	6301.50	842.39

31½ Gallons equals 1 Barrel.

To find the capacity of Tanks greater than the largest given in the table, look in the table for a Tank of one-half of the given size and multiply its capacity by 4, or one of one-third its size and multiply its capacity by 9, etc.

STEEL TANK DIMENSIONS.

Diameter, Feet.	Height, Feet.	Thickness, Shell, Inches.	Thickness, Head, Inches.	Size, Angle Iron, Inches.	Weight, Lbs.
3	2½	$\frac{3}{16}$	$\frac{3}{16}$	1½	300
3	3	$\frac{3}{16}$	$\frac{3}{16}$	1½	385
4	3	$\frac{3}{16}$	$\frac{3}{16}$	1½	475
4	4	$\frac{3}{16}$	$\frac{3}{16}$	1½	585
4½	4	$\frac{3}{16}$	$\frac{3}{16}$	1½	670
4½	4½	$\frac{3}{16}$	$\frac{3}{16}$	1½	730
5	4½	$\frac{3}{16}$	$\frac{1}{4}$	2	885
5	5	$\frac{3}{16}$	$\frac{1}{4}$	2	955
5½	5	$\frac{3}{16}$	$\frac{1}{4}$	2	1065
5½	5½	$\frac{3}{16}$	$\frac{1}{4}$	2	1135
6	5½	$\frac{1}{4}$	$\frac{1}{4}$	2	1600
6	6	$\frac{1}{4}$	$\frac{1}{4}$	2	1700
7	6	$\frac{1}{4}$	$\frac{1}{4}$	2	2100
7	7	$\frac{1}{4}$	$\frac{1}{4}$	2	2350
8	7	$\frac{1}{4}$	$\frac{1}{4}$	2½	2800
8	8	$\frac{1}{4}$	$\frac{1}{4}$	2½	3000
9	8	$\frac{1}{4}$	$\frac{1}{4}$	2½	3730
9	9	$\frac{1}{4}$	$\frac{1}{4}$	2½	4060
10	9	$\frac{5}{16}$	$\frac{5}{16}$	2½	4965
10	9	$\frac{5}{16}$	$\frac{5}{16}$	2½	5400
10	10	$\frac{5}{16}$	$\frac{5}{16}$	2½	5850
12	10	$\frac{5}{16}$	$\frac{5}{16}$	2½	7250
12	12	$\frac{5}{16}$	$\frac{5}{16}$	2½	8300

NUMBER OF U. S. GALLONS IN RECTANGULAR TANKS.
For 1 Foot in Depth.

Width of Tank, feet.	LENGTH OF TANK, FEET.																					
	2	2½	3	3½	4	4½	5	5½	6	6½	7	7½	8	8½	9	9½	10	10½	11	11½	12	
2	29.92	37.40	44.88	52.36	59.84	67.32	74.81	82.29	89.77	97.25	104.73	112.21	119.69	127.17	134.65	142.13	149.61	157.09	164.57	172.05	179.53	224.41
2½	46.75	56.10	65.45	74.80	84.16	93.51	102.86	112.21	121.56	130.91	140.26	149.61	158.96	168.31	177.66	187.01	196.36	205.71	215.06	224.41	233.76	289.30
3	67.32	78.54	89.77	101.00	112.21	123.43	134.65	145.87	157.09	168.31	179.53	190.75	201.97	213.19	224.41	235.63	246.85	258.07	269.29	280.51	291.73	347.27
3½	91.64	104.73	117.82	130.91	144.00	157.09	170.18	183.27	196.36	209.45	222.54	235.63	248.72	261.81	274.90	287.99	301.08	314.17	327.26	340.35	353.44	408.98
4	119.69	134.65	149.61	164.57	179.53	194.49	209.45	224.41	239.37	254.33	269.29	284.25	299.21	314.17	329.13	344.09	359.05	374.01	388.97	403.93	418.89	474.43
4½	148.83	168.31	187.79	207.27	226.75	246.23	265.71	285.19	304.67	324.15	343.63	363.11	382.59	402.07	421.55	441.03	460.51	480.00	499.48	518.96	538.44	593.98
5	187.01	206.49	225.97	245.45	264.93	284.41	303.89	323.37	342.85	362.33	381.81	401.29	420.77	440.25	459.73	479.21	498.69	518.17	537.65	557.13	576.61	632.15
5½	226.28	245.76	265.24	284.72	304.20	323.68	343.16	362.64	382.12	401.60	421.08	440.56	460.04	479.52	499.00	518.48	537.96	557.44	576.92	596.40	615.88	671.42
6	269.30	288.78	308.26	327.74	347.22	366.70	386.18	405.66	425.14	444.62	464.10	483.58	503.06	522.54	542.02	561.50	581.00	600.50	620.00	639.50	659.00	714.54
6½	316.05	335.53	355.01	374.49	393.97	413.45	432.93	452.41	471.89	491.37	510.85	530.33	549.81	569.29	588.77	608.25	627.73	647.21	666.69	686.17	705.65	761.19
7	366.54	386.02	405.50	424.98	444.46	463.94	483.42	502.90	522.38	541.86	561.34	580.82	600.30	619.78	639.26	658.74	678.22	697.70	717.18	736.66	756.14	811.68
7½	420.75	440.23	459.71	479.19	498.67	518.15	537.63	557.11	576.59	596.07	615.55	635.03	654.51	673.99	693.47	712.95	732.43	751.91	771.39	790.87	810.35	865.89
8	478.75	498.23	517.71	537.19	556.67	576.15	595.63	615.11	634.59	654.07	673.55	693.03	712.51	731.99	751.47	770.95	790.43	809.91	829.39	848.87	868.35	923.89
8½	540.46	560.94	581.42	601.90	622.38	642.86	663.34	683.82	704.30	724.78	745.26	765.74	786.22	806.70	827.18	847.66	868.14	888.62	909.10	929.58	950.06	1005.60
9	605.92	625.40	644.88	664.36	683.84	703.32	722.80	742.28	761.76	781.24	800.72	820.20	839.68	859.16	878.64	898.12	917.60	937.08	956.56	976.04	995.52	1051.06
9½	673.21	692.69	712.17	731.65	751.13	770.61	790.09	809.57	829.05	848.53	868.01	887.49	906.97	926.45	945.93	965.41	984.89	1004.37	1023.85	1043.33	1062.81	1118.35
10	743.00	762.48	781.96	801.44	820.92	840.40	859.88	879.36	898.84	918.32	937.80	957.28	976.76	996.24	1015.72	1035.20	1054.68	1074.16	1093.64	1113.12	1132.60	1188.14
10½	807.77	827.25	846.73	866.21	885.69	905.17	924.65	944.13	963.61	983.09	1002.57	1022.05	1041.53	1061.01	1080.49	1100.00	1119.50	1139.00	1158.50	1178.00	1197.50	1253.04
11	877.50	896.98	916.46	935.94	955.42	974.90	994.38	1013.86	1033.34	1052.82	1072.30	1091.78	1111.26	1130.74	1150.22	1169.70	1189.18	1208.66	1228.14	1247.62	1267.10	1322.64
11½	952.23	971.71	991.19	1010.67	1030.15	1049.63	1069.11	1088.59	1108.07	1127.55	1147.03	1166.51	1185.99	1205.47	1224.95	1244.43	1263.91	1283.39	1302.87	1322.35	1341.83	1397.37
12	1032.00	1051.48	1070.96	1090.44	1109.92	1129.40	1148.88	1168.36	1187.84	1207.32	1226.80	1246.28	1265.76	1285.24	1304.72	1324.20	1343.68	1363.16	1382.64	1402.12	1421.60	1477.14

Rule to find capacity of a square tank: Divide cubic inches of tank by 231. The sum will be the number of gallons.

EXAMPLE:

Tank 60'' × 60'' × 60''

$$\begin{array}{r} 60'' \text{ width} \\ 60'' \text{ long} \\ \hline 3600 \\ 60 = \text{height} \end{array}$$

gallons in cubic foot 231) 216000 (= 935 gallons capacity
2079

$$\begin{array}{r} 810 \\ 693 \\ \hline 1170 \\ 1155 \\ \hline 15 \end{array}$$

Rule to find weight of water in same tank: Multiply the number of gallons by 8.33 (this is weight of one gallon of water). This sum will be weight in pounds.

EXAMPLE:

$$\begin{array}{r} 935 = \text{gallons} \\ 8.33 = \text{weight of one gallon of water} \\ \hline 28 \ 05 \\ 280 \ 5 \\ 7480 \\ \hline 7788.55 = \text{weight of water in pounds} \end{array}$$

WATER.

One U. S. gallon equals 231 cubic inches.
 One U. S. gallon equals .133 cubic feet.
 One U. S. gallon equals 8.33 pounds.
 One U. S. gallon equals .83 imperial gallon.

One imperial gallon equals 277.274 cubic inches.
 One imperial gallon equals .16 cubic feet.
 One imperial gallon equals 10 pounds.
 One imperial gallon equals 1.2 U. S. gallon.

One cubic inch of water equals .03607 pound.
 One cubic inch of water equals .003607 imperial gallon.
 One cubic inch of water equals .004329 U. S. gallon.

One cubic foot of water equals 6.23 imperial gallons.
 One cubic foot of water equals 7.48 U. S. gallons.
 One cubic foot of water equals 62.321 pounds.
 One cubic foot of water equals .028 ton.

One pound of water equals 27.72 cubic inches.
 One pound of water equals .10 imperial gallon.
 One pound of water equals .12005 U. S. gallon.

One ton of water equals 35.98 cubic feet.
 One ton of water equals 224 imperial gallons.
 One ton of water equals 268.8 U. S. gallons.

A column of water 1 foot high equals .433 pounds pressure per square inch.

A pressure of 1 pound per square inch equals 2.31 feet of water in height.

A pressure of 1 ounce per square inch equals .144 feet of water in height.

HORSE POWER OF BELTING
 Horse-Power which may be transmitted by open single belts to pulleys running 100 revolutions per minute, the diameter of the driving and driven pulley being equal. The horse-power of double belts is 10-7 of that given in the table.

Diameter of Pulley in inches	WIDTH OF BELT IN INCHES.													
	2	3	4	5	6	8	10	12	14	16	18	20	22	
H. P.	H. P.	H. P.	H. P.	H. P.	H. P.	H. P.	H. P.	H. P.	H. P.	H. P.	H. P.	H. P.	H. P.	
6	.44	.65	.87	1.09	1.31	1.53	1.75	1.97	2.19	2.41	2.63	2.85	3.07	
7	.51	.76	1.01	1.27	1.53	1.79	2.05	2.31	2.57	2.83	3.09	3.35	3.61	
8	.58	.87	1.16	1.45	1.75	2.04	2.33	2.62	2.91	3.20	3.49	3.78	4.07	
9	.65	.98	1.31	1.64	1.97	2.30	2.63	2.96	3.29	3.62	3.95	4.28	4.61	
10	.73	1.09	1.45	1.81	2.16	2.50	2.84	3.18	3.52	3.86	4.20	4.54	4.88	
11	.80	1.20	1.60	2.00	2.40	2.80	3.20	3.60	4.00	4.40	4.80	5.20	5.60	
12	.87	1.31	1.75	2.18	2.62	3.05	3.48	3.91	4.34	4.77	5.20	5.63	6.06	
13	.95	1.42	1.89	2.36	2.83	3.30	3.77	4.24	4.71	5.18	5.65	6.12	6.59	
14	1.02	1.52	2.02	2.53	3.05	3.55	4.05	4.55	5.05	5.55	6.05	6.55	7.05	
15	1.09	1.64	2.19	2.73	3.29	3.84	4.38	4.92	5.46	6.00	6.54	7.08	7.62	
16	1.16	1.74	2.32	2.91	3.50	4.09	4.68	5.27	5.86	6.45	7.04	7.63	8.22	
17	1.24	1.85	2.47	3.09	3.70	4.31	4.92	5.53	6.14	6.75	7.36	7.97	8.58	
18	1.31	1.96	2.62	3.27	3.92	4.57	5.22	5.87	6.52	7.17	7.82	8.47	9.12	
19	1.39	2.07	2.76	3.45	4.14	4.83	5.52	6.21	6.90	7.59	8.28	8.97	9.66	
20	1.45	2.18	2.91	3.64	4.36	5.09	5.82	6.55	7.28	8.01	8.74	9.47	10.20	
21	1.52	2.29	3.05	3.82	4.58	5.34	6.10	6.86	7.62	8.38	9.14	9.90	10.66	
22	1.60	2.40	3.20	4.00	4.80	5.60	6.40	7.20	8.00	8.80	9.60	10.40	11.20	
23	1.67	2.51	3.35	4.18	5.02	5.86	6.70	7.54	8.38	9.22	10.06	10.90	11.74	
24			3.50	4.4	5.20	6.04	6.88	7.72	8.56	9.40	10.24	11.08	11.92	
25			3.6	4.5	5.5	6.3	7.1	7.9	8.7	9.5	10.3	11.1	11.9	
26			3.8	4.7	5.7	6.5	7.3	8.1	8.9	9.7	10.5	11.3	12.1	
27			3.9	4.9	5.9	6.7	7.5	8.3	9.1	9.9	10.7	11.5	12.3	
28			4.1	5.1	6.1	6.9	7.7	8.5	9.3	10.1	10.9	11.7	12.5	
29			4.2	5.3	6.3	7.1	7.9	8.7	9.5	10.3	11.1	11.9	12.7	
30			4.4	5.4	6.4	7.2	8.0	8.8	9.6	10.4	11.2	12.0	12.8	
31			4.5	5.6	6.6	7.4	8.2	9.0	9.8	10.6	11.4	12.2	13.0	
32			4.7	5.8	6.8	7.6	8.4	9.2	10.0	10.8	11.6	12.4	13.2	
33			4.8	6.0	7.0	7.8	8.6	9.4	10.2	11.0	11.8	12.6	13.4	
34			4.9	6.2	7.2	8.0	8.8	9.6	10.4	11.2	12.0	12.8	13.6	
35			5.1	6.4	7.4	8.2	9.0	9.8	10.6	11.4	12.2	13.0	13.8	
36			5.2	6.5	7.5	8.3	9.1	9.9	10.7	11.5	12.3	13.1	13.9	
37			5.4	6.7	7.7	8.5	9.3	10.1	10.9	11.7	12.5	13.3	14.1	
38			5.5	6.9	7.9	8.7	9.5	10.3	11.1	11.9	12.7	13.5	14.3	
39			5.7	7.1	8.1	8.9	9.7	10.5	11.3	12.1	12.9	13.7	14.5	
40			5.8	7.3	8.3	9.1	9.9	10.7	11.5	12.3	13.1	13.9	14.7	
42			6.1	7.6	8.6	9.4	10.2	11.0	11.8	12.6	13.4	14.2	15.0	
44			6.4	8.0	9.0	9.8	10.6	11.4	12.2	13.0	13.8	14.6	15.4	
46			6.7	8.4	9.4	10.2	11.0	11.8	12.6	13.4	14.2	15.0	15.8	
48			7.0	8.8	9.8	10.6	11.4	12.2	13.0	13.8	14.6	15.4	16.2	
50			7.2	9.0	10.0	10.8	11.6	12.4	13.2	14.0	14.8	15.6	16.4	
54			7.8	9.8	10.8	11.6	12.4	13.2	14.0	14.8	15.6	16.4	17.2	
60			8.8	10.8	11.8	12.6	13.4	14.2	15.0	15.8	16.6	17.4	18.2	
66			9.6	12.0	13.0	13.8	14.6	15.4	16.2	17.0	17.8	18.6	19.4	
72			10.4	13.0	14.0	14.8	15.6	16.4	17.2	18.0	18.8	19.6	20.4	
78			11.4	14.2	15.2	16.0	16.8	17.6	18.4	19.2	20.0	20.8	21.6	
84			12.2	15.2	16.2	17.0	17.8	18.6	19.4	20.2	21.0	21.8	22.6	

Rule to find length of belt: Add together the diameter in inches of the two pulleys; divide this by 2 and multiply the quotient by constant $3\frac{1}{4}$ (3.25); to this add twice the distance in inches between the centers of shaft; the result will give length of belt approximately.

FORMULA:

$$\left(\frac{2D}{2}\right) \times C + (2 \times d) = \text{length of belt}$$

LEGEND:

D = diameter of pulleys = $30''$
 $20''$

C = constant = 3.25

d = distance between shaft centers = $10' = 120''$

EXAMPLE:

	30" and 20" = pulley diameters

	2) 50

	25
	3.25 = constant

	1 25
	5 0
	75

twice distance	81.25
between centers of shaft =	240.

	321.25" = length of belt

THE USE OF BELTING.

The ultimate strength of a single belt one inch in width and one-quarter inch thick is about 750 pounds, but from the weakening effect of the several methods of joining, the ends not more than 200 pounds per inch in width should be depended upon for ultimate strain.

Belts will transmit a force of about 55 pounds for every inch in width, and taking the average thickness of belts at one-sixth of an inch, this means a strain of 330 pounds per square inch of section.

The horse power of a laced belt becomes a maximum at a speed of 87.41 feet per second, or 5,245 feet per minute, or considerably over a mile a minute.

One good method for lacing a belt is to punch the holes in two rows and zigzag, thus a six-inch belt would have seven holes, four nearest the end. The first row should be about three-quarters of an inch from the end of the belt and about the same from the sides. On the larger belts the distance would be somewhat increased. Begin the lacing in the center of the belt and lace both ways; keep the ends of the belt in line and the tension on both ends of the lace the same. The lacing should not be crossed on the side of the belt that runs next the pulley, so that the lacing on that side will be parallel with the edges of the belt, while on the other side it will be at an angle. Loose belts can be run on less power it takes to drive that belt, and in order to run the belt loose it must be in good order; so taking care of belts means less fuel for power and longer life to the belts.

Do not use any belt dressing that will make the belt stick to the pulley. The use of a little good oil occasionally, such as neat's-foot, to keep the leather soft and pliable, will give the very best results.

RULES FOR PULLEY SPEED CALCULATION.

Rule to find size of a pulley for a main line shaft, if the speed of shaft and diameter of pulley on the counter shafts are given: Multiply the diameter in inches of pulley on counter shafts by speed and divide by the revolution of the main shaft; the sum will be the diameter of the pulley.

EXAMPLE:

Main shaft 150 revolutions per minute; to drive a 15" pulley 350 revolutions per minute what will be the diameter of pulley on main shaft?

$$\begin{array}{r}
 15'' \text{ diameter pulley counter shaft} \\
 350 \text{ revolution of counter shaft} \\
 \hline
 750 \\
 45 \\
 \hline
 150) 5250 \text{ (35'' diameter of pulley for main} \\
 \quad 450 \quad \quad \quad \text{line)} \\
 \hline
 750 \\
 750 \\
 \hline
 \hline
 \end{array}$$

To find size of a pulley for counter shaft when revolutions of pulley on main shaft are given: Multiply diameter in inches of driving pulley by the revolutions of the main shaft and divide by the speed required on counter line.

EXAMPLE:

$$\begin{array}{r}
 35'' \text{ diameter of pulley main shaft} \\
 150 \text{ revolution main shaft} \\
 \hline
 1750 \\
 35 \\
 \hline
 \text{revolution counter shaft } 350 \overline{)5250} \text{ (15'' pulley for counter line)} \\
 350 \\
 \hline
 1750 \\
 1750 \\
 \hline
 \end{array}$$

To find speed of counter shaft when revolutions of the main shaft and size of pulleys are known:

Multiply the revolutions of main shaft by the diameter in inches of the pulley and divide by the diameter in inches of the pulley on counter shaft.

EXAMPLE:

$$\begin{array}{r}
 35'' \text{ pulley main shaft} \\
 150 \text{ revolutions} \\
 \hline
 1750 \\
 35 \\
 \hline
 \text{diameter pulley, counter shaft } 15 \overline{)5250} \text{ (350 revolution of counter shaft)} \\
 45 \\
 \hline
 75 \\
 75 \\
 \hline
 \end{array}$$

Slip of belt, also thickness of same, will vary the revolutions some.

HORSE POWER SHAFTING TRANSMISSION

Diameter of Shaft in Inches	REVOLUTIONS PER MINUTE.									
	100	125	150	175	200	225	250	300	350	400
	HORSE POWER.									
$\frac{1}{16}$	1.2	1.4	1.7	2.1	2.4	2.6	3.1	3.6	4.3	5.0
$\frac{1}{8}$	2.4	3.1	3.7	4.3	4.9	5.5	6.1	7.3	8.5	9.7
$\frac{3}{16}$	4.3	5.3	6.4	7.4	8.5	9.5	10.5	12.7	14.8	16.9
$\frac{1}{4}$	6.7	8.4	10.1	11.7	13.4	15.1	16.7	20.1	23.4	26.8
$\frac{5}{16}$	10.0	12.5	15.0	17.5	20.0	22.5	25.0	30.0	35.0	40.0
$\frac{3}{8}$	14.3	17.8	21.4	24.9	28.5	32.1	35.6	42.7	49.8	57.0
$\frac{7}{16}$	19.5	24.4	29.3	34.1	39.0	44.1	48.7	58.5	68.2	78.0
$\frac{1}{2}$	26.0	32.5	39.0	43.5	52.0	58.5	65.0	78.0	87.0	104.0
$\frac{9}{16}$	33.8	42.2	50.6	59.1	67.5	75.9	84.4	101.3	118.2	135.0
$\frac{5}{8}$	43.0	53.6	64.4	75.1	85.8	96.6	107.3	128.7	150.3	171.6
$\frac{11}{16}$	53.6	67.0	79.4	93.8	107.2	120.1	134.0	158.8	187.6	214.4
$\frac{3}{4}$	65.9	82.4	97.9	115.4	121.8	148.3	164.8	195.7	230.7	243.6
$\frac{13}{16}$	80.0	100.0	120.0	140.0	160.0	180.0	200.0	240.0	280.0	320.0
$\frac{7}{8}$	113.9	142.4	170.8	199.3	227.8	256.2	284.7	341.7	398.6	455.6
$1\frac{1}{8}$	156.3	195.3	234.4	273.4	312.5	351.5	390.6	468.7	546.8	625.0

The following table gives the maximum permissible distances between bearings of continuous shafts:

Diameter of shaft in inches	Distance between wrought iron	Bearings in feet steel
1	12. 27	12. 61
2	15. 46	15. 89
3	17. 7	18. 19
4	19. 48	20. 02
5	20. 99	21. 57
6	22. 3	22. 92
7	23. 48	24. 13
8	24. 55	25. 23
9	25. 53	26. 24
10	26. 4	27. 18

The length of a bearing is usually given as three times the diameter of the shaft in inches. The distance between bearings are also given as three times diameter, the product being expressed in feet.

Rule to find diameter of a shaft. Multiply the horse power to be transmitted by the constant 100 for wrought iron; divide the product by the number of revolutions per minute and extract the cube root of quotient; this sum will give safe diameter of shafting. For steel use constant 62.5.

Rule to find diameter of shafts as second movers, transmitting power through long lines. Use preceding rule, using constant 50 for wrought iron and 31.5 for steel.

Rule to find diameter for counter shafting well supported by bearings at short distances. Use preceding rules with constant 33 for wrought iron and 21 for steel.

Rule to find horse power a given shaft will transmit. Multiply the cube of the diameter by the revolutions per minute and divide the product by 100.

FOR SECOND MOVERS — Multiply the cube of the diameter by twice the revolutions and divide the product by 100.

FOR THIRD MOVERS — Multiply the cube of the diameter by three times the revolutions and divide by 100.

Approximately a one inch shaft will transmit at 100 revolutions 1 horse power as first mover, 2 horse power as second mover, and 3 horse power as third mover, the power transmitted with safety will vary in proportion as to the speed and as the cube of the diameter.

RULES FOR STEAM BOILERS.

See that water-level has not fallen, and examine joints and seams to detect leakage, and furnaces for evidence of bulging.

Blow through water gages; open blow-off cock to remove sediment; try safety valve to insure free action; raise dampers to clear flues of explosive gases; and stir up fire, heating boiler and setting slowly.

In case of low water, immediately cover the fires with ashes, or, if no ashes are at hand, use fresh coal, and close ash-pit doors. Don't turn on the feed under any circumstances, nor tamper with nor open the safety valve. Let the steam outlets remain as they are.

Close throttle and keep closed long enough to show true level of water. If that level is sufficiently high, feeding and blowing will usually suffice to correct the evil. In case of violent foaming, caused by dirty water, or change from salt to fresh, or vice versa, in addition to the action above stated, check draft and cover fires with fresh coal.

In preparing to get up steam after boilers have been open, or

out of service, great care should be exercised in making the man and hand-hole joints. Safety valve should then be opened, and blocked open, and the necessary supply of water run in or pumped into the boilers until it shows at second guage in tubular and locomotive boilers; a higher level is advisable in vertical tubulars as a protection to the top end of the tubes. After this is done fuel may be placed upon the grate, dampers opened, and fires started. If chimney or stack is cold and does not draw properly, burn some oily waste or light kindling at the base. Start fires in ample time so it will not be necessary to force them unduly. When steam issues from the safety valve, lower it carefully to its seat and note pressure and action of steam gauge.

If there are other boilers in operation, and stop valves are to be opened to place boilers in connection with others on a steam pipe line, watch those recently fired up until pressure is up to that of the other boilers to which they are to be connected; and, when that pressure is attained open the stop-valves very slowly and carefully.

Never feed cold water into a boiler as it is injurious to the plates and liable to spring the seams and cause them to leak. A good feed water heater should be used; they not only save early repairs on the boiler but effect a great saving in the consumption of coal.

Boilers should be blown off, a little at least, once or twice a day, and the water should be entirely blown off at least once every two weeks, depending on the nature of the feed water. Never blow out a boiler while it is too hot as the arch plates, flues and braces retain heat enough to bake the deposits of mud into a hard scale that becomes firmly attached to their surface. With the walls and arches too hot while blowing off, the plates are liable to injury. Always allow the setting to cool down before emptying completely as the scale and mud will then be quite soft and can easily be washed out with a hose.

If necessary to blow down, allow the boilers to become cool before filling again. Cold water pumped into hot boilers is very injurious from sudden contraction.

Care should be taken that no water comes in contact with the exterior of the boiler, either from leaky joints or other causes.

In tubular boilers the hand holes should be often opened, and all deposits removed, and fire-plates carefully cleaned.

Keep the boiler clean internally and externally and thoroughly examine plates and seams at frequent intervals, especially those in contact with setting or exposed to direct action of fire.

Always raise steam slowly and never light fire until water shows in gauge glasses. Keep furnace walls in good condition and well pointed up. Allow boiler and brick work to cool before emptying boiler. Prevent oil and greasy matter from entering boiler, as same lead to serious inefficiency and to dangerous heating of plates.

Mud drums should be given careful attention and cleaned and inspected regularly just the same as the boiler.

Try the safety valves cautiously and often, as they are liable to become fast in their seats and useless for the purpose intended. If the valve is of the lever type, do not load it with additional weights. The safety valve is set to blow off at a certain pressure and should blow off when the steam gauge registers this pressure; if it does not, one or the other is wrong and should be corrected.

When a blister appears there must be no delay in having it carefully examined, and trimmed or patched, as the case may require.

Particular care should be taken to keep sheets and parts of boilers exposed to the fire perfectly clean; also all tubes, flues and connections well swept. This is particularly necessary where wood or soft coal is used for fuel.

See that proper water-level is maintained. Keep water gauge glasses clean and passages clear, by trying gauges frequently.

(Lack of proper attention to water gauges leads to more accidents than any other cause.)

Maintain a fire of even thickness, free from holes and clear of ashes and clinkers. (The proper thickness of fire increases with the hardness and size of coal and with the strength of draft.) Regulate fire and draft and feed to meet demands for steam, keeping water level constant to avoid priming or burning of plates. Ash pits are to be kept clear to avoid burning grate bars and to prevent loss of draft and efficiency.

Never attempt to stop a leak or tighten a joint when boiler is

under high pressure. Never cut in a boiler with a battery until its pressure is equal to that of the battery.

Before banking fires run water to proper level, which note, and see that the steam pipe drains are open and in working order.

Water in ash pit has an effect of clinkering, and this varies with the amount of sulphur and iron pyrites and ash in fuel, thus choking up air spaces in grate effecting the life of same. Again the moisture mixing with sulphur has the corrosive effect on boiler and tubes; it also has a cooling effect which detracts from combustion, and volatile gases escape unconsumed.

NOTES.

Slight leakage at joints causes grooving.

Covering of boiler and steam pipes saves fuel and increases efficiency.

A boiler showing pulsations of engine gives evidence of being too small for duty.

Fly wheels should not have a greater speed than one mile per minute to be safe.

Globe valves should always be so placed in steam pipes that their stems are nearly horizontal.

Stack should drain inside — for reasons — appearance — as stacks are in use most of the time, the advantage of having drainage outside is not to be weighed with the advantage of draining inside and appearance.

KNOTS AND MILES.

Knts	Miles	Knts	Miles	Knts	Miles	Knts	Miles	Knts	Miles
1.00	1.1515	6.00	6.9091	11.00	12.6667	16.00	18.4242	21.00	24.1818
1.25	1.4394	6.25	7.1970	11.25	12.9545	16.25	18.7121	21.25	24.4697
1.50	1.7273	6.50	7.4848	11.50	13.2424	16.50	19.0000	21.50	24.7576
1.75	2.0152	6.75	7.7727	11.75	13.5303	16.75	19.2879	21.75	25.0455
2.00	2.3030	7.00	8.0606	12.00	13.8182	17.00	19.5758	22.00	25.3333
2.25	2.5909	7.25	8.3485	12.25	14.1061	17.25	19.8636	22.25	25.6212
2.50	2.8788	7.50	8.6364	12.50	14.3939	17.50	20.1515	22.50	25.9091
2.75	3.1667	7.75	8.9242	12.75	14.6818	17.75	20.4394	22.75	26.1970
3.00	3.4545	8.00	9.2121	13.00	14.9697	18.00	20.7273	23.00	26.4848
3.25	3.7424	8.25	9.5000	13.25	15.2576	18.25	21.0152	23.25	26.7727*
3.50	4.0303	8.50	9.7879	13.50	15.5455	18.50	21.3030	23.50	27.0606
3.75	4.3182	8.75	10.0758	13.75	15.8333	18.75	21.5909	23.75	27.3485
4.00	4.6061	9.00	10.3636	14.00	16.1212	19.00	21.8788	24.00	27.6364
4.25	4.8939	9.25	10.6515	14.25	16.4091	19.25	22.1667	24.25	27.9242
4.50	5.1818	9.50	10.9394	14.50	16.6970	19.50	22.4545	24.50	28.2121
4.75	5.4697	9.75	11.2273	14.75	16.9848	19.75	22.7424	24.75	28.5000
5.00	5.7576	10.00	11.5152	15.00	17.2727	20.00	23.0303	25.00	28.7879
5.25	6.0455	10.25	11.8030	15.25	17.5606	20.25	23.3182	25.25	29.0758
5.50	6.3333	10.50	12.0909	15.50	17.8485	20.50	23.6061	25.50	29.3636
5.75	6.6212	10.75	12.3788	15.75	18.1364	20.75	23.8939	25.75	29.6515

TABLE SHOWING KNOTS REDUCED TO MILES.

A nautical mile or knot is 6,080.27 feet.

CONTENTS

	PAGE
CHAPTER I.	
MATERIALS	5
CHAPTER II.	
SELECTION OF BOILER	18
CHAPTER III.	
BOILER CONSTRUCTION	35
CHAPTER IV.	
BRACES AND REINFORCEMENT	69
CHAPTER V.	
FURNACES, FLUES AND U. S. RULES	106
CHAPTER VI.	
LAP JOINT RULES	126
CHAPTER VII.	
BUTT JOINT RULES	154
CHAPTER VIII.	
THE STEAM BOILER	175
CHAPTER IX.	
INSPECTIONS	200
CHAPTER X.	
MISCELLANEOUS	223

INDEX

A

Adamson furnace rules.....	120 to 122, 125
Angle irons, sizes and weights, table.....	55

B

Belting, tables and rules.....	249 to 251
Boilers, construction.....	35 to 67
“ designing.....	6, 16, 17
“ U. S. Government requirements.....	218
“ selection.....	18
“ hot water, rules and tables.....	199
“ standard measurements.....	181, 182
“ heating, low pressure.....	198
“ verticle, specifications, tables.....	197
“ weights, table of.....	185
“ water tube or coil, rules.....	221, 222
Boiler room, rules and notes.....	254 to 257
Braces, measurements and weights.....	52
“ number for standard boilers, table.....	53
“ number, and rule to find.....	90
“ rods, rule to find working pressures.....	94
“ and bracing, material.....	69, 70
“ socket bolts, rules to find pressure.....	125
“ formed.....	94
Butt Joints.....	154 to 172
Brown Furnaces.....	117

C

Channel steel, size and weight, table.....	56
Chimneys and stacks, rules and tables.....	189 to 196
Circles, rules for calculations, segments.....	20 to 23, 88, 89
“ tables of areas and circumference.....	24, 25
Cones, rules.....	118, 119
Collapsing pressures, furnaces, rule to find.....	113 to 116, 123, 124, 126
Curved surfaces, rule.....	95

D

Dome plate.	48
Drills, table of sizes.	61
*Drums and Heads, U. S. Government requirements.	220

E

Engines, power.	18, 19, 31
" types, efficiencies, table.	20
Engineers, marine, classification.	208 to 212
" qualifications and duties.	208 to 212

F

Feed water, heaters and heating.	223 to 229
" " admission.	217
" " heating, tables and rules.	230, 231
Flanges, diameters, sizes for pipes.	58
Furnaces.	105
" plain, rules and tables.	108 to 112, 120
" Morrison, rules.	113, 114, 121
" U. S. Government. rules and tables.	108 to 112
" Purvis, rules.	117, 121
" verticle, rules.	121
" Leeds Suspension, rules.	116
" Brown.	117, 121
Flues and furnaces	106, 108, 109
" plain, rules.	110 to 122

G

Gauge cocks and water glass.	219
Girders, rules.	99, 103
Grate surface, rules and tables.	183, 184

H

Heads, flat.	85
" cast iron, rule.	88
" convex, rule.	86
" concaved.	87
" boiler, diameter and weights, table.	40 to 42
Heating surface, ratios, tables.	183, 198
" surface, rule to find.	50
Horse power, tables and rules.	26, 27, 28, 181, 182
Hydrostatic test.	220

I

I beams, sizes and weights.....	56
Iron, cast, composition, tables of properties.....	7, 217
" wrought.....	8
" cast, balls diameter and weight, table.....	55
Inspections, U. S. Government rules.....	106 to 122, 219
" of boilers.....	212 to 222

J

Joints, lap, single riveted, rules.....	127 to 137
" lap, single riveted, table of efficiencies.....	137
" lap, double riveted, rules.....	138 to 149
" lap, double riveted, table of efficiencies.....	149
" lap, triple riveted, rules.....	150 to 153
" lap, triple riveted, table of efficiencies.....	153
" butt, double strapped, double riveted, rules.....	154 to 159
" butt, double strapped, double riveted, table of efficiencies.....	159
" butt, double strapped, triple riveted, rules.....	160 to 168
" butt, double strapped, triple riveted, table of efficiencies.....	164
" butt, double strapped, quadruple riveted.....	169 to 174
" butt, double strapped, quadruple riveted, table of efficiencies.....	172

K

Knots and miles.....	258
----------------------	-----

L

Lap joints.....	127 to 153
-----------------	------------

M

Materials.....	5 to 16
" U. S. Govt. inspection, selection, tests.....	11, 106, 107
Metals, weights and table of.....	53 to 55
Morrison furnace.....	113 to 121

N

Notes on boiler room, rules, etc.....	254 to 257
---------------------------------------	------------

P

Pipe, steam, heating, radiation, table.....	198, 221
" expansion and radiation, table.....	58
" and piping.....	56
" steam, gas, water, dimensions, table.....	59

Pipe, rules to find thickness of.....	57
“ friction loss in discharge, table.....	237
“ discharge at nozzle, table.....	240
Plates, steel, rules and tables.....	6, 9, 10, 11, 43 to 48
Pressures, U. S. Govt. rules, shells.	175
“ U. S. Govt. tables.	176 to 180
“ water heads, tables and rules.....	241, 242, 243
“ U. S. Govt. requirements.....	222
Pump. rules.	231
“ tables, notes.	234, 235
“ capacities.	236
“ piping table.	237
“ elevation of water.....	238
“ feed, size, table.....	239
Pulleys, rules for calculations.....	251, 252
Purvis Furnace	251, 252

R

Reinforcement of openings, rules.....	103 to 105
Rivets and Riveting, table.....	36 to 39
“ shearing strength of.....	38, 39, 68
Rods, braces, rules.....	94
Rules. for calculating circles.....	20, 88
“ mensuration.	20, 23

S

Safety valve, rules and tables.....	200 to 207
Settings, boiler.	185, 186
“ measurements.	186, 187
“ materials for.	188, 189
Shafting, rules and tables.....	253, 254
Shearing strength of rivets.....	38, 39, 68
Socket bolt rules.....	125
Steam boiler notes.....	254 to 257
“ notes.	28, 32
“ pressures, temperature and tables.....	29
Steel, flat, weight per foot, table.....	62, 63
“ round, square, weights, table.....	61, 62
“ cast.	217
Stay bolts, sizes and threads of same.....	60
“ bolts, strain, areas, bracing of.....	71, 84

T

Tables, decimals, circumferences, areas.....	24 to	26
“ pressures and temperature.....		29
“ weights and size of boiler heads.....		40
“ I beams.		56
“ sizes, threads, flanges.....		58
“ flat steel, sizes and weights.....		63
“ metals, weights.	63,	64
“ Birmingham and U. S. standards, gauges.....	53, 54, 63,	64
“ rivets.		37
“ shearing strength of rivets.....	38,	39
“ circumference, areas and decimals.....	24, 25.	26
“ areas of circular arcs.....	91 to	93
“ horse power boilers.....	176 to	181
“ weights of boilers.....		185
“ chimneys and stacks.....	191,	195
“ for safety valves.....	202,	203
Tanks, capacities, tables and rules.....	244 to	247
Taps and drills.....	61,	62
Testing, boiler plate, drilling.....	219,	222
Thermometer, rules and tables.....	32, 33,	34
Tube, rules and tables. standard sizes.....	49 to	51
“ plates, rule to find pressures.....	96 to	98
“ plates, thickness.		97
“ plates, compressive strain.....	98, 101,	124

U

U. S. Government rules, tables, pressures.....	175 to	180
--	--------	-----

V

Verticle boiler, table of specifications.....	197
---	-----

W

Water tube and coil boiler requirements.....	221, 222
“ pressure tables and rules.....	241, 242, 243
“ measurement, notes.	248



